## Setup - Installation of Vitis on Ubuntu

Vitis has the most documentation on linux and Ubuntu is one of the recommended platforms. This setup tutorial shows you how to:

Install Vitis — Contains Vitis IDE, Vitis HLS, Vivado and Vivado HLS, Install OpenCL Client Driver — OpenCL drivers, Install the Xilinx Runtime — XRT for OpenCL, Install the appropriate platform (we install U200 by Xilinx)

Based off of (and heavily borrows from)

https://www.hackster.io/news/microzed-chronicles-vitis-acceleration-creating-a-vm-setup-36394 6fb4ede

Download Vitis from here: <a href="https://www.xilinx.com/products/design-tools/vitis.html">https://www.xilinx.com/products/design-tools/vitis.html</a>

Download the following OpenCL drivers:

sudo apt install ocl-icd-libopencl1 sudo apt install opencl-headers

sudo apt install ocl-icd-opencl-dev

Install xilinx runtime (dpkg file) from here:

https://www.xilinx.com/bin/public/openDownload?filename=xrt 201920.2.3.1301 18.04-xrt.deb

Install the target device (dpkg file) from here:

https://www.xilinx.com/products/boards-and-kits/alveo/u200.html#xrt1804 20191 xdma

The dpkg files need to be installed with sudo apt install <dpkg\_file\_name>.dpkg

To check if everything is installed correctly

git clone https://github.com/Xilinx/Vitis-Tutorials.git cd Vitis-Tutorials/docs/my-first-program/reference-files g++ -I\$XILINX\_XRT/include/ -I\$XILINX\_VIVADO/include/ -Wall -O0 -g -std=c++11 ./src/host.cpp -o 'host' -L\$XILINX\_XRT/lib/ -IOpenCL -Ipthread -Irt -Istdc++

This should run with no error.

### **Bug Fixes**

On Ubuntu 18.04, if youget the following error: **../src/host.cpp:47:10: fatal error:** CL/cl2.hpp: No such file or directory

Then unzip
 <a href="https://www.xilinx.com/member/forms/download/design-license-xef.html?filename">https://www.xilinx.com/member/forms/download/design-license-xef.html?filename</a>
 =rdf0476-zcu111-rf-dc-eval-tool-2019-2.zip

#### And run

cp \$(download\_location)/rdf0476-zcu111-rf-dc-eval-tool-2019-2/pl/MTSDesign\_8x8/pre-built/rfso c\_trd/zcu111\_rfsoc\_trd\_wrapper.xsa \$(vitis\_install\_location)/2019.2/data/embeddedsw/lib/fixed\_hwplatforms

 If Vitis is asking for XILINX\_VITIS to be set, then run the following: source opt/xilinx/xrt/setup.sh

#### How to Run Software Emulation and Hardware Emulation

#### In vitis\_emulation/, run the following for Software Emulation:

g++ -I\$XILINX\_XRT/include/ -I\$XILINX\_VIVADO/include/ -Wall -O0 -g -std=c++11 host.cpp dense2.cpp dense1.cpp conv7.cpp conv6.cpp conv5.cpp conv4.cpp conv3.cpp conv2.cpp conv1.cpp bnd2\_a\_b.cpp bnd1\_a\_b.cpp bn7\_a\_b.cpp bn6\_a\_b.cpp bn5\_a\_b.cpp bn4\_a\_b.cpp bn3\_a\_b.cpp bn2\_a\_b.cpp bn1\_a\_b.cpp -o 'host' -L\$XILINX\_XRT/lib/-IOpenCL -lpthread -Irt -lstdc++

v++ -t sw\_emu --config design.cfg -c -k compute\_network
-o'compute\_network.xilinx\_u200\_xdma\_201830\_2.xo' 'tw\_vgg10.cpp' 'tw\_vgg10.h'
'pred\_output.h' 'dense2.h' 'dense2.cpp' 'dense1.h' 'dense1.cpp' 'conv7.h' 'conv7.cpp' 'conv6.h'
'conv6.cpp' 'conv5.h' 'conv5.cpp' 'conv4.h' 'conv4.cpp' 'conv3.h' 'conv3.cpp' 'conv2.h'

```
'conv2.cpp' 'conv1.h' 'conv1.cpp' 'bnd2 a b.h' 'bnd2 a b.cpp' 'bnd1 a b.h' 'bnd1 a b.cpp'
 'bn7_a_b.h' 'bn7_a_b.cpp' 'bn6_a_b.h' 'bn6_a_b.cpp' 'bn5_a_b.h' 'bn5_a_b.cpp' 'bn4_a_b.h'
 'bn4 a b.cpp' 'bn3 a b.h' 'bn3 a b.cpp' 'bn2 a b.h' 'bn2 a b.cpp' 'bn1 a b.h'
 'bn1 a b.cpp' 'vgg dense 3.h'
v++ -t sw_emu --config design.cfg -l -o'compute_network.xilinx_u200_xdma_201830_2.xclbin'
compute network.xilinx u200 xdma 201830 2.xo
 emconfigutil --platform xilinx u200 xdma 201830 2
export XCL EMULATION MODE=sw emu
 ./host compute network.xilinx u200 xdma 201830 2.xo
In vitis emulation/, run the following for Hardware Emulation (Warning: 2hour+ run time):
v++ -t hw emu --config design.cfg --save-temps -c -k compute network
 -o'compute network.xilinx u200 xdma 201830 2.xo' 'tw vgg10.cpp' 'tw vgg10.h'
 'pred output.h' 'dense2.h' 'dense2.cpp' 'dense1.h' 'dense1.cpp' 'conv7.h' 'conv7.cpp'
 'conv6.h' 'conv6.cpp' 'conv5.h' 'conv5.cpp' 'conv4.h' 'conv4.cpp' 'conv3.h' 'conv3.cpp'
 'conv2.h' 'conv2.cpp' 'conv1.h' 'conv1.cpp' 'bnd2 a b.h' 'bnd2 a b.cpp' 'bnd1 a b.h'
 'bnd1_a_b.cpp' 'bn7_a_b.h' 'bn7_a_b.cpp' 'bn6_a_b.h' 'bn6_a_b.cpp' 'bn5_a_b.h'
 'bn5 a b.cpp' 'bn4 a b.h' 'bn4 a b.cpp' 'bn3 a b.h' 'bn3 a b.cpp' 'bn2 a b.h'
 'bn2_a_b.cpp' 'bn1_a_b.h' 'bn1_a_b.cpp' 'vgg_dense_3.h'
v++ -t hw emu --config design.cfg -l -o'compute network.xilinx u200 xdma 201830 2.xclbin'
compute network.xilinx u200 xdma 201830 2.xo
 emconfigutil --platform xilinx u200 xdma 201830 2
export XCL EMULATION MODE=hw emu
 ./host compute_network.xilinx_u200_xdma_201830_2.xclbin
If we had the hardware, we could simply run:
unset XCL_EMULATION_MODE
./host compute network.xilinx u200 xdma 201830 2.xclbin
```

This file (xclbin) can be run on chip, in an SD card.

# Summary (so far)

To get to this point we had to create and run vitis host files (host.cpp/host.h) and a compute\_network kernel (tw\_cpp.c) in vitis\_emulation.

Then we ran in vitis on the u200\_xdma\_201830\_2 target device.

Once officially supported by Xilinx, this will easily be ported to the ZCU111 platform simply by downloading the appropriate platform and changing the target device.