ESXi

ONTAP SAN Host

NetApp August 18, 2020

This PDF was generated from https://docs.netapp.com/us-en/ontap-sanhost/nvme_esxi_7.html on August 18, 2020. Always check docs.netapp.com for the latest.



Table of Contents

ESXi	 	. 1
NVMe/FC Host Configuration for ESXi 7.0 with ONTAP.	 	. 1

ESXi

NVMe/FC Host Configuration for ESXi 7.0 with ONTAP

Supportability

NVME/FC is supported on ONTAP 9.7 or later for ESXi 7.0.

ESXi initiator host can run both NVMe/FC & FCP traffic through the same adapter ports. See the Hardware Universe for a list of supported FC adapters and controllers. For the most current list of supported configurations & versions, see the NetApp Interoperability Matrix.

Known limitations

The following are not supported:

- · RDM mapping
- VVols

Enabling NVMe/FC with ANA

1. Disable the HppManageDegradedPaths parameter for improved interoperability with ONTAP:

```
# esxcfg-advcfg -s 0 /Misc/HppManageDegradedPaths
```

- 2. Reboot the host.
- 3. After reboot, verify that the HppManageDegradedPaths parameter is now disabled:

```
# esxcfg-advcfg -g /Misc/HppManageDegradedPaths
Value of HppManageDegradedPaths is 0
```

4. Check the ESXi host NQN string and verify that it matches with the host NQN string for the corresponding subsystem on the ONTAP array.

Configuring the Broadcom FC adapter for NVMe/FC

1. Install the recommended lpfc driver by copying it to a temporary folder and then executing the following command:

```
# esxcli software vib install -d /tmp/t/Emulex-FCoE-FC-lpfc-12.4.224.0-offline-bundle-
13621872.zip --no-sig-check
Installation Result
   Message: The update completed successfully, but the system needs to be rebooted for the changes to be effective.
   Reboot Required: true
   VIBs Installed: EMU_bootbank_lpfc_12.4.224.0-10EM.688.0.0.13621872
   VIBs Removed: EMU_bootbank_lpfc_12.4.211.6-10EM.688.0.0.13621872
   VIBs Skipped:
```

2. If necessary, set the lpfc driver parameter lpfc_enable_fc4_type=3 for enabling NVMe/FC support in the lpfc driver:



This parameter is set by default for the LPe35000-series adapters. You must perform the following step to set it manually for LPe32000-series & LPe31000-series adapters.

```
# esxcli system module parameters set -m lpfc -p lpfc_enable_fc4_type=3
```

3. Use the elxmgmt utility to upgrade the Broadcom FC adapter firmware to the recommended version:

```
# esxcli software vib install -d /tmp/t/Emulex-elxmgmt-6.8.7-12.4.211.7.zip --no-sig
-check
Installation Result
   Message: The update completed successfully, but the system needs to be rebooted for
the changes to be effective.
   Reboot Required: true
   VIBs Installed: EMU_bootbank_emu-esx-elxmgmt_12.4.211.7-01
   VIBs Removed:
   VIBs Skipped:
...
```

- 4. Reboot the host.
- 5. After reboot, verify that the recommended lpfc driver and adapter firmware versions have applied and the initiator ports are online:

```
# esxcli storage san fc list
Adapter: vmhba3
  Port ID: 010600
  Node Name: 20:00:00:90:fa:e0:ec:8e
  Port Name: 10:00:00:90:fa:e0:ec:8e
  Speed: 32 Gbps
  Port Type: NPort
  Port State: ONLINE
  Model Description: Emulex LightPulse LPe32002-M2 2-Port 32Gb Fibre Channel Adapter
  Hardware Version: 0000000c
  OptionROM Version: 12.4.217.2
  Firmware Version: 12.4.217.2
  Driver Name: lpfc
  DriverVersion: 12.4.224.0
  Adapter: vmhba4
  Port ID: 010F00
  Node Name: 20:00:00:90:fa:e0:ec:8f
  Port Name: 10:00:00:90:fa:e0:ec:8f
  Speed: 32 Gbps
  Port Type: NPort
  Port State: ONLINE
  Model Description: Emulex LightPulse LPe32002-M2 2-Port 32Gb Fibre Channel Adapter
  Hardware Version: 0000000c
  OptionROM Version: 12.4.217.2
  Firmware Version: 12.4.217.2
  Driver Name: lpfc
  DriverVersion: 12.4.224.0
```

Validating NVMe/FC

1. Verify that the ONTAP target NVMe/FC controllers are properly discovered on the ESXi host:

```
# esxcli nvme controller list
Name
Controller Number Adapter Transport Type Is Online
nqn.1992-
08.com.netapp:sn.e7f89c2c245d11e9975300a098dfce55:subsystem.interop_57_vm_01#vmhba32#2
                                               259 vmhba32 FC
04900a098dfe3d1:204a00a098dfe3d1
false
ngn.1992-
08.com.netapp:sn.e7f89c2c245d11e9975300a098dfce55:subsystem.interop_57_vm_09#vmhba32#2
04900a098dfe3d1:204a00a098dfe3d1
                                                263 vmhba32 FC
false
ngn.1992-
08.com.netapp:sn.e7f89c2c245d11e9975300a098dfce55:subsystem.interop 57 vm 11#vmhba32#2
04900a098dfe3d1:204a00a098dfe3d1
                                                267 vmhba32 FC
false
ngn.1992-
08.com.netapp:sn.e7f89c2c245d11e9975300a098dfce55:subsystem.interop_57_vm_10#vmhba32#2
04900a098dfe3d1:204a00a098dfe3d1
                                                265 vmhba32 FC
false
ngn.1992-
08.com.netapp:sn.e7f89c2c245d11e9975300a098dfce55:subsystem.interop_57_vm_02#vmhba32#2
04900a098dfe3d1:204a00a098dfe3d1
                                               261 vmhba32 FC
false
```

2. Verify that the NVMe/FC namespaces are properly created:

The UUIDs in the following example represent the NVMe/FC namespace devices.

```
#esxcfg-mpath -b
uuid.0d12b7cd97344be8a53b7913f8f72f04 : NVMe Fibre Channel Disk
(uuid.0d12b7cd97344be8a53b7913f8f72f04)
  vmhba65:C0:T9:L30 LUN:30 state:active fc Adapter: WWNN: 20:00:00:90:fa:e0:ec:8f
20:4d:00:a0:98:df:e3:d1
  vmhba64:C0:T9:L30 LUN:30 state:active fc Adapter: WWNN: 20:00:00:90:fa:e0:ec:8e
20:4c:00:a0:98:df:e3:d1
  vmhba64:C0:T5:L30 LUN:30 state:standby fc Adapter: WWNN: 20:00:00:90:fa:e0:ec:8e
20:4a:00:a0:98:df:e3:d1
  vmhba65:C0:T0:L30 LUN:30 state:standby fc Adapter: WWNN: 20:00:00:90:fa:e0:ec:8f
20:4b:00:a0:98:df:e3:d1
uuid.49de7683950d47c9898f51443d893910 : NVMe Fibre Channel Disk
(uuid.49de7683950d47c9898f51443d893910)
  vmhba65:C0:T12:L39 LUN:39 state:active fc Adapter: WWNN: 20:00:00:90:fa:e0:ec:8f
20:27:00:a0:98:df:e3:d1
  vmhba65:C0:T13:L39 LUN:39 state:standby fc Adapter: WWNN: 20:00:00:90:fa:e0:ec:8f
20:29:00:a0:98:df:e3:d1
  vmhba64:C0:T12:L39 LUN:39 state:active fc Adapter: WWNN: 20:00:00:90:fa:e0:ec:8e
20:3b:00:a0:98:df:e3:d1
  vmhba64:C0:T13:L39 LUN:39 state:standby fc Adapter: WWNN: 20:00:00:90:fa:e0:ec:8e
20:28:00:a0:98:df:e3:d1
```



In ONTAP 9.7, the default block size for a NVMe/FC namespace is 4K. This default size is not compatible with ESXi. Therefore, when creating namespaces for ESXi, you must set the namespace block size 512b. You can do this using the vserver namespace create command.

Example

vserver nvme namespace create -vserver vs_1 -path /vol/nsvol/namespace1 -size 100g -ostype vmware -block-size 512B

Refer to the ONTAP 9 Command man pages for additional details.

3. Verify the status of the individual ANA paths of the respective NVMe/FC namespace devices:

esxcli storage hpp path list

fc.20000090fae0ec8f:10000090fae0ec8f-fc.204900a098dfe3d1:204d00a098dfe3d1-

uuid.1aa669c5376240a28ae47d8d549586ea Runtime Name: vmhba65:C0:T9:L33

Device: uuid.1aa669c5376240a28ae47d8d549586ea Device Display Name: NVMe Fibre Channel Disk

(uuid.1aa669c5376240a28ae47d8d549586ea)

Path State: active

fc.20000090fae0ec8e:10000090fae0ec8e-fc.204900a098dfe3d1:204a00a098dfe3d1-

uuid.1aa669c5376240a28ae47d8d549586ea Runtime Name: vmhba64:C0:T5:L33

Device: uuid.1aa669c5376240a28ae47d8d549586ea Device Display Name: NVMe Fibre Channel Disk

(uuid.1aa669c5376240a28ae47d8d549586ea)

Path State: standby

:leveloffset: -1

:leveloffset: -1

<<<

Copyright Information

Copyright © 2020 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document

covered by copyright may be reproduced in any form or by any means-graphic, electronic, or

mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-

without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP DAS ISD AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice.

NetApp assumes no responsibility or liability arising from the use of products

described herein,

except as expressly agreed to in writing by NetApp. The use or purchase of this product does not

convey a license under any patent rights, trademark rights, or any other intellectual property

rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to

restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and

Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of

NetApp, Inc. Other company and product names may be trademarks of their respective owners.