THEFT DETERRENT (RHD)

SERVICE HINTS

L5 LUGGAGE COMPARTMENT DOOR KEY UNLOCK SW

1-2: Closed with door lock cylinder unlocked with key

E7 ENGINE HOOD COURTESY SW

1-2: Closed with engine hood open

L4 LUGGAGE COMPARTMENT DOOR COURTESY SW

2-GROUND: Closed with luggage compartment door open

D7, D8, D9, D10 DOOR COURTESY SW FRONT LH, RH, REAR LH, RH

1-GROUND: Closed with door open

D12 (B) DOOR KEY LOCK AND UNLOCK SW AND DOOR LOCK DETECTION SW FRONT RH

3 (B)–5 (B) : Closed with door lock cylinder locked with key 4 (B)–5 (B) : Closed with door lock cylinder unlocked with key

B6 (A) BODY ECU

BECU-GROUND : Always approx. 12 volts BSUB-GROUND : Always approx. 12 volts

ACC-GROUND: Approx. 12 volts with ignition SW at ACC or ON position IG-GROUND: Approx. 12 volts with ignition SW at ON or ST position

GND1-GROUND: Always continuity GND2-GROUND: Always continuity

: PARTS LOCATION

Code		See Page	Code		See Page	Code		See Page
A14	Α	106 (RHD)	D13	Α	108 (RHD)	J1	12	108 (RHD)
A15	В	106 (RHD)	סוט	В	108 (RHD)	J1	13	108 (RHD)
B6	Α	106 (RHD)	D15	Α	108 (RHD)	J1	14	108 (RHD)
B7	В	106 (RHD)	D13	В	108 (RHD)	J16		108 (RHD)
C10	Α	106 (RHD)	D16	Α	108 (RHD)	J1	17	108 (RHD)
C11	В	106 (RHD)	סוט	В	108 (RHD)	L	4	108 (RHD)
D2		106 (RHD)	E2	Α	104 (RHD)	L5		108 (RHD)
D4		106 (RHD)	E3	В	104 (RHD)	Р	8	109 (RHD)
D7		108 (RHD)	E7		104 (RHD)	R7		107 (RHD)
D8		108 (RHD)	l17		108 (RHD)	T4	Α	107 (RHD)
D9		108 (RHD)	J5		107 (RHD)	T5	В	107 (RHD)
D10		108 (RHD)	J8		107 (RHD)	T10		109 (RHD)
D12	Α	108 (RHD)	J9		107 (RHD)	U1		107 (RHD)
	В	108 (RHD)	J1	1	107 (RHD)			

: RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	81 (RHD)	Engine Room No.1 R/B (Engine Compartment Left)
2	81 (RHD)	Engine Room No.2 R/B (Engine Compartment Left)

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A		
1B	88 (RHD)	Engine Room Main Wire and Driver Side J/B (Right Kick Panel)
1C		
1F		
1G	88 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)
1H		
11		
1K	88 (RHD)	Front Door RH Wire and Driver Side J/B (Right Kick Panel)
1L	88 (RHD)	Floor Wire and Driver Side J/B (Right Kick Panel)
1M	88 (RHD)	Roof Wire and Driver Side J/B (Right Kick Panel)
2B	90 (RHD)	Front Door LH Wire and Passenger Side J/B (Left Kick Panel)
2D		
2E	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
2F		
2G	90 (RHD)	Engine Room Main Wire and Passenger Side J/B (Left Kick Panel)
2H	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)
21	90 (RHD)	Floor No.2 Wire and Passenger Side J/B (Left Kick Panel)
2L	90 (RHD)	Instrument Panel Wire and Passenger Side J/B (Left Kick Panel)

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA3	124 (RHD)	Instrument Panel Wire and Engine Room Main Wire (Near the Passenger Side J/B)
IB1	124 (RHD)	Instrument Panel Wire and Floor No.2 Wire (Near the Passenger Side J/B)
IC1	124 (RHD)	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
IH3	126 (RHD)	Instrument Panel Wire and Floor Wire (Near the Driver Side J/B)
BA1	128 (RHD)	Rear Door No.2 Wire and Floor No.2 Wire (Left Center Pillar)
BB1	128 (RHD)	Rear Door No.1 Wire and Floor Wire (Right Center Pillar)
BC1	128 (RHD)	Floor No.2 Wire and Floor Wire (Under the Right Rear Cushion)

: GROUND POINTS

Code	See Page	Ground Points Location
EC	122 (RHD)	Left Fender Apron
ID	124 (RHD)	Cowl Side Panel LH
IF	124 (RHD)	Cowl Side Panel RH
IH	124 (RHD)	Front Floor Panel Center RH
BJ	128 (RHD)	Front Floor Panel LH
BK	128 (RHD)	Left Quarter Panel LH
BL	128 (RHD)	Front Floor Panel RH
BM	128 (RHD)	Roof Panel