Lab Manual for ECE 455 Spring, 2016 Department of Electrical and Computer Engineering University of Waterloo

Written by Bernie Roehl (broehl@uwaterloo.ca)

Version 1.2 Last updated May 3, 2016

Copyright (c) 2011,2012, 2015, 2016 by Bernie Roehl.
All rights reserved unless otherwise noted.

NOTE: Students enrolled in ECE courses at the University of Waterloo are authorized to print or duplicate this lab manual in its entirety for their personal use.

Outline

1) Development Environment

Covers how to install the μ Vision IDE, and how to use it to build and deploy a simple "Hello, world" example program.

2) Hardware Overview

Describes the hardware of the MCB1700 board, focusing on those specific components that you will be using in your labs.

3) Coding

Discusses ways of optimizing your code, and describes the calling conventions used by the C compiler so you can interface between C and assembly language.

4) Debugging and Simulation

Shows how to use the debugging component of the IDE, both with the actual hardware and with the built-in simulator.

5) Lab Assignment Descriptions

Gives a description of each of the labs for your course, including the objectives of each.

Note that this lab manual does not describe the ARM architecture, instruction set, assembly language syntax, or the C programming language. References for all of those are readily available online.

Table of Contents

1. Development Environment
Setting Up Your System
A Quick Tour of the IDE
Creating a New Project
Creating Source Files
Building and Running the "Hello world" example
2. Hardware Overview
Major Functional Blocks
<u>Memory</u>
Pin Connect Block
Power Control Block
<u>Vectored Interrupt Controller</u>
General-Purpose I/O
<u>Clocks</u>
Configuration Wizard
<u>ADC</u>
DAC
<u>Timers</u>
<u>MPU</u>
<u>Display</u>
3. Coding
Writing Efficient Code
Calling Conventions
4. Debugging and Simulation
Disassembly and Call Stack Windows
Register Window
Memory and Symbol Table Windows
Watch Window
Peripheral Device Windows
Breakpoints Window
Logic Analyzer
5) Lab Assignment Descriptions
Assignment 1: Simple Timing
Assignment 2: Finite State Machines
Assignment 3: Interrupt Shaping
Assignment 4: EDF Scheduler
6) Closing Comments
Notices Regarding Software, Documents, And Services Available On This Website
Links To Third Party Sites

1. Development Environment

All development for the MCB1700 is done using the Keil μ Vision IDE. μ Vision is similar to many other IDEs you may be familiar with such as Eclipse or Visual Studio. It combines an editor, compiler, debugger and simulator into a single development environment.

The μ Vision environment is very generic, and can work with a variety of different processors and boards. It can also build binaries to run in flash memory, static RAM or a simulator that's included with the package.

Depending on your lab, much of the initial development work can be done using the simulator. You can download the free version of μ Vision and use it with the simulator on your own computer, and only use the actual MCB1700 boards for final testing. The only significant limitation of the free version of the software is that the size of your binary is limited to 32 KB, which should be adequate for any of our labs.

Setting Up Your System

The μ Vision software is already installed on the computers in the lab. However, if you are doing development using your own computer, you will need to install μ Vision. You can get it from the following URL:

https://ece.uwaterloo.ca/~ece455/mdk414.exe

When you install μ Vision, you should ask it to also install the example projects for the "Keil (NXP) MCB1xxx Boards". You will also need to let it install the ULINK driver, which communicates with the Cortex debugger interface on the board using an attached daughterboard.

The next step is to create a folder for your course, either on your own computer or on your Nexus P: drive (or your N: drive, if your P: drives is not available for any reason). You can call it whatever you like, but it should probably be named for the course (e.g. something like "ece455"). Once you've created the folder, download the support files from the following URL:

https://ece.uwaterloo.ca/~ece455/mcb1700 ece.zip

Unzip that file into the folder you created. You are now ready to start creating projects for your course.


A Quick Tour of the IDE

The full documentation for the µVision IDE can be found at the following URL:

http://www.keil.com/product/brochures/uv4.pdf


That document is over 180 pages long, and most of it is very introductory in nature. It also covers multiple different processor types that are not used in our labs. You should not need to refer to that document.

The IDE consists of a number of elements:



(image courtesy of Keil)

At first, it may seem very complex, but there are really only a few areas you need to concern yourself with: the Project windows, the Editor windows, the Output windows and the toolbars.



(image courtesy of Keil)

The Project window is generally used to give you a hierarchical view of the various files that are part of your project, and can also be used to browse functions, templates and documentation.

The Editor window has a set of tabs, one for each file you have open. You edit your source code in this area, and the editor provides some limited syntax highlighting for your C code.

The Output area gives you the results of your build operation, lists of errors, and other general information.

There are three toolbars. The "File" toolbar is always present, and lets you access commonly-used features such as load, save, undo, redo, cut, paste, search and so on. It also has some frequently-used buttons for handling breakpoints. The "Build" toolbar is only present when you're compiling code, and the "Debug" toolbar is only present when you're debugging your application. Note that you will always be in one of those two modes (Build or Debug). To

All the icons in the toolbars have tooltips that appear if you hover over the icon, and the meaning of each should be clear (e.g. "set breakpoint").

The individual windows can be dragged around by their title bars, and you can tile the editor windows to examine multiple source files at the same time. If things get out of hand, you can use the Window menu item "Reset view to defaults" to get back to a reasonable window layout. The Debug tools will be discussed later, after we've examined the hardware. For now we'll focus on the Build process.

Creating a New Project

Launch μ Vision, and use the menu item *Project/New \muVision Project* to create a new project. Choose the folder you created for your course, and give your project a name (e.g. "lab1").

You will then be asked to specify what hardware you'll be using. Expand the "NXP (founded by Philips)" tree and select the "LPC 1768" processor. When asked if the startup files should be copied over and added to your project, choose "yes".

In the Project window, click on "Target 1" (in the hierarchy tree), then click it again so you can rename it to something more meaningful such as "LPC1768 Flash". Expand the target, then right click on "Source Group 1" and select "Add files to group Source Group 1". In the resulting dialog box, under "Files of type:", choose "All files". Select "system_LPC17xx" and "GLCD_SPI_LPC1700" (both are C source files) and "GLCD" (a header file). Click Add, and then Close.

What you've done is create a new project with a new build target ("LPC1768 Flash"), then added the system startup code, the display routines and the display header file to the project.

At this point, you're ready to start writing your code.

Creating Source Files

Using the "File/New" menu item, create a new file. It will initially be a ".txt" file, so use "File/Save as" to save it out with a ".c" extension (e.g. "main.c"). Right click on "Source Group 1" in the Project window, select "Add files to group Source Group 1", select your source file, then click Add and Close. You must do this once for each new source file in your project. Forgetting to do this is a very common mistake.

Note that you can rename "Source Group 1" to something more meaningful. You can also

rename your target, create additional targets, and so on by right-clicking on the target in the Project window and selecting "Manage components".

Building and Running the "Hello world" example

Here is the code for a simple "Hello, world" example:

```
#include <lpc17xx.h>
#include "glcd.h"

int main(void)
{
    SystemInit();
    GLCD_Init();
    GLCD_Clear(White);
    GLCD_DisplayString(0, 0, 1, "Hello, world!");
    return 0;
}
```

The first line brings in the definitions for the various registers that are on the LPC1768 family of processors. The second line brings in the definitions for the display routines that put text and graphics on the LCD panel. Obviously the glcd.h file is only needed if you're using the display.

The very first thing we do in main() is call SystemInit(), which does the initialization for us. If you open the system_17xx.c file by double-clicking on it in the Project window, then look at the bottom of the editor window, you should see a "configuration wizard" tab. This wizard allows you to configure your clock settings as well as the power settings for the on-chip peripherals. The SystemInit() function is where all that initialization takes place. These settings will be discussed in detail in the Hardware section of this manual.

The GLCD_Init() function does the tedious work of initializing the LCD display. The next line calls the GLCD_DisplayString() function to put a character string on the display at line 0, row 0, using font 1 (the larger of the two available fonts).


Build your application by hitting F7. If there are no errors, click on the LOAD button() to download the code into flash memory on the MCB1700 board. To run it, just hit the button marked "Reset" on the board.

From within the IDE you can debug your program by single-stepping and setting breakpoints. You can also simulate the execution of your software without needing to have access to the board itself. Both of these will be discussed later in this manual, but first we need to become more familiar with the hardware on the board.

2. Hardware Overview

The board being used in our labs is the Keil MCB1700. It uses the NXP LPC 1768 processor, consisting of an ARM core (specifically, the Cortex M3), 512 KB of flash memory and 64 KB of SRAM along with a wide variety of on-chip peripherals.

The board itself is relatively simple, and aside from the LPC 1768 itself there are only a few support circuits (mostly RS-232 level converters, ethernet transceivers, audio amplifiers and so on). The board provides a USB port, two serial (COM) ports, two CAN ports, an ethernet connector, a micro SD card slot, a potentiometer, a speaker and a set of LEDs and buttons. It also provides a full-colour LCD display.



(image courtesy of Keil)

In our department labs, the board is connected to the host computer using two USB cables. One simply provides power to the MCB1700, while the other connects to a ULINK-ME

daughterboard that is plugged into the Cortex debugging interface on the MCB1700. It is through the ULINK-ME that you will be downloading your compiled code and debugging it.

Since all the peripherals are on-chip, your primary reference for the board will be the manual for the LPC 1768 chip itself. This can be found at the following URL:


http://www.keil.com/dd/docs/datashts/philips/lpc17xx um.pdf

Note that the document is 840 pages long, and only a small fraction of it is relevant to your labs, so there is no need to print out the entire document. This lab manual will provide all the information you need, and will also reference specific sections of the product document which you can either refer to online or print out if necessary.

Major Functional Blocks

The LPC 1768 is a "system on a chip" that combines flash, SRAM, timers, a DAC, a multi-channel ADC and numerous communications interfaces onto a single IC.

Note that many of the blocks identified in this next diagram are not used in our labs. In this manual we will only be discussing those blocks that you will actually be using.



(image courtesy of Keil)

Memory

There are four different blocks of memory on the LPC 1768. There is a block of 512 KB of flash memory, located at the bottom of the address space, which is used for storing your code and data. There is an 8 KB boot ROM, which is hard-coded and unchangeable. There is a block of 32 KB of static RAM for use by the application (it's also possible to use this space for code, as an alternative to using the flash memory). And finally, there are two banks of 16 KB of static RAM that are shared with peripheral devices. All the peripherals are memory-mapped, so they are accessible directly from C.

The overall system memory map is as follows:

0000 0000 to 0008 0000	512 KB of flash
1000 0000 to 1000 8000	32 KB of SRAM
1FFF 0000 to 1FFF 2000	8 KB of boot ROM
2007 C000 to 2008 4000	two 16 KB blocks of shared SRAM
2009 C000 to 200A 0000	GPIO
4000 0000 to 4008 0000	APB0 peripherals
4008 0000 to 4010 0000	APB1 peripherals
5000 0000 to 5020 0000	AHB peripherals
E000 0000 to E00F FFFF	Cortex-M3 related registers

Note that the address space is sparse, so the above blocks are not consecutive and are separated by "reserved" areas.

The three peripheral blocks allocate 16 KB to each peripheral. The AHB block contains the ethernet controller, USB controller, and DMA controller. The APB blocks contain all the other peripherals. Note that the pin connect registers (described below) are considered a "peripheral" in this context.

More detailed memory maps can be found in section 2 of the LPC 1768 documentation.

You generally will not need to deal with hardware addresses directly, since the lpc17xx.h include file contains definitions for all the registers. This is done using a set of variables that each reference a group of registers as a struct, and the individual registers as fields within that struct. This will be explained in detail in each of the sections below.

Pin Connect Block

Because of the large number of internal peripherals, most of the pins on the chip can perform as many as four different functions. It is therefore necessary for you to specify what function you want each pin to be used for. This is accomplished by programming a set of registers known as the Pin Connect Block. For example, pin P0.0 can be used for RD1 (received data on CAN port 1), TXD3 (transmit data on UART 3), SDA1 (part of the I²C interface) or as a general-purpose input/output pin, depending on the setting of a pin select register. The specifics of selecting particular pin functions will be discussed as needed in the sections below. You may also need to set the *mode* of each pin (internal pull-up resistor, pull-down resistor, or neither).

The pin connect block is referenced from C as a struct called LPC_PINCON, with fields called PINSEL1, PINSEL2, PINMODE1, PINMODE2, and so on.

Power Control Block

Because the LPC 1768 is designed to be used in mobile devices, power consumption is a key issue. There is a set of registers that allow an application to enable and disable power to the main processor as well as each individual on-chip peripheral. By powering down peripherals that are not used in a particular application, considerable power savings can be achieved.

For our labs, we power the board from the host computer and so power consumption is not an issue. However, some peripherals default to being "off", so you will need to use the power control block to power them up. The specifics of doing this will be addressed in the sections below.

The 32-bit peripheral power control register is referenced from C as LPC_SC->PCONP. LPC_SC is a general system-control register block, and PCONP referes to Power CONtrol for Peripherals.

Note that you can also specify which peripherals should be powered on using the configuration wizard, described elsewhere in this document.

Vectored Interrupt Controller

All the internal peripherals are capable of generating interrupts. The specific conditions that produce interrupts can be set individually for each peripheral, and the individual interrupts can be enabled or disabled using a set of registers.

Writing an interrupt handler in C is very easy -- just create a function with an appropriate name

and it will automatically be used. The name consists of the prefix from the table below, with "Handler" appended (e.g. TIMER0_IRQHandler).

Int. number	Prefix	Description
0	WDT_IRQ	Watchdog timer (not used by our labs)
1	TIMER0_IRQ	Timer 0
2	TIMER1_IRQ	Timer 1
3	TIMER2_IRQ	Timer 2
4	TIMER3_IRQ	Timer 3
5	UART0_IRQ	UART 0
6	UART1_IRQ	UART 1
7	UART2_IRQ	UART 2
8	UART3_IRQ	UART 3
9	PWM1_IRQ	PWM 1 (unused on MCB1700)
10	I2C0_IRQ	I ² C 0 (unused on MCB1700)
11	I2C1_IRQ	I ² C 1 (unused on MCB1700)
12	I2C2_IRQ	I ² C 2 (unused on MCB1700)
13	SPI_IRQ	SPI (used for communicating with LCD display)
14	SSP0_IRQ	SSP 0 (unused on MCB1700)
15	SSP1_IRQ	SSP 1 (unused on MCB1700)
16	PLL0_IRQ	PLL 0 (interrupts not used by our labs)
17	RTC_IRQ	Real-time clock
18	EINT0_IRQ	External interrupt 0
19	EINT1_IRQ	External interrupt 1 (unused on MCB1700)
20	EINT2_IRQ	External interrupt 2 (unused on MCB1700)
21	EINT3_IRQ	External interrupt 3 (unused on MCB1700) & GPIO interrupt
22	ADC_IRQ	ADC end of conversion
23	BOD_IRQ	Brown-out detected (not used in our labs)
24	USB_IRQ	USB
25	CAN_IRQ	CAN

26	DMA_IRQ	DMA
27	I2S_IRQ	I ² S (unused on MCB1700)
28	ENET_IRQ	Ethernet
29	RIT_IRQ	Repetitive-interrupt timer
30	MCPWM_IRQ	Motor control PWM
31	QEI_IRQ	Quadrature encoder
32	PLL1_IRQ	USB phase-locked loop (interrupt not used in our labs)
33	USBActivity_IRQ	USB activity
34	CANActivity_IRQ	CAN activity

Note that a particular peripheral can generate its interrupt for a variety of reasons, which are configured within that peripheral. For example, timers can be configured to generate interrupts either on match or on capture.

By default, the interrupt vector table is at the very bottom of physical memory (address 0000 0000). However, you can change this location by setting the Vector Table Offset Register (SCB->VTOR, section 6.4), placing the table anywhere in the lowest 1 GB of address space. For alignment reasons, it must be located on a 1024 byte boundary. In practice, you will typically only relocate it to the bottom of SRAM at 1000 0000.

The priorities of the interrupts can be set individually. See sections 6.5.11 to 6.5.19 for details.

A set of functions is available for enabling and disabling specific interrupts, setting their priority, and controlling their pending status:

```
void NVIC_EnableIRQ(IRQn_Type IRQn)
void NVIC_DisableIRQ(IRQn_Type IRQn)

void NVIC_SetPriority(IRQn_Type IRQn, int32_t priority)
uint32_t NVIC_GetPriority(IRQn_Type IRQn)

void NVIC_SetPendingIRQ(IRQn_Type IRQn)
void NVIC_ClearPendingIRQ(IRQn_Type IRQn)
IRQn Type NVIC GetPendingIRQ(IRQn Type IRQn)
```

The IRQn names are just the prefix from the table above with an "n" appended (e.g. TIME0_IRQn).

```
You can also enable or disable interrupts altogether using __disable_irq() and __enable_irq();
```

You can also trigger any interrupt in software by writing the interrupt number to the NVIC->STIR register (values up to 111 are permitted).

You must clear interrupt conditions in the interrupt handler. This is done in different ways, depending on what caused the interrupt. For example, if you have INT0 configured to generate an interrupt, you would clear it by setting the low-order bit of the LPC_SC->EXTINT register.

Interrupt handling is described in detail in section 6 of the Keil documentation.

General-Purpose I/O

Among the various functions that can be programmed using the pin control block is GPIO, or general-purpose I/O. GPIO allows individual pins to be used for input or output.

In the case of the MCB1700, the board provides a set of eight LEDs which are connected to specific pins on the processor. It also provides a "joystick" consisting of four directional buttons and a center "select" button, as well as a single "INT0" button, all of which are connected to input pins on the processor.

When the processor powers up or resets, the pins that are connected to the LEDs and buttons are automatically configured as GPIO (General-Purpose I/O). However, it is good practice to configure these pins before using them. In any case, it is also necessary to set the data direction register to indicate which pins are to be used for input (the buttons) and which for output (the LEDs). The GPIO control registers are accessed using structs called LPC_GPIO1 and LPC_GPIO2.

Configuring the INTO button for input is done like this:

```
LPC_PINCON->PINSEL4 &= \sim (3<<20);  // P2.10 is GPIO LPC_GPIO2->FIODIR &= \sim (1<<10);  // P2.10 is input
```

The first line above enables the INT0 button to be used for input by setting bits 21 and 20 of the PINSEL4 register (section 8.5.5) to zero, which corresponds to GPIO. The second line sets bit 10 in the GPIO2 I/O direction register (section 9.5.1) to zero, meaning the pin will be used for input. In theory you could omit these two lines, since zero is the default value for both of these registers.

Setting up the "joystick" is done as follows:

The first line of code sets five specific bits in the LPC_PCON->PINSEL3 register (section 8.5.4) to zero, again meaning that they will be used for general purpose I/O. The second line clears bits in the I/O direction register, indicating that the five buttons of the "joystick" are to be used for input. Again, these steps could be omitted since zero is the default value.

Configuring the LEDs for output is straightforward:

```
LPC_GPIO1->FIODIR |= 0xB0000000;  // LEDs on PORT1
LPC GPIO2->FIODIR |= 0x0000007C;  // LEDs on PORT2
```

These two lines simply set the pins corresponding to the LEDs to be output by turning on the corresponding bits in the I/O direction register (section 9.5.1).

Notice that in this case we didn't bother explicitly setting the pins to be GPIO. We didn't need to do that in the earlier code either, since GPIO is the default setting.

To turn on a particular LED, you would use the following code:

Notice that the LEDs are split over two separate GPIO ports, with the first three on GPIO port 1 and the remaining five on GPIO port 2. See section 9.5.2 for details. To turn the LEDs off, write to the FIOCLR registers rather than FIOSET.

All the joystick buttons are on GPIO port 1 (section 9.5.4), so to read the "joystick" you would simply do this:

```
kbd_val = \sim (LPC_GPIO1->FIOPIN >> 20) \& 0x79;
```

The INTO button is on GPIO2, so reading it is just:

```
int0 val = \sim (LPC GPIO2->FIOPIN >> 10) & 0x01;
```

You can enable interrupts from any pin on port zero or port 2, triggered on the rising and/or

falling edge. This is enabled using registered in the LPC_GPIOINT block called IO0IntEnF, IO0IntEnR, IO2IntEnF and IO2IntEnR (the 'F' stands for falling edge, and the 'R' stands for rising edge). The GPIO shares the vector for External Interrupt 3, so that's what you should enable.

For example, the following code enables an interrupt on the falling edge of pin P2.10 (which happens to be the INT0 button on the board):


```
LPC_GPIOINT->IO2IntEnF |= 1 << 10; // falling edge of P2.10
NVIC_EnableIRQ(EINT3_IRQn);</pre>
```

In your interrupt handler you should clear the interrupt condition by writing 1 bits to the appropriate IntClr register. In this particular case you would do the following:

```
\label{eq:lpc_gpioint} \mbox{LPC\_GPIOINT->IO2IntClr} \mid = 1 << 10; \ // \ \mbox{clear interrupt} \\ \mbox{condition}
```

Clocks

The clock system on the LPC 1768 is extremely flexible. The following diagram gives an overview of how the pieces fit together:



(image courtesy of Keil)

You can ignore anything related to the USB clock, since we will not be using it in our labs. The same is true of the watchdog timer.

You can select any of three different clock sources by setting the bottom two bits of the LPC_SC->CLKSRCSEL register (section 4.4.1) as follows:

00	internal 4 MHz RC oscillator (this is the default)
01	12 MHz external oscillator
10	32 KHz realtime clock oscillator


Regardless of which clock source is used, it can either be used directly or as the input to a phase-locked loop that scales it up to a higher frequency (that still follows the phase of the input clock) and then divides it down to a lower frequency. There are many configuration options for the PLL, which are beyond the scope of this lab manual but which are described in section 4.5 of the LPC 1768 documentation.

The input clock (or the output of the PLL, if used) is then put through by a divider whose value is stored is bits 7:0 of the LPC_SC->CCLKCFG register (see section 4.7.1). If the PLL is used, the divisor value in CCLKCFG must be at least 2. The output from that divider is the actual CCLK signal to the processor.

That processor clock signal is further subdivided by 2, 4 and 8 to provide four separate peripheral clocks (including the original, undivided processor clock signal), and each peripheral device on the chip can be configured to use any of those four clocks for its operation (see section 4.7.3 for details on which bits in the LPC_SC->PCLKSEL0 and LPC_SC->PCLKSEL1 registers control the clock selection for each peripheral).

Configuration Wizard

Setting all these values, particularly those of the PLL, is a complex operation that involves (among other things) waiting for the PLL to lock onto the incoming frequency. Fortunately, much of this complexity is handled by the startup code that is included with the development kit. You do not even have to modify that startup code by hand, since the µVision IDE (described earlier) provides a configuration wizard that handles the updating of the startup code. All you need to do is choose appropriate settings. Double-click the system_17xx.c file in the Project window to open it in the editor, then click on the "Configuration Wizard" tab below the file in the editor window.



Most of the settings are straightforward. Since the MCB1700 is powered from the host computer, there is no reason not to use the main (external) oscillator. Therefore the oscillator enable (OSCEN) bit should be set. The OSCRANGE should be set to "1 MHz to 20 MHz" to match the 12 MHz crystal on the board.

The PLL should be configured to use the oscillator as its input. The main parameters that should be set for PLL0 are M and N, the multiplier and divisor. The output frequency will be 2*M*F/N, where F is the input frequency. When using the oscillator, M should not be less than 6 or greater than 512, and N should always be in the range 1 to 32. In the example shown above, M is set to 100 and N is set to 6. Therefore, the 12 MHz oscillator will produce an output frequency from the PLL of 2 * 100 * 12 / 6 = 400 MHz.

Since the CCLKSEL value is 4 (which is set into the bottom 8 bits of the LPC_SC->CCLKCFG register during system initialization), the CCLK will be 100 MHz (i.e. 400 MHz divided by 4).

The four peripheral clocks would be 100 MHz, 50 MHz, 25 MHz and 12.5 MHz, and you can

configure any peripheral to use any of these four clocks (using the two Peripheral Clock Selection Registers in the wizard).

Note that these are all good values to use, and you should simply use them unless you have a specific reason not to.

ADC

The LPC 1768 provides a 12-bit analog to digital converter, with an 8-input analog mux and a separate capture register for each of those inputs. It is therefore possible to automatically capture from up to 8 analog sources, each to its own register. On the MCB1700 board, there is a potentiometer connected to analog input 2, which is most likely the only one you will be using in your labs.

Since we are just using a single input, you will only need to concern yourself with three registers:

- the analog/digital control register (LPC_ADC->ADCR, section 29.5.1)
- the analog/digital global data register (LPC_ADC->ADGDR, section 29.5.2)
- the analog/digital interrupt enable register (LPC_ADC->ADINTEN, section 29.5.3)

Initializing the ADC consists of a series of steps:

Again we see the use of the PINSEL registers. In this case, we clear the bits to zero and then set the lower bit, so we're specifying function 0x01 (analog input) for the P0.25 pin. We also see the first example of using the Power Control registers, since we need to enable power to the ADC peripheral block before it can be used (see section 4.8.9 for details). Note that this can also be done using the configuration wizard, described earlier.

We set bits 7:0 of the ADCR register to 00000100, to enable conversion of input 2 to the analog mux. In hardware-scan mode (which we're not using, since we only have a single input) you could set more than one bit to automatically sample more than one channel sequentially.

The ADC uses a successive-approximation approach, and therefore is driven internally by a clock. We set bits 15:8 of the ADCR register to 4, in order to divide the 25 MHz clock by 5 (the divisor is the value in the ADCR register plus one, since division by zero is meaningless). Note that the 25 MHz frequency is provided by choosing the third peripheral clock in the configuration wizard, which divides the 100 MHz processor clock by 4 as described in the Clocks section above.

We also turn on the PDN bit (bit 21) of the ADCR register to enable the ADC subsystem itself.

To actually capture data, we would do this:

```
LPC ADC->ADCR \mid = (1<<24);
```

which starts the A/D conversion (i.e. we write 001 to bits 26:24). We then poll until the conversion is complete, and retrieve the value:

```
while (LPC->ADGDR & 0x8000 == 0); // wait for conversion complete value = (LPC ADC->ADGDR>>4) & 0xFFF; // read result
```

There is a data register for each input channel, as well as a global data register that always stores the most recently converted value regardless of channel. Since we only have the one analog input, we simply use that global register. The top bit of the register indicates when the conversion is done, and bits15:4 store the actual 12-bit value.

Alternatively, we can set up the ADC to generate an interrupt whenever a conversion is complete:

The ADINTEN register specifies which of the 8 A/D channels should generate interrupts. In this case we're setting bit 8, which means that we should generate an interrupt when *any* of the channels captures a value.

The NVIC_EnableIRQ() function tells the vectored interrupt controller to recognize interrupts from the ADC subsystem itself.

We can read the conversion result in the interrupt handler, and possibly start another conversion going. Alternatively, we could start conversion in a timer interrupt and read the value in the ADC interrupt handler, thereby ensuring a constant sampling rate. It's also possible to have a hardware timer trigger a conversion (see section 29.6.1 for details).

DAC

The LPC 1768 has a 10-bit digital-to-analog converter that uses an internal resistor string, capable of an update rate of 1 MHz.

In the case of the MCB1700 board, the DAC is connected directly to an amplifier and speaker. You can produce sound by writing data to the DAC at a suitable rate.

To initialize the DAC, you need to set the appropriate bits in the pin control block, and set the pin mode to use neither pull-up nor pull-down resistors:

```
LPC_PINCON->PINSEL1 &= ~(3<<20);

LPC_PINCON->PINSEL1 |= (2<<20);

LPC_PINCON->PINMODE1 &= ~(3<<20);

LPC_PINCON->PINMODE1 |= (2<<20);
```

To output a value via the DAC, simply write it into bits 15:6 of the LPC_DAC->DACR register (section 30.4.1). All other bits should be zero.

```
LPC DAC->DACR = (value & 0x3FF) << 6;
```

Note that we mask the value to 10 bits and shift it into the correct position.

Timers

There are four general-purpose 32-bit timer/counters on the LPC 1768. Each of them has a 32-bit prescaler, a pair of capture registers and four match registers, and can generate interrupts on various conditions. In our labs, we don't use the counter, capture or external match functionality since we don't typically hook up external signals to the processor pins.

The timers are reference using the LPC_TIMx structs, where x is 0 through 4. Each timer can be enabled by setting bit 0 in its control register (LPC_TIMx->TCR, section 21.6.2) and reset by setting and then clearing bit 1. The timer value can be read or written using the timer/counter register (LPC_TIMx->TC, section 21.6.4), the prescaler divisor can be read and written in the prescale register (LPC_TIMx->PR, section 21.6.5), and the current prescaler value can be read and written in the prescale counter register (LPC_TIMx->PC, section 21.6.6). These are all 32-bit values.

Keep in mind that you can specify which peripheral clock is used to drive each timer (see the description in the Clocks section, above), and that you would typically set this up using the

configuration wizard.

There are four match registers for each timer (LPC_TIMx->MRy, section 21.6.7). There is also a match control register (LPC_TIMx->MCR, section 21.6.8) which contains three bits for each of the four match registers. These bits determine what should happen when the timer register equals the match register. If the low-order bit is set, an interrupt is generated. If the next higher bit is set, the timer/counter is reset to zero. If the highest-order bit of the three is set, the timer/counter stops counting.

To initialize a timer and set it to generate an interrupt on match, you would do the following:

```
LPC_TIM0->TCR = 0x02;  // reset timer
LPC_TIM0->TCR = 0x01;  // enable timer
LPC_TIM0->MR0 = 2048;  // match value (can be anything)
LPC_TIM0->MCR |= 0x03;  // on match, generate interrupt and reset
NVIC_EnableIRQ(TIMER0_IRQn);  // allow interrupts from the timer
```

The interrupt handler must clear the interrupt condition. To do this, set one of the bottom four bits of the LPC_TIMx->IR register to clear the corresponding match interrupt condition:

```
LPC_TIMO -> IR \mid = 0x01;
```

In addition to these four timers, there is a system tick timer (part of the Cortex-M3 core) that is typically used to provide an interrupt every 10 milliseconds, based on a 100 MHz processor clock. You enable this by setting the bottom two bits of the system tick control register (STCTRL, section 23.5.1), with bit 0 enabling the timer and bit 1 enabling the interrupt. Alternatively, you can initialize it using the SysTick_Config() function which takes the number of ticks per second as a parameter. One way to set this value is as a fraction of the global SystemFrequency variable, like this:

```
SysTick Config(SystemFrequency/10000);
```

The SysTick_Handler() routine gets called on system tick interrupts.

And finally, there's a repetitive interrupt timer. You simply set the RI compare register (LPC_RIT->RICOMPVAL, section 22.3.1), and an interrupt will be generated whenever the RI counter LPC_RIT->RICOUNTER reaches that value. You can also write a mask register (LPC_RIT->RIMASK, section 22.3.2) that causes the compare to always match on the corresponding bits.

MPU

The LPC 1768, like all Cortex M3 based processors, has a built-in Memory Protection Unit. This unit is used to restrict access to up to 8 different (and possibly overlapping) blocks of the address space, by generating a fault when those blocks are accessed inappropriately.

By default, the MPU is disabled. To enable it, you set the bottom bit of MPU->CTRL (section 34.4.5.2). Note that you should first define a number of memory regions, otherwise all memory access will generate a fault. Alternatively, you can set bit 2 of the MPU->CTRL register to allow privileged software to continue operating, using the default memory map. You can then define regions that override that default map.

```
MPU->CTRL \mid = 0x05; // enable MPU and allow use of default map
```

To define a region, you first select it by writing the region number (0 through 7) into the MPU Region Number Register (MPU->RNR, section 34.4.5.3). You then write values to the MPU Region Base Address Register (MPU->RBAR, section 34.4.5.4) and the MPU Region Attribute and Size Register (MPU->RASR, section 34.4.5.5).

Bit 0 of the RASR is used to enable the memory region (or disable it, if the bit is cleared). You can define regions of various sizes, but they must all be a power of two (anything from 32 bytes to 4 gigabytes). The size of the region is stored in bits 5:1 of the RASR register, expressed as the log₂ of the size, minus 1. For example, the size of a 1024 byte region would be stored as 9 (log₂ of 1024 is 10, minus 1 gives 9).

The base address of the region is stored in the RBAR register, in the top N bits (where N is log₂ of the region size). In the example above, the top 10 bits of the RBAR register would be used to store the region size.

Here's what all this looks like in code:

```
region_base_address = 0x10000000; // start of RAM
region_size = 10; // 1024 byte region

MPU->RNR = 1; // select region 1

MPU->RBAR = region_base_address << (32-region_size);
MPU->RASR = ((region_size-1_<<1)|0x01; // store size, enable</pre>
```

By default, any access to a protected region will generate a fault. If you need more precise control, you can set additional access control bits in the RASR. This is described in section

34.4.5.5 of the LPC 1768 documentation.

Note that if regions overlap, the higher region numbers (up to region 7) take precedence over the lower region numbers.

You can also disable certain subregions within a region. If you need this capability, refer to section 34.4.5.8.3 of the documentation.

Display

The MCB1700 board comes with a 320 by 240 TFT LCD display with 16 bits per pixel. The LPC 1768 communicates with the display over the SPI (Serial Peripheral Interconnect) bus. This is one of several interconnection buses that the LPC 1768 provides, and it's the only one that will be used in our labs. The details of interfacing to the display are fairly involved, but fortunately you do not need to concern yourself with them. A set of routines is available to perform the following functions:

The "font" is either 0 or 1 to select differently-sized characters. The colors can be the predefined constants Black, Navy, DarkGreen, DarkCyan, Maroon, Purple, Olive, LightGrey, DarkGrey, Blue, Green, Cyan, Red, Magenta, Yellow and White, or any RGB value packed into 16 bits in 5:6:5 format (i.e. red in bits 15:11, green in bits 10:5 and blue in bits 4:0).

3. Coding

In this section, we'll be providing hints and suggestions to help you write better code and access some of the more advanced features of the Cortex-M3 core that is inside the LPC 1768. A complete description of the ARM C compiler can be found here:

http://infocenter.arm.com/help/index.jsp?topic=/com.arm.doc.kui0097a/armcc babdidhg.htm

In this manual, we will cover only a few of the more important aspects. You are encouraged to refer to the above document for more details.

Writing Efficient Code

Even though the compiler does an excellent job of optimizing your code as it compiles it, there are things you can do to help.

Interrupt handlers should be kept short. Do not do any lengthy calculations in a handler, just collect data or update values as needed. For maximum speed, put the interrupt handlers in SRAM rather than flash. You can do this by right-clicking on the source file in the Project window, selecting "Options for file" and then specifying the memory assignment.

Any variables that are changed in an interrupt handler or are updated by hardware should be declared volatile to prevent the compiler from performing inappropriate optimizations.

Local variables will typically be assigned to registers, but you can hint this to the compiler by declaring the variables to be automatic. Both automatic variables and function parameters are kept in 32-bit registers, so it's most efficient to make those variables and parameters 32-bit types as well.

In a struct, it's most efficient to put the scalars (ints, floats, etc) near the start of the struct so that shorter address offsets may be used. These can be followed by arrays and other complex data types.

Try to write your loops in count-down-to-zero form and use simple termination conditions. Try to use counters of type unsigned int, and test for not equal to zero.

You can use #pragma Ospace to optimize the subsequent function for space, or #pragma Otime to optimize for speed. You can use #pragma unroll_completely to force loop unrolling.

Depending on the size of your data, you may need to optimize your code for size in order to fit

within the 32 KB limit of the free version of the µVision IDE.

Calling Conventions

The calling conventions follow the ARM ABI (Application Binary Interface). The full description of the ABI is lengthy and complex, and can be found at:

http://infocenter.arm.com/help/topic/com.arm.doc.ihi0042d/IHI0042D_aapcs.pdf

However, the basics are quite simple:

Registers R0 through R3 are used to pass parameters to the function. Within a function, those registers can be used for any purpose and do not need to be preserved.

Registers R4 through R11 must be preserved by the called function. If you use them, you should push the values on the stack at the start of your function and pop them at the end.

Registers R12 through R15 have special purposes. R13 is the Stack Pointer (SP), R14 is the link register (LR) and R15 is the Program Counter. You must preserve the link register if you plan to call any functions, since it is used for storing your own function's return address.

The function value is returned in register R0.

For example, the following line:

```
GLCD DisplayString(0, 0, 1, "Hello, world!");
```

generates the following code:

```
ADR r3,{pc}+2
MOVS r2,#0x01
MOVS r1,#0x00
MOV r0,r1
BL.W GLCD_DisplayString
```

The BL instruction (Branch and Link) stores the return address in the link register (LR). This minimizes use of the stack and makes function calls less expensive.

The GLCD DisplayString() function starts off like this:

```
PUSH \{r4-r8, lr\}
```

and ends like this:

```
POP {r4-r8,pc}
```

In other words, on function entry, registers R4 through R8 are stored on the stack along with the return address in register LR. On function exit, the R4 through R8 registers are restored from the stack, and the return address is popped into the program counter (causing a return from the function).

You can embed assembly language functions in your C source code by using the __asm keyword, as follows:


```
__asm void my_add(int alpha, int beta)
{
    add r0,r1
    bx lr
}
```

Note that inline assembly is *not* supported, only embedded assembly as shown above.

4. Debugging and Simulation

The μ Vision IDE includes an integrated debugger which communicates with the MCB1700 using a Cortex Debug interface. The debugger can also be configured to use a built-in simulator, to allow you to develop and test your software even if you don't have physical access to the MCB1700 board.

The first step is to select either the hardware interface or the simulator. Right-click on your target in the Project window, select the "Options for target" item, and click on the Debug tab. This will display the following dialog:



The left-hand pane is for the simulator, and the right-hand pane is for the hardware interface. Click on "Use Simulator" in the left-hand pane to use the simulator settings, or click on the "Use" button in the right-hand pane and choose "ULINK Cortex Debugger" from the drop-down to use the hardware interface. You should probably choose "Run to main()", so you can skip stepping through the initialization sequence.

Most of the settings can be left unchanged, though you may want to check to make sure they're similar to the ones in the figure above. Click OK to close the dialog.

Assuming you've already built your program (and loaded it into flash, if you're running on the hardware instead of the simulator), you can begin your debugging session by clicking on the Debug button ().

At this point your windows will be reconfigured into debug mode. To return to build mode, just click the Debug button again.

Note that when you view your source code while in debug mode, the current location of the program counter is indicated with a yellow arrow. You can set or clear breakpoints in your code by clicking on them in the left-hand margins (in either your original C source code, or in the disassembly window). A red highlight in the margin indicates the breakpoint.

Take a moment to go through the icons in the Debug toolbar. Hover over each one to get a tooltip that describes what the button does as well as any keyboard shortcut it may have.

The buttons toward the left of the toolbar are used to reset the processor, run the application from the current location, stop the application, single-step the next instruction, single step but skip over subroutine calls, run until a return to the caller is executed, or run until the current line.

The remaining buttons are used to toggle the visibility of various debugging windows that let you examine and change registers, view and modify memory, watch particular variables, see the data sent to the serial ports, examine the symbol table, and perform many other functions.

A complete discussion of all the different windows is beyond the scope of this lab manual. However, there are a few that are particularly useful.

Disassembly and Call Stack Windows

This window shows you the actual assembly language produced for each line in your original C source code. As with the editor window, a yellow arrow indicates the current instruction and red highlights in the margin indicate breakpoints

The call stack window shows you a hierarchical tree of functions calls from the main() routine all the way down to whatever routine you're executing at the moment. You can click on any element in the call stack tree to see the values of each parameter that was passed to it.

Register Window

The register window not only displays the contents of all the ARM processor registers, it also allows you to modify their values. This can be very handy for debugging. Recall from the Coding section of this manual that parameters are passed to functions in the R0 through R3 registers, and the return address is in the Link Register (R14). The stack pointer is in R13 and the program counter is in R15.

You can also expand the PSR (Program Status Register) in order to examine and modify the individual bits.

Memory and Symbol Table Windows

The memory window lets you view any block of memory you like, and directly modify individual values. Right-clicking will bring up a context menu that will let you select what format to view the memory in (ASCII, float, double, signed and unsigned char, int, short or long in either hex or decimal). This window is most useful in conjunction with the symbol table window.

The symbol table window shows you the names of all your global symbols, including variables and functions, as well as the actual memory address of each. You can put in expressions to filter the list (\$ matches any character, # matches any digit, * matches zero or more characters). You can drag symbols into other windows (such as the memory window) to view them there.

Note that the memory window is not normally updated in realtime. You can enable periodic updating using the *View/Periodic Window Update* menu item.

Watch Window

The Watch window allows you to view a variable or a memory location updated in real-time while the program is running and to also modify this value without stopping the program.

Peripheral Device Windows

There are also windows for many of the peripheral devices. These do not have dedicated toolbar buttons, but are found in the menu bar under *Peripherals*. Among other things, you can examine the pin connect block, the nested vectored interrupt controller, the GPIO registers, timers, clocks, ADC and DAC converters and all the other capabilties of the LPC 1768 processor.

Note that the LCD display is not supported in the simulator.

Breakpoints Window

You can view all your breakpoints and modify their parameters by using ctrl-B or the *Debug/Breakpoints* menu item. This is a very powerful feature, which allows you to create a variety of conditional expressions for triggering a breakpoint. Most of these features are beyond the scope of this lab manual, but the breakpoints window itself has built-in help to explain its capabilities and how to use them.

Logic Analyzer

The debugger includes a logic analyzer that will allow you to study the relative timing of various signals and variable changes. It's activated using the button in the debugger. Note that you can only use the logic analyzer when you're running in the simulator, not on the board.

The logic analyzer is mostly self-explanatory. Use the Setup button to add channels. You can use symbolic names such as FIO1PIN3 to determine what registers or variables to watch, and you can specify a mask value (which is ANDed with the contents of the register or variable) and a right shift value (which is applied after the AND operation). You can view the result as a numeric value ("analog") or as a bit value. At any point you can stop the updating of the screen (and/or stop the simulation itself), and change the resolution to zoom in or out. You can also scroll forward and backward in time using the scrollbar below the logic analyzer window. There are also "prev" and "next" buttons to move quickly from one transition to another.

There are currently some issues with saving and loading the channel configurations, but channels can be set up very quickly and you typically won't need to watch more than two or possibly three at once.

While running in the simulator, you can toggle input pins by using the Peripherals/GPIO Fast Interface menu item, choosing the port, and toggling the pins in the last row of checkboxes.

5) Lab Assignment Descriptions

ECE 455 consists of four lab assignments. Here are the descriptions of the labs.

Assignment 1: Simple Timing

Objective: At the end of this lab, you will be familiar with two different approaches to measuring the passage of time. You will also have discovered the difficulties involved in getting precise timing without using hardware support.

Tasks:

- 1. Implement a function that delays for a given number of milliseconds, using a pair of nested for() loops. Note that there are several ways of calibrating this loop. Also note that you should disable interrupts at the start of the loop, and re-enable them at the end, in order to get more accurate timing.
- 2. Implement a clock that shows minutes and seconds on the screen, using your delay function. Let it run for 10 minutes, comparing the value to a stopwatch or wall clock and noting any discrepancies.
- 3. Implement the clock again, this time using a hardware timer instead of your delay function. Let it run for 10 minutes, and compare its accuracy to that of the version using the delay function. Note that there are several ways to implement this, some much more accurate than others.

Deliverables: Demonstrate your clock to one of the TAs. Submit a report giving the source code for your timing function (including the values you chose for the for() loops). Your report should compare the accuracy of the two approaches as well as the sources of any inaccuracy. You also need to submit your binaries for evaluation.

Assignment 2: Finite State Machines

Objective: At the end of this lab you will understand how to implement Finite State Machines for common tasks such as key debouncing, simple pattern detection and (optionally) temperature control.

Tasks:

- 1. Create a general-purpose framework for implementing FSMs.
- 2. Create a small application which accepts "dot-dash" input (similar to Morse code) on INTO and displays "dot" or "dash" on the LCD display.
 - a. When the pattern *dot-dash-dash-dot-dash-dot-dot* is recognized, the message "CORRECT" should be displayed on the LCD.
 - b. Incorrect patterns should be ignored. Any sequence of dots and dashes can precede a correct pattern.
 - c. Note that you must implement key debouncing to avoid false-positive "dots".
- 3. *(optional, for extra credit)* Use the same FSM framework to implement a thermostat-like temperature control that uses hysteresis.
 - a. the potentiometer should be used to set the "actual" temperature that would be measured by the thermostat
 - b. pushbuttons will be used to increase or decrease the setpoint
 - c. the screen should display the setpoint and the actual temperature
 - d. an LED should be illuminated while the "furnace" is in operation

Deliverables: Demonstrate to the TA that the correct pattern is recognized, even when preceded by an arbitrary series of dots and dashes. For the extra-credit portion, demonstrate that the setpoint can be set and that the furnace turns on and off at appropriate times when the potentiometer is used to set the "actual" temperature.

Assignment 3: Interrupt Shaping

Objective: By the end of this lab, you will be familiar with two techniques for avoiding interrupt overloads.

Tasks: Familiarize yourself with the issues identified in the following paper:

http://www.cs.utah.edu/~regehr/papers/lctes05/regehr-lctes05.pdf

Implement both of the software algorithms described in the paper.

Deliverables: Your submitted report should include source code. You also need to submit your binaries for evaluation.

Assignment 4: EDF Scheduler

Objective: Implement an EDF scheduler in FreeRTOS

Tasks:

- Install FreeRTOS on the Keil board
- Implement an EDF scheduler
- Create a demonstration that shows the EDF scheduler in operation

6) Closing Comments

This lab manual is a "living document". If you have any comments, particularly if you find there is information needed for your labs that is not covered here, please contact the author (Bernie Roehl, broehl@uwaterloo.ca).

The online version of this manual will be continually updated, and may change during the course of a term. You should check back occasionally in case there have been changes. The "last updated" date on the title page generally indicate when the most recent change was made.

Some of the illustrations and images used in this lab manual are provided by Keil. As required, here is their copyright notice:

KEIL, ARM, AND/OR THEIR RESPECTIVE SUPPLIERS MAKE NO REPRESENTATIONS ABOUT THE SUITABILITY OF THE INFORMATION CONTAINED IN THE DOCUMENTS AND RELATED GRAPHICS PUBLISHED ON THIS SERVER FOR ANY PURPOSE. ALL SUCH DOCUMENTS AND RELATED GRAPHICS ARE PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND. KEIL, ARM, AND/OR THEIR RESPECTIVE SUPPLIERS HEREBY DISCLAIM ALL WARRANTIES AND CONDITIONS WITH REGARD TO THIS INFORMATION, INCLUDING ALL IMPLIED WARRANTIES AND CONDITIONS OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE AND NON-INFRINGEMENT. IN NO EVENT SHALL KEIL, ARM, AND/OR THEIR RESPECTIVE SUPPLIERS BE LIABLE FOR ANY SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTUOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF INFORMATION AVAILABLE FROM THIS SERVER.

THE DOCUMENTS AND RELATED GRAPHICS PUBLISHED ON THIS SERVER COULD INCLUDE TECHNICAL INACCURACIES OR TYPOGRAPHICAL ERRORS. CHANGES ARE PERIODICALLY ADDED TO THE INFORMATION HEREIN. KEIL, ARM, AND/OR THEIR RESPECTIVE SUPPLIERS MAY MAKE IMPROVEMENTS AND/OR CHANGES IN THE PRODUCT(S) AND/OR THE PROGRAM(S) DESCRIBED HEREIN AT ANY TIME.

Notices Regarding Software, Documents, And Services Available On This Website

IN NO EVENT SHALL KEIL, ARM, AND/OR THEIR RESPECTIVE SUPPLIERS BE LIABLE FOR ANY SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTUOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF SOFTWARE, DOCUMENTS, PROVISION OF OR FAILURE TO PROVIDE SERVICES, OR INFORMATION AVAILABLE FROM THIS SERVER.

Links To Third Party Sites

THE LINKS IN THIS AREA WILL LET YOU LEAVE THE KEIL WEB SITE. LINKED SITES ARE NOT UNDER THE CONTROL OF KEIL AND/OR ARM AND KEIL AND/OR ARM ARE NOT RESPONSIBLE FOR THE CONTENTS OF ANY LINKED SITE OR ANY LINK CONTAINED IN A LINKED SITE. THESE LINKS ARE PROVIDED TO YOU ONLY AS A CONVENIENCE, AND THE INCLUSION OF ANY LINK DOES NOT IMPLY ENDORSEMENT BY KEIL OR ARM. COPYRIGHT NOTICE. Copyright © 2011 Keil - An ARM Company or its suppliers, 4965 Preston Park Road, Suite 650, Plano, Texas, 75093 U.S.A. All rights reserved. TRADEMARKS. Keil products referenced herein are either trademarks or registered trademarks of Keil - An ARM Company. Other product and company names mentioned herein may be the trademarks of their respective owners.

The names of companies, products, people, characters and/or data mentioned herein are fictitious and are in no way intended to represent any real individual, company, product or

event, unless otherwise noted.
Any rights not expressly granted herein are reserved.
Contact Keil with questions or problems with this service.