■ NetApp

Minimum software requirements

FlexPod

NetApp August 27, 2021

This PDF was generated from https://docs.netapp.com/us-en/flexpod/fp-def/dc-tech-spec_minimum_software_requirements.html on October 13, 2021. Always check docs.netapp.com for the latest.

Table of Contents

Minimum	software	requirements	 	. 1											

Minimum software requirements

A FlexPod configuration has the following minimum software requirements:

- NetApp ONTAP:
 - ONTAP software version requires ONTAP 9.1 or later
- · Cisco UCS Manager releases:
 - Cisco UCS 6200 Series Fabric Interconnect—2.2(8a)
 - Cisco UCS 6300 Series Fabric Interconnect—3.1(1e)
 - Cisco UCS 6400 Series Fabric Interconnect—4.0(1)
- · Cisco Intersight Managed Mode:
 - Cisco UCS 6400 Series Fabric Interconnect 4.1(2)
- For Cisco Nexus 5000 Series Switches, Cisco NX-OS software release 5.0(3)N1(1c) or later, including NX-OS 5.1.x
- For Cisco Nexus 7000 Series Switches:
 - The 4-slot chassis requires Cisco NX-OS software release 6.1(2) or later
 - The 9-slot chassis requires Cisco NX-OS software release 5.2 or later
 - The 10-slot chassis requires Cisco NX-OS software release 4.0 or later
 - The 18-slot chassis requires Cisco NX-OS software release 4.1 or later
- For Cisco Nexus 9000 Series Switches, Cisco NX-OS software release 6.1(2) or later



The software that is used in a FlexPod configuration must be listed and supported in the NetApp IMT. Some features might require more recent releases of the software than the ones that are listed.

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.