# **Hierarchical FSM**

Lab 4, ESDM

# **Objective**

Using the Stateflow tool in Simulink to model to implement hierarchical models.

## Theoretical aspects

#### **Substates and superstates**

A FSM can have a multi-level hierarchy composed of substates and superstates.

Within the substates of a state, one of them must have a default transition to indicate which is the default substate, as in the following image<sup>1</sup>.




Figure 1: Hierarchical FSM

The check of transitions is done in **top-down order**:

1. First check all transitions of the super-state

If a transition is found valid, it is executed, and no further checks are done in the substate.

<sup>&</sup>lt;sup>1</sup>All images are from the Matlab documentation

2. Only if no super-state transition is valid, go down one level and check transitions leaving from substates.




Figure 2: What is the execution order here?

A detailed steb-by-step workflow for execution of a chart in Stateflow is provided in Matlab documentation:

Execution of a Stateflow chart

Workflow of evaluating transitions

### **History junctions**

For a normal super-state, every time execution enters the super-state, it goes to the **default substate**, marked with the default transition.

When a history junction sign is a present in a super-state, then when entering the state execution goes to the last active substate when it last exited the state.

• At first entry it goes to the default substate, since there is no last active substate.

### **Exercises**

- 1. Design a FSM in Stateflow to implement a Christmas Lights Control module, according to the following requirements:
  - 1. We design a control module for blinking Christmas Lights.
  - 2. The system has 5 leds. We control them by setting the 5 outputs OUT1, OUT2, OUT3, OUT4 OUT5 to a certain intensity:




Figure 3: States with history

- OUTx = number 0 to 100: set intensity of LED number x to specified number
- Examples:
  - OUTx = 0: turn OFF (intensity 0)
  - OUTx = 100: turn completely ON (max intensity)
  - OUTx = 50: dimmed LED to 50%

#### 3. There are 4 blinking patters:

- 1. **Mode 1: Flash**: All LEDs flashing ON OFF together, with a duration of 0.2 seconds ON and 0.2 seconds OFF
- 2. **Mode 2: Slow**: All LEDs intensity slowly increases from 0% to 100% for 3 seconds, then from 100% to 0% in 3 seconds, and so on
- 3. Mode 3: Train: Train of lights: only first LED is ON for 250ms, then only second LED is ON for 250ms, etc. Like the light is moving from one LED to the next. After the last LED, repeat from the first one.

#### 4. There is one input Command

- 1. Command = 0: Execute each mode for 10 seconds, then move to next one. Repeat forever.
- 2. Command = 1: Execute only Mode 1, keep forever.
- 3. Command = 2: Execute only Mode 2, keep forever.

- 4. Command = 3: Execute only Mode 3, keep forever.
- 5. There is one additional boolean input OVERHEATING. The input OVERHEATING = TRUE signals that the temperature is higher than a max threshold.
- 6. When OVERHEATING = TRUE, the system shall temporarily pause and turn OFF all the LEDs. The operation resumes when OVERHEATING becomes FALSE, but no sooner than 15 seconds (any pause must last at least 15 seconds). When the system resumes, it shall continue the animation from the same point.
- 2. Test your design: put appropriate inputs and observe the output signals.
- 3. Run the Model advisor tool (Analysis -> Model Advisor -> Model Advisor), select and run the "Modeling Standards for MAAB" checks. Observe the warnings/failures and fix some of them.
- 4. Generate C code from the model (Code -> C/C++ Code -> Build Model). Locate the code files, open them and identify the implementation of the state machine. How is it implemented (with which C instructions)?

## **General requirements**

• Model Settings: Set the Solver type to "Fixed-step", "discrete (no continuous states"), and fixed step size to 0.1 (see Fig.1)




Figure 4: Model Settings

- Use "Simulation Pacing" to have simulation time slightly faster than normal time (see Fig.2)
- Put all inputs and outputs into a Scope block, for visualization and analysis
- Attach a "Push Button" from the Dashboard group as the input button
- You can attach "Lamp" blocks from the Dashboard group to easily see the outputs




Figure 5: Simulation time