
DMA

What is DMA?

- Stands for Direct Memory Access.
- Hardware that is capable of high speed data transfers with minimal CPU intervention from:
 - Data memory to data memory
 - Data memory to peripheral
 - Peripheral to data memory
 - Peripheral to peripheral
- Can be triggered off numerous peripheral flags using the event system.
- Used to parallelize embedded code.

DMA Transactions

- DMA separates data into three types of transfers.
 - Burst
 - 1, 2, 4, or 8 byte long pieces of data that represent a single data element
 - This is an instantaneous transfer
 - Block
 - Group of data consisting of burst transfers. Adjustable from 1 byte to 64KB.
 - Transaction
 - Complete DMA transfer of n desired blocks



DMA Configuration

Table 5-4. Summary of triggers, transaction complete flag and channel disable according to DMA channel configuration.

REPEAT	SINGLE	REPCNT	Trigger	Flag set after	Channel disabled after
0	0	0	Block	1 block	1 block
0	0	1	Block	1 block	1 block
0	0	n > 1	Block	1 block	1 block
0	1	0	BURSTLEN	1 block	1 block
0	1	1	BURSTLEN	1 block	1 block
0	1	n > 1	BURSTLEN	1 block	1 block
1	0	0	Block	Each block	Each block
1	0	1	Transaction	1 block	1 block
1	0	n > 1	Transaction	n blocks	n blocks
1	1	0	BURSTLEN	Each block	Never
1	1	1	BURSTLEN	1 block	1 block
1	1	n > 1	BURSTLEN	n blocks	n blocks

DMA Trigger Sources

- DMA can be triggered from software (by default), peripheral, or the event system.
- Setting CTRLA's (5.14.1 AU Manual) TRFREQ bit trigger's a software request for a DMA transfer.
- TRIGSRC (5.14.4 AU Manual) is used to select the peripheral or event system trigger source.
 - A base offset is given in table 5-9 for the specific peripheral.
 - If there are different flags for a given peripheral, additional offsets are given in tables 5-10, 5-11, 5-12 and/or 5-13.

DMA Addressing

- Two important addresses:
 - Source: Where the data is coming from
 - Destination: Where the data is going to
- Address may be incremented, decremented, or remain static after each burst transfer.
- Original Source and Destination addresses are stored inside DMA controller, and may be restored after:
 - Each Burst transfer
 - · Each Block transfer
 - Each Transaction
 - Or never

DMA Protection

- Integrity of the transfers are maintained by the DMA Controller.
- If the CHnBUSY flag (bit) in STATUS (5.13.3 AU Manual) is set, the following are locked for that channel:
 - DMA CTRL register
 - DMA INTFLAGS register
 - CHEN, CHRST, TRFREQ, and REPEAT in CHn CTRL register
 - CHn TRIGSRC register
- To access these registers, simply disable the DMA channel register

DMA Interrupts

- Two types of interrupts per channel
 - Error (CHnERRIF[3:0] (5.13.2 AU Manual)) if an error condition is detected on the channel.
 - Transaction finished (CHnTRNIF[3:0] (5.13.2 AU Manual)) that will be set at the end of a transaction.
 - In the even of DMA being in repeat mode, CHnTRNIF will be set after each Block transfer.

Double Buffering

- Allows for continuous transfer by interlinking two channels so the second takes over when the first is finished, and vise versa.
 - May be set up using channels 0 and 1 as the first pair, or 2 and 3 as the second.

Data is being read into this buffer

→ 488598932938200320

while data in this buffer is being processed.

7543994880000488048840MR88900032342

DMA Set-Up

- DMA Controller
 - CTRL (5.13.1 AU Manual)
 - Enable, buffer mode, priority
- DMA Channel
 - TRIGSRC (5.14.4 AU Manual)
 - Selecting trigger source (if any)
 - ADDRCTRL (5.14.3 AU Manual)
 - If/when to reload source/destination address
 - If to increment, decrement, or remain static after burst transfer
 - TRFCNT (5.14.5/6 AU Manual)
 - Number of byte transfers in a Block transfer
 - REPCNT (5.14.7 AU Manual)
 - How many times to repeat Block transfer (or how many blocks per transaction).
 - For unlimited repeats, set to 0.

DMA Set-Up

- DMA Channel
 - SRCADDRE[2:0] (5.14.8/9/10 AU Manual)
 - Where to start reading data from
 - DESTADDR[2:0] (5.14.11/12/13 AU Manual)
 - Where to start writing data to
- DMA Channel Interrupts
 - CTRLB (5.14.2 AU Manual)
 - Error Interrupt Level/Transaction Interrupt Level