# **Theory of Operation**

## NMRA Conformance Test DCC Signal Generator

## Ken West

## 1. Introduction

The NMRA conformance test DCC signal generator provides the necessary low level DCC signal to drive the conformance testing booster. The resulting signal is then used to test a DCC receiver. The sender board has the following major features:

- 1. The board produces an RS-422 compliant balanced DCC signal output. The DCC signal output is suitable for driving the booster.
- 2. The board can generate DCC 1 and 0 signals with a resolution of 1 microsecond. The low and high time of the 0 pulse can be set independently to allow for *stretched* 0 pulses. The 1 pulse is always sent with a 50% duty cycle. The basic clock generator is crystal controlled to provide a highly accurate DCC signal.
- 3. The board provides an RS-422 compliant scope trigger signal that is controlled by software and provides a hardware generated synchronization pulse at the beginning of a selected portion of the DCC signal. This scope trigger may be used to synchronize an oscilloscope with the DCC signal.
- 4. The board provides 4 RS-422 compliant balanced inputs which can be directly read by the software. These inputs can be used to send data on motor direction, lamp status, etc., to the board.
- 5. The board uses a standard IBM PC compliant 8 bit interface which supports either polled or interrupt driven operation. The data is transferred using I/O port IN and OUT instructions.
- 6. The board provides special self test logic to provide a software controlled clock and read back signals from several places along the signal path. This allows the software to conduct a thorough self test prior to operation. This additional hardware also helps isolate hardware problems.

## 2. Construction Notes

This version of the sender board is built on the PDS-601 Breadboard from JDR Microdevices, 2233 Samaritan Drive, San Jose, Ca., 95124. The board consists of dedicated PC bus decode and buffer logic and a section of breadboard. The board works well for prototyping but has caused some problems with intermittent connections. A much better solution would be to build a printed circuit board for this circuit. Lacking this, I plan to build a soldered version of the board using the JDR PR-2 board which consists of dedicated interface circuits and plated solder pads. This will hopefully cure the loose connection problem.

I don't have the equipment to lay out and fabricate boards. I hope someone does. As an incentive, these boards make an excellent software controllable DCC signal generator for IBM PC type computers. I can send interested people the circuit net list in most of the common layout formats.

The board is constructed using standard 74LS series parts. It would be possible to replace several of these parts with one or two programmable devices (PALs, etc.) to reduce the part count. This would require access to a PAL programmer.

## 3. Circuit Description

This section summarizes each of the major circuit blocks in the sender board. Please refer to page 1 of the schematic for a block diagram of the circuit.

#### 3.1 Bus Interface

Refer to page 2 of the schematic to see the bus interface portion of the circuit. This part of the circuit provides an 8 bit IBM PC style interface. The circuit itself is part of the dedicated portion of the PDS-601 prototype board. The signals come onto the board through edge card connector J201. The address signals (BA0-BA19) are buffered by U201, U202, and U203. The 8 data bus signals (BD0-BD7) are buffered by U206. The miscellaneous control signals are buffered by U204 and U205.

**Note:** Many of the signals provided by the PDS-601 card are not used by the DCC sender circuit. For example, none of the signals on U205 are used. A dedicated circuit board could eliminate a number of these buffers.

#### 3.2 Select & Parallel Port

Refer to page 3 of the schematic to see the select and parallel port portion of the circuit. U302 is part of the dedicated bus interface logic and is a PAL circuit that is programmed to provide chip selects and an overall board select. SW301 is used to select the IO port addresses for the sender board. The following addresses are supported:

Address	SW1	SW2	SW3	SW4	Default
240-257	Off	Off	On	Off	
260-277	Off	Off	On	On	
280-297	Off	On	Off	Off	
2A0-2B7	Off	On	Off	On	
2C0-2D7	Off	On	On	Off	
2E0-2F7	Off	On	On	On	
300-317	On	Off	Off	Off	
320-337	On	Off	Off	On	
340-357	On	Off	On	Off	X
360-377	On	Off	On	On	
380-397	On	On	Off	Off	
3A0-3B7	On	On	Off	On	
3C0-3D7	On	On	On	Off	
3E0-3F7	On	On	On	On	

U301 is an 8255 parallel port which is used to provide an 8 bit data port as well as miscellaneous input and output bits. This part is in the dedicated section of the board.

Port A of the 8255 is configured as a strobed output data port and holds the DCC output data. The control signals for port A are provided by port C described below.

Port B is configured as an 8 bit input port and provides the following input signals:

Bit	Name	Direction	Description
PB0	UNDERFLOW	INPUT	Set to 1 if the board underflows.
PB1	-CLK1	INPUT	Readback of -CLK1 signal.
PB2	DCC0	INPUT	Readback of DCC0 signal.
PB3	DCCQH	INPUT	Readback of DCCQH signal.
PB4	82G0H	INPUT	Readback of 82G0H signal.
PB5	-SHOLD	INPUT	Readback of -SHOLD signal.
PB6	SCOPE	INPUT	Readback of SCOPE signal.
PB7	DCCOUTD	INPUT	Readback of DCCOUTD signal.

Port C is configured to provide the control signals for port A which is used as a strobed output port. The remaining signals are configured as outputs and support miscellaneous control functions. Pins PC0 (PCRST), PC1 (CPUEN), and PC4 (-UNDERCLR) are pulled up to make sure the board assumes a known state when it is reset.

Bit	Name	Direction	Description	
PC0	PCRST	OUTPUT	Setting to 1 will reset the board.	
PC1	CPUEN	OUTPUT	Setting to 1 activates software clock.	
PC2	-CPUCLK	OUTPUT	Software -CLK1. A 1 to 0 transition will clock the board.	
PC3	INTRA	OUTPUT	A 1 indicates port A needs a data byte.	
PC4	-UNDERCLR	OUTPUT	Setting to 0 clears the UNDERFLOW bit	
PC5	SCOPE	OUTPUT	Setting to 1 activates scope signal on the next DCC byte.	
PC6	-ACKA	INPUT	A 0 indicates port A data byte is being loaded.	
PC7	-OBFA	OUTPUT	A 0 indicates the port A data is available.	

#### 3.3 Clock Generators

Refer to page 4 of the schematic to see the clock generator portion of the circuit. The primary clock source for the board is **CLK1** and its inverse **-CLK1**. These signals are normally generated by 1 MHz. crystal oscillator U402. It is also possible for the master clock to be generated under software control by toggling **PC2** (**-CPUCLK**). The clock is generated by software if **PC1** (**CPUEN**) is set to 1. Flip flop U403A and multiplex circuit U404A and U404B is used to switch between software and hardware clocks without a glitch. No glitch will occur as long as **-CPUCLK** is set to 0 prior to switching the state of **CPUEN**.

The heart of the clock generator circuit is the U401 82C54 programmable counter. Its **CLK0** output is used to generate a square wave signal on **82OUT0T** whenever the **DCCQH** data is 0. The duration of this signal is set to the duration of a DCC 0 pulse. The clock input to the counter is gated by U406A.

**CLK1** is used to generate the high portion of a DCC 0 pulse. It begins counting at the same time **82OUT0T** begins a cycle and is programmed to produce a single pulse on **82OUT0H** at the point the **DCC0** signal should switch from 1 to 0. As such, **CLK0** sets the total duration of a DCC 0 pulse and **CLK1** sets the pulse high time. This allows stretched zeros to be generated.

**82OUT0T** and **82OUT0H** are passed to flip flop U403B which generates the overall DCC 0 pulse signal **DCC0**.

**Note: DCC0** must be initialized to 0 as part of the board initialization for proper operation. This is accomplished by forcing **82OUT0H** low temporarily which forces **DCC0** low.

**CLK2** generates the DCC 1 signal **DCC1** in a manner similar to the way **CLK0** generates **82OUT0T**. It's clock is gated by U406B so that it only counts when DCC data signal **DCCQH** is 1. It always has a 50% duty cycle since pulse stretching is not needed for DCC 1 pulses.

AND gate U405B combines DCC0 and DCC1 to produce the complete DCC signal DCCOUT.

### 3.4 DCC Signal Generator

Refer to page 5 of the schematic to see the DCC signal generator portion of the circuit. U503A, U405C, and U406C are used to generate the **82G0H** signal used to synchronize the **82C54 CLK1** signal which generates **82OUT0H**. **82G0H** will go low for one clock cycle at the beginning of a DCC 0 pulse and resets CLK1. It remains high during all other times.

DCC data is shifted out using shift register U501. U501 generates **DCCQH** which will be set to 0 to send a DCC 0 pulse, and 1 to send a DCC 1 pulse. It is shifted on each 0 to 1 transition of **DCCQUT** in order to make the next DCC data bit available on **DCCQH**. If no data is loaded into the shift register, it will eventually underflow and begin sending DCC 0 pulses. This is true because in serial input (SER) line of the shift register is tied to 0.

A new data BYTE is loaded into U501 under control of the state machine made up of U503B, U502, etc. In operation, a new data BYTE is sent to port A of the 8255. This causes PC7 (**-OBFA**) to go to 0 when the new data is present on the output port. **-OBFA** is synchronized to **-CLK1** by flip flop U503B. To prevent an underflow, data must be written to port A at least one half clock cycle (500 nsec.) plus setup time prior to the completion of the present BYTE.

Counter U502 together with gates U404C and U404D is used to load new data BYTES into the U501 shift register or signal an underflow at appropriate times. In normal operation, loading a new BYTE causes U502 to be set to an initial count of 8. It is incremented each time the **DCCOUT** signal goes from 0 to 1. As such, it maintains a count of each bit sent.

The main action occurs when 8 bits have been sent. At this point, U502 will be at count 15 and the carry out signal (RCO) will go to 1 when DCCOUT goes from 1 to 0 half way through the sending of the last bit. If a new data BYTE is available, DATARDY will be high at this time, causing the U404D output signal - DATALD to go to 0. Setting -DATALD to 0 causes a new data BYTE to be loaded into shift register U501 on the 0 to 1 transition of DCCOUT. It also resets counter U502 to count 8 and resets the -OBFA high via PC6 (-ACKA).

**Note: -DATALD** is also connected to the clear lead of U503B. This is done to prevent **DATARDY** from going inactive prematurely.

If a new data BYTE is not ready when it is needed, the U404C output signal **-SHOLD** will go low. This signal causes the U502 counter to remain at count 15. Also, U501 will shift a 0 out on **DCCQH**, causing a DCC 0 pulse to be sent. Flip flop U504A produces the latched **PB0** (**UNDERFLOW**) signal. Once activated, the **UNDERFLOW** signal remains at 1 until it is reset from software using the **PC4** (**-UNDERCLR**) signal. Software should test the **UNDERFLOW** signal periodically to make sure no data BYTES were missed.

The **SCOPE** signal is generated by U406D. The SCOPE output will follow the state of **-DATALD** whenever software sets PC5 (**-SCOPE**) low prior to sending a BYTE of data. This causes a single 1 pulse to occur on the **SCOPE** line with a duration equal to one half the pulse width of the last DCC pulse sent. This pulse will occur just prior to the beginning of a new BYTE of DCC data pulses.

**Note:** The external DCC signal is actually **DCCOUTD** which is delayed one **CLK1** time (1 microsecond) from **DCCOUT**. This gives enough time for a scope to trigger from **SCOPE** and still show a view of the first 0 to 1 transition of the selected DCC output BYTE.

#### 3.5 External Interface

Refer to page 6 of the schematic to see the external interface portion of the circuit. The two external output signals **DCCOUTD** and **SCOPE** are buffered by RS-422 driver U601. These balanced signals will drive most types of boosters or scopes and provide excellent noise immunity.

U602 is an RS-422 balanced receiver which provides 4 balanced inputs. These input bits can be read by the software by issuing an IN command. Each complementary input lead is pulled down by a 10K resistor to make sure that unused leads remain at 1.

**Note:** It is assumed that the balanced inputs to the sender board will be used, possibly with some external hardware, to convey motor direction and lamp status to the sender board. The software will use this data as part of the receiver testing process.

All external signals as well as a number of power and ground signals appear on DB-37S connector J601 which is on the back panel of the sender board.