# EasyMx PRO v7 for STM32 ARM

Prepared by: Omar Samir


#### Introduction

- ARM® Cortex™-M3 and Cortex™-M4 are increasingly popular microcontrollers
- A development board with as many peripherals on the board as possible
- Covers many internal modules
- On-board programmer and debugger




## **Power Supply**

Creates VCC 3.3 power supply



#### **MCU Card**

- STM32F407VGT6
- 16 MHz default CPU clock
- 5 PORTS (A, B, C, D, E)



#### **MikroProg**

- Fast programmer and debugger
- Enabled by placing the jumpers on the left side
- Takes the following pins for programming
  - o PA13
  - o PA14
  - o PA15
  - PB3
  - PB4







#### MikroC pro for ARM

- A compiler for ARM
- Produces hex file to be programmed on MCU
- Can be used for debugging
- Download:
  - https://download.mikroe.com/setups/compilers/mikroc/arm/mikroc-arm-setup-v620.zip

#### Program our board

To program our board you need to do the following:


- Download and install mikroProg for STM32 drivers.
  - https://download.mikroe.com/setups/drivers/mikroprog/arm/st-link-usb-drivers.rar
- Download and install MikroC pro for ARM
  - While installing it will ask you to install MikroProg accept and install it as it is mandatory for programming
- Connect the board to your computer with the USB cable
- Power on the board

Having done these steps, your board is ready to be programmed!


- 1. Open MikroC pro for ARM
- 2. Select File -> new -> new project




3. Choose standard project then click next




- 4. Type your project name in (Project Name)
- 5. Choose the location of the project in (Project folder)
- 6. Choose STM32F407VG in (Device Name)
- 7. Choose 16 MHz as our device clock frequency
- 8. Click Next




9. Click Finish



You are ready to code



#### **Build your Project**



#### **Build and Program**

You need to be connected to the board and to power it on



