Module Interface Specification for SynthEddy

Phil Du (Software) Nikita Holyev (Theory)

March 21, 2024

1 Revision History

Date	Version	Notes
2024-03-18	1.0	Initial MIS

2 Symbols, Abbreviations and Acronyms

See SRS Documentation at GitHub repo

Contents

1	Rev	vision 1	History					
2	Syn	abols,	Abbreviations and Acronyms					
3								
4								
5	Mo	dule D	Decomposition					
6	MIS	S of Q	uery Interface					
	6.1		ile					
	6.2	Uses						
	6.3	Syntax	NX					
		6.3.1	Exported Constants					
		6.3.2	Exported Access Programs					
	6.4	Semar	ntics					
		6.4.1	State Variables					
		6.4.2	Environment Variables					
		6.4.3	Assumptions					
		6.4.4	Access Routine Semantics					
		6.4.5	Local Functions					
7	MIS	S of Ed	ddy Profile Module					
	7.1	Modu	ıle					
	7.2	Uses						
	7.3	Syntax	ux					
		7.3.1	Exported Constants					
		7.3.2	Exported Access Programs					
	7.4	Semar	ntics					
		7.4.1	State Variables					
		7.4.2	Environment Variables					
		7.4.3	Assumptions					
		7.4.4	Access Routine Semantics					
		7.4.5	Local Functions			•		
8	MIS	s of Fl	low Field Module					
	8.1	Modu	ıle					
	8.2	Uses						
	8.3	Syntax	ux					
		8.3.1	Exported Constants					
		8.3.2	Exported Access Programs			_		

	8.4	Seman	tics										7
		8.4.1	State Variables										7
		8.4.2	Environment Variables										8
		8.4.3	Assumptions										8
		8.4.4	Access Routine Semantics .										8
		8.4.5	Local Functions									•	9
9	MIS	of Ed	ldy Module										10
	9.1	Modul	e										10
	9.2												10
	9.3	Syntax	ζ										10
		9.3.1	Exported Constants										10
		9.3.2	Exported Access Programs.										10
	9.4	Seman	itics										10
		9.4.1	State Variables										10
		9.4.2	Environment Variables										11
		9.4.3	Assumptions										11
		9.4.4	Access Routine Semantics .										11
		9.4.5	Local Functions									•	11
10	MIS	of Sh	ape Function Module										12
			e										12
													12
			ζ										12
		•	Exported Constants										12
			Exported Access Programs .										12
	10.4		itics										12
			State Variables										12
			Environment Variables										12
			Assumptions										12
			Access Routine Semantics .										13
			Local Functions										13
11	MIS	of Ma	ain Control Module										14
			e										14
													14
			ζ										14
			Exported Constants										14
			Exported Access Programs .										14
	11.4		tics										14
			State Variables										14
			Environment Variables										14
			Assumptions										14

	11.4.4	4 Access Routine Semantics		 	14
	11.4.	5 Local Functions		 	15
12	MIS of F	ile I/O Module			16
	12.1 Mod	ıle		 	16
	12.2 Uses			 	16
	12.3 Synta	ux		 	16
	12.3.	Exported Constants		 	16
	12.3.	2 Exported Access Programs		 	16
		ntics			16
	12.4.	State Variables		 	16
	12.4.	2 Environment Variables		 	16
	12.4.	3 Assumptions		 	16
	12.4.	4 Access Routine Semantics		 	16
	12.4.	5 Local Functions	• •	 	17
13	MIS of V	isualization Module			18
13		$egin{aligned} ext{isualization Module} \ ext{ile} & \dots & \dots & \dots & \dots \end{aligned}$		 	18 18
13					_
13	13.1 Modu 13.2 Uses	ıle		 	18
13	13.1 Modu 13.2 Uses 13.3 Synta	ile	• •	 	18 18
13	13.1 Modu 13.2 Uses 13.3 Synta 13.3.	ıle	• • •	 	 18 18 18
13	13.1 Modu 13.2 Uses 13.3 Synta 13.3.1 13.3.2	ale		 	 18 18 18 18
13	13.1 Modu 13.2 Uses 13.3 Synta 13.3.1 13.3.2	ax	• • •	 	 18 18 18 18 18
13	13.1 Modu 13.2 Uses 13.3 Synta 13.3.1 13.4 Sema 13.4.2	ax		 	 18 18 18 18 18
13	13.1 Modu 13.2 Uses 13.3 Synta 13.3. 13.4 Sema 13.4. 13.4.	ax		 	 18 18 18 18 18 18
13	13.1 Modu 13.2 Uses 13.3 Synta 13.3. 13.4 Sema 13.4. 13.4. 13.4.	ax	• • • · · · · · · · · · · · · · · · · ·	 	 18 18 18 18 18 18 18
13	13.1 Modu 13.2 Uses 13.3 Synta 13.3.1 13.4 Sema 13.4.1 13.4.2 13.4.3 13.4.4	ax		 	 18 18 18 18 18 18 18 18
	13.1 Modu 13.2 Uses 13.3 Synta 13.3.1 13.4 Sema 13.4.1 13.4.2 13.4.3 13.4.4	ax		 	 18 18 18 18 18 18 18 18 18

3 Introduction

The following document details the Module Interface Specifications for SynthEddy, a software to artificially generate flow field that mimics turbulent flow, which can be use as starting point for CFD simulation.

Complementary documents include the System Requirement Specifications and Module Guide. The full documentation and implementation can be found at SRS, MG.

4 Notation

The structure of the MIS for modules comes from Hoffman and Strooper (1995), with the addition that template modules have been adapted from Ghezzi et al. (2003). The mathematical notation comes from Chapter 3 of Hoffman and Strooper (1995). For instance, the symbol := is used for a multiple assignment statement and conditional rules follow the form $(c_1 \Rightarrow r_1|c_2 \Rightarrow r_2|...|c_n \Rightarrow r_n)$.

The following table summarizes the primitive data types used by SynthEddy.

Data Type	Notation	Description
character	char	a single symbol or digit
integer	\mathbb{Z}	a number without a fractional component in $(-\infty, \infty)$
natural number	N	a number without a fractional component in $[1, \infty)$
real	\mathbb{R}	any number in $(-\infty, \infty)$
string	str	an array of char

The specification of SynthEddy uses some derived data types: sequences, strings, and tuples. Sequences are lists filled with elements of the same data type. Strings are sequences of characters. Tuples contain a list of values, potentially of different types. In addition, SynthEddy uses functions, which are defined by the data types of their inputs and outputs. Local functions are described by giving their type signature followed by their specification.

5 Module Decomposition

The following table is taken directly from the Module Guide document for this project.

Level 1	Level 2
Hardware-Hiding Module	
Behaviour-Hiding Module	Query Interface Eddy Profile Module Flow Field Module Eddy Module Shape Function Module Vector Module
Software Decision Module	Main Control Module File I/O Module Visualization Module

Table 1: Module Hierarchy

6 MIS of Query Interface

6.1 Module

query

6.2 Uses

• Flow Field Module [MIS8]

6.3 Syntax

6.3.1 Exported Constants

None.

6.3.2 Exported Access Programs

Name	In	Out	Exceptions
handle_request	request str	${ t response } { m str}$	InvalidRequestFormat

6.4 Semantics

6.4.1 State Variables

None.

6.4.2 Environment Variables

None.

6.4.3 Assumptions

None.

6.4.4 Access Routine Semantics

handle_request(request):

- output: out := encode({VectorT}), velocity vectors at all the queried points in one JSON string.
- exception: exc := (decode(request) is not {VectorT} ⇒ InvalidRequestFormat), the request should be a JSON string of positions vectors to query get the velocity vectors.

More request methods to be implemented in the future.

6.4.5 Local Functions

decode(request):

 \bullet output: out := {VectorT}, an array of position vectors.

7 MIS of Eddy Profile Module

7.1 Module

eddy_profile

7.2 Uses

• File I/O Module [MIS12]

7.3 Syntax

7.3.1 Exported Constants

None.

7.3.2 Exported Access Programs

Name	In	Out	Exceptions
load	${ t profile_name} \ { m str}$	-	InvalidProfile
$\mathtt{get_params}$	-	$\texttt{params}\ \{\{\mathbb{R}+,\mathbb{R}+\}\}$	-
get_weights	-	weights $\{\mathbb{R}+\}$	-

7.4 Semantics

7.4.1 State Variables

- name: str, name of the eddy profile (is also filename).
- params: $\{\{\mathbb{R}+, \mathbb{R}+\}\}\$, array of strength and radius sets for each type of eddy.
- weights: $\{\mathbb{R}+\}$, corresponding array of weights for each type of eddy.

7.4.2 Environment Variables

None.

7.4.3 Assumptions

7.4.4 Access Routine Semantics

load(profile_name):

- transition: params, weights := fileIO.read('profile', profile_name)
- exception: exc := (params is not $\{\{\mathbb{R}+, \mathbb{R}+\}\}\$ or weights is not type $\{\mathbb{R}+\} \Rightarrow$ InvalidProfile)

get_params():

• output: out := params

get_weights():

• output: out := weights

7.4.5 Local Functions

Some functions to compute the eddy profile based on user provided parameters, to be implemented in the future.

8 MIS of Flow Field Module

8.1 Module

flow_field

8.2 Uses

- Eddy Module [MIS9]
- Vector Module [NumPy]
- File I/O Module [MIS12]
- Visualization Module [MIS13] (PLACEHOLDER)

8.3 Syntax

8.3.1 Exported Constants

None.

8.3.2 Exported Access Programs

Name	In	Out	Exceptions
init	profile EddyProfileT,	-	InvalidDimensions
	$\mathtt{field_name}\ \mathrm{str},$		${ t InvalidAvgVelocity}$
	dimensions VectorT,		EddyScaleTooLarge
	$\texttt{avg_vel} \ \mathbb{R},$		
	$\mathtt{eddy_count}\ \mathbb{Z}$		
load	${\tt field_name} \; {\rm str}$	-	-
save	-	field Record	-
$\mathtt{get}_\mathtt{vel}$	position VectorT,	${\tt velocity}\ { m Vector}{ m T}$	OutOfBoundary
	time $\mathbb R$	•	NegativeTime

8.4 Semantics

8.4.1 State Variables

- profile: eddy_profileT, eddy profile to be used to generate the flow field.
- name: str, name of the flow field (is also filename).
- dimensions: Vector T of $\{L_x, L_y, L_z\}$, size of the flow field, with x being the axial direction, y vertical and z horizontal.
- avg_vel: \mathbb{R} , average flow velocity along x-axis.

• eddies: {EddyT}, array of eddies in the flow field.

8.4.2 Environment Variables

None.

8.4.3 Assumptions

• External flow [SRS: A4, MG: AC2]

8.4.4 Access Routine Semantics

init(profile, field_name, dimensions, avg_vel, eddy_count):

- transition:
 - profile, name, length_x, length_y, length_z, avg_vel := as inputted
 - eddies := {eddy_count number of EddyT randomly generated with profile}
- exception:
 - exc := (any of d in dimensions $\leq 0 \Rightarrow$ InvalidDimensions)
 - $-\exp := (avg_vel < 0 \Rightarrow InvalidAvgVelocity)$
 - exc := (any of 2*{radius in profile} \geq any of d in dimensions \Rightarrow EddyScaleTooLarge)

load(field_name):

• transition: all state variables reconstructed from fileIO.read('field', field_name).

save(new_name?):

- transition: name := new_name if provided, otherwise name remains the same.
- output: out := Record (dict) with all current state variables. Each EddyT in eddies is also converted to a Record. So that fileIO.write('field', Record) can be called to serialized the current state of the flow field into a JSON string for saving.

get_vel(position, time):

• output: out := \sum {eddy.get_vel(position - eddy_pos(eddy, time)) for each eddy in eddies}, with wrap-around applied for eddies near the boundary.

8.4.5 Local Functions

eddy_pos(eddy, time):

```
• output: out := VectorT: {
  get_offset(time) + eddy.get_init_x(),
  eddy.get_y(get_iter(time), dimensions[1]),
  eddy.get_z(get_iter(time), dimensions[2])
}the center position of the eddy at a given time (moving due to flow).
```

get_iter(time):

• output: out := round($\frac{avg_vel*time}{dimensions[0]}$), the number of iterations of the flow field at a given time (how many x-lengths have passed due to average flow velocity).

get_offset(time):

• output: out := avg_vel * time%dimensions[0], the x-offset of the flow field at given time in current iteration.

9 MIS of Eddy Module

9.1 Module

eddy

9.2 Uses

• Shape FUnction Module [MIS10]

9.3 Syntax

9.3.1 Exported Constants

None.

9.3.2 Exported Access Programs

Name	In	Out	Exceptions
init	field_dimensions VectorT,	-	-
	$\texttt{strength} \mathbb{R}+,$		
	radius $\mathbb{R}+,$		
	orient VectorT		
$\mathtt{get_init_x}$	-	$\mathtt{init}_\mathtt{x} \ \mathbb{R}$	-
$\mathtt{get}_{\mathtt{-}}\mathtt{y}$	iter $\mathbb{Z},$	уR	-
	$\texttt{length}_{-} \texttt{y} \mathbb{R} +$		
get_z	iter $\mathbb{Z},$	${\tt z}\;\mathbb{R}$	-
	$\texttt{length}_{\texttt{z}} \; \mathbb{R} +$		
${ t get_vel}$	${\tt rel_position}\ { m Vector}{ m T}$	velocity Vec	C
		torT	

9.4 Semantics

9.4.1 State Variables

- init_x: \mathbb{R} , the initial offset from zero x-position.
- strength: $\mathbb{R}+$, intensity of the eddy.
- radius: \mathbb{R} + for length scale. Velocity outside of radius is always zero.
- orient: VectorT, unit vector describing the orientation of the eddy spin axis.
- y_{arr} : { \mathbb{R} }, array of y-positions at each flow iteration.
- z_{arr} : { \mathbb{R} }, array of z-positions at each flow iteration.

9.4.2 Environment Variables

None.

9.4.3 Assumptions

• EddyT objects are not created manually, but generated by calls from flow_field. Thus, the caller has ensured the validity of all parameters.

9.4.4 Access Routine Semantics

```
init(init_x, strength, radius, orient):
```

- transition:
 - strength, radius, orient := as inputted
 - init_x := rand(0, field_dimensions[0])
 - $-y[0], y[1], y[2] := \{rand(0, field_dimensions[1])\}$
 - -z[0], z[1], $z[2] := \{rand(0, field_dimensions[2])\}$

get_init_x():

• output: out := init_x

get_y(iter, length_y):

- transition: y[iter] := rand(0, length_y) if y[iter] does not exist.
- output: out :=y[iter]

get_z(iter, length_z):

- transition: z[iter] := rand(0, length_z) if z[iter] does not exist.
- output : out :=z[iter]

get_vel(rel_position):

• output: out := computed from rel_position with strength, radius, orient and ShapeFunction.active(rel_position, radius), see [SRS: TM1, TM2]

dump():

• output: out := Record of all current state variables. Used by flow_field.save() to serialize the eddy object.

9.4.5 Local Functions

10 MIS of Shape Function Module

10.1 Module

 ${\tt shape_function}$

10.2 Uses

• Vector Module [NumPy]

10.3 Syntax

10.3.1 Exported Constants

None.

10.3.2 Exported Access Programs

Name	In	Out	Exceptions
set_active	active_func Function	-	_
active	${\tt rel_position\ Vector T},$	$\mathtt{shape_val} \mathbb{R}$	-
	radius $\mathbb R$		
squared	${\tt rel_position\ VectorT},$	$\mathtt{shape_val} \mathbb{R}$	-
	radius $\mathbb R$		
gaussian	${\tt rel_position\ VectorT},$	$\mathtt{shape_val} \mathbb{R}$	-
	radius $\mathbb R$		
	${\tt rel_position}\ { m Vector}{ m T},$	${\tt shape_val} \mathbb{R}$	-
	radius $\mathbb R$		

User can modify this module to add more shape functions.

10.4 Semantics

10.4.1 State Variables

• active: The function that is currently designated as the active shape function.

10.4.2 Environment Variables

None.

10.4.3 Assumptions

10.4.4 Access Routine Semantics

set_active(active_func):

• transition: active := active_func, so that other modules can always call shape_function.active() to use the designated function. This should be set in main when the program starts.

active():

• output: out := init_x

active(rel_position, radius):

• output: out := shape function value, depending on the active shape function.

squared(rel_position, radius):

• output: out := shape function value computed by taking the distance from the rel_position to the center mag(rel_position), and radius (or length sclae) of the eddy. See [SRS: TM1].

gaussian(rel_position, radius):

• output: out := Use a different (gaussian) equation to get the above value, as may be preferred by some researchers.

10.4.5 Local Functions

11 MIS of Main Control Module

11.1 Module

main

11.2 Uses

- Query Interface [MIS6]
- Flow Field Module [MIS8]
- Eddy Profile Module [MIS9]

11.3 Syntax

11.3.1 Exported Constants

None.

11.3.2 Exported Access Programs

Name	In	Out	Exceptions
main	${\tt command_args} \ {\rm str},$	-	-

11.4 Semantics

11.4.1 State Variables

None.

11.4.2 Environment Variables

• Command line console.

11.4.3 Assumptions

None.

11.4.4 Access Routine Semantics

main(command_args):

- --new_field --name <field_name> --dim <Lx>,<Ly>,<Lz>, --vel <avg_vel> --count <eddy_count> --profile <profile_name>
 - call eddy_profile.load(profile_name) to read the eddy profile file.

- call flow_field.init(profile, field_name, dimensions, avg_vel, eddy_count) to create a new flow field.
- --field <field_name> --query <request>
 - call flow_field.load(field_name) to load the flow field.
 - call query.handle_request(request) to get the velocity vectors at the queried points.

11.4.5 Local Functions

12 MIS of File I/O Module

12.1 Module

fileI0

12.2 Uses

• Hardware Hiding Module [OS]

12.3 Syntax

12.3.1 Exported Constants

None.

12.3.2 Exported Access Programs

Name	In	Out	Exceptions
read	type str, name str	Record or Array	FileNotExist
write	type str, content Record or Array	-	FailToWrite

12.4 Semantics

12.4.1 State Variables

None.

12.4.2 Environment Variables

• Files on disk.

12.4.3 Assumptions

- The field name or profile name is the same as the filename.
- \bullet Saved fields are in ./fields/ and saved profiles are in ./profiles/ directories

12.4.4 Access Routine Semantics

read(type, name):

- output: out := Record or Array, the parsed content of the file.
- exception: $exc := (file cannot be found at ./<type>./son <math>\Rightarrow FileNotExist)$

write(type, content):

- transition: write the serialized JSON string to the file on disk.
- exception: exc := (file cannot be written to disk \Rightarrow FailToWrite)

12.4.5 Local Functions

13 MIS of Visualization Module

THIS IS A PLACEHOLDER [MG: AC5]

13.1 Module

visualize

13.2 Uses

• None

13.3 Syntax

13.3.1 Exported Constants

None.

13.3.2 Exported Access Programs

Name	In	Out	Exceptions

13.4 Semantics

13.4.1 State Variables

?

13.4.2 Environment Variables

?

13.4.3 Assumptions

'?

13.4.4 Access Routine Semantics

?

13.4.5 Local Functions

?

References

Carlo Ghezzi, Mehdi Jazayeri, and Dino Mandrioli. Fundamentals of Software Engineering. Prentice Hall, Upper Saddle River, NJ, USA, 2nd edition, 2003.

Daniel M. Hoffman and Paul A. Strooper. Software Design, Automated Testing, and Maintenance: A Practical Approach. International Thomson Computer Press, New York, NY, USA, 1995. URL http://citeseer.ist.psu.edu/428727.html.

14 Appendix

[Extra information if required —SS]

15 Reflection

The information in this section will be used to evaluate the team members on the graduate attribute of Problem Analysis and Design. Please answer the following questions:

- 1. What are the limitations of your solution? Put another way, given unlimited resources, what could you do to make the project better? (LO_ProbSolutions)
- 2. Give a brief overview of other design solutions you considered. What are the benefits and tradeoffs of those other designs compared with the chosen design? From all the potential options, why did you select the documented design? (LO_Explores)