## Robotics Assignment #02

## Paul Bienkowski, Konstantin Kobs

May 4, 2015

## **Task 2.1.** 1) The manipulator transformation is a series of multiple rotational $Rot_z(\theta_i)$ and translational $Trans_{x_i}(a_i)$ transformations. That means, ${}^0T_3 = {}^0A_1{}^1A_2{}^2A_3$ is given by

$${}^{0}A_{1} = Rot_{z}(\theta_{1}) \cdot Trans_{x_{1}}(a_{1})$$

$${}^{1}A_{2} = Rot_{z}(\theta_{2}) \cdot Trans_{x_{2}}(a_{2})$$

$${}^{2}A_{3} = Rot_{z}(\theta_{3}) \cdot Trans_{x_{3}}(a_{3})$$

where 
$$Rot_z(\theta_i) = \begin{bmatrix} C_i & -S_i & 0 & 0 \\ S_i & C_i & 0 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$
 and  $Trans_{x_i}(a_i) = \begin{bmatrix} 1 & 0 & 0 & a_i \\ 0 & 1 & 0 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix}$ .

With this in mind, we can calculate the partial homogeneous transformations:

$${}^{0}A_{1} = \begin{bmatrix} C_{1} & -S_{1} & 0 & C_{1}a_{1} \\ S_{1} & C_{1} & 0 & S_{1}a_{1} \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix} \quad {}^{1}A_{2} = \begin{bmatrix} C_{2} & -S_{2} & 0 & C_{2}a_{2} \\ S_{2} & C_{2} & 0 & S_{2}a_{2} \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix} \quad {}^{2}A_{3} = \begin{bmatrix} C_{3} & -S_{3} & 0 & C_{3}a_{3} \\ S_{3} & C_{3} & 0 & S_{3}a_{3} \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

For intermediate results, we first calculate  ${}^{0}T_{2} = {}^{0}A_{1}{}^{1}A_{2}$  and then  ${}^{0}T_{3} = {}^{0}T_{2}{}^{2}A_{3}$ .

$${}^{0}T_{2} = \begin{bmatrix} C_{1} & -S_{1} & 0 & C_{1}a_{1} \\ S_{1} & C_{1} & 0 & S_{1}a_{1} \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix} \begin{bmatrix} C_{2} & -S_{2} & 0 & C_{2}a_{2} \\ S_{2} & C_{2} & 0 & S_{2}a_{2} \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

$$= \begin{bmatrix} C_{1}C_{2} - S_{1}S_{2} & -C_{1}S_{2} - S_{1}C_{2} & 0 & C_{1}C_{2}a_{2} - S_{1}S_{2}a_{2} + C_{1}a_{1} \\ S_{1}C_{2} + C_{1}S_{2} & -S_{1}S_{2} + C_{1}C_{2} & 0 & S_{1}C_{2}a_{2} + C_{1}S_{2}a_{2} + S_{1}a_{1} \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

$$= \begin{bmatrix} C_{1+2} & -S_{1+2} & 0 & C_{1+2}a_{2} + C_{1}a_{1} \\ S_{1+2} & C_{1+2} & 0 & S_{1+2}a_{2} + S_{1}a_{1} \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

$$= \begin{bmatrix} C_{1+2} & -S_{1+2} & 0 & C_{1+2}a_{2} + C_{1}a_{1} \\ S_{1+2} & C_{1+2} & 0 & S_{1+2}a_{2} + S_{1}a_{1} \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix} \begin{bmatrix} C_{3} & -S_{3} & 0 & C_{3}a_{3} \\ S_{3} & C_{3} & 0 & S_{3}a_{3} \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

$$= \begin{bmatrix} C_{1+2}C_{3} - S_{1+2}S_{3} & -C_{1+2}S_{3} - S_{1+2}C_{3} & 0 & C_{1+2}C_{3}a_{3} - S_{1+2}S_{3}a_{3} + C_{1+2}a_{2} + C_{1}a_{1} \\ 0 & 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 0 & 1 \end{bmatrix}$$

$$= \begin{bmatrix} C_{1+2+3} & -S_{1+2+3} & 0 & C_{1+2+3}a_3 + C_{1+2}a_2 + C_1a_1 \\ S_{1+2+3} & C_{1+2+3} & 0 & S_{1+2+3}a_3 + S_{1+2}a_2 + S_1a_1 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

Because the relation  $\theta_1 + \theta_2 + \theta_3 = 180^{\circ}$  is given, we can simplify the results. For  $\cos(180^{\circ}) = -1$  and  $\sin(180^{\circ}) = 0$ :

$${}^{0}T_{3} = \begin{bmatrix} -1 & 0 & 0 & -a_{3} + C_{1+2}a_{2} + C_{1}a_{1} \\ 0 & -1 & 0 & S_{1+2}a_{2} + S_{1}a_{1} \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

Furthermore,  $\cos(\alpha) = -\cos(180^{\circ} - \alpha)$  and  $\sin(\alpha) = \sin(180^{\circ} - \alpha)$  for  $\alpha \in [0^{\circ}, 180^{\circ}]$ . These facts result in the given transformation matrix:

$${}^{0}T_{3} = \begin{bmatrix} -1 & 0 & 0 & C_{1}a_{1} - C_{3}a_{2} - a_{3} \\ 0 & -1 & 0 & S_{1}a_{1} + S_{3}a_{2} \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

2) To rotate around  $x_0$ , we need to use Euler angles and append the rotation transformation matrix to the left side of  ${}^{0}T_3$ , because we need to rotate the manipulator before the other transformation can be started.

$${}^{0}T_{3}{}' = Rot_{x_{0}}(\theta_{0}) \cdot {}^{0}T_{3}$$

$$= \begin{bmatrix} 1 & 0 & 0 & 0 \\ 0 & C_{0} & -S_{0} & 0 \\ 0 & S_{0} & C_{0} & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix} \begin{bmatrix} -1 & 0 & 0 & C_{1}a_{1} - C_{3}a_{2} - a_{3} \\ 0 & -1 & 0 & S_{1}a_{1} + S_{3}a_{2} \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

$$= \begin{bmatrix} -1 & 0 & 0 & C_{1}a_{1} - C_{3}a_{2} - a_{3} \\ 0 & -C_{0} & -S_{0} & C_{0}S_{1}a_{1} + C_{0}S_{3}a_{2} \\ 0 & 0 & 0 & 1 \end{bmatrix}$$


$$= \begin{bmatrix} -1 & 0 & 0 & C_{1}a_{1} - C_{3}a_{2} - a_{3} \\ 0 & -S_{0} & C_{0} & S_{0}S_{1}a_{1} + S_{0}S_{3}a_{2} \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

For the second rotation around  $x_3$  by  $\theta_4$ , we append the rotation matrix to the right side of  ${}^0T_3$ .

$$\begin{split} ^0T_3{''} &= {}^0T_3 \cdot Rot_{x_3}(\theta_4) \\ &= \begin{bmatrix} -1 & 0 & 0 & C_1a_1 - C_3a_2 - a_3 \\ 0 & -1 & 0 & S_1a_1 + S_3a_2 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix} \begin{bmatrix} 1 & 0 & 0 & 0 \\ 0 & C_4 & -S_4 & 0 \\ 0 & S_4 & C_4 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix} \\ &= \begin{bmatrix} -1 & 0 & 0 & C_1a_1 - C_3a_2 - a_3 \\ 0 & -C_4 & S_4 & S_1a_1 + S_3a_2 \\ 0 & S_4 & C_4 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

## Task 2.2.

**Task 2.3.** The coordinate frames are specified via the figure 1. In this drawing, every z-axis points towards the viewer, in order to complete a right-handes coordinate system.



Link i	$\theta_i$	$\alpha_{i-1}$	$a_{i-1}$	$d_i$
1	$\theta_1$	0°	$L_1$	0
2	$\theta_2$	0°	$L_2$	0
3	$\theta_3$	0°	$L_3$	0

Figure 1: The specified coordinate frames and the DH parameters of 2.3

- Task 2.4. 1) The manipulator shown in the figure follows the Denavit-Hartenberg-convention. Every z-axis is given by the axis of rotation of its joint. Every x-axis shows in the directions of the common normal of both z-axes, or better in the direction of the shortest connection between both z-axes, since there are no common normals for parallel z-axes. Every y-axis and every rotation direction is then given by the fact, that we want to have a right handed coordinate system.
  - 2) The homogeneous transformation  $^{Base}T_{Tool}$  is given by concatenation of the partial transformations from one frame to the next:

$$^{Base}T_{Tool} = {}^{0}T_{1}{}^{1}T_{2}{}^{2}T_{3}{}^{3}T_{4}$$

We determine the partial transformation matrices as follows and convert milimeters to meters to avoid big numbers:

$$\begin{split} {}^{0}T_{1} &= Trans_{(0,0,877mm)} \cdot Rot_{z_{0}}(\theta_{1}) \cdot Trans_{(425mm,0,0)} \cdot Rot_{x_{0}}(\pi) \\ &= \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 1 & 0 & 0 \\ 0 & 0 & 1 & 0.877 \\ 0 & 0 & 0 & 1 \end{pmatrix} \begin{pmatrix} \cos(\theta_{1}) & -\sin(\theta_{1}) & 0 & 0 \\ \sin(\theta_{1}) & \cos(\theta_{1}) & 0 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{pmatrix} \\ & \begin{pmatrix} 1 & 0 & 0 & 0.425 \\ 0 & 1 & 0 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{pmatrix} \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & \cos(\pi) & -\sin(\pi) & 0 \\ 0 & \sin(\pi) & \cos(\pi) & 0 \\ 0 & 0 & 0 & 1 \end{pmatrix} \\ & = \begin{pmatrix} \cos(\theta_{1}) & -\sin(\theta_{1}) & 0 & 0 \\ \sin(\theta_{1}) & \cos(\theta_{1}) & 0 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{pmatrix} \begin{pmatrix} 1 & 0 & 0 & 0.425 \\ 0 & 1 & 0 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{pmatrix} \\ & = \begin{pmatrix} \cos(\theta_{1}) & -\sin(\theta_{1}) & 0 & 0 \\ 0 & 0 & 1 & 0.877 \\ 0 & 0 & 0 & 1 \end{pmatrix} \begin{pmatrix} 1 & 0 & 0 & 0.425 \\ 0 & 1 & 0 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{pmatrix}$$

$$\begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & -1 & 0 & 0 \\ 0 & 0 & -1 & 0 \\ 0 & 0 & 0 & 1 \end{pmatrix}$$

$$= \begin{pmatrix} \cos(\theta_1) & -\sin(\theta_1) & 0 & 0.425 \cdot \cos(\theta_1) \\ \sin(\theta_1) & \cos(\theta_1) & 0 & 0.425 \cdot \sin(\theta_1) \\ 0 & 0 & 1 & 0.877 \\ 0 & 0 & 0 & 1 \end{pmatrix} \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & -1 & 0 & 0 \\ 0 & 0 & -1 & 0 \\ 0 & 0 & 0 & 1 \end{pmatrix}$$

$$= \begin{pmatrix} \cos(\theta_1) & \sin(\theta_1) & 0 & 0.425 \cdot \cos(\theta_1) \\ \sin(\theta_1) & -\cos(\theta_1) & 0 & 0.425 \cdot \sin(\theta_1) \\ 0 & 0 & -1 & 0.877 \\ 0 & 0 & 0 & 1 \end{pmatrix}$$

$$= \begin{cases} \cos(\theta_2) & \sin(\theta_2) & 0 & 0 \\ \sin(\theta_2) & \cos(\theta_2) & 0 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{pmatrix} \begin{pmatrix} 1 & 0 & 0 & 0.375 \\ 0 & 1 & 0 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{pmatrix}$$

$$= \begin{cases} \cos(\theta_2) & -\sin(\theta_2) & 0 & 0 \\ \cos(\theta_2) & -\sin(\theta_2) & 0 & 0.375 \cdot \cos(\theta_2) \\ \sin(\theta_2) & \cos(\theta_2) & 0 & 0.375 \cdot \sin(\theta_2) \\ 0 & 0 & 0 & 1 \end{pmatrix}$$

$$= \begin{cases} \cos(\theta_2) & -\sin(\theta_2) & 0 & 0.375 \cdot \cos(\theta_2) \\ \sin(\theta_2) & \cos(\theta_2) & 0 & 0.375 \cdot \sin(\theta_2) \\ 0 & 0 & 0 & 1 \end{pmatrix}$$

$$= Trans_{(0,0,d_3)}$$

$$= \begin{cases} 1 & 0 & 0 & 0 \\ 0 & 1 & 0 & 0 \\ 0 & 0 & 1 & d_3 \\ 0 & 0 & 1 \end{cases}$$

$$= Trans_{(0,0,200mm)} \cdot Rot_{z_3}(\pi/2 + \theta_4)$$

$$= \begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 1 & 0 & 0 \\ 0 & 0 & 1 & 0.2 \\ 0 & 0 & 0 & 1 \end{pmatrix}$$

$$= \begin{pmatrix} \cos(\pi/2 + \theta_4) & -\sin(\pi/2 + \theta_4) & 0 & 0 \\ \sin(\pi/2 + \theta_4) & \cos(\pi/2 + \theta_4) & 0 & 0 \\ 0 & 0 & 0 & 1 & 0.2 \\ 0 & 0 & 0 & 1 & 0.2 \\ 0 & 0 & 0 & 1 & 0.2 \\ 0 & 0 & 0 & 1 & 0.2 \\ 0 & 0 & 0 & 0 & 1 \end{pmatrix}$$

Now we can compute the final transformation matrix:

$$\begin{split} ^{Base}T_{Tool} &= {}^{0}T_{1}{}^{1}T_{2}{}^{2}T_{3}{}^{3}T_{4} \\ &= \begin{pmatrix} C_{1}C_{2} + S_{1}S_{2} & -S_{2}C_{1} + S_{1}C_{2} & 0 & 0.375C_{1}C_{2} + 0.375S_{1}S_{2} + 0.425C_{1} \\ S_{1}C_{2} - C_{1}S_{2} & -S_{1}S_{2} - C_{1}C_{2} & 0 & 0.375S_{1}C_{2} - 0.375C_{1}S_{2} + 0.425S_{1} \\ 0 & 0 & -1 & 0.877 \\ 0 & 0 & 0 & 1 \end{pmatrix} {}^{2}T_{3}{}^{3}T_{4} \end{split}$$

$$=\begin{pmatrix} C_1C_2+S_1S_2 & -S_2C_1+S_1C_2 & 0 & 0.375C_1C_2+0.375S_1S_2+0.425C_1\\ S_1C_2-C_1S_2 & -S_1S_2-C_1C_2 & 0 & 0.375S_1C_2-0.375C_1S_2+0.425S_1\\ 0 & 0 & -1 & -d_3+0.877\\ 0 & 0 & 0 & 1 \end{pmatrix}^3T_4$$

$$=\begin{pmatrix} n_x & o_x & a_x & p_x\\ n_y & o_y & a_y & p_y\\ n_z & o_z & a_z & p_z\\ 0 & 0 & 0 & 1 \end{pmatrix}$$

with:

$$n_x = (C_1C_2 + S_1S_2)\cos(\pi/2 + \theta_4) + (-S_2C_1 + S_1C_2)\sin(\pi/2 + \theta_4)$$

$$n_y = (S_1C_2 - C_1S_2)\cos(\pi/2 + \theta_4) + (-S_1S_2 - C_1C_2)\sin(\pi/2 + \theta_4)$$

$$n_z = 0$$

$$o_x = -(C_1C_2 + S_1S_2)\sin(\pi/2 + \theta_4) + (-S_2C_1 + S_1C_2)\cos(\pi/2 + \theta_4) = n_y$$

$$o_y = -(S_1C_2 - C_1S_2)\sin(\pi/2 + \theta_4) + (-S_1S_2 - C_1C_2)\cos(\pi/2 + \theta_4) = -n_x$$

$$o_z = 0$$

$$a_x = 0$$

$$a_x = 0$$

$$a_y = 0$$

$$a_z = -1$$

$$p_x = 0.375C_1C_2 + 0.375S_1S_2 + 0.425C_1$$

$$p_y = 0.375S_1C_2 - 0.375C_1S_2 + 0.425S_1$$

$$p_z = -0.2 - d_3 + 0.877$$

where  $C_i = \cos(\theta_i)$  and  $S_i = \sin(\theta_i)$ .

3) Before we can calculate the result, we need to insert the variables into  $^{Base}T_{Tool}$ . **Note:** Since we work with meters and not with mm we need to convert 120 to 0.12. Overall, this leads to:

$$Base_{T_{Tool}} \approx egin{pmatrix} -0.7071 & -0.9659 & 0 & 0.2035 \\ -0.9659 & 0.7071 & 0 & 0.6627 \\ 0 & 0 & -1 & 0.557 \\ 0 & 0 & 0 & 1 \end{pmatrix}$$

Assuming the origin of the base frame is the origin of the world coordinate system (at (0,0,0)), we can calculate the coordinates of the tool center point as follows:

$$B^{ase}T_{Tool} \cdot \begin{pmatrix} 0 \\ 0 \\ 0 \\ 1 \end{pmatrix} pprox \begin{pmatrix} -0.7071 & -0.9659 & 0 & 0.2035 \\ -0.9659 & 0.7071 & 0 & 0.6627 \\ 0 & 0 & -1 & 0.557 \\ 0 & 0 & 0 & 1 \end{pmatrix} \cdot \begin{pmatrix} 0 \\ 0 \\ 0 \\ 1 \end{pmatrix}$$
  $pprox \begin{pmatrix} 0.2035 \\ 0.6627 \\ 0.557 \\ 1 \end{pmatrix}$ 

The tool center point is at the point (203.5, 662.7, 557) of the base coordinate system.