## Instructions

## February 11, 2018

- The following five files will be output from the interface (under inputs/ directory):
  - eweld.in
  - eweld\_weld\_parameters.in
  - eweld\_boundary\_condition.in
  - eweld\_preheat\_interpass\_temperature.in
  - eweld\_temperature\_monitor.in
  - eweld\_mesh\_key.txt (Not need to do now. This option will allow users to input their own meshes.)
- For automatic mesh, the following steps will be run:
  - 1. Check if pass\_coordinates.out exists in input directory, if no, run utils/determine\_passes\_arc\_v4.exe to create inputs/pass\_coordinates.out ¹: ./utils/determine\_passes\_arc\_v4.out inputs/ eweld.in will be input.
  - 2. Run utils/Automesh\_v14.py from SALOME's Python Console to create Mesh\_3D.unv, or run without Salome GUI:

```
SALOMEPATH/salome start -t -w 1 utils/Automesh_v14.py \ --write_separate_step_files
```

- (a) The input files are:
  - ./inputs/eweld.in
  - ./inputs/eweld\_weld\_parameters.in

<sup>&</sup>lt;sup>1</sup>On Linux, compile determine\_passes\_arc\_v4.out, to get determine\_passes\_arc\_v4.out via gfortran determine\_passes\_arc\_v4.for -o determine\_passes\_arc\_v4.out

```
- ./setting/Setting_arc_efficiency_dfault.in- ./inputs/pass_coordinates.out
```

(b) The output files will be:

```
- Mesh_3D.unv
```

- model\_dflux.for
- model\_step1.inp
- model\_step2.inp
- model\_step3.inp
- model\_step4.inp
- model\_step5.inp
- model\_step6.inp
- model\_step7.inp

Note: The model\_step.inp file has been broken into several files (model\_stepX.inp) to resolve and issue with post-processing of cases where elements get added during the simulation.

3. Run ./utils/runCGX.sh to generate the nodesElems.inp and model\_film.in files (using cgx and unical):

./utils/runCGX.sh Mesh\_3D.unv ./utils/write\_film.fbd

4. Run

python2 utils/Analysis\_file\_create.py

- The input files are:
  - \* ./inputs/eweld.in
  - \* ./inputs/eweld\_boundary\_condition.in
  - \* ./inputs/eweld\_preheat\_interpass\_temperature.in
  - \* ./nodesElems.inp
- The output files will be:
  - \* model\_bc.in
  - \* model\_ini\_temperature.in
  - \* model\_material.in
- 5. Move model\_dflux.for to the CalculiX directory (to CalculiX-PW/src/) and rename to dflux.f, and compile CalculiX (see the notes in CalculiX-PW/README.md for compilation/installation of CalculiX). Or decompress tools/CalculiX-PW.tar (works under Ubuntu 14.04, if all the required packages for CalculiX are installed):

```
tar -xf tools/CalculiX-PW.tar
```

The script ./utils/compileCcx.sh performs the above automatically on Ubuntu 14.04 if all required packages for compiling CalculiX are installed:

./utils/compileCcx.sh model\_dflux.for tools/CalculiX-PW.tar ccx\_2.12\_MT

6. Run analysis.inp with CalculiX: To get around an issue with post-processing of results in cases with element addition/removal during simulation, we have divided the simulation into several steps. In each step, the number of elements remain constant. To run the whole simulation, restart files written at the end of one step are used as a start point for the next step.

The bash script ./tests/runCCX\_manual.sh runs the multiple simulation steps consecutively. When running ./utils/runCCX\_manual.sh, the number of processors can be specified (the default number of processors is 1):

```
./tests/runCCX_manual.sh 4
```

The output exo, sta and cvg files with be compressed in ccx-results.tar after the simulations are complete.

7. Post processing: To post process the simulation results using Paraview, the Metrics Extraction Python library can be used. The properties of image and metrics can be specified via a json file. An example json file is in file:///setting/mex/welding\_anim.json. For details of the json syntax please

https://github.com/parallelworks/MetricExtraction.

To generate images and animations and extract statistics, follow these steps:

(a) Set the environment variable PARAVIEWPATH to the path of Paraview on your system, i.e, to the directory of pvpython. For example if pvpython is in directory /opt/paraview530/bin, run:

export PARAVIEWPATH=/opt/paraview530/bin

- (b) Archive the model\_stepX.inp files: tar -cf model\_step.tar model\_step?\*.inp
- (c) Run utils/mexdex/extract.sh:

./utils/mexdex/extract.sh model\_step.tar ccx-results.tar \
setting/mex/welding\_anim.json results/ results/metrics.csv \
pass\_coordinates.out

The images, animations and metrics.csv file (with extracted statistics) will be written under the directory results