
Raspberry Pi Distance Sensor using the HC-SR04



This guide will go through showing you how to wire up the sensor with the Raspberry Pi as well as exploring how we can utilize the sensor also to read distance.

We will be showing you how to wire the <u>HC-SR04 sensor</u> up to the Raspberry Pi, including how to wire a voltage divider as the circuit requires one to drop the 5v output from the sensor to 3.3v for the Raspberry Pi.

This is just one of many sensors you can use with your Raspberry Pi, if you're interested in more, then be sure to check out our <u>Raspberry Pi sensor tutorials</u> section.

Including showing how to wire up the sensor to the Raspberry Pi, we also explore writing a Python script that will utilize the HC-SR04 Ultrasonic sensor to calculate distance.

We achieve this by measuring the time it takes the ultrasonic pulse being sent out to it being received back by the sensor.

Equipment List

Below are all the bits and pieces that we utilized for this guide on setting up a Raspberry Pi distance sensor circuit

- Raspberry Pi 2 or newer
- Micro SD Card
- Power Supply
- HC-SR04 Ultrasonic Sensor
- 1k OHM Resistor
- 2k OHM Resistor
- Breadboard
- Breadboard Wire

Optional

- Raspberry Pi Case
- Ethernet Cable or Wi-Fi

Raspberry Pi Distance Sensor Hardware Setup

In this section, we will be showing you how to wire your HC-SR04 Distance Sensor to your Raspberry Pi. Wiring your sensor is a relatively simple process as most pins of the distance sensor map directly to a pin on the Raspberry Pi.


The only slightly complicated part of wiring the device to the Raspberry Pi is the voltage divider that we set up for the echo pin.

The reason for adding a voltage divider is to drop the voltage going to the GPIO pins down to 3.3v from 5v. In this guide, we will be utilizing a 1k Ω resistor and a 2k Ω resistor to achieve this. If you

want to understand how we calculate the values of a voltage divider, you can check out the guide featured at the end of this book.

Follow the guides below to see how to wire your HC-SR04 distance sensor to your Raspberry Pi.

- VCC Connects to Pin 2 (5v)
- Trig Connects to Pin 7 (GPIO 4)
- Echo Connects to R1 (1k Ω)
- R2 ($2k \Omega$) Connects from R1 to Ground
- Wire from R1 and R2 connects to Pin 11
- GND connects to Pin 6 (Ground)





To construct the circuit just do the following.

Don't forget you can use the diagram above to give yourself an idea of what you need to do.

- 1. Run a wire from the ground pin (Pin 6) to the ground/negative rail on the breadboard.
- **2.** Run a wire from 5v **pin** (**Pin 2**) to the **VCC** pin on the **HC-SR04** distance sensor.
- 3. Run a wire from **pin 7** to the **TRIG** pin on the distance sensor.
- **4.** Run a **1k** Ω resistor from the **ECHO** pin on the distance sensor to a spot on the breadboard.
- **5.** Run a $2k \Omega$ resistor from the $1k \Omega$ resistor to the **ground/negative rail** on the Raspberry Pi.
- **6.** Run a wire from between the **1k** Ω resistor and the **2k** Ω resistor to **pin 11** on the Raspberry Pi.

Utilizing your Raspberry Pi Distance Sensor

1. To utilize our Raspberry Pi Distance Sensor we luckily only have to program up a python script. Since we only <u>use GPIO pins</u> to interact with the distance sensor, there is no need to mess around with the raspi-config tool.

Before we begin writing our script, lets first make a folder to keep it. Run the following two commands on your Raspberry Pi to create the folder and <u>change directory</u> to it.

#Terminal

```
mkdir ~/distance_sensor/
cd ~/distance_sensor
```

2. Now that we are in our new directory, let's begin writing our distance sensor python script by running the following nano command on the Raspberry Pi.

#Terminal

nano distance_sensor.py

3. Within this file, write the following lines of code. We will explain the important parts of each block of code as we write it. Remember when <u>writing in Python code</u> that it is whitespace sensitive, so make sure that you retain the tabs that we have put in.

#Terminal

#!/usr/bin/python
import RPi.GPIO as GPIO
import time

try:

The first line tells the shell what we should be utilizing to run our Python file. Without it, there is no guarantee our file will be interpreted by Python.

We then proceed to import the two libraries that we need to write our script and interact with the distance sensor from our Raspberry Pi. The two libraries that we import are the following:

Rpi.GPIO – This is the package that allows us to control and interact with the GPIO pins, without this package we wouldn't be able to talk with our distance sensor.

time – This package allows us to control time-related functions with the script. We mainly just use this to put the script to sleep and also time how long it takes to receive data back from the sensor.

Finally, we begin our try: statement, we cover the vast majority of the code within this to ensure that we clear the GPIO pins on exit.

#Terminal

```
GPIO.setmode(GPIO.BOARD)

PIN_TRIGGER = 7

PIN_ECHO = 11

GPIO.setup(PIN_TRIGGER, GPIO.OUT)

GPIO.setup(PIN_ECHO, GPIO.IN)
```

On the first line here we set our GPIO mode to GPIO.BOARD, this means we are using the physical pin numbers and not the BCM numbers. We use this to ensure compatibility with our script as the BCM Numbers are not guaranteed to stay the same.

Next two lines we create two variables to store the physical pins that we have the trigger and echo wired to. We define them here to make it easy to change them without having to sift through the code continually.

Next we setup both our pins to either expect an output or an input. Our trigger pin is obviously an output pin as we need to ping this pin to start the sensor. The Echo pin is where we expect our data from, so we set this to receive input.

#Terminal

```
GPIO.output(PIN_TRIGGER, GPIO.LOW)

print "Waiting for sensor to settle"

time.sleep(2)
```

The first line we set our **PIN_TRIGGER GPIO** Pin, so it doesn't send out anything by setting it to "Low". We do this to let our **HC-SR04** sensor settle. This ensures we should be getting more consistent readings.

We then proceed to sleep the script for 2 seconds to ensure we give the distance sensor enough time to settle and don't immediately start triggering it.

#Terminal

```
print "Calculating distance"

GPIO.output(PIN_TRIGGER, GPIO.HIGH)

time.sleep(0.00001)

GPIO.output(PIN_TRIGGER, GPIO.LOW)
```

Finally, we get to the piece of code which gets the **HC-SR04 distance sensor** to trigger. To do this, we need to first set our **PIN_TRIGGER** to high.

We then need to sleep the script for 1 nanosecond, the reason for this is that the HC-SR04 distance sensor requires a pulse of 1 nanosecond to trigger it.

Immediately after the sleep has completed, we set **PIN_TRIGGER** low again.

#Terminal

```
while GPIO.input(PIN_ECHO)==0:
    pulse_start_time = time.time()

while GPIO.input(PIN_ECHO)==1:
    pulse_end_time = time.time()

pulse_duration = pulse_end_time - pulse_start_time

distance = round(pulse_duration * 17150, 2)

print "Distance:",distance,"cm"
```

First, we run a while loop to continually check if **PIN_ECHO** is **low** (**0**) if it is we continually set the **pulse_start_time** to the current time until it becomes **high** (**1**)

Once **PIN_ECHO** reads **high**, we set **pulse_end_time** to the current time. We do this until **PIN_ECHO** is set to low again.

These two loops allow us to calculate the time that it took for the ultrasonic pulse to be sent out and received back. Once we have both times, we just minus the two saved times to work out the duration.

With the pulse duration calculated we can work out the distance, it traveled since we know the rough speed of ultrasonic sound is **34300 cm/s**.

Since the duration of the pulse is the time it took for the ultrasonic sound to hit an object and bounce back, we will just use half the speed to calculate the distance it traveled before returning. Doing this is a simpler calculation then calculating the distance with the full speed then dividing by 2.

So finally our distance is equal to the duration of the pulse, multiplied by **17150 cm/s**.

#Terminal

```
finally:

GPIO.cleanup()
```

These two final lines of code are quite crucial as it ensures an end to our try: statement and ensures that we run **GPIO.cleanup()** when the script is terminated in any way. Failing to do so will throw warnings when rerunning the script or any other script that makes use of the GPIO pins.

4. Once you have finished typing in all the code, you should end up with something that looks like what we have below.

```
GPIO.setup(PIN TRIGGER, GPIO.OUT)
      GPIO.setup(PIN ECHO, GPIO.IN)
      GPIO.output(PIN TRIGGER, GPIO.LOW)
      print "Waiting for sensor to settle"
      time.sleep(2)
      print "Calculating distance"
     GPIO.output(PIN TRIGGER, GPIO.HIGH)
     time.sleep(0.00001)
      GPIO.output(PIN TRIGGER, GPIO.LOW)
      while GPIO.input(PIN ECHO)==0:
            pulse_start_time = time.time()
      while GPIO.input(PIN_ECHO)==1:
            pulse end time = time.time()
      pulse duration = pulse end time - pulse start time
      distance = round(pulse duration * 17150, 2)
      print "Distance:",distance,"cm"
finally:
      GPIO.cleanup()
```

With the code entered in properly then you can save the file by pressing CTRL + X then Y and pressing ENTER.

5. Now that you have successfully written the script we can run it by running the following simple command on your Raspberry Pi.

#Terminal

python ~/distance_sensor/distance_sensor.py

6. If everything is working correctly, you should get something like what is shown below in your terminal. Of course, the distance will be different to what we got.

Waiting for sensor to settle Calculating distance
Distance: 29.69 cm

Hopefully, by now you will have successfully set up your Raspberry Pi distance sensor and also written a python script that interacts with the sensor and successfully calculates the distance.

If you're looking to extend this project then you might want to check out the 16×2 LCD tutorial. It will be the perfect way to display the distance without needing to connect a monitor to the Raspberry Pi.

Feel free to drop a comment below if you enjoyed this tutorial on setting up an HC-SR04 distance sensor with your Raspberry Pi or need some help getting it up and running.