

Intro

If you want to continue with using unsupported verion of Blynk, check out Getting Started.

GETTING STARTED


How Blynk Works

Blynk was designed for the Internet of Things. It can control hardware remotely, it can display sensor data, it can store data, vizualize it and do many other cool things.

There are three major components in the platform:

- **Blynk App** - allows to you create amazing interfaces for your projects using various widgets we provide.
- **Blynk Server** - responsible for all the communications between the smartphone and hardware. You can use our Blynk Cloud or run your [private Blynk server](#) locally. It's open-source, could easily handle thousands of devices and can even be launched on a Raspberry Pi.
- **Blynk Libraries** - for all the popular hardware platforms - enable communication with the server and process all the incoming and outcoming commands.

Now imagine: every time you press a Button in the Blynk app, the message travels to space the Blynk Cloud, where it magically finds its way to your hardware. It works the same in the opposite direction and everything happens in a blynk of an eye.



Features

- Similar API & UI for all supported hardware & devices
- Connection to the cloud using:
 - WiFi
 - Bluetooth and BLE
 - Ethernet
 - USB (Serial)
 - GSM
 - ...
- Set of easy-to-use Widgets
- Direct pin manipulation with no code writing
- Easy to integrate and add new functionality using virtual pins
- History data monitoring via SuperChart widget
- Device-to-Device communication using Bridge Widget
- Sending emails, tweets, push notifications, etc.
- ... new features are constantly added!

You can find [example sketches](#) covering basic Blynk Features. They are included in the library. All the sketches are designed to be easily combined with each other.

What do I need to Blynk?

At this point you might be thinking: "Ok, I want it. What do I need to get started?" – Just a couple of things, really:

1. Hardware.

An Arduino, Raspberry Pi, or a similar development kit.

Blynk works over the Internet. This means that the hardware you choose should be able to connect to the internet. Some of the boards, like Arduino Uno will need an Ethernet or Wi-Fi Shield to communicate, others are already Internet-enabled: like the ESP8266, Raspberry Pi with WiFi dongle, Particle Photon or SparkFun Blynk Board. But even if you don't have a shield, you can connect it over USB to your laptop or desktop (it's a bit more complicated for newbies, but we got you covered). What's cool, is that the [list of hardware](#) that works with Blynk is huge and will keep on growing.

2. A Smartphone.

The Blynk App is a well designed interface builder. It works on both iOS and Android, so no holywars here, ok?

Downloads

Blynk Apps for iOS or Android



Blynk Library


[DOWNLOAD THE BLYNK LIBRARY](#)

In case you forgot, or don't know how to install Arduino libraries [click here](#).

Getting Started

Let's get you started in 5 minutes (reading doesn't count!). We will switch on an LED connected to your Arduino using the Blynk App on your smartphone.

Connect an LED as shown here:




Getting Started With The Blynk App

1. Create a Blynk Account

After you download the Blynk App, you'll need to create a New Blynk account. This account is separate from the accounts used for the Blynk Forums, in case you already have one.

We recommend using a **real** email address because it will simplify things later.




Why do I need to create an account?

An account is needed to save your projects and have access to them from multiple devices from anywhere. It's also a security measure.

You can always set up your own [Private Blynk Server](#) and have full control.


2. Create a New Project

After you've successfully logged into your account, start by creating a new project.




3. Choose Your Hardware

Select the hardware model you will use. Check out the [list of supported hardware!](#)



4. Auth Token

Auth Token is a unique identifier which is needed to connect your hardware to your smartphone. Every new project you create will have its own Auth Token. You'll get Auth Token automatically on your email after project creation. You can also copy it manually. Click on devices section and selected required device :



And you'll see token :

Device Name

HARDWARE MODEL

ESP8266

CONNECTION TYPE

WiFi

AUTH TOKEN

f064daa6f6a7411ebe591f796f2e6a17


Refresh E-mail

Create

NOTE: Don't share your Auth Token with anyone, unless you want someone to have access to your hardware.

It's very convenient to send it over e-mail. Press the e-mail button and the token will be sent to the e-mail address you used for registration. You can also tap on the Token line and it will be copied to the clipboard.


Now press the "Create" button.



5. Add a Widget


Your project canvas is empty, let's add a button to control our LED.

Tap anywhere on the canvas to open the widget box. All the available widgets are located here. Now pick a button.




Drag-n-Drop - Tap and hold the Widget to drag it to the new position.

Widget Settings - Each Widget has its own settings. Tap on the widget to get to them.




The most important parameter to set is **PIN**. The list of pins reflects physical pins defined by your hardware. If your LED is connected to Digital Pin 8 - then select **D8** (**D** - stands for Digital).



6. Run The Project


When you are done with the Settings - press the **PLAY** button. This will switch you from EDIT mode to PLAY mode where you can interact with the hardware. While in PLAY mode, you won't be able to drag or set up new widgets, press **STOP** and get back to EDIT mode.

You will get a message saying "Arduino UNO is offline". We'll deal with that in the next section.



Getting Started With Hardware How To Use an Example Sketch

You should by now have the Blynk Library installed on your computer. If not - [click here](#).



Let's take a look at the example sketch for an [Arduino UNO + Ethernet shield](#)

```
#define BLYNK_PRINT Serial
#include <SPI.h>
#include <Ethernet.h>
#include <BlynkSimpleEthernet.h>

char auth[] = "YourAuthToken";

void setup()
{
    Serial.begin(9600); // See the connection status in Serial Monitor
    Blynk.begin(auth); // Here your Arduino connects to the Blynk Cloud.
}

void loop()
{
    Blynk.run(); // All the Blynk Magic happens here...
}
```

Auth Token

In this example sketch, find this line:

```
char auth[] = "YourAuthToken";
```

This is the [Auth Token](#) that you emailed yourself. Please check your email and copy it, then paste it inside the quotation marks.

It should look similar to this:

```
char auth[] = "f45626c103a94983b469637978b0c78a";
```


Upload the sketch to the board and open Serial Terminal. Wait until you see something like this:

Blynk connected!

Congrats! You are all set! Now your hardware is connected to the Blynk Cloud!

Blynking

Go back to the Blynk App, push the button and turn the LED on and off! It should be Blynking.



Check out [other example sketches](#).

Feel free to experiment and combine different examples together to create your own amazing projects.

For example, to attach an LED to a [PWM](#)-enabled Pin on your Arduino, set the slider widget to control the brightness of an LED. Just use the same steps described above.

Hardware set-ups

Arduino over USB (no shield)

1. Open [Arduino Serial USB example](#) and change [Auth Token](#)

```
// You could use a spare Hardware Serial on boards that have it (like Mega)
#include <SoftwareSerial.h>
SoftwareSerial DebugSerial(2, 3); // RX, TX

#define BLYNK_PRINT DebugSerial
#include <BlynkSimpleStream.h>

// You should get Auth Token in the Blynk App.
// Go to the Project Settings (nut icon).
char auth[] = "YourAuthToken";

void setup()
{
    // Debug console
    DebugSerial.begin(9600);

    // Blynk will work through Serial
    Serial.begin(9600);
    Blynk.begin(auth, Serial);
}

void loop()
{
    Blynk.run();
}
```

2. Run the script which is usually located in `/scripts` folder:

- Windows: My Documents\Arduino\libraries\Blynk\scripts
- Mac User\$/Documents/Arduino/libraries/Blynk/scripts

On Windows:

Open cmd.exe

Write your path to blynk-ser.bat folder. For example:

```
cd C:\blynk-library-0.3.1\blynk-library-0.3.1\scripts
```

Run `blynk-ser.bat` file. For example : `blynk-ser.bat -c COM4` (where COM4 is port with your Arduino)

And press "Enter", press "Enter" and press "Enter"

On Linux and Mac:

Navigate to `/scripts` folder. For example:

When inside this folder, run:

```
user:scripts User$ ./blynk-ser.sh
```

Warning: Do no close terminal window with running script.

In some cases you may also need to perform :

```
user:scripts User$ chmod +x blynk-ser.sh
```

You may need also to run it with `sudo`

```
user:scripts User$ sudo ./blynk-ser.sh
```

This is what you'll see in Terminal app on Mac (usbmodem address can be different):

```
[ Press Ctrl+C to exit ]
/dev/tty.usbmodem not found.
Select serial port [ /dev/tty.usbmodem1451 ]:
```

Copy the serial port address: `/dev/tty.usbmodem1451` and paste it back:

```
Select serial port [ /dev/tty.usbmodem1451 ]: /dev/tty.usbmodem1451
```

After you press Enter, you should see an output similar to this:

```
Resetting device /dev/tty.usbmodem1451...
Connecting: GOPEN:/dev/tty.usbmodem1451,raw,echo=0,clocal=1,cs8,nonblock=1,ixoff=0,ixon=0,ispee
2015/10/03 00:29:45 socat[30438.2046857984] N opening character device "/dev/tty.usbmodem1451" f
2015/10/03 00:29:45 socat[30438.2046857984] N opening connection to LEN=16 AF=2 45.55.195.102:9
2015/10/03 00:29:45 socat[30438.2046857984] N successfully connected from local address LEN=16 AF
2015/10/03 00:29:45 socat[30438.2046857984] N SSL connection using AES128-SHA
2015/10/03 00:29:45 socat[30438.2046857984] N starting data transfer loop with FDs [3,3] and [4,4]
```

NOTE: Arduino IDE may complain with "programmer is not responding". You need to terminate script before uploading new sketch.

Additional materials:

- [Tutorial: Control Arduino over USB with Blynk app. No shield required. Mac OS](#)
- [How to control arduino \(Wirelessly\) with blynk via USB. Windows](#)
- [Instructables: Control Arduino with Blynk over USB](#)

Raspberry Pi

1. Connect your Raspberry Pi to the Internet and open it's console.
2. Run this command (it updates your OS package repository to include the required packages):

```
curl -sL "https://deb.nodesource.com/setup_6.x" | sudo -E bash -
```

3. Download and build Blynk JS library using npm:

```
sudo apt-get update && sudo apt-get upgrade
sudo apt-get install build-essential
sudo apt-get install -g npm
sudo npm install -g onoff
sudo npm install -g blynk-library
```

4. Run Blynk test script (put your auth token):

```
blynk-client 715f8cafe95f4a91bae319d0376caa8c
```

5. You can write our own script based on [examples](#)

6. To enable Blynk auto restart for Pi, find `/etc/rc.local` file and add there:

```
node full_path_to_your_script.js <Auth Token>
```

Additional materials:

- [Instructables: Blynk on Javascript for Raspberry Pi, Intel Edison and others](#)
- [Instructables: Use DHT11/DHT12 sensors with Raspberry Pi and Blynk](#)

Note: Instead of using Node.js, you can also build a C++ libarry version (same as Arduino, WiringPi-based) installation: - [Library README for Linux](#) - [Blynk Community Topic: How-To Raspberry Pi](#) - [Video tutorial - Setting up Blynk and Raspberry Pi](#):

ESP8266 Standalone

You can run Blynk directly on the ESP8266!

Install the latest ESP8266 library for Arduino using [this guide](#).

Example Sketch: [ESP8266 Standalone](#)

Additional materials:

[Step-by-Step Tutorial in Russian language](#)

NodeMCU

Please follow [this detailed instruction](#). Or watch [this Video tutorial](#).

Arduino + ESP8266 WiFi with AT commands

This connection type is not recommended for beginners.

If you would like to try it, please carefully read [this help topic](#) Note: Some boards like Arduino UNO WiFi from Arduino.org, do not use AT commands (and do not provide relevant libraries), so this renders them unusable with Blynk.

Particle

Blynk works with the whole family of Particle products: Core, Photon and Electron

1. Open [Particle Web IDE](#).
2. Go to the libraries.
3. Search for **Blynk** in the Community Libraries and click on it
4. Open `01_PARTICLE.INO` example
5. Click "use this example"
6. Put your Auth Token here: `char auth[] = "YourAuthToken";` and flash the Particle!

You can scan this QR code from the Blynk App and you'll get a ready-to-test project for **Particle Photon**. Just put your Auth Token into the `01_PARTICLE.INO` example.



Blynk main operations

Virtual Pins

Blynk can control Digital and Analog I/O Pins on your hardware directly. You don't even need to write code for it. It's great for blinking LEDs, but often it's just not enough...

We designed Virtual Pins to send **any** data from your microcontroller to the Blynk App and back.

Anything you connect to your hardware will be able to talk to Blynk. With Virtual Pins you can send something from the App, process it on microcontroller and then send it back to the smartphone. You can trigger functions, read I2C devices, convert values, control servo and DC motors etc.

Virtual Pins can be used to interface with external libraries (Servo, LCD and others) and implement custom functionality.

Hardware may send data to the Widgets over the Virtual Pin like this:

```
Blynk.virtualWrite(pin, "abc");
Blynk.virtualWrite(pin, 123);
Blynk.virtualWrite(pin, 12.34);
Blynk.virtualWrite(pin, "hello", 123, 12.34);
```


For more information about virtual pins, [read this](#)

Send data from app to hardware

You can send any data from Widgets in the app to your hardware.


All [Controller Widgets](#) can send data to Virtual Pins on your hardware. For example, code below shows how to get values from the Button Widget in the App

```
BLYNK_WRITE(V1) //Button Widget is writing to pin V1
{
    int pinData = param.toInt();
}
```



Full example sketch: [Get Data](#)
Sending array from Widget

Some Widgets (e.g Joystick, zeRGBa) have more than one output.



This output can be written to Virtual Pin as an array of values. On the hardware side - you can get any element of the array [0,1,2,...] by using:

```

int y = param[1].asInt(); // getting second value
int z = param[N].asInt(); // getting N value
}


```

Sketch: [JoystickTwoAxis](#)

Get data from hardware

There are two ways of pushing data from your hardware to the Widgets in the app over Virtual Pins.
Perform requests by Widget

- Using Blynk built-in reading frequency while App is active by setting 'Reading Frequency' parameter to some interval:




```

BLYNK_READ(V5) // Widget in the app READs Virtual Pin V5 with the certain frequency
{
    // This command writes Arduino's uptime in seconds to Virtual Pin V5
    Blynk.virtualWrite(5, millis() / 1000);
}

```

Sketch: [PushDataOnRequest](#)
Pushing data from hardware

If you need to PUSH sensor or other data from your hardware to Widget, you can write any logic you want. Just set the frequency to PUSH mode. Any command that hardware sends to Blynk Cloud is automatically stored on server and you get this info either with [History Graph](#) widget or with [HTTP API](#).



We recommend sending data in intervals and avoiding [Flood Error](#). You can use timers like [BlynkTimer](#). Please read instructions inside this [example sketch](#) for more details.

Here is how it can work:

```
#include <SPI.h>
#include <Ethernet.h>
#include <BlynkSimpleEthernet.h>

char auth[] = "YourAuthToken"; // Put your token here

BlynkTimer timer; // Create a Timer object called "timer"!

void setup()
{
    Serial.begin(9600);
    Blynk.begin(auth);

    timer.setInterval(1000L, sendUptime); // Here you set interval (1sec) and which function to call
}

void sendUptime()
{
    // This function sends Arduino up time every 1 second to Virtual Pin (V5)
    // In the app, Widget's reading frequency should be set to PUSH
    // You can send anything with any interval using this construction
    // Don't send more than 10 values per second

    Blynk.virtualWrite(V5, millis() / 1000);
}

void loop()
{
    Blynk.run(); // all the Blynk magic happens here
}
```

Sketch: [PushData](#)

State syncing For hardware

If your hardware loses Internet connection or resets, you can restore all the values from Widgets in the Blynk app.

```
BLYNK_CONNECTED() {
    Blynk.syncAll();
}

//here handlers for sync command
BLYNK_WRITE(V0) {
    ...
}
```

The `Blynk.syncAll()` command restores all the Widget's values based on the last saved values on the server. All analog and digital pin states will be restored. Every Virtual Pin will perform `BLYNK_WRITE` event.

WARNING: if pin is empty and wasn't initialized - hardware will not get any response for those pin during sync.

[Sync Hardware with App state](#)

You can also update a single Virtual Pin value by calling `Blynk.syncVirtual(V0)` or you can update several pins with `Blynk.syncVirtual(V0, V1, V2, ...)`.

You can also use server to store any value without widget. Just call `Blynk.virtualWrite(V0, value)`.

[Storing single value on server](#)

[Storing multiple values on server](#) **For app**

If you need to keep your hardware in sync with Widgets' state even if app is offline use `Blynk.virtualWrite`.


Imagine you have a LED Widget connected to the Virtual Pin V1 in the app, and a physical button attached to your hardware. When you press a physical button, you would expect to see updated state of the LED Widget in the app. To achieve that you need to send `Blynk.virtualWrite(V1, 255)` when a physical button gets pressed.

[Represent physical button state via LED widget with interrupts](#)


[Represent physical button state via LED widget with polling](#)


Control of multiple devices

Blynk app has support of multiple devices. That means you can assign any widget to specific device with own auth token. For example - you may have button on V1 that controls wi-fi bulb A and another button on V1 that controls wi-fi bulb B. In order to do this you need more than 1 device within your project. To achieve this please go to project settings and click on "Devices" section :




You'll see list of devices :





After above steps, every widget will have one more field "Target" :




Now you need to assign widget to device and after that widget will control only this specific device.

That's it! Now you need to upload sketches with correct Auth Tokens to your hardware.
Tags

Tags feature allows you to group multiple devices. Tags are very useful in case you want to control few devices with 1 widget. For example, imagine a case when you have 3 smart bulbs and you want to turn on all those bulbs with one single click. You need to assign 3 devices to 1 tag and assign tag to button. That's it.

Devices online status

Blynk app has support for online statuses for multiple devices.



In ideal world when device closes tcp connection with some `connection.close()` - connected server will get notification regarding closed connection. So you can get instant status update on UI. However in real world this mostly exceptional situation. In majority of cases there is no easy and instant way to find out that connection is not active anymore.

That's why Blynk uses `HEARTBEAT` mechanism. With this approach hardware periodically sends `ping` command with predefined interval (10 seconds by default, `BLYNK_HEARTBEAT` [property](#)). In case hardware don't send anything within 10 seconds server waits additional 5 seconds and after that connection assumed to be broken and closed by server. So on UI you'll see connection status update only after 15 seconds when it is actually happened.

You can also change `HEARTBEAT` interval from hardware side via `Blynk.config`. In that case `newHeartbeatInterval * 2.3` formula will be applied. So in case you decided to set `HEARTBEAT` interval to 5 seconds. You'll get notification regarding connection with 11 sec delay in worst case.

Project Settings

Every project has its own settings:

- **Theme** - switch between the Light and Black Blynk Theme (Business accounts have wider choice);

and APP DISCONNECTED commands to your hardware when your Blynk app goes online/offline.

Usage example:

- Do not show offline notifications - right now, for debugging purposes, every time your hardware goes offline - the Blynk Server will notify you with popup in the app about that. However, when debugging is not needed or the Blynk app is used only via HTTP/S this notifications are meaningless. So this switch allows you to turn off this popups. Also this switch turns off the Push notification "Notify when offline" option.

Change Widget properties

Changing some of the widget properties from hardware side is also supported.
For example, you can change the color of LED widget based on a condition:

```
//change LED color
Blynk.setProperty(V0, "color", "#D3435C");

//change LED label
Blynk.setProperty(V0, "label", "My New Widget Label");

//change MENU labels
Blynk.setProperty(V0, "labels", "Menu Item 1", "Menu Item 2", "Menu Item 3");
```

[Set Property for single value field](#)

[Set Property for multi value field](#)

NOTE : Changing these parameters work **only** for widgets attached to Virtual pins (analog/digital pins won't work).

Four widget properties are supported - `color` , `label` , `min` , `max` for all widgets :

`label` is string for label of all widgets.

`color` is string in [HEX](#) format (in the form: #RRGGBB, where RR (red), GG (green) and BB (blue) are hexadecimal values between 00 and FF). For example :

```
#define BLYNK_GREEN    "#23C48E"
#define BLYNK_BLUE     "#04C0F8"
#define BLYNK_YELLOW   "#ED9D00"
#define BLYNK_RED      "#D3435C"
#define BLYNK_DARK_BLUE "#5F7CD8"
```

`min` , `max` - minimum and maximum values for the widget (for example range for the Slider). This numbers may be float.

Button

`onLabel` / `offLabel` is string for ON/OFF label of button;

Styled Button

`onLabel` / `offLabel` is string for ON/OFF label of button;

`onColor` / `offColor` is string in HEX format for ON/OFF colors of the button;

`onBackColor` / `offBackColor` is string in HEX format for ON/OFF colors of the button background.

Music Player

`isOnPlay` is boolean accepts true/false.

```
Blynk.setProperty(V0, "isOnPlay", "true");
```

Menu

`labels` is list of strings for Menu widget selections;

```
Blynk.setProperty(V0, "labels", "label 1", "label 2", "label 3");
```

Video Streaming

```
Blynk.setProperty(V1, "url", "http://my_new_video_url");
```

Step

```
Blynk.setProperty(V1, "step", 10);
```

Image

```
Blynk.setProperty(V1, "opacity", 50); // 0-100%
```

```
Blynk.setProperty(V1, "scale", 30); // 0-100%
```

```
Blynk.setProperty(V1, "rotation", 10); //0-360 degrees
```

or you can change individual image by it index:

```
Blynk.setProperty(V1, "url", 1, "https://image1.jpg");
```

You can also change widget properties via [HTTP API](#).

Limitations and Recommendations

- Don't put `Blynk.virtualWrite` and any other `Blynk.*` command inside `void loop()` - it will cause lot's of outgoing messages to our server and your connection will be terminated;
- We recommend calling functions with intervals. For example, use [BlynkTimer](#)
- Avoid using long delays with `delay()` – it may cause connection breaks;
- If you send more than 100 values per second - you may cause [Flood Error](#) and your hardware will be automatically disconnected from the server;
- Be careful sending a lot of `Blynk.virtualWrite` commands as most hardware is not very powerful (like ESP8266) so it may not handle many requests.

Widgets


Widgets are interface modules. Each of them performs a specific input/ output function when communicating with the hardware.

There are 4 types of Widgets:

- **Controllers** - used to send commands that control your hardware
- **Displays** - used for data visualization from sensors and other sources;
- **Notifications** - send messages and notifications;
- **Interface** - widgets to perform certain GUI functions;
- **Other** - widgets that don't belong to any category;

Each Widget has its own settings. Some of the Widgets (e.g. Bridge) just enable functionality and they don't have any settings.

Common Widget Settings




Digital Pins - represent physical Digital IO pins on your hardware. PWM-enabled pins are marked with the `~` symbol

Analog Pins - represent physical Analog IO pins on your hardware

Virtual Pins - have no physical representation. They are used to transfer any data between Blynk App and your hardware. Read more about Virtual Pins [here](#).

Data Mapping

In case you want to map incoming values to specific range you may use mapping button:



Let's say your sensor sends values from 0 to 1023. But you want to display values in a range 0 to 100 in the app. When Data Mapping enabled, incoming value 1023 will be mapped to 100.

SPLIT/MERGE

Some of the Widgets can send more than one value. And with this switch you can control how to send them.

- **SPLIT:** Each of the parameters is sent directly to the Pin on your hardware (e.g D7). You don't need to write any code.

NOTE: In this mode you send multiple commands from one widget, which can reduce performance of your hardware.

Example: If you have a Joystick Widget and it's set to D3 and D4, it will send 2 commands over the Internet:

```
digitalWrite(3, value);
digitalWrite(4, value);
```

- **MERGE:** When MERGE mode is selected, you are sending just 1 message, consisting of array of values. But you'll need to parse it on the hardware.

This mode can be used with Virtual Pins only.

Example: Add a zeRGBa Widget and set it to MERGE mode. Choose Virtual Pin V1

```
BLYNK_WRITE(V1) // There is a Widget that WRITES data to V1
{
    int r = param[0].asInt(); // get a RED channel value
    int g = param[1].asInt(); // get a GREEN channel value
    int b = param[2].asInt(); // get a BLUE channel value
}
```

slider will only send integer values with no decimals. "1 digit" means that values will look like 1.1, 1.2, ..., 2.0, etc.

Send On Release

This option allows you to optimize data traffic on your hardware.

For example, when you move joystick widget, commands are streamed to the hardware, during a single joystick move you can send dozens of commands. There are use-cases where it's needed, however creating such a load may lead to hardware overload and reset. **Send On Release** is a recommended setting for majority of applications. This is also a default setting.

Write interval

Similar to "Send on Release" option. However, it allows you to stream values to your hardware within certain interval. For example, setting **write interval** to 100 ms means that while you move the slider, only 1 value will be sent to hardware within 100 ms period. This option is also used to optimize data traffic flow to your hardware.

Color gradient

When you choose gradient, it affects the color of widget elements based on incoming values. For example: You set Gauge Widget with Min and Max parameters of 0-100, and choose green-yellow-red gradient. When hardware sends: - 10 , Gauge will change its color to green color - 50 will change Gauge to yellow color - 80 will change Gauge to red color


There are 2 types of gradients you can choose from: - Warm: Green - Orange - Red; - Cold: Green - Blue - Violet;

Controllers

Button


Works in push or switch modes. Allows to send ON and OFF (LOW/HIGH) values. Button sends 1 (HIGH) on press and sends 0 (LOW) on release.






Sketch: [BlynkBlink](#) **Slider**

Similar to potentiometer. Allows to send values between in a given MIN/MAX range.



Sketch: [BlynkBlink](#) **Timer**

Recent Android version also has improved Timer within Eventor widget. With Eventor Time Event you can assign multiple timers on same pin, send any string/value, select days and timezone. It is recommended to use Eventor over Timer widget. However Timer widget is still suitable for simple timer events.



NOTE: The timer widget rely on the server time and not your phone time. Sometimes the phone time may not match the server time.


Sketch: [Timer](#) [Joystick](#)

Control servo movements in 4 directions

Settings:

- SPLIT/MERGE modes - read [here](#)
- Rotate on Tilt

When it's ON, Joystick will automatically rotate if you use your smartphone in landscape orientation
- **Auto-Return** - When it's OFF, Joystick handle will not return back to center position. It will stay where you left it.



Sketch: [JoystickTwoAxis](#)
zeRGBa

zeRGBa is a usual RGB color picker + brightness picker

Settings:

- **SPLIT:** Each of the parameters is sent directly to the Pin on your hardware (e.g D7). You don't need to write any code.

NOTE: In this mode you send multiple commands from one widget, which can reduce performance of your hardware.

Example: If you have a zeRGBa Widget and it's set to D1, D2, D3 it will send 3 commands over the Internet:

```
digitalWrite(1, r);
digitalWrite(2, g);
digitalWrite(3, b);
```

- **MERGE:** When MERGE mode is selected, you send 1 message with an array of values inside. You would need to parse the message on the hardware.

This mode can be used with Virtual Pins only.

Example: Add a zeRGBa Widget and set it to MERGE mode. Choose Virtual Pin V1.

```

int r = param[0].asInt();
// get a GREEN channel value
int g = param[1].asInt();
// get a BLUE channel value
int b = param[2].asInt();
}

```

Step Control

Step Control is used to set granular values with a given step


2 buttons are assigned to 1 pin. One button increments the value, another one decrements it.

Send Step option allows you to send step value to hardware instead of actual value of step widget.
Loop value option allows you to reset step widget to start value when maximum value is reached.

Sketch: [Basic Sketch](#)


Displays Value Display

Displays incoming data.



Sketch: [BlynkBlink](#)

suffixes and prefixes on the app side, with no coding on the hardware.



Sketch: [BlynkBlink](#)

Formatting options


For example: your sensor sends value of 12.6789 to Blynk application. Next formatting options are supported:

/pin/ - displays the value without formatting (12.6789)

/pin./ - displays the rounded value without decimal part (13)

/pin.#/ - displays the value with 1 decimal digit (12.7)

/pin.##/ - displays the value with two decimal places (12.68)



A simple LED for indication. You need to send 0 in order to turn LED off. And 255 in order to turn LED on. Or just use Blynk API as described below:

```
WidgetLED led1(V1); //register to virtual pin 1
led1.off();
led1.on();
```

All values between 0 and 255 will change LED brightness:


```
WidgetLED led2(V2);
led2.setValue(127); //set brightness of LED to 50%.
```



Sketch: [LED Gauge](#)

Visual display of numeric values.





Sketch: [BlynkBlink](#)

Formatting options

For example: your sensor sends value of 12.6789 to Blynk application. Next formatting options are supported:

/pin/ - displays the value without formatting (12.6789)

/pin./ - displays the rounded value without decimal part (13)

/pin.#/ - displays the value with 1 decimal digit (12.7)

/pin.##/ - displays the value with two decimal places (12.68)

This is a regular 16x2 LCD display made in our secret facility in China.

SIMPLE / ADVANCED MODE


Commands

You need to use special commands with this widget:

```
lcd.print(x, y, "Your Message");
```

Where x is a symbol position (0-15), y is a line id (0 or 1),

```
lcd.clear();
```



Sketch: [LCD Advanced Mode Sketch](#): [LCD Simple Mode Pushing Sketch](#): [LCD Simple Mode Reading](#)

Formatting options

For example: your sensor sends value of 12.6789 to Blynk application. Next formatting options are supported:

/pin/ - displays the value without formatting (12.6789)

/pin./ - displays the rounded value without decimal part (13)

/pin.#/ - displays the value with 1 decimal digit (12.7)

/pin.##/ - displays the value with two decimal places (12.68)




SuperChart is used to visualise live and historical data. You can use it for sensor data, for binary event logging and more.


To use SuperChart widget you would need to push the data from the hardware with the desired interval by using timers.

[Here is](#) a basic example for data pushing.

Interactions:

- **Switch between time ranges and Live mode**
Tap time ranges at the bottom of the widget to change time ranges
- **Tap Legend Elements** to show or hide datastreams
- **Tap'n'hold** to view timestamp and corresponding values






Then you can then scroll data back and forward within the given time range.

- **Full Screen Mode**

Press this button to open Full Screen view in landscape orientation:




Simply rotate the phone back to portrait mode. Chart should rotate automagically. In full screen view you will see X (time) and multiple Y scales. Full Screen Mode can be disabled from widget Settings.

- **Menu Button**

Menu button will open additional functions:

- Export to CSV
- Erase Data on the server




SuperChart Settings:

- Chart Title
- Title Font Size You have a choice of 3 font sizes
- Title Alignment Choose chart title alignment. This setting also affects Title and Legend position on the Widget.
- Show x-axis (time) Select it if you want to show the time label at the bottom of your chart.
- Time ranges picker Allows you to select required periods (15m , 30m , 1h , 3h , ...) and resolution for your chart. Resolution defines how precise your data is. Right now chart supports 2 types of resolution standard and high . Resolution also depends on the selected period. For example, standard resolution for 1d means you'll get 24 points per day (1 per hour), with high resolution you'll get for 1d 1440 points per day (1 per minute).
- Datastreams - add datastreams (read below how to configure datastreams)

Datastream Settings

Widget supports up to 4 Datastreams. Press Datastream Settings Icon to open Datastream Settings.



Design: Choose available types of Chart:

- Line
- Area
- Bar
- Binary (anchor LINK to binary)

Color: Choose solid colors or gradients

Source and input: You can use 3 types of Data source:

1. Virtual Pin Choose the desired Device and Virtual Pin to read the data from.

2. Tags SuperChart can aggregate data from multiple devices using built-in aggregation functions. For example, if you have 10 Temperature sensors sending temperature with the given period, you can plot average value from 10 sensors on the widget.

To use Tags:

- Add Tag** to every device you want to aggregate data from.
- Push data to the same **Virtual Pin** on every device. (e.g. `Blynk.virtualWrite (V0, temperature);`)
- Choose Tag as a source in SuperChart Widget and use the pin where the data is coming to (e.g `V0`)

- with the chosen tag
- **AVG**, will plot average value
 - **MED**, will find a median value
 - **MIN**, will plot minimum value
 - **MAX** will plot maximum value

⚠️ IMPORTANT: Tags are not working in Live Mode.

1. **Device Selector** If you add Device Selector Widget to your project, you can use it as a source for SuperChart. In this case, when you change the device in Device Selector, chart will be updated accordingly

Y-Axis Settings


There are 4 modes of how to scale data along the Y axis

1. Auto

Data will be auto-scaled based on min and max values of the given time period. This is nice option to start with.

2. Values

When this mode is selected, Y scale will be set to the values you choose. For example, if your hardware sends data with values varying from -100 to 100, you can set the chart to this values and data will be rendered correctly.



You may also want to visualize the data within some specific range. Let's say incoming data has values in the range of 0-55, but you would like to see only values in the range 30-50. You can set it up and if values are out of Y scale you configured, chart will be cropped


1. % of Height

This option allows you to auto-scale incoming data on the widget and position it the way you want. In this mode, you set up the percentage of widget height on the screen, from 0% to 100%.




If you set 0-100%, in fact it's a full auto-scale. No matter in which range the data is coming, it will be always scaled to the whole height of the widget.

If you set it to 0-25%, then this chart will only be rendered on 1/4 of the widget height:



This setting is very valuable for **Binary Chart** or for visualizing a few datastreams on the same chart in a different way.



1. Delta


While data stays within the given Delta value, chart will be auto-scaled within this range. If delta exceeds the range, chart will be auto-scaled to min/max values of the given period.

Suffix:


Here you can specify a suffix that will be shown during the Tap'n'hold

Connect Missing Data Points

If this switch is ON, then SuperChart will connect all the dots even if there was no data



If it's set to OFF, then you will see gaps in case there was no data.



Binary Chart Settings

This type of chart is useful to plot binary data, for example when unit was ON or OFF, or when motion was detected or when certain threshold was reached.


You need to specify a **FLIP** point, which is the point where incoming data will be turned into TRUE or FALSE state.

For example, you send the data in the range of `0 to 1023`. If you set `512` as a **FLIP** point, then everything above `512` (excluding 512) will be recorded as `TRUE`, any value below `512` (including 512) will be `FALSE`.

State Labels:

Here you can specify how `TRUE/FALSE` should be shown in Tap'n'Hold mode.

For example, you can set to `TRUE` to "Equipment ON" label, `FALSE` to "Equipment OFF".



Superchart supports currently 2 types of granularity:

- Minute granularity - `1h` , `6h` , `1d` ;
- Hour granularity - `1w` , `1m` , `3m` ;

This means that minimum chart update interval is 1 minute for `1h` , `6h` , `1d` periods. 1 hour for `1w` , `1m` and `3m` periods. As Blynk Cloud is free to use we have a limit on how many data you can store. At the moment Blynk Cloud accepts 1 message per minute per pin. In case you send your data more frequently your values will be averaged. For example, in case you send value `10` at 12:12:05 and than again `12` at 12:12:45 as result in chart you'll see value `11` for 12:12.


In order to see data in chart you need to use either widgets with "Frequency reading" interval (in that case your app should be open and running) or you can use `Blynk.virtualWrite` on hardware side. Every `Blynk.virtualWrite` command is stored on server automatically. In that case you don't need application to be up and running.

Terminal

Displays data from your hardware. Allows to send any string to your hardware. Terminal always stores last 25 messages your hardware had send to Blynk Cloud. This limit may be increased on Local Server with `terminal.strings.pool.size` property.

You need to use special commands with this widget:

```
terminal.print(); // Print values, like Serial.print
terminal.println(); // Print values, like Serial.println()
terminal.write(); // Write a raw data buffer
terminal.flush(); // Ensure that data was sent out of device
terminal.clear(); // Erase all values in the terminal
```



Sketch: [Terminal](#) Video Streaming

Simple widget that allows you to display any live stream. Widget supports RTSP (RP, SDP), HTTP/S progressive streaming, HTTP/S live streaming. For more info please follow [official Android documentation](#).

At the moment Blynk doesn't provide streaming servers. So you can either stream directly from camera, use 3-d party services or host streaming server on own server (on raspberry for example).

You can also change video url from hardware with:

```
Blynk.setProperty(V1, "url", "http://my_new_video_url");
```

Level Display

Level Display is very similar to progress bar, when you need to visualize a level between min/max value. To update Level Display from hardware side with code:

```
Blynk.virtualWrite(V1, val);
```

Every message that hardware sends to server is stored automatically on server. PUSH mode doesn't require application to be online or opened.

Sketch: [Push Example](#)

Notifications

Twitter

Twitter widget connects your Twitter account to Blynk and allows you to send Tweets from your hardware.



Example code:

```
Blynk(tweet("Hey, Blynkers! My Arduino can tweet now!"));
```

Limitations:

- you can't send 2 tweets with same message (it's Twitter policy)
- only 1 tweet per 5 seconds is allowed

Sketch: [Twitter](#) [Email](#)

Email widget allows you to send email from your hardware to any address.

Example code:

```
Blynk.email("my_email@example.com", "Subject", "Your message goes here");
```

It also contains `to` field. With this field you may define receiver of email in the app. You may skip `to` field when you want to send email to your Blynk app login email:

```
Blynk.email("Subject", "Your message goes here");
```

You can send either `text/html` or `text/plain` (some clients don't support `text/html`) email. You can change this content type of email in the Mail widget settings.

Additionally you may use `{DEVICE_NAME}`, `{DEVICE_OWNER_EMAIL}` and `{VENDOR_EMAIL}` (for the local server) placeholders in the mail for the `to`, `subject` and `body` fields:

```
Blynk.email("{DEVICE_OWNER_EMAIL}", "{DEVICE_NAME} : Alarm", "Your {DEVICE_NAME} has critical
```

Limitations:

- Maximum allowed email + subject + message length is 120 symbols. However you can increase this limit if necessary by adding `#define BLYNK_MAX_SENDBYTES XXX` to your sketch. Where `XXX` is desired max length of your email. For example for ESP you can set this to 1200 max length `#define BLYNK_MAX_SENDBYTES 1200`. The `#define BLYNK_MAX_SENDBYTES 1200` must be included before any of the Blynk includes.
- Only 1 email per 5 seconds is allowed
- In case you are using gmail on the Local Server you are limited with 500 mails per day (by google). Other providers may have similar limitations, so please be careful.
- User is limited with 100 messages per day in the Blynk Cloud;

Sketch: [Email](#)
Push Notifications

Push Notification widget allows you to send push notification from your hardware to your device. Currently it also contains 2 additional options:

- **Notify when hardware offline** - you will get push notification in case your hardware went offline.
- **Offline Ignore Period** - defines how long hardware could be offline (after it went offline) before sending notification. In case period is exceeded - "hardware offline" notification will be sent. You will get no notification in case hardware was reconnected within specified period.
- **Priority** high priority gives more chances that your message will be delivered without any delays. See detailed explanation [here](#).

WARNING: high priority contributes more to battery drain compared to normal priority messages.



Example code:

```
Blynk.notify("Hey, Blynkers! My hardware can push now!");
```

You can also use placeholder for device name, that will be replaced on the server with your device name:

```
Blynk.notify("Hey, Blynkers! My {DEVICE_NAME} can push now!");
```

Limitations:

- Maximum allowed body length is 120 symbols;

The library handles all strings as UTF8 Unicode. If you're facing problems, try to print your message to the Serial and see if it works (the terminal should be set to UTF-8 encoding). If it doesn't work, probably you should read about unicode support of your compiler.

If it works, but your message is truncated - you need to increase message length limit (all Unicode symbols consume at least twice the size of Latin symbols).


Increasing message length limit

You can increase maximum message length by putting on the top of your sketch (before Blynk includes):

```
#define BLYNK_MAX_SENDBYTES 256 // Default is 128
```


Interface Tabs

The only purpose of Tabs widget is to extend your project space. You can have up to 4 tabs. Also you can drag widgets between tabs. Just drag widget on the label of required tab of tabs widget.



Menu

Menu widget allows you to send command to your hardware based on selection you made on UI. Menu sends index of element you selected and not label string. Sending index is starts from 1. It works same way as usual ComboBox element. You can also set Menu items [from hardware side](#).



Example code:

```
switch (param.asInt())
{
    case 1: { // Item 1
        Serial.println("Item 1 selected");
        break;
    }
    case 2: { // Item 2
        Serial.println("Item 2 selected");
        break;
    }
}
```

Sketch: [Menu](#) [Time Input](#)

Time input widget allows you to select start/stop time, day of week, timezone, sunrise/sunset formatted values and send them to your hardware. Supported formats for time now are **HH:MM** and **HH:MM AM/PM** .

Hardware will get selected on UI time as seconds of day (**3600 * hours + 60 * minutes**) for start/stop time. Time that widget sends to hardware is user local time. Selected days indexes:

```
Monday - 1
Tuesday - 2
...
Saturday - 6
Sundays - 7
```

You can also change state of widget on UI. See below sketches.

Sketch: [Update Time Input State on UI Map](#)

Map widget allows you set points/pins on map from hardware side. This is very useful widget in case you have multiple devices and you want track their values on map.

You can send a point to map with regular virtual wrtei command:

```
Blynk.virtualWrite(V1, pointIndex, lat, lon, "value");
```

We also created wrapper for you to make usage of map simpler:

You can change button labels from hardware with:

```
WidgetMap myMap(V1);
...
int index = 1;
float lat = 51.5074;
float lon = 0.1278;
myMap.location(index, lat, lon, "value");
```

Using save `index` allows you to override existing point value.

Sketch: [Basic Sketch Table](#)

Table widget comes handy when you need to structure similar data within 1 graphical element. It works as a usual table.

You can add a row to the table with:

```
Blynk.virtualWrite(V1, "add", id, "Name", "Value");
```

You can update a row in the table with:

```
Blynk.virtualWrite(V1, "update", id, "UpdatedName", "UpdatedValue");
```

To highlight any item in a table by using it's id in a table:

```
Blynk.virtualWrite(V1, "pick", 0);
```

To select/deselect (make icon green/grey) item in a table by using it's row id in a table:

To clear the table at any time with:

```
Blynk.virtualWrite(V1, "clr");
```

You can also handle other actions coming from table. For example, use row as a switch button.

```
BLYNK_WRITE(V1) {
    String cmd = param[0].asStr();
    if (cmd == "select") {
        //row in table was selected.
        int rowId = param[1].asInt();
    }
    if (cmd == "deselect") {
        //row in table was deselected.
        int rowId = param[1].asInt();
    }
    if (cmd == "order") {
        //rows in table where reordered
        int oldRowIndex = param[1].asInt();
        int newIndex = param[2].asInt();
    }
}
```

Note: Max number of rows in the table is 100. When you reach the limit, table will work as FIFO (First In First Out) list. This limit can be changed by configuring `table.rows.pool.size` property for Local Server.

Sketch: [Simple Table usage](#)

Sketch: [Advanced Table usage](#)
Device Selector

Device selector is a powerful widget which allows you to update widgets based on one active device. This widget is particularly helpful when you have a fleet of devices with similar functionality.

Imagine you have 4 devices and every device has a Temperature & Humidity sensor connected to it. To display the data for all 4 devices you would need to add 8 widgets.

With Device Selector, you can use only 2 Widgets which will display Temperature and Humidity based on the active device chosen in Device Selector.

All you have to do is:

1. Add Device Selector Widget to the project
2. Add 2 widgets (for example Value Display Widget) to show Temperature and Humidity
3. In Widgets Settings you will be able assign them to Device Selector (Source or Target section)
4. Exit settings, Run the project.

NOTE: Webhook Widget will not work with Device Selector (yet).
Device Tiles

Device tiles is a powerful widget and very similar to the device selector widget, but with UI. It allows you to display 1 pin per device per tile. This widget is particularly helpful when you have a fleet of devices with similar functionality. So you can group similar devices within one layout (template).

Sensors Accelerometer

Accelerometer is kind of [motion sensors](#) that allows you to detect motion of your smartphone. Useful for monitoring device movement, such as tilt, shake, rotation, or swing. Conceptually, an acceleration sensor determines the acceleration that is applied to a device by measuring the forces that are applied to the sensor. Measured in `m/s^2` applied to `x` , `y` , `z` axis.

In order to accept data from it you need to:

```
BLYNK_WRITE(V1) {
    //acceleration force applied to axis x
    int x = param[0].asFloat();
    //acceleration force applied to axis y
    int y = param[1].asFloat();
    //acceleration force applied to axis y
    int z = param[2].asFloat();
}
```

Accelerometer doesn't work in background.
Barometer/pressure

Barometer/pressure is kind of [environment sensors](#) that allows you to measure the ambient air pressure.

Measured in `in hPa` or `mbar` .

In oder to accept data from it you need to:

```
BLYNK_WRITE(V1) {
    //pressure in mbar
    int pressure = param[0].asInt();
}
```

Barometer doesn't work in background.
Gravity

Gravity is kind of [motion sensors](#) that allows you to detect motion of your smartphone. Useful for monitoring device movement, such as tilt, shake, rotation, or swing.

In order to accept data from it you need to:

```
BLYNK_WRITE(V1) {
    //force of gravity applied to axis x
    int x = param[0].asFloat();
    //force of gravity applied to axis y
    int y = param[1].asFloat();
    //force of gravity applied to axis y
    int z = param[2].asFloat();
}
```

Gravity doesn't work in background.

Humidity

Humidity is kind of [environment sensors](#) that allows you to measure ambient relative humidity.

Measured in % - actual relative humidity in percent.

In order to accept data from it you need to:

```
BLYNK_WRITE(V1) {
    // humidity in %
    int humidity = param.toInt();
}
```

Humidity doesn't work in background.

Light

Light is kind of [environment sensors](#) that allows you to measure level of light (measures the ambient light level (illumination) in lx). In phones it is used to control screen brightness.

In order to accept data from it you need to:

```
BLYNK_WRITE(V1) {
    //light value
    int lx = param.toInt();
}
```

Light doesn't work in background.

Proximity

Proximity is kind of [position sensors](#) that allows you to determine how close the face of a smartphone is to an object. Measured in cm - distance from phone face to object. However most of this sensors returns only FAR / NEAR information. So return value will be 0/1. Where 0/LOW is FAR and 1/HIGH is NEAR .

In order to accept data from it you need to:

```
if (proximity) {
    //NEAR
} else {
    //FAR
}
```

Proximity doesn't work in background.

Temperature

Temperature is kind of [environment sensors](#) that allows you to measure ambient air temperature.

Measured in °C - celcius.

In order to accept data from it you need to:

```
BLYNK_WRITE(V1) {
    // temperature in celcius
    int celcius = param.asInt();
}
```

Temperature doesn't work in background.

GPS Trigger

GPS trigger widget allows easily trigger events when you arrive to or leave from some destination. This widget will work in background and periodically will check your coordinates. In case your location is within/out required radius (selected on widget map) widget will send HIGH / LOW command to hardware. For example, let's assume you have GPS Trigger widget assigned to pin V1 and option

Trigger When Enter . In that case when you'll arrive to destination point widget will trigger HIGH event.

```
BLYNK_WRITE(V1) {
    int state = param.asInt();
    if (state) {
        //You enter destination
    } else {
        //You leave destination
    }
}
```

More details on how GPS widget works you can read [here](#).

GPS trigger widget works in background.

GPS Streaming

Useful for monitoring smartphone location data such as latitude, longitude, altitude and speed (speed could be often 0 in case smartphone doesn't support it).

In order to accept data from this widget you need to:

```
float longitude = param[1].asFloat(),
float altitude = param[2].asFloat();
float speed = param[3].asFloat();
}
```

or you can use prepared wrapper `GpsParam` :

```
BLYNK_WRITE(V1) {
    GpsParam gps(param);
    // Print 6 decimal places for Lat
    Serial.println(gps.getLatitude(), 7);
    Serial.println(gps.getLongitude(), 7);

    Serial.println(gps.getAltitude(), 2);
    Serial.println(gps.getSpeed(), 2);
}
```

GPS Streaming works in background.

Sketch: [GPS Stream](#)

Other Bridge

Bridge can be used for Device-to-Device communication (no app. involved). You can send digital/analog/virtual write commands from one device to another, knowing it's auth token. At the moment Bridge widget is not required on application side (it is mostly used for indication that we have such feature).

You can use multiple bridges to control multiple devices.



Bridge widget takes a virtual pin, and turns it into a channel to control another device. It means you can control any virtual, digital or analog pins of the target device. Be careful not to use pins like A0, A1, A2 ... when communicating between different device types, as Arduino Core may refer to wrong pins in such cases.

Example code for device A which will send values to device B:

```
WidgetBridge bridge1(V1); //Initiating Bridge Widget on V1 of Device A
...
void setup() {
    Blynk.begin(...);
    while (Blynk.connect() == false) {
```

```

bridge1.virtualWrite(V1, "hello"); // you need to write code on Device B in order to receive this value.
bridge1.virtualWrite(V2, "value1", "value2", "value3");
}

BLYNK_CONNECTED() {
    bridge1.setAuthToken("OtherAuthToken"); // Token of the hardware B
}

```

IMPORTANT: when performing `virtualWrite()` with Bridge Widget, Device B would need to process the incoming data from Device A. For example, if you are sending value from Device A to Device B using `bridge.virtualWrite(V5)` you would need to use this handler on Device B:

```

BLYNK_WRITE(V5){
    int pinData = param.asInt(); //pinData variable will store value that came via Bridge
}

```

Keep in mind that `bridge.virtualWrite` doesn't send any value to mobile app. You need to call `Blynk.virtualWrite` for that.

Sketch: [Bridge Eventor](#)

Eventor widget allows you to create simple behaviour rules or **events**. Let's look at a typical use case: read temperature from DHT sensor and send push notification when the temperature is over a certain limit:

```

float t = dht.readTemperature();
if (isnan(t)) {
    return;
}
if (t > 40) {
    Blynk.notify(String("Temperature is too high: ") + t);
}

```

With Eventor you don't need to write this code. All you need is to send the value from the sensor to the server:


```

float t = dht.readTemperature();
Blynk.virtualWrite(V0, t);

```

Don't forget that `virtualWrite` commands should be wrapped in the timer and can't be used in the main loop.

Now configure new **Event** in Eventor widget:




NOTE Don't forget to add notification widget.

Eventor comes handy when you need to change conditions on the fly without re-uploading new sketch on the hardware. You can create as many **events** as you need. Eventor also could be triggered from the application side. You just need to assign the widget to the same pin as your Event within Eventor. Eventor doesn't constantly sends events. Let's consider simple event as above `if (temperature > 40) send notification`. When temperature goes beyond 40 threshold - notification action is triggered. If temperature continues to stay above the 40 threshold no actions will be triggered. But if `temperature` goes below threshold and then passes it again - notification will be sent again (there is no 5 sec limit on Eventor notifications).

Eventor also supports Timer events. For example, you can set a pin `V1 ON/HIGH at 21:00:00 every Friday`. With Eventor Time Event you can assign multiple timers on same pin, send any string/number, select days and timezone.

In order to remove created **event** please use swipe. You can also swipe out last element in the Event itself.

NOTE: The timer widget rely on the server time and not your phone time. Sometimes the phone time may not match the server time. **NOTE:** Events are triggered only once when the condition is met. That's mean [chaining of events](#) is not possible (however, could be enabled for commercials).




Sketch: [Eventor](#)

NOTE: Events are triggered only once when the condition is met. Exception: Let's consider simple event as above `if (temperature > 40) send notification`. When temperature goes beyond 40 threshold - notification action is triggered. If temperature continues to stay above the 40 threshold no actions will be triggered. But if `temperature` goes below threshold and then passes it again - notification will be sent again (there is no 5 sec limit on Eventor notifications).

RTC

Real-time clock allows you to get time from server. You can preselect any timezone on UI to get time on hardware in required locale. No pin required for RTC widget.



Sketch: [RTC](#)
[BLE](#)

Blynk currently supports a handful of different BLE modules. Please check sketches below.

Sketches: [BLE](#) [Bluetooth](#)

Widget to enable Bluetooth support. At the moment Bluetooth widget is supported only on Android and requires internet connection to login and to load your profile. This will be fixed soon. Alsom some Blynk widgets do not work within the Bluetooth connection.

Blynk currently supports bunch of different modules. Please check sketches below.

Sketches: [Bluetooth](#) [Music Player](#)

Simple UI element with 3 buttons with common music player controls. Every button sends it's own command to hardware: `play` , `stop` , `prev` , `next` .

You can change widget state within the app from hardware side with next commands:

```
Blynk.virtualWrite(Vx, "play");
Blynk.virtualWrite(Vx, "stop");
```

You can also change widget play/stop state with next code (equivalent to above commands):

```
Blynk.setProperty(V1, "isOnPlay", "false");
```

Sketch: [Music Player](#) [Webhook](#)


Webhook is a widget designed to communicate with 3rd party services. With Webhook widget you can send HTTP(S) requests to any 3rd party service or device that has HTTP(S) API (e.g. Philips Hue bulb). You can trigger 3-d party service with a single click of a button.

Any `write` operation from hardware side will trigger Webhook Widget. You can also trigger webhook from Blynk app when a app widget is assigned to the same pin as Webhook.

For example, when you need to send data from your hardware not only to Blynk, but also to Thingspeak, you would need to write a long http request code like this (this is just an example, not a full sketch):

```
WiFiClient client;
if (client.connect("api.thingspeak.com", 80)) {
    client.print("POST /update HTTP/1.1\n");
    client.print("Host: api.thingspeak.com\n");
    client.print("Connection: close\n");
    client.print("X-THINGSPEAKAPIKEY: " + apiKeyThingspeak1 + "\n");
    client.print("Content-Type: application/x-www-form-urlencoded\n");
    client.print("Content-Length: ");
```

Instead, with Webhook widget you would only need to fill in these fields:



And add this code on hardware side:

```
Blynk.virtualWrite(V0, value);
```

where `V0` is pin assigned to the Webhook widget.

Use standard Blynk placeholders for Pin Value in the body or URL, for example:

```
https://api.thingspeak.com/update?api_key=xxxxxx&field1=/pin/
```

or for the body

```
["/pin/"]
```

When you need to send an array of values, you can refer to a specific index of the array value. Blynk Pin can hold an array of max 10 values:

```
/pin[0]/ , /pin[1]/ , /pin[2]/
```

You can also make GET requests from Blynk Server and get responses directly to your hardware.

To parse the response on the hardware side:

```
BLYNK_WRITE(V0){
    String webhookdata = param.asStr();
    Serial.println(webhookdata);
}
```

Now, every time there is a “write” command to `V0` pin (e.g. with `Blynk.virtualWrite(V0, 1)` from hardware or from app widget assigned to `V0`), `BLYNK_WRITE(V0)` construction will be triggered and processed.

NOTE: Usually, 3rd party servers return long responses. You have to increase the maximum allowed message size your hardware can process. Modify this line in your firmware code:

```
#define BLYNK_MAX_READBYTES 1024 . Where 1024 - is maximum allowed message size.
```

NOTE: Blynk Cloud has limitation for Webhook Widget - you can only send 1 request per second. This can be changed on a Local Server by changing `webhooks.frequency.user.quota.limit`. Be careful with Webhooks, as many 3rd party services can't handle 1 req/sec, and you can be banned on some of them. For example, Thingspeak allows only 1 request per 15 seconds.

NOTE: To avoid spamming, Blynk Webhook feature has another limitation - if your Webhook requests fail 10 times in a row, Webhook Widget will be stopped. To resume it, you would need to open Widget Settings and re-save it. Failed request is a request that doesn't return `200` or `302`.

NOTE: Webhook widget may affect `Blynk.syncAll()` function when a returned response is large.
Reports Widget

Function of Reports is to configure and customize data reports in CSV format. You can choose between one-time or continuous scheduled reports.

Also, within the Reports you can clear all the data collected by your devices.

You need to configure initial inputs in Edit mode, and then, in Play mode you will be able to customize reports.

Edit mode. Data inputs configuration

In edit mode (when your project is stopped) you define the Datastreams you would like to later be included in reports. Reports widget is designed to work with the Device Tiles widget. If you don't use Device Tiles you can still select a single device or a group of devices as a source of data for reports.

You have to choose either Device Tiles or single / group of the devices for the report. You can't combine these 2 options.

After you added source devices and their Datastreams click Play button and click on the Reports button.

Customizing Reports.

Every Report option supposes its own settings:

Report name - give your report a meaningful name.

Data source - select the Datastreams you would like to be included in reports.

Report Frequency - Defines how often reports will be sent. They can be one-time and scheduled.

one-time - will instantly generate report and send it to the email addresses specified. Click on the right icon to send it.

Scheduled reports can be sent **daily / weekly / monthly**.

At Time will set up a time of the day the report will be sent. **Start / End** specifies start and end date the reports will continue to be sent.

For Weekly Report you can select a day of the week when report should be sent. For Monthly report you can choose whether to send report on the first or last day of the month.

Recipients - specify up to 5 email addresses.

Data resolution defines granularity of your reports. Supported granularities are: **minute**, **hourly** and **daily**. For example, when you generate daily report with 1 minute granularity you'll get **24 * 60 * 60** points in your daily report for every selected Datastream.

Group data in reports by - specify the output format of the CSV file(s).

Datastream you will get 1 CSV file for each Datastream.

Device you will get 1 CSV file per each device. Each file will contain all of the included Datastreams.

Report you will get 1 CSV file for all your devices and all your Datastreams.

Timezone correction - specify the time zone adjustment if you need to get report date and time adjusted to a specific time zone

Date and time format - defines the format of the timestamp field of your data. You can select **2018-06-21 20:16:48**, **2018-06-21T20:16:48+03:00** or other supported formats.

There is one specific **Timestamp** format - which reflects the difference between the current time and midnight, January 1, 1970 UTC measured in milliseconds.

After the report is set up - click on "OK" button at the right upper corner. Your report is ready.

After the report was sent at least once, you can see when the `Last` report was sent.

`Last` label also contains the status regarding the report:

- `OK` : the report was generated and sent to the Recipients successfully;
- `No Data` : the report doesn't contain any data for the configured period;
- `Error` : something went wrong. Please contact the Blynk Team support;

Reports will be generated even if your project is not in active (Play) mode. However, inactive projects don't generate any data.

NOTE: all reports are encoded in UTF-16. Please, make sure you selected UTF-16 as required "Character set" for your csv reader.

Sharing

Blynk offers two types of sharing your projects with other people:

- **Share access to your hardware.** Think about giving someone an App for your Project. They can't modify, but can control and see what's there.
- **Share your Project configuration.** Others will get a clone of your project by scanning a given QR link, but they won't be able to control your hardware. It's great for tutorials, instructables, etc.


Shared access to your hardware

Imagine giving someone an App to control your Project.


- people you've shared your project with can't modify anything. They can only use it
- you can update your app, change the layout, add widgets and it's immediately synced to everyone
- you can revoke access at any moment

How it works: - you send the QR code to your users (you can email, print, post to social media, do whatever you want) - others download Blynk app, scan the QR code and your app opens for them ready to use. They don't even need to login or create an account.

Go to your Project's Settings:



Click on "Generate Link" button :




It will generate QR code you can share with others:



That's it! Now **Exit the settings and press PLAY button.**

Another person would need to install Blynk app and scan QR code from the login screen (scanning from existing profile is not yet supported) ;




NOTE: Your Project should be active, don't forget to press Play button.


WARNING: Sharing costs 1000 energy and this energy is not recoverable even you didn't use sharing at all.

Share your Project configuration


In Project's Settings go to **Clone** button.



It will generate QR code you can share with anyone.



Another person **should Log In to Blynk app** and press QR button in Projects gallery



After the scan, a new Project will be created, all the widgets, settings, layout will be cloned. Another person would need enough Energy Balance to clone your Project.

Auth Token will be different! Nobody will get access to your hardware. They just get a copy of the layout and settings.

HTTP RESTful API

Blynk HTTP RESTful API allows to easily read and write values of Pins in Blynk apps and Hardware. API description can be found [here](#). **Warning:** Blynk HTTP API still has GEO DNS issue. This means, for now you need to use direct server IP instead of hostname in order to make it work with 3-d party services like IFTTT.

Supported Hardware

Attention! This documentation is for the LEGACY version of Blynk platform which is no longer supported.

Please check out the [new documentation](#)

Blynk supports more than 400 boards already, including support for Arduino, Particle, ARM mbed, TI Energia, MicroPython, Node.js, OpenWRT and many Single Board Computers. You can add your own connection types easily (see [these](#) examples for Arduino)!

Platforms

- **Arduino** (<https://github.com/blynkkk/blynk-library>)
 - Arduino MKR WiFi 1010
 - Arduino MKR GSM 1400
 - Arduino MKR NB 1500
 - Arduino Uno, Duemilanove
 - Arduino Nano, Mini, Pro Mini, Pro Micro, Due, Mega
 - Arduino 101 (Intel Curie, with BLE)
 - Arduino MKR1000
 - Arduino Zero
 - Arduino Yún (onboard WiFi and Ethernet, via Bridge)
 - Arduino.org Uno WiFi
 - Arduino MKR VIDOR 4000 (use the example for MKR WiFi 1010)
 - Arduino Uno WiFi Rev.2 (use the example for MKR WiFi 1010)
- **Arduino-like**
 - Blynk Board
 - ESP8266 (Generic, NodeMCU, Witty Cloud, Huzzah, WeMos D1, Seeed Wio Link, etc.)
 - ESP32 (WiFi, BLE)
 - Nordic nRF51/nRF52 - based boards
 - Teensy 3.2/3.1
 - Blue Pill (STM32F103C)
 - Realtek RTL8710 / Ameba via [RTLduino](#)
 - BBC micro:bit
 - LightBlue Bean , *soon*
 - DFRobot Bluno
 - RedBear Duo (WiFi, BLE)
 - RedBearLab Blend Micro
 - RedBearLab BLE Nano (v1 and v2)
 - Seeed Tiny BLE
 - Simblee BLE
 - RFduino BLE
 - The AirBoard (BLE-Link, RN-XV)
 - Feather M0 WiFi
 - Feather 32u4 BLE
 - Intel Edison
 - Intel Galileo
 - Fishino Guppy, Uno, Mega
 - TinyCircuits TinyDuino (CC3000)
 - Microduino/mCookie Core, Core+, CoreUSB
 - Wicked WildFire V2, V3, V4
 - Digistump Oak
 - chipKIT Uno32

- Texas Instruments
 - CC3220SF-LaunchXL
 - CC3200-LaunchXL
 - Tiva C Connected LaunchPad
 - Stellaris LM4F120 LaunchPad
 - MSP430F5529 + CC3100
 - LaunchPad MSP432
- RedBearLab (CC3200, WiFi Mini)
- Particle <https://github.com/vshymanskyy/blynk-library-spark>
 - Core
 - Photon
 - Electron
 - RPi
 - SparkFun RedBoard
 - RedBear Duo (WiFi & BLE)
- ARM mbed (<https://developer.mbed.org/users/vshymanskyy/code/Blynk/>)
 - Seeed Tiny BLE
 - RedBearLab BLE Nano
 - BBC micro:bit
 - STM32 Nucleo + Wiznet 5100 , *soon*
- JavaScript (Node.js, Espruino, Browsers) (<https://www.npmjs.com/package/blynk-library>)
 - Regular PC with Linux / Windows / OS X
 - Raspberry Pi (Banana Pi, Orange Pi, ...)
 - BeagleBone Black
 - Onion Omega
 - Onion Omega 2
 - Intel Galileo
 - Intel Edison
 - Intel Joule
 - LeMaker Guitar
 - LeMaker Banana Pro
 - Samsung ARTIK 5
 - PandaBoard, CubieBoard, pcDuino, Tessel 2
 - VoCore, VoCore2 (OpenWRT + [Espruino package](#))
 - Espruino Pico
 - ...
- Python (<https://github.com/vshymanskyy/blynk-library-python>)
 - MicroPython
 - Python 2

- NodeMCU

Arduino connection types

- USB (Serial), connected to your laptop or desktop
- **Ethernet**
 - Arduino MKR ETH
 - Arduino Ethernet Shield (W5100)
 - Arduino Ethernet Shield 2 (W5500)
 - SeeedStudio Ethernet Shield V2.0 (W5200)
 - ENC28J60-based modules
- **WiFi**
 - ESP8266 as WiFi modem (running original firmware)
 - Arduino WiFi 101 Shield
 - Arduino WiFi Shield
 - WIZnet WizFi310
 - Adafruit CC3000 WiFi Breakout / Shield
 - RN-XV WiFly
- **Bluetooth Smart (BLE 4.0)**
 - HM-10, HC-08
 - DFRobot BLE-Link module
 - Microduino/mCookie BLE
 - RedBearLab BLE Mini
 - nRF8001-based boards (Adafruit Bluefruit LE, etc.)
- **Bluetooth 2.0 Serial Port Profile (SPP)**
 - HC-05, HC-06, ...
- **Cellular (GSM/3G/LTE)**
 - SIMCom SIM800 series (SIM800A, SIM800C, SIM800L, SIM800H, SIM808, SIM868)
 - SIMCom SIM900 series (SIM900A, SIM900D, SIM908, SIM968)
 - A6/A7
 - M590
 - BG96
 - GPRSbee
 - Microduino GSM
 - Adafruit FONA (Mini Cellular GSM Breakout)
 - Adafruit FONA 800/808 Shield

Made by Community

- [Marvell® EZ-Connect™ MW300/MW302](#)
- [WIZnet-W5500-EVB](#)
- [LabVIEW](#)
- [Node-RED](#) (can be used as bridge to HTTP, TCP, UDP, MQTT, XMPP, IRC, OSC...)

Problematic Boards

These boards are not supported and do not work out of the box: - [Arduino Tian](#)

Here is a list of [known library issues](#)

Troubleshooting

Connection

If you experience connection problems, follow these steps:

1. Check that your hardware, wires, cables and power supply are good quality, not harmed or damaged, etc.
Use high power USB cables and USB ports.
2. Check your wiring using the examples (TCP/HTTP Client or similar) **provided with your shield and hardware.**
 - Once you understand how to manage connection, it's much easier to use Blynk.
3. Try running command `telnet blynk-cloud.com 80` from your PC, connected to the same network as your hardware. You should see something like: `Connected to blynk-cloud.com.` .
4. Try running Blynk default examples for your platform **without modifications** to see if it is working.
 - Double-check that you have selected **the right example** for your connection type and hardware model.
 - Our examples come with **comments and explanations. Read them carefully.**
 - Check that your Auth Token is valid (copied from the App and **doesn't contain spaces, etc.**)
 - If it doesn't work, try looking into [serial.debug.prints](#).
5. Done! Add your modifications and functionality. Enjoy Blynk!

[configuration](#) example.

WiFi network connection

If you encounter WiFi connection problems, please check these pitfalls:

- You're trying to connect to "WPA & WPA2 Enterprise" network (often used in offices), and your shield does not support this security method
- Your WiFi network has a login page that requests entering an access token (often used in restaurants)
- Your WiFi network security disallows connecting alien devices completely (MAC filtering, etc)
- There is a firewall running. Default port for hardware connections is 80 (8080 on the Local Server). Make sure it's open.

Delay

If you use long `delay()` or send your hardware to sleep inside of the `loop()` expect connection drops and downgraded performance.

DON'T DO THAT:

```
void loop()
{
...
delay(1000); // this is long delay, that should be avoided
other_long_operation();
...
Blynk.run();
}
```

Note: This also applies to the BLYNK_READ & BLYNK_WRITE handlers!

IMPORTANT:

This documentation is for the LEGACY version of Blynk platform which is no longer supported and will be shut down.

You can sign up for the current version of Blynk platform [here](#).

The new mobile apps can be downloaded from [App Store](#) and [Google Play](#).

The actual Blynk documentation is [here](#).

When `Blynk.virtualWrite` is in the `void loop`, it generates hundreds of "writes" per second

```
{
  Blynk.virtualWrite(1, value); // This line sends hundreds of messages to Blynk server
  Blynk.run();
}
```

SOLUTION: If you need to perform actions in time intervals - use timers, for example [BlynkTimer](#).

Using `delay()` will not solve the problem either. It may cause [another issue](#). Use timers!

If sending hundreds of requests is what you need for your product you may increase flood limit on local server and within Blynk library. For local server you need to change `user.message.quota.limit` property within `server.properties` file :

```
#100 Req/sec rate limit per user.
user.message.quota.limit=100
```

For library you need to change `BLYNK_MSG_LIMIT` property within `BlynkConfig.h` file :

```
//Limit the amount of outgoing commands.
#define BLYNK_MSG_LIMIT 20
```

Enable debug

To enable debug prints on the default Serial, add this on the top of your sketch (**it should be the first line in your sketch**):

```
#define BLYNK_DEBUG // Optional, this enables lots of prints
#define BLYNK_PRINT Serial
```

And enable serial in `void setup() :`

```
Serial.begin(9600);
```

You can also use spare Hardware serial ports or SoftwareSerial for debug output (you will need an adapter to connect to it with your PC).

Note: enabling debug mode will slow down your hardware processing speed up to 10 times.


Geo DNS problem

Reset password

On login screen click on "Forgot password?" label and than type your email and **Send** button. You'll get instruction on your email.

Android reset password flow

1. Open instruction email from your smartphone or tablet;
2. Click on "Reset now" button in your email;
3. Click on Blynk icon in below popup and reset the pass:



Security

Blynk server has 5 ports open for different security levels.

- 80 - plain TCP connection for the hardware (no security)
- 8080 - plain TCP connection for hardware (no security)
- 443 - SSL/TLS connection for the Mobile Apps and hardware with SSL
- 9443 - SSL/TLS connection for the Mobile Apps and hardware with SSL

Hardware may select to connect to 443 (9443) or 80 (8080), depending on it's capabilities. Connection between the app and the server is always done through SSL/TLS, so it is always secured. Connection between the hardware and server depends on your hardware capabilities.

Use Local Blynk Server

Local Blynk Server is no longer supported.

Use SSL gateway

Most platforms are not capable to handle SSL, so they connect to 80. However, our [gateway script](#) can be used to add SSL security layer to communication.

```
./blynk-ser.sh -f SSL
```

This will forward all hardware connections from 9443 port to the server via SSL gateway. You can run this script on your Raspberry Pi, desktop computer, or even directly on your router!

Note: when using your own server, you should overwrite the bundled server.crt certificate, or specify it to the script using `--cert` switch:

```
./blynk-ser.sh -f SSL -s <server ip> -p 9443 --cert=<certificate>.crt
```

Flag `-f SSL` is enabled by default for USB communication so you don't have to explicitly declare it.

Note: SSL is supported by the gateway only on Linux/OSX for now

If you want to skip SSL, and connect to TCP, you can also do that:

```
./blynk-ser.sh -t TCP
```

OTA

Blynk also supports over the air updates for - ESP8266, NodeMCU and SparkFun Blynk boards. OTA supported only for the private servers and for the paid customers for now.

How does it work?

- You need to use [regular sketch for exported apps](#);
- After you launched your hardware you are ready for OTA;

-
2. User provides within HTTPS request admin credentials and firmware binary file to update hardware with;
 3. When hardware connects to server - server checks it firmware. In case, hardware firmware build date differs from uploaded firmware, than server sends special command to hardware with url for the new firmware;
 4. Hardware processes url with below [handler](#):

```
LYNK_WRITE(InternalPinOTA) {
    //url to get firmware from. This is HTTP url
    //http://localhost:8080/static/ota/FUp_2441873656843727242_upload.bin
    overTheAirURL = param.asString();
    ...
}
```

1. Hardware downloads new firmware and starts flashing firmware;

Trigger update for the specific hardware

```
curl -v -F file=@Template_ESP8266.ino.nodemcu.bin --insecure -u admin@blynk.cc:admin https://localho
```

- Template_ESP8266.ino.nodemcu.bin - is relative (or full) path to your firmware;
- --insecure flag for servers with self-generated certificates. You don't need this flag if you used Let's Encrypt or other trusted certificates;
- admin@blynk.cc:admin admin credentials to your server. This is default ones. Format is username:password . You can change it in server.properties file;
- token is token of your hardware you want apply the firmware update to. The firmware update will be initiated only in case device is online;

Trigger OTA for all devices

Update for all devices will be triggered only when they are connected to the cloud. You need to remove the token part for that.

```
curl -v -F file=@Template_ESP8266.ino.nodemcu.bin --insecure -u admin@blynk.cc:admin https://localho
```

In that case, OTA will be triggered right after device connected to the server. In case device is online firmware update will be initiated only when device will be connected again.

Trigger OTA for the specific user

In that case firmware update will be triggered for all devices of specified user.

```
curl -v -F file=@Template_ESP8266.ino.nodemcu.bin --insecure -u admin@blynk.cc:admin https://localhost:9443/admin/ota/start
```

Trigger OTA for specific user and project

In that case firmware update will be triggered for all devices of specified user within specified project.

```
curl -v -F file=@Template_ESP8266.ino.nodemcu.bin --insecure -u admin@blynk.cc:admin https://localhost:9443/admin/project/1/ota/start
```

Stop OTA

```
curl -v --insecure -u admin@blynk.cc:admin https://localhost:9443/admin/ota/stop
```

How to make firmware

In order to make firmware in Arduino IDE - go to menu: Sketch -> Export compiled Binary.

NOTE: ESP8266 right now takes firmware only via HTTP. And not HTTPS.

Blynk server

No longer supported

Blynk Firmware

Configuration

Blynk.begin()

The easiest way to configure Blynk is to use `Blynk.begin()` :

```
Blynk.begin(auth, ...);
```

It has multiple parameters for different hardware models and it also depends on the type of connection. Follow the example sketches for your specific hardware model.

What happens inside of `Blynk.begin()` function:

1. Connection to the network (WiFi, Ethernet, ...)
2. Call of `Blynk.config(...)` to set Auth Token, Server Address, etc.
3. Attempts to connect to the server once (can block for more than 30s)

If your shield/connection type is not supported yet - you can implement it by yourself. [Here are some examples](#).

Blynk.config()

`config()` allows you to manage network connection. You can set up your connection type (WiFi, Ethernet, ...) by yourself, and then call:

```
Blynk.config(auth, server, port);
```

or just

```
Blynk.config(auth);
```

NOTE: After `Blynk.config(...)` is called, your hardware is not yet connected to the server. It will try to connect while until it hits first instance of `Blynk.run()` or `Blynk.connect()` routine.
To skip connecting to the server or to disconnect manually, call `Blynk.disconnect()` after configuration.

Use `connectWiFi` to conveniently set up WiFi connection:

```
Blynk.connectWiFi(ssid, pass);
```

To connect to open WiFi networks, set pass to an empty string (`""`).

Connection management

There are several functions to help with connection management:

if timeout have been reached. Default timeout is 30 seconds.

```
bool result = Blynk.connect();
bool result = Blynk.connect(timeout);
```

Blynk.disconnect()

Disconnects hardware from Blynk server:

```
Blynk.disconnect();
```

Blynk.connected()

Returns `true` when hardware is connected to Blynk Server, `false` if there is no active connection to Blynk server.

```
bool result = Blynk.connected();
```

Blynk.run()

This function should be called frequently to process incoming commands and perform housekeeping of Blynk connection. It is usually called in `void loop() {}`.

This command can be initiated it in other places of your code unless you run out of heap memory (in the cascaded functions with local memory).

For example, it is not recommended to call `Blynk.run()` inside of the `BLYNK_READ` and `BLYNK_WRITE` functions on low-RAM devices.

Digital & Analog pins control

Blynk library can perform basic pin IO (input-output) operations out-of-the-box:

```
digitalRead
digitalWrite
analogRead
analogWrite (PWM or Analog signal depending on the platform)
```

No need to write code for simple things like LED, Relay control and analog sensors. Just choose a corresponding Pin in Blynk app and control it directly with no additional code

Virtual pins control

Virtual Pins is a way to exchange any data between your hardware and Blynk app. Think about Virtual Pins as channels for sending any data. Make sure you differentiate Virtual Pins from physical GPIO pins

custom logic. The device can send data to the App using `BLYNK_WRITE(vPin, value)` and receive data from the App using `BLYNK_WRITE(vPIN)`. Read below

Virtual Pin data types

All Virtual Pin values are always sent as Strings and there are no practical limits on the data that can be sent.

However, there are certain limitations on the hardware side when dealing with numbers. For example, the integer on Arduino is 16-bit, allowing range -32768 to 32767.

To interpret incoming data as Integers, Floats, Doubles and Strings use:

```
param.toInt();
param.toFloat();
param.toDouble();
param.toString();
```

You can also get the RAW data from the param buffer:

```
param.getBuffer()
param.getLength()
```

Blynk.virtualWrite(vPin, value)

NOTE: Use `BlynkTimer` when you use this command to send data. Otherwise your hardware will be disconnected from the server

Send data in various formats to Virtual Pins.

```
// Send string
Blynk.virtualWrite(pin, "abc");

// Send integer
Blynk.virtualWrite(pin, 123);

// Send float
Blynk.virtualWrite(pin, 12.34);

// Send multiple values as an array
Blynk.virtualWrite(pin, "hello", 123, 12.34);

// Send RAW data
Blynk.virtualWriteBinary(pin, buffer, length);
```

Calling `virtualWrite` attempts to send the value to the network immediately.

Note: For virtual pins with numbers > 127, the `V128` syntax is not available. Please use plain virtual pin number, for example:

BlynkTimer

It's important to send data in intervals and keep the void loop() as clean as possible.

`BlynkTimer` allows you to send data periodically with given intervals not interfering with Blynk library routines. `Blynk Timer` inherits [SimpleTimer Library](#), a well known and widely used library to time multiple events on hardware. `BlynkTimer` is included in Blynk library by default and there is no need to install SimpleTimer separately or include `SimpleTimer.h`.

- A single `BlynkTimer` object allows to schedule up to 16 timers
- Improved compatibility with boards like `Arduino 101`, `Intel Galileo`, etc.
- When a timer struggles to run multiple times (due to a blocked `loop`), it just skips all the missed intervals, and calls your function only once. This differs from `SimpleTimer`, which could call your function multiple times in this scenario.

For more information on timer usage, please see: <http://playground.arduino.cc/Code/SimpleTimer>
And here is a `BlynkTimer` [example sketch](#).

Please also remember that a single `BlynkTimer` can schedule many timers, so most probably you need only one instance of `BlynkTimer` in your sketch.

BLYNK_WRITE(vPIN)

`BLYNK_WRITE` is a function called every time device gets an update of Virtual Pin value from the server (or app):

To read the received data use:

```
BLYNK_WRITE(V0)
{
    int value = param.asInt(); // Get value as integer

    // The param can contain multiple values, in such case:
    int x = param[0].asInt();
    int y = param[1].asInt();
}
```

`BLYNK_WRITE` can't be used inside of any loop or function. It's a standalone function.

Note: For virtual pins with numbers > 127, please use `BLYNK_WRITE_DEFAULT()` API
BLYNK_READ(vPIN)

`BLYNK_READ` is function called when device is requested to send its current value of Virtual Pin to the server. Normally, this function should contain `Blynk.virtualWrite` call(s).

```
BLYNK_READ(V0)
{
```

NOTE: For virtual pins with numbers > 127, please use `BLYNK_READ_DEFAULT()` API
BLYNK_WRITE_DEFAULT()

Redefines the handler for all pins that are not covered by custom `BLYNK_WRITE` functions.

```
BLYNK_WRITE_DEFAULT()
{
    int pin = request.pin;    // Which exactly pin is handled?
    int value = param.toInt(); // Use param as usual.
}
```

BLYNK_READ_DEFAULT()

Redefines the handler for all pins that are not covered by custom `BLYNK_READ` functions.

```
BLYNK_READ_DEFAULT()
{
    int pin = request.pin;    // Which exactly pin is handled?
    Blynk.virtualWrite(pin, newValue);
}
```

BLYNK_CONNECTED()

Use this function when you need to run certain routine when hardware connects to Blynk Cloud or private server. It's common to call sync functions inside of this function.


```
BLYNK_CONNECTED() {
// Your code here
}
```

BLYNK_APP_CONNECTED()

This function is called every time Blynk app client connects to Blynk server.

```
BLYNK_APP_CONNECTED() {
// Your code goes here
}
```

Note: Enable this feature in Project Settings first:




Example
BLYNK_APP_DISCONNECTED()

This function is called every time the Blynk app disconnects from Blynk Cloud or private server.

```
BLYNK_APP_DISCONNECTED() {
// Your code here
}
```

Note: Enable this feature in Project Settings first:



Example
Blynk.syncAll()

```
BLYNK_CONNECTED() {
    Blynk.syncAll();
}
```

Blynk.syncVirtual(vPin)

This command updates individual Virtual Pin to the latest stored value on the server. When it's used, a corresponding `BLYNK_WRITE` handler is called.

```
Blynk.syncVirtual(V0);
```

To update multiple pins, use:

```
Blynk.syncVirtual(V0, V1, V6, V9, V16);
```

Blynk.setProperty(vPin, "property", value)

This command allows [changing widget properties](#)

Debugging

```
#define BLYNK_PRINT Serial
```

To enable debug prints on the default Serial port add on the top of your sketch **IMPORTANT: This should be the first line in your code:**

```
#define BLYNK_PRINT Serial // Defines the object that is used for printing
#define BLYNK_DEBUG // Optional, this enables more detailed prints
```

Then enable Serial Output in setup():

```
Serial.begin(9600);
```

Open Serial Monitor and you'll see the debug prints.

You can also use spare Hardware serial ports or SoftwareSerial for debug output (you will need an adapter to connect to it with your PC).

WARNING: Enabling `BLYNK_DEBUG` will slowdown your hardware processing speed up to 10 times!

`BLYNK_LOG()`

When `BLYNK_PRINT` is defined, you can use `BLYNK_LOG` to print your logs. The usage is similar to `printf` :

```
BLYNK_LOG("This is my value: %d", 10);
```

```
BLYNK_LOG1("Hello World"); // Print a string
BLYNK_LOG1(10); // Print a number
BLYNK_LOG2("This is my value: ", 10); // Print 2 values
BLYNK_LOG4("Temperature: ", 24, " Humidity: ", 55); // Print 4 values
...
```

Minimizing footprint

To minimize the program Flash/RAM, you can disable some of the built-in functionality:

1. Comment-out `#define BLYNK_PRINT` to remove prints
2. Put on the top of your sketch:

```
#define BLYNK_NO_BUILTIN // Disable built-in analog & digital pin operations
#define BLYNK_NO_FLOAT // Disable float operations
```

Porting, hacking

If you want to dive into crafting/hacking/porting Blynk library implementation, please also check [this documentation](#).

FAQ

- I backed Blynk on Kickstarter. Where are my widgets and why the app is free?

App is free because otherwise you would have to pay to download it. This is how AppStore and Google Play works. Current Blynk release has a limited amount of widgets. We decided to make them free for everyone until we implement store. After that, every widget will be paid. However every backer will get them for free (according to their pledge).

- What is Blynk Cloud?

Blynk Cloud is a open-source software written on Java using plain TCP/IP and secured TCP/IP (for hardware that supports it) sockets and running on our server. Blynk iOS and Android apps connect to Blynk Cloud by default. Access is free for every Blynk user. We also provide a Private Server distribution for those who want to [install it locally](#).

- How much access to Cloud Blynk Server cost?

Yes. Those of you, who want extra security or don't have internet connection, can install Local Blynk Server and run it in your own local network. Blynk Server is Open-Source and it takes less than few seconds to deploy. All the instructions and files are [here](#).

- What are the requirements to run Private Blynk Server?

To run Private Blynk Server, all you need is Java Runtime Environment.

- Can I run Blynk server on Raspberry Pi?

Yes, surely! [Here is instruction.](#)

- Does Blynk app work over Bluetooth?

Yes. It is in beta right now.

- Does Blynk support Ethernet / Wi-Fi / UART?

Yes, all of them. See full list of [supported hardware](#) and shields.

- I don't have any shield. Can I use Blynk with my computer?

Yes, you can use Blynk just with a USB cable. There is a step-by-step [instruction](#) on how to do it.

- Can Blynk handle multiple Arduinos?

Yes. There 3 ways right now :

- add multiple devices to your project.
- you may use same [Auth Token](#) for different hardware. In that case you can control few hardwares from 1 dashboard.
- you can do it using [Bridge functionality](#) which allows you to send messages from one hardware to another.

- Does Blynk server store sensor data when app goes offline?

Yes, every command that hardware sends to server is stored. You could use [History Graph](#) widget in order to view it.

- How many Virtual Pins I can use?

It depends mostly on your hardware. Low-end hardware may use up to 32 Virtual Pins. More powerful (like ESP8266) can use up to 128 but it requires also BLYNK_USE_128_VPINS property in your sketch. [Example](#).

- Why app requires all this permissions?

<http://help.blynk.cc/faq/blynk-android-permissions-explained>

Links

- [Blynk site](#)
- [Blynk community](#)
- [Facebook](#)
- [Twitter](#)
- [Blynk Library](#)
- [Blynk Examples](#)
- [Blynk Server](#)
- [Kickstarter campaign](#)

License

This project is released under The MIT License (MIT)