

### INSTALLATION INSTRUCTIONS FOR

# ATLASGS60H

WARNING: Read the following carefully before attempting to install ore service this unit! Failure to do so may result in bodily injury, property and/or fixture damage. Retain this sheet for future reference.

#### **GENERAL DESCRIPTION**

This luminaire is designed for indoor and outdoor ceiling mounted application areas and is suitable for use in wet locations. It should not be installed in locations with limited ventilation or within enclosures with high ambient temperatures.

#### **WIRING NOTE:**

Some ATLAS models may have different wiring coming from the driver. Please refer to the color code chart below:

HOT = Brown or Black NEUTRAL = Blue or White GROUND = Green or green/yellow

## **Mounting Instructions**

- Using the mounting plate as a template, drill 4 holes for screws and a 1" hole for center wiring.
- Thread wiring through hole, and up through center hole of mounting plate.
- Insert Atlas housing screws through the 4 holes, sandwiching the ceiling between the Atlas and the mounting plate.
- 4. Secure the luminaire with the supplied hardware.

#### **ELECTRICAL CONNECTIONS**

Luminaires are factory wired for specific voltages. Make sure the supply voltage is compatible with the luminaire. Universal voltage luminaires may be used with any voltage between 120V and 277V.

#### **CAUTION:**

Please be sure to follow local electrical codes. Luminaires should only be installed by a qualified electrician.









