# AMBA Remap and Pause

Revision: r0p0

**Technical Reference Manual** 



# AMBA Remap and Pause Technical Reference Manual

Copyright © 1997 ARM Limited. All rights reserved.

#### **Release Information**

The following changes have been made to this book.

#### **Change History**

| Date       | Issue | Confidentiality | Change       |
|------------|-------|-----------------|--------------|
| April 1997 | C     | NonConfidential | Firs release |

#### **Proprietary Notice**

Words and logos marked with ® or ™ are registered trademarks or trademarks of ARM Limited in the EU and other countries, except as otherwise stated below in this proprietary notice. Other brands and names mentioned herein may be the trademarks of their respective owners.

Neither the whole nor any part of the information contained in, or the product described in, this document may be adapted or reproduced in any material form except with the prior written permission of the copyright holder.

The product described in this document is subject to continuous developments and improvements. All particulars of the product and its use contained in this document are given by ARM in good faith. However, all warranties implied or expressed, including but not limited to implied warranties of merchantability, or fitness for purpose, are excluded.

This document is intended only to assist the reader in the use of the product. ARM Limited shall not be liable for any loss or damage arising from the use of any information in this document, or any error or omission in such information, or any incorrect use of the product.

Where the term ARM is used it means "ARM or any of its subsidiaries as appropriate".

#### **Confidentiality Status**

This document is Non-Confidential. The right to use, copy and disclose this document may be subject to license restrictions in accordance with the terms of the agreement entered into by ARM and the party that ARM delivered this document to.

#### **Product Status**

The information in this document is final, that is for a developed product.

#### Web Address

http://www.arm.com

# Contents

# AMBA Remap and Pause Technical Reference Manual

| Chapter 1 | AMBA Remap and Pause |   |       |  |
|-----------|----------------------|---|-------|--|
|           | 1.1                  | About AMBA Remap and Pause                | . 1-2 |  |
|           | 1.2                  | Hardware Interface and Signal Description | . 1-0 |  |
|           | 1.3                  | Remap and Pause                           | . 1-  |  |
|           | 1 /                  | Roman and Pause Memory Man                | -1 (  |  |

Contents

# Chapter 1 **AMBA Remap and Pause**

This document provides information on the Remap and Pause module, which is connected to the Advanced Peripheral Bus (APB). It contains the following sections:

- About AMBA Remap and Pause on page 1-2
- Hardware Interface and Signal Description on page 1-3
- Remap and Pause on page 1-5
- Reset Memory Map on page 1-7

## 1.1 About AMBA Remap and Pause

The Reset and Pause module provides:

- defined boot behavior with power on reset detection
- wait for interrupt Pause mode
- an identification register.

Figure 1-1 shows the remap and pause block diagram.




Figure 1-1 Remap and Pause block diagram

## 1.2 Hardware Interface and Signal Description

The Remap and Pause module is connected to the APB bus. Table 1-1 describes the APB signals used and produced.

Table 1-1 APB signal descriptions

| Name   | Туре  | Source/<br>Destination         | Description  |
|--------|-------|--------------------------------|--|
| PA     | In    | APB Bridge                     | This is the peripheral address bus, which is used by individual peripherals for decoding register accesses to that peripheral. The addresses become valid before <b>PSTB</b> goes HIGH and remain valid after <b>PSTB</b> goes LOW.              |
| PD     | InOut | APB Peripherals, BD bus        | This is the bidirectional peripheral data bus. The data bus is driven by this block during read cycles (when <b>PWRITE</b> is LOW).  |
| PSTB   | In    | APB Bridge                     | This strobe signal is used to time all accesses on the peripheral bus. The falling edge of <b>PSTB</b> is coincident with the falling edge of <b>BCLK</b> .  |
| PWRITE | In    | APB Bridge                     | This signal indicates a write to a peripheral when HIGH and a read from a peripheral when LOW. It has the same timing as the peripheral address bus. It becomes valid before <b>PSTB</b> goes HIGH and remains valid after <b>PSTB</b> goes LOW. |
| PSEL   | In    | APB Bridge                     | When HIGH, this signal indicates that this module has been selected by the APB bridge. This selection is a decode of the system address bus. See the <i>AMBA Peripheral Bus Controller</i> for more details.                                     |
| Pause  | Out   | APB peripherals/external world | Pause signal. Module has entered Pause mode.   |
| ReMap  | Out   | Memory Controller              | Remap. Output that indicates that the reset memory map is in operation.  |
| NFIQ   | In    | Interrupt Controller           | NFIQ interrupt input from the interrupt controller.  |
| NIRQ   | In    | Interrupt Controller           | NIRQ interrupt input from the interrupt controller.  |
| BnRES  | In    | Reset Controller               | The active LOW bus reset signal.   |

### 1.2.1 APB write cycle

Writes to the Reset and Pause module are generated from the Peripheral Bus Controller Module. Figure 1-2 shows the Reset and Pause module APB write cycle.




Figure 1-2 Reset and Pause module APB write cycle

The access lasts for two cycles, starting in C1 and completing in C2. Pause can be reset by the **BnRES**, **NFIQ**, or **NIRQ** signals.

### 1.3 Remap and Pause

The remap and pause control is the combination of the following functions:

#### **Pause**

Defines a method of allowing the processor system to enter a low-power, wait for interrupt state, when the system does not require the processor to be active.

#### Identification

Provides an indication of the system configuration. *Identification* describes the minimum case, a single bit identification register.

#### Reset status

Provides an indication of the cause of the most recent reset condition. A minimum implementation is defined.

#### Reset memory map

Provides a method of overlaying the system base memory at reset.

#### 1.3.1 Pause

#### Pause register

Write-only. Writing to the Pause location causes the system to enter a wait for interrupt state.

The exact effect of writing to this location is not defined, but typically this would prevent the processor from fetching further instructions until the receipt of an interrupt or a power on reset. Further registers may be added to provide more sophisticated power-saving modes.

#### 1.3.2 Identification

**ID** register

Read-only. The ID register provides identification information about the system. Only a single-bit implementation (bit 0) is required, which is used to indicate if there is further ID information.

ID Bit 0 flag

Identification bit.

0 no further ID information

1 further ID information is available

If the bottom bit of the ID register is set, further bits are required to provide more detailed system identification information.

#### 1.3.3 Reset status

#### Reset Status register

Read-only. The Reset Status register provides the reset status. Only one bit of this register is defined in this specification and this is bit 0, which provides the power on reset status. Further bits in the reset status register may be implemented to provide more detailed reset information.

The status register has a dual mechanism for setting and clearing bits, allowing independent bits to be altered with no knowledge of the other bits in the register.

The single bit defined in this specification is the power on reset bit, which may be used to determine if the most recent reset was caused by initial power on, or if a warm reset has occurred.

#### POR Bit 0 flag

Power on reset bit.

0 no POR since flag was last cleared

1 POR

#### Reset Status Clear register

Write-only. This location is used to clear Reset Status flags. When writing to this register each data bit which is HIGH causes the corresponding bit in the Reset Status register to be cleared. Data bits which are LOW have no effect on the corresponding bit in the Reset Status register.

#### Reset Status Set register

Write-only. This location is used to set Reset Status flags. When writing to this register each data bit which is HIGH causes the corresponding bit in the Reset Status register to be set. Data bits which are LOW have no effect on the corresponding bit in the Reset Status register.

This register has no function in the minimal reference microcontroller specification, because the power on reset status bit cannot be set by software. This register is included in the specification to ensure expandability of the reset status functionality.

#### 1.3.4 Reset Memory Map

#### Clear Reset Map register

Write-only. Writing to the clear reset memory map location causes the system memory map to change from that required after reset, to that required during normal operation.

When the reset memory map has been cleared and the normal memory map is in use, there is no method of resuming the reset memory map, other than undergoing a power on reset condition.

A typical system implementation is to map the system ROM to location 0 at reset, but to change the memory map after reset, such that RAM is located at location 0 for normal operation. In a system where such remapping does not occur, writing to this register has no effect.

## 1.4 Remap and Pause Memory Map

The base address of the Remap and Pause controller memory is not fixed and can be different for any particular system implementation. However, the offset of any particular register from the base address is fixed. Table 1-2 shows the memory map of the remap and pause controller APB peripheral.

Table 1-2 Memory map of the remap and pause controller APB peripheral

| Address          | Read location  | Write location   |
|------------------|----------------|------------------|
| RemapBase        | -              | Pause            |
| RemapBase + 0x10 | Identification | -                |
| RemapBase + 0x20 | -              | ClearResetMap    |
| RemapBase + 0x30 | ResetStatus    | ResetStatusSet   |
| RemapBase + 0x34 | -              | ResetStatusClear |