




STEM Experience

© 2026 Quanser Inc., All rights reserved.



Quanser Inc.
119 Spy Court
Markham, Ontario
L3R 5H6
Canada

info@quanser.com
Phone: 19059403575
Fax: 19059403576
Printed in Markham, Ontario.

For more information on the solutions Quanser Inc. offers, please visit the web site at:
<http://www.quanser.com>


This document and the software described in it are provided subject to a license agreement. Neither the software nor this document may be used or copied except as specified under the terms of that license agreement. Quanser Inc. grants the following rights: a) The right to reproduce the work, to incorporate the work into one or more collections, and to reproduce the work as incorporated in the collections, b) to create and reproduce adaptations provided reasonable steps are taken to clearly identify the changes that were made to the original work, c) to distribute and publicly perform the work including as incorporated in collections, and d) to distribute and publicly perform adaptations. The above rights may be exercised in all media and formats whether now known or hereafter devised. These rights are granted subject to and limited by the following restrictions: a) You may not exercise any of the rights granted to You in above in any manner that is primarily intended for or directed toward commercial advantage or private monetary compensation, and b) You must keep intact all copyright notices for the Work and provide the name Quanser Inc. for attribution. These restrictions may not be waved without expressing prior written permission of Quanser Inc.

Table of Contents

Table of Contents	2
A. Description	3
B. Overview of System	4
QCar Interface	5
Infrastructure	6
C. Running the STEM Experience	6
Mat Layout & Roadway Walls	6
System Setup	6
Running the Controllers	8
Running the STEM Experience App (QLabs)	8
D. Setting Manual Driving	11
E. Race/Game Scenario	12
F. Peripherals	12
G. Troubleshooting	12

A. Description

The STEM Self-Driving Experience can support up to five (5) QCars that drive autonomously around a custom-designed roadway track pattern. The latest version of the roadway mat is pictured below. The QCars obey certain traffic rules defined for the track, such as stopping at the traffic light and not colliding with other QCars. The QCars will continue to drive and navigate around the track autonomously until a stop condition is encountered, such as having a hand or an object in front of it or another QCar being too close.




The Graphical Interface App, shown below, can connect and communicate with one QCar at a time. The *Do*, *See*, and *Think* tabs in the app allow the user to examine different aspects of Self-Driving Autonomy. [Each tab will have different interactive elements to affect the otherwise autonomous behavior of the connected QCar.] The user will also be able to enable manual driving mode to allow them to drive the car using a joystick/wheel as the input to help them understand the benefits of self-driving.]

Commented [TD1]: Added latest v23 mat layout

Commented [ML2]: We need a section that describes more about the App and each tab

Commented [ML3]: Tablets are not supplied or joystick/wheel are not supplied. This should be removed or modified.



The app shows the virtual environment that reflects the real-time status of each of the components in the systems, such as the traffic light status, the speed and position of the QCar on the track, and their corresponding battery levels. When the QCars are turned off and/or not connected to the Mission Server, that QCar will be shown at its default location at the side of the track.


Commented [ML4]: This has not been defined previously.

B. Overview of System

During normal operations, the QCars will:

- Steer based on detecting the selected color coded Pre-Defined Path as specified in the app.
- If not connected to Graphical Interface App, the car will randomly choose a path to follow and a speed to drive at to have some variability in the system.
- Adjust speed and keep a certain distance from other objects, such as another QCar.
- Go back to its followed Color coded Pre-Defined Path after minor collision.
- Speak when it is lifted.
- Produce different honk sounds when following different lanes.
- Turn on signal lights and break lights as appropriate.
- React to the traffic signs, such as the Stop and Slow signs.

QCar Interface



DO tab

- Adjust max speed and acceleration.
- Change the colour of the line to follow.
- Observe power consumption over a period of time.
- Monitor how different factors affect the consumption rate (e.g., speed, lights).
- Turn lights/indicators and horn.


SEE tab

- Live color image.
- Adjustable color filtering thresholds (MIN/MAX).
- Observe and compare results in real-time.

THINK tab

- Observe AI Classification in real-time.
- Monitor current state and request of QCar and how it changes when certain conditions are met.

Infrastructure



- Overall view/monitor and QCar connection status.
- Shows QCar localization on virtual map (i.e., where the QCars think they are).
- Switch between MANUAL and FULL AI mode.
- Error Indicators.

C. Running the STEM Experience

Mat Layout & Roadway Walls

Refer to the Mat Setup Guide to layout the mat segments and roadway walls to assemble the table. **The STEM Experience will not operate well without the roadway walls in place.**


System Setup

1. Power ON the router.
2. Connect the router to the laptop via Ethernet (e.g., using a USB to Ethernet adapter) or through Wi-Fi. The router broadcasts a Quanser_UVS-5G Wi-Fi. Each QCar is configured to automatically log-on to this Wi-Fi.
3. After the router has initialized, connect the traffic lights to the batteries and power on 1-5 QCars.
4. Ensure the connected QCars and traffic lights have appropriate IP address. For the cars, the IP addresses should be within the range from 192.168.X.11 to 192.168.X.15, and the IP addresses for the traffic lights should be 192.168.X.20, and 192.168.X.21, where "X" is dependent on the IP gateway of your router.


Device	IP Address
QCar 1	192.168.X.11
QCar 2	192.168.X.12
QCar 3	192.168.X.13
QCar 4	192.168.X.14
QCar 5	192.168.X.15
Traffic Light 1	192.168.X.20
Traffic Light 2	192.168.X.21

Refer to the *How to Setup Fixed IP Addresses* **Error! Reference source not found.** document to confirm or change the IP addresses of the devices.

- Place the cars following traffic order anywhere within the roadway. The recommended placement is shown below. **The cars will not localize properly if they do not start inside the table.**
- Place the two traffic lights in the designated areas on the roadway map. The map is labelled with the last two digits of their IP address, i.e., one for traffic light 192.168.X.20 and 192.168.X.21. Their orientation is shown below.



Commented [ML5]: We can have this as a separate router configuration Knowledge Base Article.



Running the Controllers


1. Ensure the `IP_GATEWAY` and `CAR_TYPE` in the **config.txt** file in the `\STEM_Interactive_Exhibit` folder is set correctly.
2. Before running the QCars for the first time, the reference scans must be transferred to the QCars. To automatically transfer the scans to the cars, follow the procedure below:
 - a. Run **transfer_scan.bat** located at: `STEM_Experience\Cars\Reference_Scans`.
 - b. When prompted, type "yes", then enter the password "nvidia" (two times).
 - c. Please see the `ReadMe.txt` file in the folder for more information.
3. Go to the `STEM_Experience\Infrastructure` folder and execute the **run_infrastructure_models.bat** file. See the `ReadMe.txt` file for more information, e.g., how to configure this to run on boot.
4. Go to the `STEM_Experience\Traffic Light` folder and execute the **run_all_traffic_light.bat** file. See the `ReadMe.txt` file for more information, e.g., how run this on boot.
5. Go to the `STEM_Experience\Cars` folder and execute the **run_car_model.bat** file. See the `ReadMe.txt` file for more information, e.g., how run this on boot.

Running the STEM Experience App (QLabs)


1. The QCar STEM Experience Graphical Interface App should be in a folder on your desktop. Locate the folder and double-click on the **QLabs.exe** application.



2. Select the **infrastructure** option to open the map. The QCars should be shown on the virtual map.




3. Open the app again and click on the **QCar interface**. That will open the application in full screen mode (to exit this press f11 in the keyboard).



4. On the top left corner above the **DO** tab, click on "SELECT CAR IN SETUP" or the cars number to enter the configuration menu.



5. This will prompt you for a password. The password is `STEM_table`. The password can be changed in the following screen, if desired.
6. In the configuration menu under communications, you can select which car to connect to. It's also possible to connect to multiple cars with additional laptops, tablets, or other computers running the App. For example, [if you have 3 tablets for 3 cars, select QCar 1 on one tablet, QCar 2 on the second one and so on]. The selected car will be saved, so this step will not need to be repeated when the system starts.



Commented [ML6]: We don't supply multiple tablets with the STEM Experience. This sentence is clear that we don't supply them, but we do have a few references to the them. We may end-users reach out and ask about this.

7. Edit the IP addresses to have the correct IP gateway ("192.168.1.X" or "192.168.2.X").
8. Ensure positions are correct in the **infrastructure** app display. It might take a few seconds after the car starts moving for the car position to be correct. If your cars were not on, it will hang in the "connecting" status. That will change once the cars are set up and turned on.

Warning: Never lift the car to place it in another position in the track, it could stop being able to localize properly. Moving a QCar by a small amount to one side (e.g., if it collided or did not behave correctly) is permissible.

9. Click on the START button for the QCar to start driving on the specified yellow, blue, or pink lane.

10. For any subsequent uses, just open the app on additional tablets or computers and the system will proceed with saved configurations.

D. Setting Manual Driving

To enable manual driving:


1. Open the App and go to the **infrastructure**.
2. Next to the cars, click on the **FULL AI** button next to the battery level of the QCar to toggle on **MANUAL**.



3. Once this is clicked, a new tab will appear on the car tablet all the way to the right named **DRIVE**. To use it, the car will need to be already following the yellow line. Once you are in this tab you will be able to start manual driving when clicking on the **ENABLE** button. This will stop the car in place and wait for the input to come from the joystick or wheel.

The manual driving has some assistance using the car's position with respect to the center of the lane. If the car is near the center of the lane (within a predefined threshold), the user has full autonomy of the car. The further away the car is from the center of the line beyond the predefined threshold, steering assistance will provide proportional correction. If the user drives too far from the lane, the car steers autonomously to prevent cars from driving all over the map. Once it is back in the driving area, the user can continue to drive the QCar manually.

This is shown in the image below. While the user is driving the car in the blue area, they have full autonomy. In the pink area, the steering assistance will proportionally correct the car based on how far from the centre of the lane they are. For everything outside the pink area, the car will only use autonomous steering until it is back inside the pink boundary.



E. Race/Game Scenario

1. Cars used for race/game scenario will need to be following the yellow lane which is selected on the app.
2. Once the cars are in the start position, click on the **Stop Car** button from the **DO** tab so it stops in the correct position.
3. Change to the **DRIVE** tab. Once the cars are stopped at the correct position, click on **Enable Manual** on both **infrastructure** and **QCar interface** Apps, and click on the **Start Car** button (in the DO tab where the Stop Car was pressed) so that the 'race' begins.
4. As the drivers drive along the roadway, their "score" will be calculated as an accumulated weighted sum of the distance traveled from the starting location (positive weight) and the "distance offset" of the car from the "yellow" center line (negative weight). This total "score" will be saturated at 0 (i.e., the score can only be positive, with 0 being the minimum score). If the cars run through an intersection without a green light, a fixed value will be subtracted from the total.]
5. After the "race" is started and as the car starts to move, the "score" will start to increase. If the car remains within a certain distance threshold from the "yellow" center line, their score will just be proportional to the distance traveled. If the car deviates beyond the "threshold" from the "yellow" center line, then a penalty (negative weighted value of the distance offset) will be applied to their score. Passing an intersection without a green light will also have a negative impact on the score.
6. Wherever the end position is, once the cars are there and the user stops driving, they can look at the score at completion.
7. The instantaneous value of these "scores" (or the "running total") is transmitted continuously as part of the data packet to the laptop. The score will be reset to zero when the "Enable Manual" drive button is toggled off.

Commented [ML7]: They are not supplied with tablets.

Commented [ML8]: Are the scores still being tabulated in the current App?

F. Peripherals

The STEM Experience includes one laptop to run the application. However, additional computers and accessories can also be used:

- The app can run on multiple devices (e.g., laptops or tablets), with each device connected to a different QCar.
- The app also supports certain game controllers such as the Logitech G920 Steering for manual driving.

G. Troubleshooting

1. QCar not running applications on boot properly:

Use QUARC "Monitor" app to connect to device by selecting "Target -> Remote" and type the IP of the QCar. After connected to the QCar, open the console by selecting "Console" and run the application manually by executing "**run_car_model.bat**".

- a. QUARC console showing "**video format not supported**" or "**camera not found or not supported**" error:

Unplug the RealSense camera cable and plug it back in then reboot the QCar. If this fails, replace the camera cable with a new one.

- b. QUARC console doesn't show any error, and the application runs properly:

The QCar might not have sufficient time to start up properly before running the application. Increase the **"INITIAL_WAIT"** variable in the config file then execute **"enable_run_on_boot_car_model.bat"** to deploy the changes.

- 2. Application does not run after executing the batch scripts:

Ensure the laptop and the devices are connected to the provided router. In addition, ensure the **"IP_GATEWAY"** variable is consistent with the IP gateway of connected network.

- 3. If the car LiDAR starts spinning but stops immediately, please turn the car off and turn it on again.
- 4. The application is running (LiDAR is spinning) but QCar is not moving:

Restart the infrastructure models by running **"stop infrastructure model"** and then **"run infrastructure model"** batch scripts.

© Quanser Inc., All rights reserved.



Solutions for teaching and research. Made in Canada.