VSR

Button Modes

	Light		Operation		Music Player		Admin

Operation	Press	Hold
9	Time Travel	Display mode: Pushwheel value
10	Play "key3.mp3"	Display mode: Temperature
4C	Play "key6.mp3"	Display mode: Speed

Music Player	Press	Hold
9	Previous song	Disable shuffle mode
10	Play / Stop	Enable shuffle mode
4C	Next song	Go to song #0

Admin	Press	Hold
9	Volume up	Display IP address
10	Volume down	**Re-activate** or **connect** WiFi
4C		Delete static IP and AP password

VSR

Commands from TCD/HA	
Select pushwheel display mode	8010
Select temperature display mode	8011
Select speed display mode	8012
Select volume level (00 - 19)	83xx
Set brightness level (00 - 15)	84xx
Music Player : Play / Stop	8005
Music Player : Previous Song	8002
Music Player : Next Song	8008
Music Player : Set folder number	805x
Music Player : Shuffle off	8222
Music Player : Shuffle on	8555
Music Player : Go to song 000	8888
Music Player : Go to song xxx	8888xxx
Play "keyX.mp3" (X = 1, 3, 4, 6, 7, 9)	800x
Play "keyX.mp3" (X = 1 - 9)	850x
Display current IP address	8090
Restart*	8064738
Delete static IP address*	8123456

Control through TCD requires BTTFN connection.

---

* Not through HA/MQTT