

WALLER®
Design of Shear Wall Buildings

A Postprocessor for ETABS®

by
Ashraf Habibullah

COPYRIGHT

The computer program WALLER and all associated documentation are proprietary and copyrighted products. Worldwide rights of ownership rest with Computers and Structures, Inc. Unlicensed use of the program or reproduction of the documentation in any form, without prior written authorization from Computers and Structures, Inc., is explicitly prohibited.

Further information and copies of this documentation may be obtained from:


Computers and Structures, Inc.
1995 University Avenue
Berkeley, California 94704 USA
Phone: (510) 845-2177
FAX: (510) 845-4096

© Copyright Computers and Structures, Inc., 1985 - 1991.

The CSI logo is a registered trademark of Computers and Structures, Inc.

WALLER and BTABS are registered trademarks of Computers and Structures, Inc.

MS-DOS is a registered trademark of Microsoft Corporation.



WALLER®

Design of Shear Wall Buildings

A Postprocessor for ETABS®

by
Ashraf Habibullah

Version 5.4
Revised July, 1992

Developed and written in U.S.A.

COPYRIGHT

The computer program WALLER and all associated documentation are proprietary and copyrighted products. Worldwide rights of ownership rest with Computers and Structures, Inc. Unlicensed use of the program or reproduction of the documentation in any form, without prior written authorization from Computers and Structures, Inc., is explicitly prohibited.

Further information and copies of this documentation may be obtained from:


Computers and Structures, Inc.
1995 University Avenue
Berkeley, California 94704 USA
Phone: (510) 845-2177
FAX: (510) 845-4096

© Copyright Computers and Structures, Inc., 1985 - 1991.

The CSI logo is a registered trademark of Computers and Structures, Inc.

WALLER and ETABS are registered trademarks of Computers and Structures, Inc.

MS-DOS is a registered trademark of Microsoft Corporation.



WALLER®

Design of Shear Wall Buildings

A Postprocessor for ETABS®

by
Ashraf Habibullah

COPYRIGHT

The computer program WALLER and all associated documentation are proprietary and copyrighted products. Worldwide rights of ownership rest with Computers and Structures, Inc. Unlicensed use of the program or reproduction of the documentation in any form, without prior written authorization from Computers and Structures, Inc., is explicitly prohibited.

Further information and copies of this documentation may be obtained from:

Computers and Structures, Inc.
1995 University Avenue
Berkeley, California 94704 USA
Phone: (510) 845-2177
FAX: (510) 845-4096

© Copyright Computers and Structures, Inc., 1985 - 1991.

The CSI logo is a registered trademark of Computers and Structures, Inc.

WALLER and ETABS are registered trademarks of Computers and Structures, Inc.

MS-DOS is a registered trademark of Microsoft Corporation.

DISCLAIMER

CONSIDERABLE TIME, EFFORT AND EXPENSE HAVE GONE INTO THE DEVELOPMENT AND DOCUMENTATION OF WALLER. THE PROGRAM HAS BEEN THOROUGHLY TESTED AND USED. IN USING THE PROGRAM, HOWEVER, THE USER ACCEPTS AND UNDERSTANDS THAT NO WARRANTY IS EXPRESSED OR IMPLIED BY THE DEVELOPERS OR THE DISTRIBUTORS ON THE ACCURACY OR THE RELIABILITY OF THE PROGRAM.

THE PROGRAM IS A VERY PRACTICAL TOOL FOR THE DESIGN OF CONCRETE AND MASONRY SHEAR WALL STRUCTURES. PREVIOUS VERSIONS OF THIS PROGRAM HAVE BEEN VERY SUCCESSFULLY USED ON A VARIETY OF BUILDINGS. HOWEVER, THE USER MUST THOROUGHLY READ THE MANUAL AND CLEARLY RECOGNIZE THE ASPECTS OF CONCRETE AND MASONRY DESIGN THAT THE PROGRAM ALGORITHMS DO NOT ADDRESS.

THE USER MUST EXPLICITLY UNDERSTAND THE ASSUMPTIONS OF THE PROGRAM AND MUST INDEPENDENTLY VERIFY THE RESULTS.

(

(

(

TABLE of CONTENTS

I. INTRODUCTION

II. SYSTEM PREPARATION and EXECUTION PROCEDURE

- A. Installing, Configuring and Testing II-2
- B. Input Preparation before
Executing WALLER II-2
- C. Executing the WALLER Program II-3

III. DESIGN ALGORITHMS

- A. Design Loading Combinations III-3
- B. Wall Design III-4
- C. Spandrel Design III-22
- D. Options for other Codes III-31

IV. INPUT DATA for PROGRAM WALLER

- A. Free Format IV-2
- B. Comment Data IV-2
- C. Arithmetic Operations IV-3
- D. Units IV-4
- E. ETABS Data Preparation Hints IV-4
- F. Detailed Description of the
WALLER Input Data IV-5
 - 1. Control Information IV-8
 - 2. Load Combination Definition Data . IV-15
 - 3. Material Property Replacement Data IV-21
 - 4. Section Property Redefinition Data . IV-26
 - 5. Frame Design Activation Data Sets . IV-52

V. PROGRAM OUTPUT

A. Description of Output Files	V-1
B. Design Overstresses and Failure Situations	V-4
C. Details of the Design Output Information	V-4

VI. REFERENCES

VII. SAMPLE EXAMPLE

(

(

(

I.

INTRODUCTION


WALLER is a concrete design postprocessor for the three-dimensional static and dynamic building analysis computer program ETABS [1].

The program is intended for the automated ACI code design [2,3] of shear wall structures that have been modeled for analysis using ETABS. Special seismic provisions in the ACI code and in the UBC91 [4] can be activated. An option for using the Canadian Concrete code [5] is also available. A typical shear wall system is shown in Figure I-1. The design is based upon user-specified loading combinations.

Most of the data required by WALLER for the design processing, i.e. material and section properties, member forces and geometry, is recovered directly from the ETABS data base. Therefore, the data input typically required by WALLER is very nominal and **if the program defaults are acceptable, no data input is required.**

The program options allow for the design of pier-spandrel systems, as well as isolated shear walls, including shear walls with special enlarged edge members. The program only designs planar portions of walls. It is important to utilize the ETABS option of separately obtaining the component forces on each planar portion of three-dimensional walls.

The walls (or piers) are designed for overturning moments and shear forces. The overturning effects may be processed in a



Typical Shear Wall System
Figure I-1

check mode or a design mode. In the check mode the user specifies the distribution of the steel across the wall section and the program will check the adequacy of the wall section based upon the generation of a load-moment interaction diagram.

In the design mode the program will develop the trim steel required by the wall, based upon the axial forces and overturning moments, using an approximate conservative iterative technique.

Every beam spandrel is designed for flexure and shear at five stations along the beam span.

The presentation of the output is in a format that not only allows the engineer to quickly study the stress conditions that exist in the structure but also aids the engineer in taking appropriate remedial measures in the event of member overstress. Backup design information, for convenient verification of the results produced by the program, is also provided.

Changes in structural member section properties are possible at the postprocessor level to study the effects of member changes without rerunning the ETABS analysis.

English as well as MKS metric and SI metric units are possible.

(

(

(

II.

SYSTEM PREPARATION and EXECUTION PROCEDURE

This chapter deals with the installation and execution of WALLER on an MS-DOS based computer system.

User familiarity with MS-DOS is assumed.

The complete WALLER package includes:

1. This manual
2. Floppy Disk, containing the following:
 - a. Program Executable, WALLER.EXE
 - b. Sample Test Data and Results

Note: The characters <CR> appear repeatedly in the text of this chapter. These characters mean "press the carriage return key." Do NOT type the characters <, C, R, and >.

A. INSTALLING, CONFIGURING and TESTING

The program provided must first be copied to the hard disk. The program and computer must then be configured before the program can be used. Follow the instructions in the SAP90/ETABS/SAFE Installation Guide (included with the ETABS package) for this procedure.

Before putting the system into a production mode, the user should test the system by running the sample example provided on the disk. The output files produced should be compared with the corresponding output files that are also provided on this disk.

B. INPUT PREPARATION before EXECUTING WALLER

WALLER is a postprocessor for the ETABS analysis program. Therefore, before running WALLER the user must generate an ETABS input data file and execute ETABS to create the ETABS postprocessing file.

Say that the ETABS data associated with the structure the user wishes to analyze has been prepared and entered into a data file called EXWAL. A successful execution of ETABS with the data file EXWAL will create a postprocessing file EXWAL.PST.

The user may then also prepare a WALLER input data file using the text editor EDLIN (or any other MS-DOS compatible editor). This data file must conform to the specifications detailed in Chapter IV of this manual. This data file is not required if all program defaults are acceptable. Sample data is provided

on the disk (filenames EXWAL for ETABS data and DESWAL for WALLER data) associated with the complete WALLER package.

C. EXECUTING the WALLER PROGRAM

This section explains how to execute the WALLER program.

Say that ETABS has been run using an input data file named EXWAL, to create the postprocessing file EXWAL.PST; and that the data associated with the design of this structure for the WALLER postprocessor has been prepared and entered into a data file called DESWAL. In order to execute the WALLER program, proceed as follows:

From the directory where the WALLER input data file is resident, enter the command:

C> WALLER <CR>

Note: the WALLER input data file and the ETABS postprocessing file, EXWAL.PST, must always exist in the same directory. The WALLER executable must also reside in the same directory unless a path to the WALLER executable has been activated using the MS-DOS PATH command.

After a few seconds the following banner will appear on the screen:

DESIGN OF CONCRETE SHEAR WALL BUILDINGS
VERSION 5.xx
BY
ASHRAF HABIBULLAH

Copyright (c) 1985-1992
COMPUTERS AND STRUCTURES, INC.
All rights reserved

hit it baby...<CR>

Enter <CR>

The program will then display a copyright notice followed by a prompt for the **WALLER** input data filename as follows:

THE USE OF THIS PROGRAM IS GOVERNED BY THE TERMS
OF A LICENSE AGREEMENT AND THE PROGRAM IS TO BE
USED ONLY BY AUTHORIZED LICENSEES.

UNAUTHORIZED USE IS UNETHICAL, UNPROFESSIONAL
AND IN VIOLATION OF FEDERAL COPYRIGHT LAWS.

ADDITIONAL INFORMATION MAY BE OBTAINED FROM

COMPUTERS AND STRUCTURES, INC.
1995 UNIVERSITY AVENUE
BERKELEY, CALIFORNIA 94724

(415) 845-2177

IT IS THE RESPONSIBILITY OF THE USER TO VERIFY
ALL RESULTS PRODUCED BY THIS PROGRAM.

ENTER "WALLER" INPUT DATA FILE NAME

Enter DESWAL <CR>

Note: if program defaults are acceptable and no WALLER input file is required, simply enter a <CR> above.

The program will then ask for the ETABS postprocessing file name as follows:

ENTER ETABS POSTPROCESSING FILENAME

Enter EXWAL.PST <CR>

Note: the postprocessing filename must have a .PST extension. If the user enters a filename with no extension, the program will append the .PST extension to the filename.

The program will then display the input and output filenames as follows:

INPUT DATA ----- DESWAL
ETABS POSTPROCESSING FILE --- EXWAL.PST
WALL/SPANDREL DESIGN ----- DESWAL.WAL
WALL DESIGN BACK-UP INFO --- DESWAL.WIN

<CR> TO CONTINUE

If all of the filenames are appropriate,

Enter <CR>

The program will go into execution mode and a series of progress messages will be flashed to the screen until the job has been completed. The job completion message will read

JOB COMPLETED . . . NO CHARGE!!!

The output files created by the program are explained in Chapter V. To print an output file the MS-DOS PRINT command may be used. Appropriate line counts and page ejects are built into the files.

III.

DESIGN ALGORITHMS

This chapter describes in detail the various aspects of the concrete design procedures that are used by the program WALLER.

Special terminology associated with the input and the output of the program is also described in the following sections.

An engineering background in the general area of multistory reinforced concrete design and user familiarity with References [2] and [3], or [4] or [5] is assumed.

A description of the typical notation used throughout this chapter is presented in Figure III-1. References to pertinent sections and equations of the ACI Code [2] are indicated with the "ACI" prefix, and similarly for other codes. For simplicity, all equations and descriptions presented in this chapter correspond to inch-pound-second units unless otherwise noted. Units required by ETABS and WALLER are described in Chapter IV.

The details of the algorithms presented in sections B and C for concrete Wall and Spandrel design are all based on the ACI Code [2], excluding the seismic provisions (Chapter 21 of Reference 2). Section D identifies the differences between these algorithms and those used for the other codes or for masonry walls.

A_{cv}	Area used to determine shear stress, sq-in
A_g	Gross section area, sq-in
A_n	Net cross-sectional area, sq-in
A_s	Total area of reinforcement, sq-in
A_{sc}	Area of compression reinforcement, sq-in
A_{st}	Area of tension reinforcement, sq-in
A_v	Area of vertical shear reinforcement, sq-in
A_h	Area of horizontal shear reinforcement, sq-in
A_{vd}	Area of diagonal reinforcement, sq-in
b	Width of member, in
b_w	Width of web (T-beam section)
b_r	Effective width of flange (T-Beam section), in
D	Total depth of member, in.
d	Distance from compression face to tension reinforcement, in
d'	Concrete cover to center of reinforcing, in
d_s	Thickness of flange (T-Beam section), in
E_c	Modulus of elasticity of concrete, psi
E_s	Modulus of elasticity of reinforcement, assumed as 29,000,000 psi
f'_c	Specified compressive strength of concrete, psi
f'_m	Specified compressive strength of masonry, psi
f_y	Specified yield strength of flexura reinforcement, psi
f_{ys}	Specified yield strength of shear reinforcement, psi
L	Length of member, in.
M_b	Moment capacity at balanced strain conditions, lb-in
M_o	Moment capacity with no axial load, lb-in
M_u	Factored moment, lb-in
P_b	Axial load capacity at balanced strain conditions, lb
P_{max}	Maximum axial load strength allowed, lb
P_n	Nominal Axial Load Capacity, lbs
P_o	Axial load capacity at zero eccentricity, lb
P_u	Factored axial load, lb
V_c	Nominal shear strength of concrete, lb
V_m	Nominal shear strength of masonry, lb
V_s	Nominal shear strength of shear reinforcement, lb
V_u	Factored shear force, lb
ϵ_c	Strain in concrete
ϵ_s	Strain in reinforcing steel
ϕ	Strength reduction factor

Abbreviations
Figure III-1

A. DESIGN LOADING COMBINATIONS

The design loading combinations define the various factored combinations of the load conditions for which the structure is to be checked. The user is referred to the ETABS manual for the definition of load conditions (and load cases).

The load combination data specified in the WALLER input data is totally independent of the load case data specified in the ETABS manual.

The postprocessing file brings across forces and moments associated with the eight independent load conditions (I, II, III, A, B . . .) for each of the members. The load combination multipliers are applied to the forces and moments from the load conditions to form the factored design forces and moments for each load combination. However, there is an exception to this procedure in computing boundary member forces in walls designed for dynamic loads; the forces are first computed at modal level and then the modal combination is made before any other load combination is added.

If a building is subjected to dead load (DL) and live load (LL) only, the design will need only one loading combination, namely 1.4 DL + 1.7 LL.

However, in addition to the dead load and live load, if the structure is subjected to seismic forces from two mutually perpendicular directions (EQX and EQY), and considering that seismic forces are subject to reversals, the following load combinations may have to be considered:

1. 1.4 DL + 1.7 LL
2. $1.4 \text{ DL} + 1.4 \text{ LL} + \sqrt{(1.4 \text{ EQX})^2 + (1.4 \text{ EQY})^2}$

$$3. 1.4 \text{ DL} + 1.4 \text{ LL} - \sqrt{(1.4 \text{ EQX})^2 + (1.4 \text{ EQY})^2}$$

$$4. 0.9 \text{ DL} + \sqrt{(1.4 \text{ EQX})^2 + (1.4 \text{ EQY})^2}$$

$$5. 0.9 \text{ DL} - \sqrt{(1.4 \text{ EQX})^2 + (1.4 \text{ EQY})^2}$$

Of the three vertical load conditions I, II or III, one is usually identified as being associated with the dead load and another is identified as the live load condition. By identifying the load conditions in this manner, live load reduction factors as allowed by Reference [4] can be applied to the member forces of the live load condition on a level-by-level basis to reduce the contribution of the live load to the factored loading.


B. WALL DESIGN

The shear wall design algorithms of WALLER allow for the design of symmetric shear wall sections of the types shown in Figure III-2. The design procedure considers only the wall in-plane moments and shears as shown in Figure III-3, and involves

1. Design (or checking) for overturning moment,
2. Design for shear.


A shear wall may be modeled using column elements or "walls" (i.e. assemblages of panel elements).

In each case the program assumes the major direction to be the in-plane direction.



(a) RECTANGULAR SECTION, TYPE W1: REBAR NOT SPECIFIED
TYPE RW1: REBAR SPECIFIED


(PLAN)



(b) FLANGED SECTION, TYPE W2: REBAR NOT SPECIFIED
TYPE RW2: REBAR SPECIFIED

(PLAN)

Wall Section Types
Figure III-2



In-plane Wall Design Forces
Figure III-3

A "wall" (defined as an assemblage of panel elements), where all the panel elements of the "wall" are in one plane, will display no out-of-plane moments or shears. It is important that each group of planar panels be assigned a different wall number in ETABS, so as to obtain component forces on each planar section of three dimensional walls separately.

For walls that are modeled using column elements, the WALLER program assumes the major direction of the column to be the in-plane direction. Therefore, in order to suppress any out-of-plane behavior, the minor direction moment of inertia and shear area of such columns should be set to zero.

1. Design (or Checking) for overturning moment

The WALLER program has options whereby the user can specify the section geometry and the explicit distribution of the vertical reinforcing across a shear wall section.

If the distribution of the reinforcing is specified (i.e. section types RW1 and RW2), the program will check the capacity of the specified wall section according to the procedure described in Section **a** below.

If only the section geometry is defined and the vertical reinforcing is not specified (i.e. section types W1 and W2) the program will calculate the vertical reinforcing (trim bars) required to resist the overturning moment effects, based upon the approximate design algorithm described in Section **b** below.

a. Checking wall section for overturning moment
when wall vertical reinforcing is specified


When the geometry and the vertical reinforcing distribution for a particular wall section are specified, the capacity check of the section involves generating a load-moment interaction curve for the whole wall section. A typical interaction diagram is shown in Figure III-4.

The interaction diagram is numerically described by a series of discrete points. The coordinates of these points are determined by rotating a plane of linear strain on the section of the column. See Figure III-5. In addition to axial compression and bending, the formulation allows for axial tension and bending considerations as shown in Figure III-3.

The formulation is based consistently upon the basic principles of ultimate strength design, (ACI 10.3).

The linear strain diagram limits the maximum concrete strain, ϵ_c , at the extremity of the section, to .003.

The stress in the steel is given by the product of the steel strain and the steel modulus of elasticity, $\epsilon_s E_s$, and is limited to the yield stress of the steel, f_y . The area associated with each rebar is placed at the actual location of the center of the bar and the algorithm does not assume any simplifications in the manner in which the area of steel is distributed over the cross section of the column (such as an equivalent steel plate).



Typical Moment Interaction Diagram
Figure III-4

The concrete compression stress block is assumed to be rectangular, with a stress value of $0.85 f'_c$. See Figure III-6. The interaction algorithm provides corrections to account for the concrete area that is displaced by the reinforcing in the compression zone.

The effects of the strength reduction factor, ϕ , are included in the generation of the interaction surfaces. The strength reduction factor, ϕ , for high axial compression, with or without moment is assumed to be 0.70. For low values of axial load, ϕ is increased linearly from 0.70 to 0.90 as the axial force capacity, ϕP_n , decreases from the smaller of $0.10 f'_c A_g$ or ϕP_b to zero. See Figure III-7.


In cases involving axial tension, ϕ is always 0.90 (ACI 9.3.2.2).

The maximum factored compressive axial load (including ϕ -factor reduction) is limited to P_{max} , where


$$P_{max} = 0.80 \phi (0.85 f'_c (A_g - A_s) + f_y A_s) \quad (\text{ACI 10.3.5.2})$$

After the moment interaction curve is generated, the wall capacity is checked for each loading combination at the top and bottom ends of each wall. In checking a particular wall for a particular loading combination at a particular location, the following steps are involved.

- (i) Determining the factored moments and axial forces from the analysis load conditions and the specified load combination factors to give P_u and M_u .
- (ii) Determining if the point, defined by the factored axial load and moment set, lies within the interaction curve.




Generation of Interaction Diagram *Figure III-5*



Concrete Stress-Strain Relationships

Figure III-6



The following two sections describe in detail the algorithms associated with the abovementioned steps (i) and (ii).

(i) Determine factored moments and forces

Each load combination is defined with a set of load factors corresponding to the eight ETABS load conditions. The analysis results associated with the ETABS load conditions are recovered from the postprocessing data file that was created by the corresponding ETABS analysis run. The factored loads for a particular load combination are obtained by applying the corresponding load factors to the ETABS load conditions, giving P_u and M_u , the factored axial load and moment applied to the whole wall section.


For dynamic loads, the relationship between the signs of the axial load and moments is lost during the modal combination. Additional loading combinations are automatically created by the program similar to those specified by the user, with the sign of the dynamic axial load reversed.

(ii) Capacity check

The point L (P_u, M_u) is placed on the interaction diagram as shown in Figure III-8. If the point lies within the interaction curve, the wall capacity is adequate; however, if the point lies outside of the interaction curve, the wall is overstressed.

As a measure of the stress condition of the wall, a capacity ratio is calculated.

This ratio is achieved by plotting the point L, defined by P_u, M_u and determining the location of point C. The point C is defined as the point where the line OL (if extended outward) will intersect the interaction curve.



Geometric Representation of the Wall Capacity Ratio
Figure III-8

The capacity ratio, CR, is given by the ratio $\frac{OL}{OC}$

If $OL = OC$ (or $CR=1$) the point lies on the interaction curve and the wall is stressed to capacity.

If $OL < OC$ (or $CR < 1$) the point lies within the interaction curve and the wall capacity is adequate.

If $OL > OC$ (or $CR > 1$) the point lies outside the interaction curve and the wall is overstressed.


The maximum of all the values of CR calculated from each load combination is reported for the top and the bottom of the wall along with the controlling P_u and M_u set and associated load combination number.

The capacity ratio is basically a factor that gives an indication of the stress condition of the wall with respect to the capacity of the wall.

In other words, if the factored axial load and moment for which the wall is being checked is divided by the reported capacity ratio, the point defined by the resulting axial load and moment will lie on the interaction curve.

**b. Designing for wall section overturning moment
when wall vertical reinforcing is not specified**

When the wall vertical reinforcing is not specified, the program will calculate the required edge reinforcing to resist the axial forces and overturning moments. The algorithm focuses upon the development of edge members at the left and right ends of the wall while limiting the compression and tension reinforcing to the user-specified percentages.



The design procedure is as follows.

Consider the wall (type W1) shown in Figure III-9.

For a given location, say the top of the wall, for a given loading combination, the wall section is to be designed for a factored axial force F_T and a factored overturning moment M_T .

The program initiates the design procedure by assuming an edge member of thickness t and width B_1 (where $B_1 = t$) at each end of the wall.

The overturning moment and axial force are converted to an equivalent force set P_L^T and P_R^T using the following relationship.

$$P_L^T = \frac{F_T}{2} + \frac{M_T}{ARM}$$

$$P_R^T = \frac{F_T}{2} - \frac{M_T}{ARM}$$

where $ARM = L - B_1$ the first time around. For any given loading combination, the net values for P_L^T or P_R^T could be tension or compression.

Note that, for dynamic loads, P_L^T and P_R^T are obtained at the modal level and the modal combinations made, before combining with other loads. Also for loading combinations involving SRSS the P_L^T and P_R^T forces are obtained first for each load condition before combinations are made.

If any P value is tension, the area of steel required for tension is calculated as

$$A_{st} = \frac{P}{\phi f_y} \quad \text{where } \phi = 0.90$$

If any P value is compression, for section adequacy, the compressive area of steel, A_{sc} , must satisfy the following relationship.

$$P = 0.80 \phi [0.85 f'_c (A_g - A_{sc}) + f_y A_{sc}]$$

where $A_g = t B_1$ and $\phi = 0.70$ (ACI 10.3.5.2)

From which

$$A_{sc} = \frac{\left(\frac{P}{0.80\phi} - 0.85 f'_c A_g \right)}{(f_y - 0.85 f'_c)}$$

If A_{sc} calculates negative, no compressive reinforcing is needed.

The maximum tensile reinforcing to be packed within the $t \times B_1$ concrete edge member is limited by

$$A_{st}^{\max} = PTMAX t B_1$$

Similarly, the compressive reinforcing is limited by

$$A_{sc}^{\max} = PCMAX t B_1$$

where **PTMAX** and **PCMAX** are user-specified values for the section.

If A_{st} is less than A_{st}^{\max} and A_{sc} is less than A_{sc}^{\max} the program will proceed to check the next loading combination, otherwise

the program will increment the B_1 dimension to B_2 (i.e. $1.5 t$) and calculate new values for P_L^T , P_R^T , as the value of ARM changes to $(L - B_2)$, resulting in new values of A_{st} and A_{sc} . This procedure continues until A_{st} and A_{sc} are within the allowed steel percentages.

If the value of width of the edge member B increments to where it reaches a value equal to $L/2$, the iteration is terminated and a failure condition is declared.

The tension design iteration is satisfied before the compression design iteration is initiated, in order to maintain the tensile reinforcing as close to the outer edge of the wall as possible.

For W2 type walls the program will only attempt one design iteration with the edge member growth being limited to the $B_1 \times t$ area, as shown in Figure III-9(c).

This is an approximate but convenient design algorithm. Walls that are declared as overstressed using this algorithm could be found to be adequate if modeled using RW1 or RW2 wall types where the capacity of the wall is accurately evaluated using moment interaction diagrams. It should be noted, however, that some seismic codes require the use of edge members to resist the P_L^T and P_R^T values calculated.

2. Design for Shear

The shear reinforcing is designed for each of the loading combinations. In designing the shear reinforcing for a particular wall for a particular loading combination, the following steps are involved.

- (i) Determining the factored forces acting on the section, P_u , M_u and V_u . Note that P_u and M_u are needed for the calculation of V_c .
- (ii) Determining the shear force, V_c , that can be resisted by the concrete.
- (iii) Calculating the reinforcing steel required to carry the balance.

The following three sections describe in detail the algorithms associated with the above-mentioned steps (i), (ii) and (iii).

(i) Determine section forces

For a particular load combination, the wall axial force, P_u , the maximum moment along the member, M_u , and the wall shear force, V_u , are obtained by factoring the ETABS analysis load conditions with the corresponding load combination load factors.

(ii) Determine the concrete shear capacity

Given the design force set P_u , M_u and V_u , the shear force carried by the concrete, V_c , is calculated as follows (ACI 11.10.6):

$$V_c = 3.3 \sqrt{f'_c} td + \frac{P_{ud}}{4L}$$

where V_c may not be greater than

$$V_c = \left[0.6 \sqrt{f'_c} + \frac{L \left(1.25 \sqrt{f'_c} + 0.2 \frac{P_u}{L t} \right)}{\frac{M_u}{V_u} - \frac{L}{2}} \right] td$$

where L is the length of the wall, t is the thickness of the wall, d is taken as $0.8L$, and P_u is negative for tension. The second equation doesn't apply if $\frac{M_u}{V_u} - \frac{L}{2}$ is negative.

(iii) Determine the required shear reinforcing

Given V_u and V_c , the required shear reinforcing in area/unit length (e.g. square inches/foot) is given by

$$A_v = \frac{\frac{V_u}{\phi} - V_c}{f_{ys} d}$$

where $\frac{V_u}{\phi} - V_c$ must not exceed $8 \sqrt{f'_c} t d$ (ACI 11.5.6.8)

and $\frac{V_u}{\phi}$ must not exceed $10 \sqrt{f'_c} t d$ (ACI 11.10.3)

where ϕ , the strength reduction factor, is 0.85 (ACI 9.3.2.3). The maximum of all the calculated A_v values obtained from each load combination is reported for the wall.

Also reported is the maximum factored shear force V_u , a corresponding shear stress based on gross concrete area and the corresponding load combination number.

The wall shear reinforcing requirements reported by the program are based purely upon shear strength consideration. Any other minimum shear steel requirements must be investigated independently of the program by the user.

C. SPANDREL DESIGN

In the design of concrete spandrels, the WALLER program will calculate and report the required areas of steel for flexure and shear based upon the beam moments and shears, load combination factors and other criteria described below. The reinforcing requirements are calculated at five stations along the beam span.

All the spandrels are only designed for major direction flexure and shear. Effects due to any axial forces or minor direction bending or torsion that may exist in the spandrels (e.g. due to column disconnections) must be investigated independently of the program by the user.

The spandrel design procedure involves the following steps:

1. Design for Flexure
2. Design for Shear

1. Design for Flexure

The beam top and bottom flexural steel is designed at five stations along the beam span, namely END I, 1/4-PT, MIDDLE, 3/4-PT and END J.

In designing the flexural reinforcing for a particular beam for a particular section, for the beam major moment, the following steps are involved:

- (i) Determine the maximum factored moments.

(ii) Determine the required flexural reinforcing.

(i) Determine the maximum factored moments

In the design of the flexural reinforcing of the spandrels, the factored moments for each load combination at a particular beam station are obtained by factoring the ETABS analysis load condition results with the corresponding load factors.

The beam section is then designed for the maximum positive M_u^+ and the maximum negative M_u^- factored moments obtained from all of the load combinations.

Negative beam moments produce top steel. In such cases the beam is always designed as a rectangular section.


Positive beam moments produce bottom steel. In such cases the beam may be designed as a rectangular section, or T-Beam effects may be included.

(ii) Determine the required flexural reinforcing

In the flexural reinforcing design process, the program assumes that all sections are singly reinforced. In other words, no compression reinforcing is designed and the effects of any reinforcing in the compression zone of the beam section are neglected.

In designing for a factored negative moment, M_u^- , (i.e. designing top steel) the depth of the compression block is given by

$$a = d - \sqrt{d^2 - \frac{2M_u^-}{0.85 f'_c \phi b}}$$



Rectangular Beam Spandrel Design
Figure III-10

If $a > 0.75 \beta_1 c_b$, a concrete compression overstress is declared (ACI 10.3.3),

$$\text{where } \beta_1 = 0.85 - \frac{0.05 (f'_c - 4000)}{1000} \quad (\text{ACI 10.2.7.3})$$

with a maximum of 0.85 and a minimum of 0.65, and

$$c_b = \frac{87000}{87000 + f_y} d$$

The area of steel is then given by

$$A_s = \frac{M_u}{\phi f_y \left(d - \frac{a}{2} \right)}$$

where the value of ϕ in the above equation is 0.90, (ACI 9.3.2.1).

In designing for a factored positive moment, M_u , (i.e. designing bottom steel), the formulation for calculating the area of steel is exactly the same as above if the beam section is rectangular, i.e. no T-Beam data has been specified. See Figure III-10.

If the member is a T-Beam, the depth of the compression block is given by

$$a = d - \sqrt{d^2 - \frac{2M_u}{0.85 f'_c \phi b_f}}$$


where $a \leq 0.75 \beta_1 c_b$

If $a < d_s$, the subsequent calculations for A_s are exactly as previously defined for the rectangular section design.

If $a > d_s$, calculation for A_s is in two parts. The first part is for balancing the compressive force from the flange, C_f , and the second part is for balancing the compressive force from the web, C_w .

As shown in Figure III-11,

$$C_f = 0.85 f'_c (b_f - b_w) d_s$$



T-Beam Spandrel Design
Figure III-11

$$\text{Therefore } A_{s1} = \frac{C_f}{f_y}$$

and the portion of M_u that is resisted by the flange is given by

$$M_{uf} = C_f \left(d - \frac{d_s}{2} \right) \phi$$

Therefore, the balance of the moment, M_u , to be carried by the web is given by

$$M_{uw} = M_u - M_{uf}$$

The web is a rectangular section of dimensions b_w and d , for which the depth of the compression block is recalculated as

$$a_1 = d - \sqrt{d^2 - \frac{2M_{uw}}{0.85 f'_c \varphi b_w}}$$

where $a_1 \leq 0.75 \beta_1 c_b$

from which the second part of the reinforcing is calculated, giving

$$A_{s2} = \frac{M_{uw}}{\varphi f_y \left(d - \frac{a_1}{2} \right)}$$

The total required reinforcing for the T-section is then given by

$$A_s = A_{s1} + A_{s2}$$

Again, the value for φ is 0.90.

2. Design for Shear

The shear reinforcing is designed for each loading combination at five stations along the beam span, namely END I, 1/4-PT, MIDDLE, 3/4-PT and END J.

In designing the shear reinforcing for a particular beam for a particular loading combination at a particular station due to the beam major shear, the following steps are involved.

- (i) Determining the factored shear force, V_u .
- (ii) Determining the shear force, V_c , that can be resisted by the concrete.

- (iii) Determining the reinforcing steel required to carry the balance.

The following three sections describe in detail the algorithms associated with the abovementioned steps (i), (ii) and (iii).

(i) Determine the factored shear force

In the design of the beam shear reinforcing of a spandrel, the shear force, V_u , for a particular load combination at a particular beam station is obtained by factoring the ETABS analysis load conditions with the corresponding load combination factors.

(ii) Determine the concrete shear capacity

The allowable concrete shear capacity is given by

$$V_c = 2.0 \sqrt{f'_c} bd \quad (\text{ACI 11.3.1.1})$$

(iii) Determine the required shear reinforcing

Given V_u and V_c , the required shear reinforcing in area/unit length is calculated as

$$A_v = \frac{\frac{V_u}{\phi} - V_c}{f_{ys} d}$$

The following additional checks are also performed.

$$\text{When } \frac{L}{d} > 5 \text{ and if } \frac{V_u}{\phi} > 0.5 V_c$$

$$A_{v_{min}} = \frac{50 b}{f_{ys}} \quad (ACI 11.5.5.3)$$

$$A_{h_{min}} = 0$$

and $\left(\frac{V_u}{\phi} - V_c \right)$ must not exceed $8 \sqrt{f'_c} bd$

When $L/d > 5$ and if $\frac{V_u}{\phi} \leq 0.5 V_c$ then

$$A_{v_{min}} = A_{h_{min}} = 0$$

For deep beams when $L/d \leq 5$

$$A_{v_{min}} = 0.0015b \quad (ACI 11.8.9)$$

$$A_{h_{min}} = 0.0025b \quad (ACI 11.8.10)$$

and $\left(\frac{V_u}{\phi} \right)$ must not exceed $(2/3)(10 + L/d) \sqrt{f'_c} bd$

$$\text{for } 2 \leq L/d \leq 5 \quad (ACI 11.8.4)$$

However, when L/d is less than 2, $\frac{V_u}{\phi}$ must not exceed $8 \sqrt{f'_c} bd$.

Where ϕ , the strength reduction factor is 0.85 (ACI 9.3.2.3) and L/d is the span to depth ratio. The maximum of all the calculated A_v values, obtained from each load combination for each location and $A_{v_{min}}$ are reported.

Also reported are the L/d ratios and maximum shear stress at each location.

()

()

()

D. OPTIONS FOR OTHER CODES

1. ACI 318-89 including Chapter 21 (Seismic)

For this code WALLER uses all the algorithms listed in Sections B and C above and the following additional requirements:

The nominal shear strength of walls is limited to

$$V_n = \left(2\sqrt{f'_c} + \frac{A_v}{t} f_y \right) Lt \quad (\text{ACI 21.7.3.2})$$

where A_v is per unit length.

Since $V_u = \phi V_n$, A_v can be calculated as

$$A_v = \frac{\frac{V_u}{\phi} - 2\sqrt{f'_c} Lt}{L f_y}$$

where ϕ is 0.60 for shear.

(ACI 9.3.4.1.)

It is noted here that a lower value of A_v may be required based on ACI 21.7.3.3. Also in the satisfaction of ACI 21.7.3.6, the program makes the more conservative check that the individual pier nominal shear strength does not exceed $8\sqrt{f'_c} Lt$.

The value of ϕ for spandrel shear design is also taken as 0.60 (ACI 9.3.4.1).

2. UBC91 for Concrete Walls excluding Section 2625

For this code, WALLER uses algorithms identical to those listed in Sections B and C above.

3. UBC91 for Concrete Walls including Section 2625 (seismic)

For this code WALLER uses all the algorithms listed in Sections B and C above and the additional requirements listed for the ACI 318-89 including Chapter 21 in 1 above.

For coupling beams when $L/d < 4$ and $v_u > 4\sqrt{f'_c}$, area of one leg of diagonal shear reinforcement is also reported as

$$A_{vd} = \frac{V_u}{2 f_y \sin \alpha}$$

where $\sin \alpha = \frac{0.80D}{\sqrt{L^2 + (0.80D)^2}}$

4. CAN3-A22.3-M84 excluding Chapter 21

For this code, WALLER uses all of the algorithms listed in sections B and C above, except the following modified formulas (expressed in millimeter-Newton units) are used:

Note: $\phi_c = 0.6$ (CAN 9.3.2) and $\phi_s = 0.85$ (CAN 9.3.3) in all formulas below

(i) Maximum compressive load in wall,

$$P_{max} = 0.80 (0.85 \phi_c f'_c (A_g - A_s) + \phi_s f_y A_s)$$

(CAN 10.3.5.3)

(ii) The area of steel required for tension edge members,

$$A_{st} = \frac{P}{\phi_s f_y}$$

(iii) The area of steel required for compression edge members,

$$A_{sc} = \frac{\left[\frac{P}{0.80} - 0.85 \phi_c f'_c A_g \right]}{(\phi_s f_y - 0.85 \phi_c f'_c)}$$

(iv) Concrete shear strength for walls,

$$V_c = 0.2 \phi_c \sqrt{f'_c} \left(1 + \frac{3P_u}{A_g f'_c} \right) t d$$

(CAN 11.3.4.3)

when P_u is positive (compression),
or

$$V_c = 0.2 \phi_c \sqrt{f'_c} \left(1 + \frac{P_u}{0.6 \phi_c \sqrt{f'_c} A_g} \right) t d$$

(CAN 11.3.4.2)

when P_u is negative (tension).

(v) Area of required shear reinforcing,

$$A_v = \frac{V_u - V_c}{\phi_s f_{ys} d} \quad (\text{CAN 11.3.6.1})$$

where $V_u - V_c$ does not exceed $0.8 \phi_c \sqrt{f'_c} t d$

(CAN 11.3.6.6) ()

(vi) Depth of compression block in beam design,

$$a = d - \sqrt{d^2 - \frac{2 M_u}{0.85 f'_c \phi_c b}}$$

when $a > \beta_1 c$ a concrete compressive overstress condition occurs where

$$\beta_1 = 0.85 - \frac{0.08 (f'_c - 30)}{10} \quad (\text{CAN 10.2.7.C})$$

and

$$c = \frac{600}{600 + f_y} d \quad (\text{CAN 10.3.3})$$

(vii) Area of steel required in rectangular beams,

$$A_{st} = \frac{M_u}{\phi_s f_y (d - \frac{a}{2})}$$

(viii) For T-beam design,

$$C_f = 0.85 f'_c \phi_c (b_f - b_w) d s$$

$$A_{st1} = \frac{C_f}{\phi_s f_y}$$

$$M_{uf} = C_f (d - \frac{d_s}{2})$$

and

$$A_{st2} = \frac{M_{uw}}{\phi_s f_y (d - \frac{a_1}{2})}$$

where

$$a_1 = d - \sqrt{d^2 - \frac{2 M_u}{0.85 f'_c \phi_c b_w}}$$

(ix) Concrete shear strength for beams,

$$V_c = 0.2 \phi_c \sqrt{f'_c} b d \quad (\text{CAN 11.3.4.1})$$

and

$$V_s \leq 0.8 \phi_c \sqrt{f'_c} b d \quad (\text{CAN 11.3.6.6})$$

when $L/d > 4$ and if $V_u > 0.5 V_c$ (CAN 11.2.5.1)

$$A_{v_{\min}} = 0.35 \frac{b}{f_y} \quad (\text{CAN 11.2.5.4})$$

$$A_{h_{\min}} = 0$$

when $L/d > 4$ and if $V_u \leq 0.5 V_c$ then

$$A_{v_{\min}} = A_{h_{\min}} = 0$$

For deep beams when $L/d \leq 4$

$$A_{v_{\min}} = 0.002b \quad (\text{CAN 11.5.3.1})$$

$$A_{h_{\min}} = 0.002b \quad (\text{CAN 11.5.3.2})$$

5. CAN 3-A22-3-M84 including Chapter 21 (Seismic)

For this code, WALLER uses all of the algorithms listed in sections B and C above, as modified for the CAN3-A23.3-M84 excluding chapter 21 (in 4 above) with the following additional requirement:

A member strength reduction factor of 0.70 is applied for shear only to all members over and above the material strength reduction factors (CAN 21.2.3.2).

No special requirements for ductile walls are checked.

6. UBC91 for Masonry Walls excluding Seismic

For the design of masonry shear walls and spandrel beams WALLER uses the same algorithms as listed in Section B above for concrete shear walls and beams with the following changes:

- (i) The specified compressive strength of masonry, f'_m is used instead of f'_c .
- (ii) The strength reduction factors, ϕ , used in the algorithms are modified as follows (UBC 2412.d.2):

ϕ is 0.65 for compression,
 ϕ varies from 0.65 to 0.85 as ϕP_n decreases
from 0.10 $f'_m A_n$ or 0.25 P_b to zero,
 ϕ is 0.85 for flexure,
 ϕ is 0.60 for shear

- (iii) The shear capacity of masonry, V_m (in lieu of V_c) is taken as

$$V_m = C_d \sqrt{f'_m} L_t$$

where

$$C_d = 2.4 - \left(\frac{M}{Vd} - 0.25 \right) 1.6$$

but not less than 1.2 or greater than 2.4.

d is the effective depth, assumed as 0.8L for walls, and M and V are the moment and shear for the loading combinations being considered.

(iv) The check on maximum nominal shear is made as follows:

$$\frac{V_u}{\phi} = C_m \sqrt{f_m} L t$$

where

$$C_m = 6 - \left(\frac{M}{Vd} - 0.25 \right) 2.67$$

but not less than 4 or greater than 6. M, V and d are as defined above for C_d .

It should be noted that the program assumes fully grouted masonry. That is, A_n , the net area and A_e , the effective area are both taken equal to A_g , the gross area.

7. UBC91 for Masonry Walls including Seismic

For this code, WALLER uses all of the algorithms as listed in section 6 above.

()

()

()

IV.

INPUT DATA for PROGRAM WALLER

In order to execute the WALLER program, an ETABS postprocessing file and a WALLER input data file are required. However, if the program defaults are acceptable, the WALLER input data file is optional.

The ETABS postprocessing file contains information pertaining to the structural geometry and loading and the analytical results from the corresponding ETABS analysis. This file forms the interface between ETABS and the WALLER postprocessor. Only those elements with material properties of type W or M will be processed by WALLER.

The sequence of data lines described herein will establish the data file required by WALLER.

The user must read and understand the contents of Chapter III before proceeding with the data preparation described in this section.

The user should also be thoroughly familiar with the WALLER control variables described below, and with the main control variables of ETABS. Repeated references are made to these variables throughout this chapter.

A. FREE FORMAT

All input data for WALLER is prepared in free format. In other words, the data on a particular line does not have to correspond to prespecified column locations. The data is input as a string of numbers which are separated by one or more blanks. **It is important to enter all items even if they are zero; however, trailing zeros on any data line need not be input.** No data line may be more than eighty characters in length. Also, the data file should not contain spacing tab characters that are generated by some editors while preparing a data file.

Decimal points for **whole** floating point numbers are not necessary. For example, the number (6.0) may be entered as (6).

B. COMMENT DATA

Any line having a \$ (dollar) sign in Column 1 is treated as a comment line and ignored by the program.

The \$ sign may also be used in any other column on any data line. In such cases entries to the right of the \$ sign will be treated as comment data and ignored by the program. This option allows the user to effectively comment the data as it is being prepared.

C. ARITHMETIC OPERATIONS

Simple arithmetic statements are possible when entering floating point real numbers in the free format fields. The following type of operators can be used:

- + for addition
- for subtraction
- / for division
- * for multiplication
- P for raising to the power of

The following are typical data entries that are possible:

11.92*12
7.63/386.4
3P.5
150P1.5*33
6.66-1.11*7.66/12.2

The operators are applied as they are encountered in the scan from left to right, so that

11.92*12 is evaluated as 11.92×12

7.63/386.4 is evaluated as $\frac{7.63}{386.4}$

3P.5 is evaluated as 3^5

150P1.5*33 is evaluated as $(150^{1.5}) \times 33$

6.66-1.11*7.66/12.2 is evaluated as $\frac{(6.66 - 1.11) \times 7.66}{12.2}$

Scientific exponential notation is also allowed. For example, the number 1.5E10 is read as 1.5×10^{10} .

D. UNITS

All input data for WALLER and the corresponding ETABS data must be prepared using either English or MKS metric or SI metric units.

If the English option is used, the input must be prepared using inch-kip-second units.

If the MKS metric option is used, the input must be prepared using meter-kilogram-second units.

If the SI metric option is used, the input must be prepared using meter-kiloNewton-second units.

This is irrespective of the fact that all the numerical techniques described in Chapter III are presented in inch-pound-second units or millimeter-Newton-second units.

E. ETABS DATA PREPARATION HINTS

The design algorithm for shear walls in WALLER is for the design of wall sections for axial load, in plane moments and in plane shears only.

Therefore, for walls modeled as column elements, the user must suppress all out-of-plane action. This involves setting the minor moments of inertia and minor shear areas to zero, in the ETABS model.

(In the ETABS input data, this may be conveniently achieved. If the minor dimension is input as a negative number, the minor moment of inertia, the minor shear area and the torsional constant of the section will be set to zero. Similarly, if the major dimension is input as a negative number, the major moment of inertia, the major shear area and the torsional constant of the section will be set to zero. Also inputting both the major and minor dimensions as a negative number sets the torsional constant only as zero.)

Planar "wall" assemblages modeled with panel elements do not have any out-of-plane stiffness. For three-dimensional walls, separate wall numbers should be assigned in ETABS to groups of planar contiguous panels for WALLER design to be correct.

F. DETAILED DESCRIPTION OF THE WALLER INPUT DATA

There are basically six data sections associated with the WALLER input. A summary of the data setup is shown in Table IV-1. This chapter details each section and the associated data lines. A sample data file is listed in the last section of this manual.

The following is the convention used to define each data line:

First, the sequence of the entries of each data line is presented as a series of abbreviations of the options (or variables).

Each data section is then followed by a table in the form:

Variable Field Note Entry

The **Variable** is the abbreviation of the entry made on the data line.

The **Field** is a number that corresponds to the sequence in which the variable exists on the data line. Thus if a variable is the fourth entry on a data line, it will have a field number of 4.

The **Note** number refers to the series of notes that exist after each corresponding data section. The notes describe the data options in more detail and give important information to aid the user in better understanding the options of the program.

The **Entry** is a brief description of the option (or entry).

It is assumed that the user is thoroughly familiar with the main control variables and the frame control variables of ETABS. Repeated references are made to these variables throughout the chapter.

Data Block	When Needed
1. Control Information	always
2. Load Combination Definition Data	if $NLC > 0$
3. Material Property Redefinition Data	if $NRMP > 0$
4. Section Property Redefinition Data	
i) Column Property	if $NRCP > 0$
ii) Beam Property	if $NRBP > 0$
iii) Wall Property	if $NRWP > 0$
5. Frame Design Activation Data Sets	
i) Frame Design Control Data	if $NFR > 0$
ii) Element Reassignment Data	
a. Column Reassignment	if $IRCP > 0$
b. Beam Reassignment	if $IRBP > 0$
c. Wall Reassignment	if $IRWP > 0$

Typical Data Set-up For WALLER
Table IV-1

1. CONTROL INFORMATION

Prepare the following data as defined in sections (a) and (b) below. This data is always needed. A total of 3 data lines are required.

a. Heading Data

Prepare two lines of data for output labeling, up to 70 characters per line. This information will appear on every page.

b. Execution Control Data

Prepare one line of data to define the program execution options in the following form:

**ICODE NFR NLC LLC NRMP NRCP NRBP
NRWP NPTS IPRI IPHI IUNIT IEX**

Note: The 13 entries shown above are to be entered on one data line in the input.

If no WALLER input file is provided, the **Heading Data** defaults to the Heading Data of ETABS; the **ICODE** parameter defaults to 1 (i.e. the UBC91 code for concrete); **NFR** defaults to designing all frames; **NLC** defaults to using the loading combination defaults given in the following Section 2; **LLC** defaults to 2; **NRMP**, **NRCP**, **NRBP** and **NRWP** all default to zero; **NPTS** defaults to 21; **IPRI** and **IPHI** default to zero; **IUNIT** defaults to E; and **IEX** defaults to zero.

1. CONTROL INFORMATION (continued)

Variable Field Note Entry

ICODE	1	(1)	Code identifier = 1 UBC 91 concrete = 2 ACI 318-89 = 3 CAN3-A23.2-M84 = 11 UBC 91 masonry
NFR	2	(2)	Number of frames to be designed
NLC	3	(3)	Number of design loading combinations
LLC	4	(4)	ETABS load condition number that corresponds to live load: = 1 Vertical load condition I = 2 Vertical load condition II = 3 Vertical load condition III
NRMP	5	(5,6)	Number of redefined (or new) material property types
NRCP	6	(5,7)	Number of redefined (or new)column section property types

1. CONTROL INFORMATION (continued)

Variable Field Note Entry

NRBP 7 (5,8) Number of redefined (or new) beam section property types

NRWP 8 (5,9) Number of wall section property types with reinforced concrete property assignments

NPTS 9 (10) Number of points on each interaction diagram curve

IPRI 10 (11) Interaction diagram print code:
 = 0 Suppress printing of interaction curves.
 = 1 Tabulate interaction curves

IPHI 11 (12) Strength reduction factor, ϕ ,
 overwrite code:
 = 0 use code values
 = 1 overwrite all ϕ 's to 1.0

IUNIT 12 (13) Type of units:
 = E English units
 = M MKS metric units
 = S SI metric units

IEX 13 (14) Execution mode:
 = 0 Normal execution mode
 = 1 Data check mode

1 - NOTES:

1. The WALLER program has options to check or design the shearwall structures with respect to several different codes. This options allows the user to choose the code to be used. Refer to chapter III for details of the checks used for the different codes.

It is reiterated here that only the design/checks listed in chapter III are performed by the WALLER program. Other significant aspects of shear-wall design, for example, detailing, minimum thickness, minimum reinforcement, out-of-plane bending, etc., are not addressed by the program and should be separately addressed by the user.

2. This variable defines the number of frame design activation data sets to be provided in Section 5 below. If this number is zero, no data is expected or read in Section 5, but all frames are designed with default values.
3. This variable defines the number of design loading combinations and controls the number of data lines to be read in Section 2 below. If this number is zero, no data is expected or read in Section 2, but the default values of loading combinations given in section 2 are used.
4. This entry defines the vertical load condition of ETABS that corresponds to the live load.

The live load reduction factors for the members are applied to the member forces associated with this load condition, before the member forces are summed into the combinations.

1 - NOTES: (continued)

5. It is possible to redefine or add new material properties or section properties in the material and section property tables that the user originally defined in the ETABS data.

Via this option, the user can modify the material strengths or the dimensions of the walls or spandrels and make design iteration runs with WALLER without rerunning the analysis runs of ETABS.

After the design is satisfactory, the user may incorporate the changes into the ETABS data and rerun the analysis and make the design runs for final convergence.

6. The entry **NRMP** defines the number of material property sets that are defined in Section 3 below.
7. The entry **NRCP** defines the number of column section property sets that are defined in Section 4(i) below.
8. The entry **NRBP** defines the number of beam section property sets that are defined in Section 4(ii) below.
9. The entry **NRWP** defines the number of wall section property sets that are defined in Section 4(iii) below.

1 - NOTES: (continued)

10. If the user specifies the steel reinforcing for a particular concrete wall section, the program will calculate a load-moment interaction diagram for the section.

Each interaction curve is defined by a series of points connected by straight lines. The entry NPTS specifies the number of points that will be generated on each curve. A recommended value for NPTS is 21. The maximum allowed value is 51. The value for NPTS must be odd.

11. The tabulation of each interaction diagram requires one page of output.

12. This option is useful if checks have to be made with respect to the ultimate capacities of the materials.

13. If IUNIT is E all WALLER (and ETABS) input data must be prepared in inch-kip-second units and all output will be in the same units except required shear reinforcing area is given in in^2/ft .

If IUNIT is M all WALLER (and ETABS) input data must be prepared in meter-kilogram-second units, however, all WALLER force and moment output will be in meter-ton-second units and required reinforcing area is given in cm^2 and cm^2/meter .

If IUNIT is S all WALLER (and ETABS) input data must be prepared in meter-kiloNewton-second units and all output will be in the same units except required reinforcing area is given in cm^2 and cm^2/meter .

If IUNIT is input as anything other than E or M or S it is assumed to be E.

1 - NOTES: (continued)

14. If IEX is 1, the program will only read, print and check the data for consistency and will terminate execution after all the input has been read. All design operations will be bypassed. The normal execution mode will produce a complete echo of the input and results. If a data error is detected in a normal execution mode, the program will immediately switch to the data check mode and execution will be terminated after all the input has been read.

2. LOAD COMBINATION DEFINITION DATA

Load combinations are defined as summations of the eight basic load conditions, namely:

- a. The vertical static load conditions, I, II and III.
- b. The lateral static load conditions, A and B.
- c. The lateral dynamic load conditions, Dyn-1, Dyn-2 and Dyn-3.

The load combinations convert the ETABS analysis conditions to factored ultimate load levels with load factors that are specified in this section.

Provide one data line to define each of the NLC load combinations in the following form:

L LTYP XI XII XIII XA XB XD1 XD2 XD3

The data provided in this data section is completely independent of the load case data that is provided in the corresponding ETABS analysis run.

2. LOAD COMBINATION DEFINITION DATA (continued)

Variable Field Note Entry

L 1 (1) Load combination number

LTYPE 2 (2) Load combination type
= 0 Linear combination,
consider all signs
= 1 Linear combination, use absolute
value of responses, but consider
signs of multipliers
= 2 SRSS A and B load conditions,
combine linearly with others
= 3 SRSS DYN-1 and DYN-2 load
conditions, combine linearly
with others

XI 3 (3) Multiplier for vertical load
condition I

XII 4 Multiplier for vertical load
condition II

XIII 5 Multiplier for vertical load
condition III

XA 6 Multiplier for lateral load
condition A

XB 7 Multiplier for lateral load
condition B

2. LOAD COMBINATION DEFINITION DATA (continued)

Variable Field Note Entry

XD1 8 Multiplier for dynamic load
condition Dyn-1

XD2 9 Multiplier for dynamic load
condition Dyn-2

XD3 10 Multiplier for dynamic load
condition Dyn-3

2 - NOTES:

1. This number must be in ascending consecutive numerical sequence starting with the number 1.
2. If this entry is 0, linear combinations are produced and all signs are considered.

If this entry is 1, linear combinations are produced, except that absolute values of responses are used, although signs of multipliers are considered. This type of combination is not recommended for WALLER. It has been kept here for consistency with ETABS.

If this entry is 2, a square root of the sum of the squares (SRSS) combination of the load conditions A and B responses with the specified multipliers is first made, before combining linearly with the other load conditions. The SRSS value is assigned the sign of XA. This type of combination is required in some design codes for considering orthogonal effects of seismic excitations.

If this entry is 3, a SRSS combination of the load condition DYN-1 and DYN-2 responses with the specified multiplier is first made before combining linearly with the other load conditions. The SRSS value is assigned the sign of XD1. This type of combination is commonly used for dynamic analysis and is required by some design codes to consider orthogonal effects of seismic excitation.

3. Each member is designed (or checked) for each of the applicable loading combinations. The design (or stress ratio) from the controlling loading combination is reported.

2 - NOTES: (continued)

Typically, building systems are subjected to vertical loads due to dead and live loads which usually act downwards. In addition to the vertical loads, the building is usually subjected to lateral loads, resulting from wind or seismic forces, which act along different directions (usually assumed to be in two mutually orthogonal directions), and the directions are reversible.

If the structure is subjected to dead load (DL) and live load (LL) only, the user need only specify one loading combination, namely, 1.4 DL + 1.7 LL as dead load and live load are not reversible.

However, if in addition to the dead load (DL) and the live load (LL) the structure is subjected to wind forces from two mutually perpendicular reversible directions (WX, WY), the user needs to specify the following loading combinations. See Reference [2].

1. 1.4 DL + 1.7 LL
2. 0.75 (1.4 DL + 1.7 LL + 1.7 WX)
3. 0.75 (1.4 DL + 1.7 LL + 1.7 WY)
4. 0.75 (1.4 DL + 1.7 LL - 1.7 WX)
5. 0.75 (1.4 DL + 1.7 LL - 1.7 WY)
6. (0.9 DL + 1.3 WX)
7. (0.9 DL + 1.3 WY)
8. (0.9 DL - 1.3 WX)
9. (0.9 DL - 1.3 WY)

These are the program defaults whenever the ACI code is requested, assuming DL is gravity load condition I, LL is gravity load condition II, WX is static lateral load condition A and WY is static lateral load condition B. The user should specify other combinations if seismic loads are present.

2 - NOTES: (continued)

When using UBC91 (Reference [4]) for concrete or masonry under seismic loads, the required loading combinations would be:

1. 1.4 DL + 1.7 LL
2. 1.4 DL + 1.4 LL + $\sqrt{(1.4 \text{ EQX})^2 + (1.4 \text{ EQY})^2}$
3. 1.4 DL + 1.4 LL - $\sqrt{(1.4 \text{ EQX})^2 + (1.4 \text{ EQY})^2}$
4. 0.9 DL + $\sqrt{(1.4 \text{ EQX})^2 + (1.4 \text{ EQY})^2}$
5. 0.9 DL - $\sqrt{(1.4 \text{ EQX})^2 + (1.4 \text{ EQY})^2}$

These are the program defaults whenever the UBC code is requested, assuming DL is gravity load condition I, LL is gravity load condition II, EQX is static lateral load condition A and EQY is static lateral load condition B.

When using the CAN3-A23.2-M84 the load combinations for wind loads would be and the program defaults are:

1. 1.25 DL
2. 1.25 DL + 1.5 LL
3. 1.25 DL + 1.05 LL + 1.05 WX
4. 1.25 DL + 1.05 LL - 1.05 WX
5. 1.25 DL + 1.05 LL + 1.05 WY
6. 1.25 DL + 1.05 LL - 1.05 WY
7. 1.25 DL + 1.5 WX
8. 1.25 DL - 1.5 WX
9. 1.25 DL + 1.5 WY
10. 1.25 DL - 1.5 WY
11. 0.85 DL + 1.5 WX
12. 0.85 DL - 1.5 WX
13. 0.85 DL + 1.5 WY
14. 0.85 DL - 1.5 WY

3. MATERIAL PROPERTY REDEFINITION DATA

This data section is only needed if the material property table that has been previously defined in the ETABS data is to be modified (or expanded).

If NRMP is 0, this data section is not needed and must be skipped. In this case, the values of the material properties used by WALLER will retain the values that were assigned in the ETABS data. However, if for any W material type the values for FY, FC or FYS have not been defined, they will be set to the default values defined herein (Notes 4, 5 and 6 below) irrespective of whether any material properties are being redefined.

If NRMP is not 0, provide NRMP data lines to redefine material property types that were previously defined in the ETABS data, or to define additional material property types.

Prepare the data in the following form:

MID MTYPE E U P FY FC FYS FCS

3. MATERIAL PROPERTY REDEFINITION DATA (continued)

Variable Field Note Entry

MID 1 (1) Identification number of material type that is being redefined or added

MTYPE 2 (2) Material type:
= S Steel
= C Concrete (frames)
= W Concrete (walls)
= M Masonry (walls)
= O Other

E 3 (3) Modulus of elasticity

U 4 Unit weight

P 5 Poisson's ratio

FY 6 (4) Yield stress of reinforcing steel

FC 7 (5) Compressive strength of concrete or masonry

3. MATERIAL PROPERTY REDEFINITION DATA (continued)

Variable Field Note Entry

FYS 8 (6) Yield stress of shear reinforcing steel

FCS 9 (7) Equivalent compressive strength of
concrete for shear strength
evaluation

3 - NOTES:

1. The material property sets may be entered in any order; however, the identification numbers must lie between 1 and (NMAT + NRMP).

If the identification number is less than or equal to NMAT, this property set will replace the corresponding material property set that was previously defined in the ETABS data. If the identification number is greater than NMAT, the material property table is expanded, and a new material property set corresponding to this identification number is created.

2. A series of design/stress check postprocessors operating off the ETABS postprocessing data base are available. The material type designation is basically an indicator for the postprocessors.

The shear wall design postprocessor, WALLER, for example, will only process those members that have a material type of W or M. The concrete frame design postprocessor, CONKER, will only design those members that have a material type C. The structural steel checking postprocessor, STEELER, will only stress check members having a material designation of S. Materials having a designation type O will not be processed by any of the postprocessors.

3. Remember consistent units.
4. If the yield stress has not been specified, it is assumed to be 60 ksi or MKS or SI equivalent.

3 - NOTES: (continued)

5. If the concrete strength has not been specified, it is assumed to be 4 ksi or MKS or SI equivalent. If the masonry strength has not been specified, it is assumed to be 1.5ksi or MKS or SI equivalent.
6. If the yield stress of the shear reinforcing has not been specified, it is assumed to be 40 ksi or MKS or SI equivalent.
7. A nonzero value for this parameter causes the program to use this equivalent value of f'_c in evaluating the value of $\sqrt{f'_c}$ for use in calculating the concrete shear strength, V_c . This option is useful for lightweight concrete where an equivalent value of $\sqrt{f'_c}$ must be used in the shear design (ACI 11.2.1).

A zero value for this parameter defaults to the value for FC.

4. SECTION PROPERTY REDEFINITION DATA

The following data sections (i), (ii) and (iii) below redefine section properties for the column elements, beam elements and "wall" assemblages previously defined in the ETABS analysis. Properties specific to reinforced concrete design are added in this section.

4(i) Column Property Redefinition Data

This data section is for assigning specific concrete wall properties to the column section properties that have previously been defined in the ETABS data, or to define additional column property types.

Only column sections that have a wall or masonry material type (i.e. equal to W or M) will be included in the processing by WALLER.

If NRCP is 0, skip this data section. Otherwise, provide NRCP data sets to assign wall properties to the ETABS column property table, or to define additional column properties.

Each data set consists of two data lines, a section definition data line immediately followed by a reinforcing definition data line.

a. Section Definition Data Line

Prepare one data line in the following form:

ID IMAT ITYPE WD1 WD2 WD3 WD4

b. Reinforcement Definition Data Line

The format of this data line depends upon the section type, ITYPE.

4(i) Column Property Redefinition Data (continued)

If **ITYPE** is **W1** or **W2**, namely, the explicit wall reinforcing is not being specified, prepare one data line in the following form to define the acceptable values of reinforcing percentages.

PTMAX PCMAX

If **ITYPE** is **RW1** or **RW2**, namely, the wall reinforcing is explicitly being specified, prepare one data line to define the section reinforcing in the following form. See Figure IV-2.

D1 A1 N1 S1 D2 A2 N2 S2 D3 A3...

**4(i).Column Property Redefinition Data
(continued)****Variable Field Note Entry**

ID 1 (1) Identification number of
 column section property that is being
 redefined or added

IMAT 2 (2) Material identification number for
 this section property

ITYPE 3 (3) Section type:
 See Figures IV-1 and IV-2.
 = W1 Rectangular section
 reinforcing not specified
 = W2 Flanged section
 reinforcing not specified
 = RW1 Rectangular section
 reinforcing specified
 = RW2 Flanged section
 reinforcing specified

WD1 4 (4) Section dimension in major direction,
 inches or meters


WD2 5 (4) Section dimension in minor direction,
 inches or meters

4(i). Column Property Redefinition Data (continued)


Variable Field Note Entry

WD3 6 (4) Flange dimension in major direction, inches or meters (not needed for section types W1 and RW1).


WD4 7 (4) Flange dimension in minor direction, inches or meters (not needed for section types W1 and RW1).



Wall Section Types W1 and W2 (Reinforcing Not Specified)
Figure IV-1



(a) WALL SECTION TYPE RW1



(b) WALL SECTION TYPE RW2

Wall Section Types RW1 and RW2 (Reinforcing Specified)

Figure IV-2

**4(i). Column Property Redefinition Data
(continued)****Variable Field Note Entry**

PTMAX 1 (5) Maximum percentage of steel allowed for tension design

PCMAX 2 (5) Maximum percentage of steel allowed for compression design

Defining Reinforcing Set #1:

D1 1 (6) Distance to center of first reinforcing station from face of section, inches or meters

A1 2 (6) Total area of reinforcing placed at the distance D1, inches² or meters²

N1 3 (6) Number of equally spaced reinforcing locations, (including first station)

S1 4 (6) Spacing between equally spaced reinforcing locations, inches or meters

**4(i). Column Property Redefinition Data
(continued)****Variable Field Note Entry****Defining Reinforcing Set #2:**

D2	5	(6)	Distance to center of first reinforcing station from face of section, inches or meters
A2	6	(6)	Total area of reinforcing placed at the distance D2, inches ² or meters ²
N2	7	(6)	Number of equally spaced reinforcing locations, (including first station)
S2	8	(6)	Spacing between equally spaced reinforcing locations, inches or meters

4(i) - NOTES:

1. The column property sets may be entered in any order; however, the identification numbers must lie between 1 and (NCP + NRCP).

If the identification number is less than or equal to NCP, this property set will replace the corresponding column property set that was previously defined in the ETABS data. If the identification number is greater than NCP, the column property table is expanded and a new column property set corresponding to this identification number is created.

2. This entry references the material property types that were previously defined in the ETABS data or subsequently redefined or added in Section 3 above. This entry must not be less than 1 and must not be greater than the maximum number of material types which exist in the material property table.
3. The WALLER program can only be used for the design of symmetric rectangular or flanged wall sections as shown in Figures IV-1 and IV-2.

For wall section types W1 and W2, the wall trim reinforcing to satisfy overturning requirements and the wall horizontal reinforcing to satisfy shear requirements will be calculated by the program.

For wall section types RW1 and RW2 the program will calculate load-moment interaction diagrams based upon the specified section dimension and reinforcing and report an overturning capacity ratio based upon the axial forces and overturning moments that exist in the walls. The shear design formulation for the RW1 and RW2 section types is identical to that of the W1 and W2 section types.

4(i) - NOTES: (continued)

See Chapter III for details of the design algorithms.

For ETABS column properties not redefined in this section, the default section type is W1.

4. The entries **WD1**, **WD2**, **WD3** and **WD4** define the geometry of the sections. The **WD3** and **WD4** entries are obviously not needed for section types W1 and RW1. For wall type W1, **WD1** must be greater than $2 \times \text{WD2}$. If the section property is not redefined, **WD1** and **WD2** default to the major and minor dimensions of the column property specified in the original ETABS data.
5. The wall design to accommodate the tension and compression effects of overturning is implemented using an iterative solution scheme which is based upon limiting the tension and compression steel percentages in the edge members of the wall. Details of the algorithms are presented in Chapter III. These entries define the values of the steel percentages. Recommended values are

PTMAX = .060

PCMAX = .040

6. The wall reinforcing is defined by a series of **D**, **A**, **N** and **S** entries. To define the reinforcing of the section, the user may enter as many **D**, **A**, **N**, **S** sets as are possible on one data line.

4(i) - NOTES: (continued)

For example, the reinforcing in the wall section type RW1 shown in Figure IV-2a may be defined by a data line having two D, A, N, S sets as follows:

D1 A1 N1 S1 D2 A2 N2 S2

where **D1 A1 N1 S1** define the reinforcing at reinforcing stations 1, 2 and 3 as shown in the figure so that **N1 = 3** and the entries **D1, A1** and **S1** are as illustrated in Figure IV-2a.

Similarly, **D2 A2 N2 S2** define the reinforcing at stations 4 through 7 so that **N2= 4**.

The reinforcing in the wall section type RW2 as shown in Figure IV-2b is defined by three D, A, N, S sets, so that the data line is as follows:

D1 A1 2 S1 D2 A2 1 0 D3 A3 3 S3

The value of **N** in the **D, A, N, S** sequence must be at least 1. If **N** is 1, the **S** value is not used, however, a zero value must be entered to complete the sequence of the four **D, A, N, S** entries.

Only the reinforcing that exists to the left of the center line of the wall should be specified. Reinforcing to the right of the center line will be generated by the program using symmetry. If reinforcing exists on the center line only one half of it should be specified.

4(ii). Beam Property Redefinition Data


This data section is for assigning specific concrete spandrel properties to the beam section properties that have been previously defined in the ETABS data, or to define additional beam property types.

It should be reiterated that only beams with a wall or masonry material type (i.e. equal to W or M) will be included in the processing by WALLER.

If NRBP is 0, skip this data section. Otherwise, provide NRBP data lines to assign reinforced concrete properties to the ETABS beam property table or to define additional beam properties. See Figure IV-3.

Prepare the data in the following form:

ID IMAT ITYPE DD BB DCT DCB DS BF



Spandrel Design
Figure IV-3

**4(ii). Beam Property Redefinition Data
(continued)****Variable Field Note Entry**

ID	1	(1)	Identification number of the beam section property that is being redefined or added
IMAT	2	(2)	Material identification number for this section property
ITYPE	3	(3)	Section type = SPANDREL
DD	4	(4)	Depth of beam, inches or meters
BB	5	(4)	Width of beam, inches or meters
DCT	6	(4)	Cover to center of top reinforcing steel, inches or meters
DCB	7	(4)	Cover to center of bottom reinforcing steel, inches or meters

**4(ii). Beam Property Redefinition Data
(continued)****Variable Field Note Entry**

DS 8 (4,5) Thickness of flange, inches or meters
(only for T-Beam sections, enter 0.0
for rectangular sections)

BF 9 (4,5) Effective width of flange, inches or
meters (only for T-Beam sections,
enter 0.0 for rectangular sections)

4(ii) - NOTES:

1. The beam property sets may be entered in any order; however, the identification numbers must lie between 1 and (NBP + NRBP).

If the identification number is less than or equal to NBP, this property set will replace the corresponding beam property set that was previously defined in the ETABS data. If the identification number is greater than NBP, the beam property table is expanded and a new beam property set corresponding to this identification number is created.

2. This entry references the material property types that were previously defined in the ETABS data or subsequently redefined or added in Section 3 above. This entry must not be less than 1 and must not be greater than the maximum number of material types which exist in the material property table.
3. The only valid reinforced concrete beam section type is SPANDREL. Enter the word SPANDREL for ITYPE.
4. See Figure IV-3 for an illustration of this variable. If the section property is not redefined, DD and BB default to the major and minor dimensions of the beam property specified in the original ETABS data. Also, DCT and DCB default to 0.1*DD.
5. The entries DS and BF are for introducing T-Beam effects into the beam design algorithm.

The depth DS is always assumed to be at the top of the beam and the T-Beam effect is only introduced when the moment condition indicates compression at the top of the beam.

4(ii) - NOTES: (continued)

If DS is 0 or BF is 0 the section defaults to a rectangular section of dimensions **BB x DD**.

4(iii). Wall Property Redefinition Data

This data section is for defining a table of concrete wall section properties assigning concrete wall properties to the wall assemblages that have been previously defined in the ETABS data.

It should be reiterated that only wall sections with a wall or masonry material type (i.e. equal to W or M) will be included in the processing by WALLER.

If NRWP is 0, skip this data section. Otherwise, provide NRWP data sets to assign wall properties to the ETABS panel property data, or to define additional wall properties.

Each data set consists of two data lines, a section definition data line immediately followed by a reinforcing definition data line.

a. Section Definition Data Line

Prepare one data line in the following form:

ID IMAT ITYPE WD1 WD2 WD3 WD4

b. Reinforcement Definition Data Line

The format of this data line depends upon the section type, ITYPE.

If ITYPE is W1 or W2, namely, the explicit wall reinforcing is not being specified, prepare one data line in the following form to define the acceptable values of reinforcing percentages.

PTMAX PCMAX

4(iii). Wall Property Redefinition Data (continued)

If **ITYPE** is **RW1** or **RW2**, namely, the wall reinforcing is explicitly being specified, prepare one data line to define the section reinforcing in the following form. See Figure IV-2.

D1 A1 N1 S1 D2 A2 N2 S2 D3 A3 ...

4(iii). Wall Property Redefinition Data (continued)

Variable Field Note Entry

N1 3 (6) Number of equally spaced reinforcing locations (including first station)

S1 4 (6) Spacing between equally spaced reinforcing locations, inches or meters

Defining Reinforcing Set #2:

D2 5 (6) Distance to center of first reinforcing station from face of section, inches or meters

(Reci
re:

A2 6 (6) Total area of reinforcing placed at the distance D2, inches² or meters²

N2 7 (6) Number of equally spaced reinforcing locations (including first station)

S2 8 (6) Spacing between equally spaced reinforcing locations, inches or meters

Data

Number of the concrete element being added or the property being redefined

Station number for this type

and IV-2.
ular section

cing not specified

section

cing not specified

ular section

cing specified

section

cing specified

es or meters

ches or meters

**4(iii). Wall Property Redefinition Data
(continued)****Variable Field Note Entry**

WD3 6 (4) Flange dimension in the direction of the wall length, inches or meters
(not needed for section types W1 and RW1)

WD4 7 (4) Flange dimension in the direction of the wall thickness, inches or meters
(not needed for section types W1 and RW1)

PTMAX 1 (5) Maximum percentage of steel allowed for tension design

PCMAX 2 (5) Maximum percentage of steel allowed for compression design

Defining Reinforcing Set #1:

D1 1 (6) Distance to center of first reinforcing station from face of section, inches or meters

A1 2 (6) Total area of reinforcing placed at the distance **D1**, inches² or meters²

4(iii) - NOTES: (continued)

The default section type is W1.

4. The entries **WD1**, **WD2**, **WD3** and **WD4** define the geometry of the sections. The **WD3** and **WD4** entries are obviously not needed for section types W1 and RW1. For wall type W1, **WD1** must be greater than $2 \times \text{WD2}$. Also, for wall type W1, if **WD1** is left as zero or if the section property is not redefined, it defaults to the sum of lengths of all panels making up the wall to which this section property is assigned. If the section property is not redefined **WD2** defaults to the thickness of the first panel that makes up the wall to which this section is assigned.
5. The wall design to accommodate the tension and compression effects of overturning is implemented using an iterative solution scheme which is based upon limiting the tension and compression steel percentages in the edge members of the wall. Details of the algorithms are presented in Chapter III. These entries define the values of the steel percentages. Recommended values are

PTMAX = .060

PCMAX = .040

4(iii) - NOTES:

1. The wall property sets may be entered in any order, however, the identification numbers must be between 1 and (NPP+NRWP). If the identification number is less than or equal to NPP, the property set replaces the corresponding panel property set that was previously defined in the ETABS data. If the identification number is greater than NPP, this new set of properties is added to the panel/wall property table.
2. This entry references the material property types that were previously defined in the ETABS data or subsequently redefined or added in Section 3 above. This entry must not be less than 1 and must not be greater than the maximum number of material types which exist in the material property table.
3. The WALLER program can only be used for the design of symmetric rectangular or flanged wall sections as shown in Figures IV-1 and IV-2.

For wall section types W1 and W2, the wall trim reinforcing to satisfy overturning requirements and the wall horizontal and vertical reinforcing to satisfy shear requirements will be calculated by the program.

For wall section types RW1 and RW2 the program will calculate load-moment interaction diagrams based upon the specified section dimension and reinforcing and report an overturning capacity ratio based upon the axial forces and overturning moments that exist in the walls. The shear design formulation for the RW1 and RW2 section types is identical to that of the W1 and W2 section types.

See Chapter III for details of the design algorithms.

5. FRAME DESIGN ACTIVATION DATA SETS

Provide NFR data sets, one for each of the ETABS frames that are to be designed/stress checked.

(i). Frame Design Control Data

Prepare one line of data in the following form:

I ITYP IRCP IRBP IRWP

4(iii) - NOTES: (continued)

6. The wall reinforcing is defined by a series of D, A, N and S entries. To define the reinforcing of the section, the user may enter as many D, A, N, S sets as are possible on one data line.

For example, the reinforcing in the wall section type RW1 shown in Figure IV-2a may be defined by a data line having two D, A, N, S sets as follows:

D1 A1 N1 S1 D2 A2 N2 S2

where D1 A1 N1 S1 define the reinforcing at reinforcing stations 1, 2 and 3 as shown in the figure so that N1 = 3 and the entries D1, A1 and S1 are as illustrated in Figure IV-2a.

Similarly, D2 A2 N2 S2 define the reinforcing at stations 4 through 7 so that N2 = 4.

The reinforcing in the wall section type RW2 as shown in Figure IV-2b is defined by three D, A, N, S sets, so that the data line is as follows:

D1 A1 2 S1 D2 A2 1 0 D3 A3 3 S3

The value of N in the D, A, N, S sequence must be at least 1. If N is 1, the S value is not used, however, a zero value must be entered to complete the sequence of the four D, A, N, S entries.

Only the reinforcing that exists to the left of the center line of the wall should be specified. Reinforcing to the right of the center line will be generated by the program using symmetry. If reinforcing exists on the center line only one half of it should be specified.

5(i) - NOTES:

1. This is a positive nonzero number, not greater than NTF. This sequence number refers to the sequence in which the frames are entered in the ETABS data. See Chapter V, Section D-7 of the ETABS manual (Frame Location Data). In this data section the frame that is entered first has a sequence number of 1, and the frame that is entered last has a sequence number of NTF.

The frames may be stress checked in any sequence.

2. This flag determines whether the special seismic requirements of the codes are to be used. If ITYP is 1, the seismic requirements are used. If ITYP is 2, the seismic requirements are not used. The default value for ITYP is 1.
3. Irrespective of any material or section property redefinition in the material or section property data above, it is possible to reassign section properties on an element-by-element basis.

It is also possible to assign live load reduction factors on an element-by-element basis.

If any of these parameters are to be reassigned for any of the column elements in this frame, IRCP must be set to 1. The program will then expect column element reassignment data in Section 5(ii)-a below.

If any of these parameters are to be reassigned for any of the beam elements in this frame, IRBP must be set to 1. The program will then expect beam element reassignment data in Section 5(ii)-b below.

5(i). FRAME DESIGN CONTROL DATA
(continued)**Variable Field Note Entry**

I	1	(1)	Frame sequence number that uniquely identifies this frame among the NTF total frames
ITYP	2	(2)	Frame design type = 1 Seismic = 2 Non-Seismic
IRCP	3	(3)	Column reassignment flag: = 0 No column reassignments provided. = 1 Column reassignments provided
IRBP	4	(3)	Beam reassignment flag: = 0 No beam reassignments provided. = 1 Beam reassignments provided.
IRWP	5	(3)	Wall reassignment flag: = 0 No wall reassigments provided. = 1 Wall reassigments provided

a. Column Element Reassignment Data

If IRCP is 0, none of the column element parameters are to be reassigned, therefore, skip this data section (including the blank termination line defined below).

Otherwise, provide as many data lines as needed to define the required parameters. The order of input is immaterial and parameter assignments for any column element at any level may be repeated. The last values read (or generated) will be used. **End this data section with a blank line.** Prepare the data in the following form:

NT NSAME MC1 MC2 SD1 SD2 P

5(ii). Element Reassignment Data

If any of the parameters are to be reassigned for any of the wall assemblages in this frame, IRWP must be set to 1. The program will then expect wall assemblage reassignment data in Section 5(ii)-c below. The default wall assemblage property number is the panel property number of the first panel making up the wall assemblage.

This data section is only needed if the column, beam or wall element section property identifications or live load reduction factors are to be assigned or reassigned.

Prepare one (or up to three) of the following data Sections a, b and c below, as required.

b. Beam Element Reassignment Data

If IRBP is 0, none of the beam element parameters are to be reassigned, therefore, skip this data section (including the blank termination line defined below). Also, if NB is 0 there are no bays defined in this frame. Therefore, skip this data section completely (including the blank termination line defined below).

Otherwise, provide as many data lines as needed to define the required parameters. The order of input is immaterial and parameter assignments for any beam element at any level may be repeated. The last values read (or generated) will be used. **End this data section with a blank line.** Prepare the data in the following form:

NT NSAME MB1 MB2 SD1 SD2 P

**5(ii)-a. Column Element Reassignment Data
(continued)****Variable Field Note Entry**

NT	1	(1)	Data line type: = I Property type = R Live load factor
NSAME	2	(2)	Column line number, the properties of which are to be repeated at column lines MC1 through MC2
MC1	3	(4,7)	Column line number of first column line being reassigned
MC2	4	(4,7)	Column line number of last column line being reassigned
SD1	5	(6,7)	Identification of the story level associated with topmost column being reassigned
SD2	6	(6,7)	Identification of the story level associated with bottommost column being reassigned
P	7	(10)	Parameter being assigned: = Column property ID (NT = I) = Live load factor (NT = R)

c. Wall Element Reassignment Data

If **IRWP** is 0, none of the wall element parameters are to be reassigned, therefore, skip this data section (including the blank termination line defined below). ()

Also, if **NPAN** is 0, there are no wall elements in this frame. Therefore, skip this data section completely (including the blank termination line defined below). ()

Otherwise, provide as many data lines as needed to define the required parameters. The order of input is immaterial and parameter assignments for any wall element at any level may be repeated. The last values read (or generated) will be used. **End this data section with a blank line.** Prepare the data in the following form:

NT MW1 MW2 SD1 SD2 P ()

**5(ii)-b. Beam Element Reassignment Data
(continued)****Variable Field Note Entry**

NT	1	(1)	Data line type: = I Property type = R Live load factor
NSAME	2	(3)	Bay number, the properties of which are to be repeated at bays MB1 through MB2
MB1	3	(5,8)	Bay number of first bay being reassigned
MB2	4	(5,8)	Bay number of last bay being reassigned
SD1	5	(6,8)	Identification of the story level associated with topmost beam being reassigned
SD2	6	(6,8)	Identification of the story level associated with bottommost beam being reassigned
P	7	(10)	Parameter being assigned: = Beam property ID (NT = I) = Live load factor (NT = R)

5(ii) - NOTES:

1. This entry identifies the type of data that is being defined by this data line. For example, if **NT** = **R**, the parameter **P** on this data line is the live load factor.
2. If **NSAME** is nonzero, it is a column line number, the properties of which are already defined by default or by user specifications in preceding data lines of this data section.

The nonzero entry for **NSAME** puts the program into a duplication mode. In this mode, the member properties (as identified by the **NT** entry) for the column elements at all levels on column lines **MC1** through **MC2** are set identical to the properties of the column elements, at the corresponding levels, of column line **NSAME** as it stands defined at the time of this entry.

Redefinitions of column properties on column line **NSAME** in subsequent data lines will not result in automatic corresponding redefinitions of the member properties on the duplicated column lines **MC1** through **MC2**.

In the duplication mode, the entries for **SD1**, **SD2** and **P** are meaningless and must not be entered. These entries are only needed if **NSAME** is 0.

3. If **NSAME** is nonzero, it is a bay number, the properties of which are already defined by default or by user specification in preceding data lines of this data section.

5(ii)-c. Wall Element Reassignment Data
(continued)**Variable Field Note Entry**

NT	1	(1)	Data line type: = I Property type = R Live load factor
MW1	2	(9)	ETABS Wall ID of first wall being reassigned
MW2	3	(9)	ETABS Wall ID of last wall being reassigned
SD1	4	(9)	Identification of the story level associated with topmost wall being reassigned
SD2	5	(9)	Identification of the story level associated with bottommost wall being reassigned
P	6	(10)	Wall parameter being reassigned: = WALLER Wall property ID (NT = I) = Live load factor (NT = R)

5(ii) - NOTES: (continued)

7. All column elements existing on column lines MC1 through MC2 associated with levels SD1 through SD2 will be assigned the properties identified by the entries NT and P on this data line.

As a reminder, column elements associated with a particular level exist below the level.

8. All beam elements existing in bays MB1 through MB2 between levels SD1 through SD2 (inclusive) will be assigned the properties identified by the entries NT and P on this data line.
9. All wall assemblages associated with levels SD1 through SD2 having identifications between MW1 and MW2 will be assigned the properties identified by the entries NT and P on this data line.

As a reminder, walls associated with a particular level exist below the level.

10. If NT = I, the data line is for reassigning member property identifications and the parameter P is an integer entry referring to the section property tables originally defined in the ETABS data or redefined in Section 4 above. The default values for the section properties are as originally defined in the ETABS data. For wall assemblages, since there is no corresponding wall property in ETABS, the wall property number in WALLER defaults to the panel property number of the first panel making up the wall assemblage.

5(ii) - NOTES: (continued)

The nonzero entry for **NSAME** puts the program into a duplication mode. In this mode, the member properties (as identified by the **NT** entry) for the beam elements at all levels in bays **MB1** through **MB2** are set identical to the properties of the beam elements, at the corresponding levels, in bay **NSAME** as it stands defined at the time of this entry.

Redefinitions of beam properties in bay **NSAME** in subsequent data lines will not result in automatic corresponding redefinitions of the member properties in the duplicated bays **MB1** through **MB2**.

In the duplication mode, the entries for **SD1**, **SD2** and **P** are meaningless and must not be entered. These entries are only used if **NSAME** is 0.

4. This entry is a column line number. The number must not be greater than **NC**. Also, **NC2** may never be less than **NC1**.
5. This entry is a bay number. The number must not be greater than **NB**. Also, **NB2** may never be less than **NB1**.
6. This entry is an alphanumeric story identifier that must correspond to one of the story level identifiers previously defined in Section 3 of the ETABS data.

The level associated with **SD2** may never be higher than the level associated with **SD1**.

()

()

()

5(ii) - NOTES: (continued)

If $NT = R$, the data line is for defining live load reduction factors. The entry P is the live load reduction factor for the column.

Thus, for instance, if the axial force in a column at a particular level for load condition **LLC** is 50k, and the entry P is 0.7, then the axial force in load condition **LLC** (that will further be scaled by the design load combinations) will be taken as

$$0.7 \times 50k = 35k$$

The program does not have any algorithm based upon tributary area of the column to calculate the live load reduction factor.

The default value for the reduction factor is 1.0.

In addition to the echo of all of the WALLER input data and control information recovered from the ETABS postprocessing file, the file DESWAL.WAL may contain the following:

1. For every wall (modeled as a column or an assemblage of panel elements) for which the explicit reinforcing has been specified by the user, namely, wall types RW1 and RW2, the file will contain the controlling moment interaction capacity ratios for the top and bottom ends of the wall with the associated load combination numbers and the critical axial force and moment sets, namely, the coordinates of point L in Figure III-8.

For every wall for which the explicit reinforcing has not been specified, namely, wall types W1 and W2, the file will contain the required tension and compression trim reinforcing for the top and bottom ends of the wall and the associated edge distance from the ends of the wall, within which the calculated reinforcing must be placed.

Also, for every wall, the required shear reinforcing, the controlling shear force and shear stress, along with the controlling load combination number, are tabulated.

See Figures V-2 and V-3 for details of the output formats.

2. For each concrete beam-spandrel, the file will contain the required top and bottom flexural reinforcing, shear reinforcing and shear stress at each of the five beam design stations. See Figure V-4 for details of the output format.

V.

PROGRAM OUTPUT

A. DESCRIPTION OF OUTPUT FILES

If the name of the ETABS analysis data file is EXWAL, the ETABS analysis will produce a postprocessing file called EXWAL.PST.

If the name of the WALLER input data file is DESWAL, there will be two output files produced by WALLER, namely DESWAL.WAL and DESWAL.WIN. However, if program defaults are acceptable, and WALLER input data file is not provided, the two output files produced by WALLER are EXWAL.WAL and EXWAL.WIN.

Sample output is presented in the last section of this manual. For English units, all output is in kip-inch units except for the shear reinforcing steel, which is in square inches/foot. For MKS metric units, all tabulations associated with the echoing of the input data are in MKS units. However, all calculated forces and moments are in meter-ton-second units. All calculated reinforcing steel is output in square centimeters and all shear steel is tabulated in square centimeters/meter. For SI metric units, all output is in meter-kiloNewton units except calculated reinforcing steel is output in square centimeters and all shear reinforcing steel is tabulated in square centimeters/meter.

The walls modeled as column elements are output first, followed by the design of the walls modeled as panel elements. The spandrel design is output last.

B. DESIGN OVERSTRESSES AND FAILURE SITUATIONS

In the design or capacity check process, the program will produce diagnostic messages if overstress or failure conditions are encountered.

The diagnostics are in the form of check numbers, namely CHK#1, CHK#2, etc.

A description of the design diagnostic checks is presented in Figure V-1.

C. DETAILS OF THE DESIGN OUTPUT INFORMATION

The following notes detail the information that is presented in the output files produced by the program. The notes correspond to the numbers shown in Figures V-2, V-3, V-4, V-5 and V-6.

- (1) This is the level ID number of the column element being designed. The column line ID number is shown above.

The output shown in Figure V-2 is for walls modeled with column elements. The output for walls modeled with wall elements will have the same information, except that the wall ID number is displayed instead of the column ID.

The file DESWAL.WIN contains additional back-up information associated with the design of each wall and beam. The purpose of this information is to aid the user in the manual verification of the results produced by the program. The file contains the following:

1. A numerical tabulation of the load-moment interaction diagrams generated by the program for the wall section types RW1 and RW2, namely, the wall sections for which explicit reinforcing has been specified by the user. See Figure III-4. The printing of these tables is optional.

The interaction diagrams are tabulated both with the strength reduction factor and without it. The P_{max} limit is included in both tables.

2. For each wall of types RW1 or RW2, the file will contain the coordinates of the failure point, namely point C in Figure III-8, corresponding to the stress ratios calculated for the top and bottom ends of the wall. See Figure V-5.
3. For each wall of types W1 or W2, the file will contain the controlling tension and compression edge forces (with the associated combination numbers) used for calculating the compression and tension reinforcing requirements for the top and bottom ends of the wall. See Figure V-6.
4. For each beam-spandrel, the file will contain the controlling positive and negative bending moments and shear forces at each of the five beam design stations, along with the controlling load combination numbers.

The design output for a particular frame is in the following sequence:

- (2) This is the station identification corresponding to the output line.
- (3) This is the controlling axial force and moment set that produced the controlling stress ratio. A negative axial force indicates tension. This force, moment set represents the point L in Figure III-8; point C is defined in the DESWAL.WIN file. See Note (22) below.
- (4) This is the controlling load combination number that produced the controlling capacity ratio.
- (5) This is the controlling capacity ratio.
- (6) This is the value of the maximum factored shear force.
- (7) This is the value of the maximum factored shear stress, obtained by dividing the maximum factored shear force by the gross area of the section.
- (8) This is the controlling load combination number for the maximum factored shear force.
- (9) This is the required shear reinforcing in square inches/foot (or square centimeters/meter), namely, horizontal bars, averaging an area equal to this reported value for every foot along the height of the wall, to be provided. For example, if the reported steel is 0.60, #5 bars (area = 0.31 square inches) placed horizontally at 6 inches center to center along the height of the wall in a single layer at midplane of the wall will be adequate, giving a total of 0.62 square inches/foot.

The vertical reinforcing size and spacing is in general made to match that of the horizontal reinforcing.

CHECK #	OVERSTRESS CONDITION
CHK#1	Concrete compression failure (depth of compression block exceeds maximum allowed). Increase section size, or try T-Beam if failure is due to positive moment.
CHK#2	Beam shear stress exceeds maximum allowed. No shear reinforcing calculated. Increase section size.
CHK#3	Wall shear stress exceeds maximum allowed. No shear reinforcing calculated. Increase section size.
CHK#4	P_u is greater than P_{max} . See Figure III-4. Increase section size.
CHK#5	P_u is less than $-P_o$. See Figure III-4. Increase reinforcing.
CHK#6	Tension failure in approximate design algorithm. Increase maximum steel percentage, PTMAX, or try using wall type with reinforcing specified, as this algorithm is conservative.
CHK#7	Compression failure in approximate design algorithm. Increase maximum steel percentage, PCMAX, or try using wall type with reinforcing specified, as this algorithm is conservative.
CHK#8	Design suppressed due to other compression or tension failure on section.

- (18) This is the required top reinforcing at the station corresponding to the factored negative design moment.
- (19) This is the required bottom reinforcing at the station corresponding to the factored positive design moment.
- (20) This is the required vertical shear reinforcing in square inches/foot (or square centimeters/meter), namely vertical stirrups, averaging an area equal to this reported value for every foot of beam length are to be provided. For example, if the reported steel is 0.60, and the shear reinforcing is of the type shown in the beam section in Figure IV-3, a #5 stirrup (area = 0.31 square inches) placed at 12 inches center to center will be adequate, giving a total of 0.62 square inches/foot.
- (21) This is the required minimum horizontal shear reinforcing in square inches/foot (or square centimeters/meter), namely horizontal bars, averaging an area equal to this reported value for every foot of beam height are to be provided, when the beam falls under the category of a deep beam.
- (22) This is the required area of one leg of the diagonal (cross-bar) reinforcement in square inches (or square centimeters) for coupling beams which satisfy the UBC '88 chapter 26, Section 25 requirements.
- (23) This axial force and moment set corresponds to the point C in Figure III-8. See Note (3) above. A negative axial force indicates tension.
- (24) These are controlling factored design tension forces (and associated load combination numbers) that are used in the design of the edge member tension reinforcing.

The shear reinforcing may be controlled by a different loading combination than the maximum factored shear force.

- (10) This is the edge member width, B, within which the calculated tension and compression steel must be located (see Figure III-9). As far as practical, the center of gravity of the steel must coincide with the center of this edge member.

The reinforcing provided in the edge member distance must be the greater of the tension and compression steel areas that are reported. For the correct orientation of the left and right side of the wall, the element must be viewed with the positive axis (major) of the element pointing to the right.

- (11) This is the reinforcing that must be provided in the edge member to satisfy tension requirements.
- (12) This is the reinforcing that must be provided in the edge member to satisfy compression requirements.
- (13) This is the bay number of the spandrel.
- (14) This is the size of the beam being used. For a T-Beam section, these are the dimensions of the beam web.
- (15) This is the station identification where the stress ratio is being evaluated.
- (16) This is the beam length to effective depth ratio.

- (17) This is the value of the maximum factored shear stress, obtained by dividing the maximum factored shear force by the gross area of the section.

CSI/ETABS - EXTENDED THREE DIMENSIONAL ANALYSIS OF BUILDING SYSTEMS PAGE 8
 ETABS_FILE:EXWAL.PST/WALLER/FILE:DESWAL.WAL

/SAMPLE EXAMPLE FOR WALLER MANUAL
 /CONCRETE SHEAR WALL BUILDING

WALL PROCESSING OF COLUMN ELEMENTS (UBC 1991 CONCRETE)

FRAME ID /PIER-SPANDREL WALL
 COLUMN ID 1

OUTPUT FOR WALL TYPES RW1 AND RW2

LEVEL TYPE / ----- / WALL MOMENT INTERACTION ----- / ----- / WALL SHEAR DESIGN ----- /																			
ID	STA	FORCE																	
	LOC	(K)																	
ROOF	LOC	(K-in)																	
RW1	(8.00in x 48.00in)																		
	TOP	13	568	< 3 >	.08														
	BOT	3	373	< 5 >	.07														
NOTE:	(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)	(9)										

Typical Wall Design Output from File DESWAL.WAL
 (Column and Panel Elements) Wall Section Types RW1 and RW2

Figure V-2

- (25) These are the controlling design compression forces (and associated load combination numbers) that are used in the design of the edge member compression reinforcing.
- (26) This is the maximum factored negative moment value (negative sign suppressed) at the station from all the loading combinations along with the number of the controlling load combination.
- (27) This is the maximum factored positive moment value at the station from all the loading combinations along with the number of the controlling load combination.
- (28) This is the maximum factored design shear force at the station from all the loading combinations along with the number of the controlling load combination.

CSI/ETABS - EXTENDED THREE DIMENSIONAL ANALYSIS OF BUILDING SYSTEMS PAGE 12
 /SAMPLE EXAMPLE FOR WALLER MANUAL
 /CONCRETE SHEAR WALL BUILDING

SPANDREL DESIGN OF BEAM ELEMENTS (UBC 1991 CONCRETE)
 FRAME ID /PIER-SPANDREL WALL
 LEVEL ID ROOT

BAY ID	WIDTH X (in)	DEPTH (in)	BEAM SIZE 36.00	STRESS {ksi}	L/d	SHEAR M{top} / {kipin}	REQUIRED REBAR		
							M{bot} / {kipin}	Vv / {kipin}	Vh / {kipin}
END I	2.3	.07	.34	.17	.14	.24	.00	.00	
1/4-PT	2.3	.06	.14	.12	.14	.24	.00	.00	
MIDDLE	2.3	.04	.01	.06	.14	.24	.00	.00	
3/4-PT	2.3	.04	.06	.12	.14	.24	.00	.00	
END J	2.3	.06	.19	.17	.14	.24	.00	.00	
NOTE: (13) (14) (15) (16) (17) (18) (19) (20) (21) (22)									

Typical Beam Design Output from File DESWAL.WAL
 Figure V-4

CSI/ETABS - EXTENDED THREE DIMENSIONAL ANALYSIS OF BUILDING SYSTEMS PAGE 19
ETABS_FILE:DESWAL.PST/WALLER/FILE:DESWAL.WAL

```
/ CONCRETE SHEAR WALL BUILDING
WALL PROCESSING OF COLUMN ELEMENTS (UBC 1991 CONCRETE)

FRAME ID .... /CANTILEVER WALL
COLUMN ID .... 1

OUTPUT FOR WALL TYPES W1 AND W2

LEVEL TYPE/-----WALL OVERTURNING DESIGN-----//----WALL SHEAR DESIGN----/
ID STA EDGE /-TENS STEEL-/ -COMP STEEL-/ FORCE STRESS COMBO A(/ft)
LOC MEMBER LEFT RIGHT LEFT RIGHT
(in) (sqin) (sqin) (sqin) (sqin) (sqin) (sqin)
ROOF W1 (8.00in X 216.00in)
TOP 6.00 .0 .0 .0 .059 < 2 > .00
BOT 6.00 1.1 1.1 .0 .0
NOTE: (1) (2) (10) (11) (11) (12) (12) (6) (7) (6) (9)
```

Typical Wall Design Output from File DESWAL.WAL
(Column and Panel Elements) Wall Section Types W1 and W2
Figure V-3

CSI/ETABS - EXTENDED THREE DIMENSIONAL ANALYSIS OF BUILDING SYSTEMS PAGE 11
 /SAMPLE EXAMPLE FOR WALLER MANUAL
 /CONCRETE SHEAR WALL BUILDING

WALL PROCESSING OF COLUMN ELEMENTS (UAC 1991 CONCRETE)
 FRAME ID ... / CANTILEVER WALL
 COLUMN ID ... 1

BACKUP DESIGN INFORMATION FOR WALL TYPES W1 AND W2

LEVEL TYPE / ID	STA / LOC	WALL DESIGN INFORMATION			COMPRESSION FORCE / RIGHT COMBO	LEFT COMBO (K)	RIGHT COMBO (K)
		TENSION FORCE (K)	LEFT COMBO (K)	RIGHT COMBO (K)			
ROOT	W1 (8.000in x 216.00in)	TOP 0 < 5>	0 < 5>	15 < 2>	15 < 2>		
	BOT 60 < 5>	60 < 5>	85 < 2>	85 < 2>			
NOTE:	(1)	(2)	(24)	(24)	(25)	(25)	

Typical Wall Design Backup Information from File DESWAL.WIN
 (Column and Panel Elements) Wall Section Types W1 and W2

Figure V-6

CSI/ETABS - EXTENDED THREE DIMENSIONAL ANALYSIS OF BUILDING SYSTEMS PAGE 2
ETABS_FILE:DESWAL.PST/WALL/FILE:DESWAL.WIN

/SAMPLE EXAMPLE FOR WALLER MANUAL
/CONCRETE SHEAR WALL BUILDING

WALL PROCESSING OF COLUMN ELEMENTS (UBC 1991 CONCRETE)

FRAME ID /PIER-SPANDREL WALL
COLUMN ID 1

BACKUP DESIGN INFORMATION FOR WALL TYPES RW1 AND RW2

LEVEL TYPE/---WALL INTERACTION INFORMATION---/
ID STA /---FAILURE POINT---/
LOC FORCE MOMENT
 (K) (K-in)

ROOF	RW1 (8.00in x 48.00in)	155	6696
	TOP	37	5490
	BOT		

NOTE: (1) (2) (23) (23)

Typical Wall Design Backup Information from File DESWAL.WIN
(Column and Panel Elements) Wall Section Types RW1 and RW2

Figure V-5

()

()

()

CSI/ETABS - EXTENDED THREE DIMENSIONAL ANALYSIS OF BUILDING SYSTEMS PAGE 6
ETABS_FILE:DESWAL.PST/WALLER/FILE:DESWAL.WIN

/SAMPLE EXAMPLE FOR WALLER MANUAL
/CONCRETE SHEAR WALL BUILDING

SPANDREL DESIGN OF BEAM ELEMENTS (UAC 1991 CONCRETE)

FRAME ID	/PIER-SPANDREL WALL				
LEVEL ID	ROOF				
BAY	BEAM SLICE STRESS	/-FACTORED	LOADS &	COMBOS-/		
ID	WIDTH X DEPTH	POINT	+MOMENT	SHEAR		
	{in}	{in}	{in-in}	{in}		
1	8.00 x 36.00	END I	612 < 3>	915 < 4>	20 < 3>	
		1/4-PT	244 < 3>	217 < 4>	15 < 3>	
		MIDDLE	10 < 5>	117 < 2>	11 < 3>	
		3/4-PT	106 < 5>	212 < 2>	11 < 2>	
		END J	344 < 3>	314 < 4>	15 < 2>	
NOTE:	(13)	(14)	(15)	(26)	(27)	(28)

Typical Beam Design Backup Information from File DESWAL.WIN
Figure V-7

(

(

(

VI.

REFERENCES AND BIBLIOGRAPHY

1. Habibullah, A.

"ETABS - Three-Dimensional Analysis of Building Systems," Computers and Structures, Inc., Berkeley, California, 1991.

2. American Concrete Institute

"Building Code Requirements for Reinforced Concrete (ACI 318-89)," Detroit, Michigan, 1989.

3. American Concrete Institute

"Commentary on Building Code Requirements for Reinforced Concrete (ACI 318-89)," Detroit, Michigan, 1989.

4. International Conference of Building Officials

"Uniform Building Code," Whittier, California, 1991.

5. Canadian Standards Association

"Design of Concrete Structures for Buildings, A National Standard of Canada, (CAN3-A23.3-M84)," Rexdale, Ontario, 1989.

The superimposed load on the pier-spandrel frame and the shear wall with an opening for all levels is as follows.

Dead Load 1.0 K/ft

Live Load 0.5 K/ft

The design material properties are as follows:

$f'_c = 4.0$ ksi

$f_y = 60.0$ ksi

$f_{ys} = 40.0$ ksi

The UBC91 concrete code (including the seismic provisions) is used for design.

VII.

SAMPLE EXAMPLE

The following is an example to illustrate the typical input and output associated with a typical WALLER run.


The WALLER input data file, DESWAL, and the corresponding ETABS input data file EXWAL, along with ETABS postprocessing file EXWAL.PST, all exist on the WALLER disk, which comes with the complete WALLER package.

The three-story shear wall building consists of three frames, namely

1. Pier-Spandrel Frame
2. Shear Wall with an Opening
3. Cantilever Shear Wall

Elevations of these three frames illustrating the structural geometry are shown in the figure.

In the pier-spandrel frame the piers are defined as walls of type RW1, whereas all the wall elements have been designated as type W1.



WALLER Example

```

ETABS ANALYSIS FOR WALLER EXAMPLE UNITS:KIP-INCH-SECOND
CONCRETE SHEAR WALL BUILDING - UBC STATIC SEISMIC ANALYSIS
$ CONTROL DATA
3 3 3 1 4 6 2 2 3 0 1 2 1 0 0 2 0 1 0
386.4
$ STORY MASS PROPERTIES
1 1 1/386.4
.200/144 0 0 36*12 36*12
$ STORY DATA
ROOF 12*12 1
3RD 12*12 1
2ND 12*12 1
$ MATERIAL PROPERTY DATA
1 W 3833 .150/1728 .15
2 O
$ COLUMN SECTION PROPERTY DATA
1 1 RECT 4*12 8
2 1 RECT 18*12 8
$ BEAM SECTION PROPERTY DATA
1 2 USER
0 0 0 0 0
2 1 RECT 3*12 0 8
3 1 RECT 3*12 3*12 8
$ PANEL SECTION PROPERTY DATA
1 1 8
/FRAME DATA FOR PIER-SPANDREL WALL
1 3 4 3 0 0 0 2 0
$ COLUMN LINE COORDINATES
1 -16*12 0 0
2 -5*12 0 0
3 5*12 0 0
4 16*12 0 0
$ BAY CONNECTIVITY
1 1 2
2 2 3
3 3 4
$ BEAM SPAN VERTICAL LOADING PATTERNS (BSL)
1 0 1.0/12
2 0 0.5/12
$ COLUMN LOCATION DATA
1 0 ROOF 1 2
2 1
4 1
3 0 ROOF 1
$ BEAM LOCATION DATA
1 0 ROOF 2
1 0 3RD 3 1
2 1
3 0 ROOF 2 1
3 0 2ND 3
$ BSL LOCATION DATA
1 0 ROOF 1 2 0 2
2 1
3 1
/FRAME DATA FOR WALL WITH OPENING
2 3 4 3 0 8 0 2 0
$ COLUMN LINE COORDINATES
1 -18*12 0 0
2 -6*12 0 0
3 6*12 0 0
4 18*12 0 0
$ BAY CONNECTIVITY
1 1 2
2 2 3
3 3 4
$ BEAM SPAN VERTICAL LOADING PATTERNS (BSL)
1 0 1.0/12
2 0 0.5/12
$ COLUMN LOCATION DATA

```

```
$ BEAM LOCATION DATA
1 0 ROOF 1 2
2 1
3 1

$ PANEL LOCATION DATA
1 ROOF 1 2 1 2
1 ROOF 2 3 1 1
1 ROOF 3 4 1 1
2 2ND 3 4 1

$ BSL LOCATION DATA
1 0 ROOF 1 2 0 2
2 1
3 1

/FRAME DATA FOR CANTILEVER WALL
3 3 1 0 0 0 0 0 0
$ COLUMN LINE COORDINATES
1 0 0 0
$ COLUMN LOCATION DATA
1 0 ROOF 2 2

$ FRAME LOCATION DATA
1 0 0 18*12 0 /PIER-SPANDREL WALL
2 0 0 -18*12 0 /WALL WITH OPENINGS
3 0 -18*12 0 90 /CANTILEVER WALL
$ UBC STATIC SEISMIC LOADS
1 1.5 1
0 1.33 ROOF
0 1.33 ROOF
$ ADDITIONAL STORY ECCENTRICITIES
0 0 0 0
0 0 0 0
0 0 0 0

$ LOAD CASE DATA
1 0 1
2 0 0 1
3 0 0 0 0 1
4 0 0 0 0 0 1
```

```

/SAMPLE EXAMPLE FOR WALLER MANUAL
/CONCRETE SHEAR WALL BUILDING
$
$CONTROL DATA
$ ICODE NFR NLC LLC NRMP NRCP NRBP NRWP NPTS IPRI IPHI IUNIT IEX
$ 1 3 5 2 1 2 2 2 21 1 0 E 0
$
$LOAD COMBINATION DEFINITION DATA
$ L LTYP XI XII XIII XA XB XD1 XD2 XD3
$ 1 0 1.4 1.7 1.4
$ 2 2 1.4 1.4 1.4 1.4 1.4
$ 3 2 1.4 1.4 1.4 -1.4 1.4
$ 4 2 0.9 0 0.9 1.4 1.4
$ 5 2 0.9 0 0.9 -1.4 1.4
$
$MATERIAL PROPERTY REDEFINITION DATA
$ MID MTYPE E U P FY FC FYS FCS
$ 1 W 3833 .150/1728 .15 60 4 40 4
$
$COLUMN (WALL) PROPERTY REDEFINITION DATA
$ ID IMAT ITYPE WD1 WD2
$ 1 1 RW1 48 8
$ 2 1 W1 18*12 8
$ .06 .04 5 PTMAX AND PCMAX
$
$BEAM (SPANDREL) PROPERTY REDEFINITION DATA
$ ID IMAT ITYPE DD BB DCT DCB DS BF
$ 2 1 SPANDREL 36 8 2.5 2.5 8 40
$ 3 1 SPANDREL 72 8 2.5 2.5
$
$WALL (PANEL) PROPERTY REDEFINITION DATA
$ ID IMAT ITYPE WD1 WD2
$ 1 1 W1 36*12 8
$ .06 .04 5 PTMAX AND PCMAX
$ 2 1 W1 12*12 8
$ .06 .04 5 PTMAX AND PCMAX
$
$FRAME DESIGN ACTIVATION DATA
$ I ITYPE IRCP IRBP IRWP FRAME 1
$ 1 1 0 0 0
$ I ITYPE IRCP IRBP IRWP FRAME 2
$ 2 1 0 0 1
$WALL ELEMENT REASSIGNMENT DATA
$ NT MW1 MW2 SD1 SD2 P
$ I 1 1 ROOF 3RD 1
$ I 1 2 2ND 2ND 2
$
$ I ITYPE IRCP IRBP IRWP FRAME 3
$ 3 1 0 0 0

```

CSI/ETABS - EXTENDED THREE DIMENSIONAL ANALYSIS OF BUILDING SYSTEMS PAGE 1
ETABS_FILE:exwai.PST/WALLER_FILE:deswai.WAL
/SAMPLE EXAMPLE FOR WALLER MANUAL
/CONCRETE SHEAR WALL BUILDING

DESIGN CODE TYPE-----	1 (UBC 1991 CONCRETE)
NUMBER OF FRAMES TO BE DESIGNED/CHECKED---	3
NUMBER OF LOAD COMBINATIONS-----	5
ETABS LIVE LOAD CONDITION NUMBER-----	2
NUMBER OF REPLACED MATERIAL PROPERTY SETS--	1
NUMBER OF COLUMN-WALL DESIGN PROPERTY SETS--	2
NUMBER OF SPANDREL DESIGN PROPERTY SETS-----	2
NUMBER OF PANEL-WALL DESIGN PROPERTY SETS--	2
NUMBER OF POINTS PER INTERACTION CURVE-----	21
CODE FOR PRINTING INTERACTION CURVES-----	1
CODE FOR UNITY PHI FACTOR OVER RIDE-----	0
TYPE OF UNITS (ENGLISH, MKS OR SI)-----	E
EXECUTION MODE-----	0

CSI/ETABS - EXTENDED THREE DIMENSIONAL ANALYSIS OF BUILDING SYSTEMS PAGE 2
ETABS_FILE:exwal.PST/WALLER_FILE:deswal.WAL
/SAMPLE EXAMPLE FOR WALLER MANUAL
/CONCRETE SHEAR WALL BUILDING

DESIGN LOADING COMBINATION DATA

LOAD TYPE	I	II	III	A	B	DYN-1	DYN-2	DYN-3
1	0	1.400	1.700	1.400	.000	.000	.000	.000
2	2	1.400	1.400	1.400	1.400	1.400	.000	.000
3	2	1.400	1.400	1.400	-1.400	1.400	.000	.000
4	2	.900	.000	.900	1.400	1.400	.000	.000
5	2	.900	.000	.900	-1.400	1.400	.000	.000

Sample Output from WALLER (continued)

CSI/ETABS - EXTENDED THREE DIMENSIONAL ANALYSIS OF BUILDING SYSTEMS PAGE 3
ETABS_FILE:exwval.PST/WALLER_FILE:deswval.WAL
/SAMPLE EXAMPLE FOR WALLER MANUAL
/CONCRETE SHEAR WALL BUILDING

MATERIAL PROPERTIES

MAT ID	MAT TYPE	ELASTIC MODULUS [Ksi]	UNIT WEIGHT (K/cu.in)	POISONS RATIO	YIELD FY (Ksi)	STRENGTH FC (FM) (Ksi)	YIELD FYS (Ksi)	STRENGTH FCS (FMS) (Ksi)
1	W	.383E+04	.868E-04	.150E+00	.600E+02	.400E+01	.400E+02	.400E+01
2	O	.000E+00	.000E+00	.000E+00				

Sample Output from WALLER (continued)

CSI/ETABS - EXTENDED THREE DIMENSIONAL ANALYSIS OF BUILDING SYSTEMS PAGE 4
 ETABS_FILE:exwali.PST/WALLER_FILE:deswali.WAL
 /SAMPLE EXAMPLE FOR WALLER MANUAL
 /CONCRETE SHEAR WALL BUILDING

SECTION PROPERTIES FOR COLUMN ELEMENT WALLS

SECTION DEFINITION DATA

MATERIAL ID	SECTION ID	SECTION TYPE	WALL LENGTH (in)	WALL THICK (in)	FLANGE LENGTH (in)	FLANGE THICK (in)
1	1	RW1	48.0000	8.0000		
2	1	W1	216.0000	8.0000		

SECTION PROPERTIES FOR COLUMN ELEMENT WALLS

REINFORCEMENT DEFINITION DATA

/---REBAR LIMITS---/ /-----REBAR SPECIFICATIONS-----/						
SECTION ID	TYPE	(FOR W1 OR W2 TYPES) (FOR RW1 OR RW2 TYPES)				
		PTMAX	PCMAX	DISTANCE (in)	AREA NUMBER (sqin)	SPACING (in)
1	RW1			3.000	1.80000	1 .000
				17.000	.40000	1 .000
2	W1	.060	.040			

Sample Output from WALLER (continued)

CSI/ETABS - EXTENDED THREE DIMENSIONAL ANALYSIS OF BUILDING SYSTEMS PAGE 5
ETABS_FILE:exwal.PST/WALLER_FILE:deswal.WAL
/SAMPLE EXAMPLE FOR WALLER MANUAL
/CONCRETE SHEAR WALL BUILDING

SECTION PROPERTIES FOR BEAM SPANDRELS

ID	MATERIAL ID	SECTION TYPE	BEAM DEPTH (in)	BEAM WIDTH (in)	TOP COVER (in)	BOT COVER (in)	FLANGE THICK (in)	FLANGE WIDTH (in)
1	2	SPANDREL	.0000	.0000	.0000	.0000	.0000	.0000
2	1	SPANDREL	36.0000	8.0000	2.5000	2.5000	8.0000	40.0000
3	1	SPANDREL	72.0000	8.0000	2.5000	2.5000	.0000	.0000

Sample Output from WALLER (continued)

CSI/ETABS - EXTENDED THREE DIMENSIONAL ANALYSIS OF BUILDING SYSTEMS PAGE 6
ETABS_FILE:exwal.PST/WALLER_FILE:deswal.WAL
/SAMPLE EXAMPLE FOR WALLER MANUAL
/CONCRETE SHEAR WALL BUILDING

SECTION PROPERTIES FOR PANEL ELEMENT WALLS

SECTION DEFINITION DATA

MATERIAL ID	SECTION ID	SECTION TYPE	WALL LENGTH (in)	WALL THICK (in)	FLANGE LENGTH (in)	FLANGE THICK (in)
1	1	W1	432.0000	8.0000		
2	1	W1	144.0000	8.0000		

SECTION PROPERTIES FOR PANEL ELEMENT WALLS

REINFORCEMENT DEFINITION DATA

/---REBAR LIMITS---/		/-----REBAR SPECIFICATIONS-----/				
SECTION ID	TYPE	(FOR W1 OR W2 TYPES)		(FOR RW1 OR RW2 TYPES)		
		PTMAX	PCMAX	DISTANCE (in)	AREA NUMBER (sqin)	SPACING (in)
1	W1	.060	.040			
2	W1	.060	.040			

Sample Output from WALLER (continued)

CSI/ETABS - EXTENDED THREE DIMENSIONAL ANALYSIS OF BUILDING SYSTEMS PAGE 7
ETABS_FILE:exwval.PST/WALLER_FILE:deswval.WAL
/SAMPLE EXAMPLE FOR WALLER MANUAL
/CONCRETE SHEAR WALL BUILDING

FRAME DESIGN ACTIVATION CONTROL DATA . . .

FRAME SEQUENCE NUMBER-----	1
FRAME DESIGN TYPE-----	1 (SEISMIC)
COLUMN PROPERTY REASSIGNMENT FLAG-----	0
BEAM PROPERTY REASSIGNMENT FLAG-----	0
WALL PROPERTY ASSIGNMENT FLAG-----	0

FRAME CONTROL INFORMATION FROM ETABS DATA . . .

FRAME TYPE NUMBER-----	1
NUMBER OF STORY LEVELS-----	3
NUMBER OF COLUMN LINES-----	4
NUMBER OF BAYS-----	3
NUMBER OF BRACING ELEMENTS-----	0
NUMBER OF PANEL ELEMENTS-----	0 (GIVING 0 WALL SECTIONS)
NUMBER OF COLUMN LOAD TYPES-----	0
NUMBER OF BEAM SPAN LOAD TYPES-----	2
MAXIMUM POINT LOADS PER BEAM SPAN-----	0

Sample Output from WALLER (continued)

CSI/ETABS - EXTENDED THREE DIMENSIONAL ANALYSIS OF BUILDING SYSTEMS PAGE 8
 ETABS_FILE:exwal.PST/WALLER_FILE:deswal.WAL
 /SAMPLE EXAMPLE FOR WALLER MANUAL
 /CONCRETE SHEAR WALL BUILDING

WALL PROCESSING OF COLUMN ELEMENTS (UBC 1991 CONCRETE)

FRAME ID /PIER-SPANDREL WALL
 COLUMN ID 1

OUTPUT FOR WALL TYPES RW1 AND RW2

LEVEL TYPE/-----WALL MOMENT INTERACTION-----/				----WALL SHEAR DESIGN----		
ID	STA LOC	FORCE (K)	MOMENT (K-in)	COMBO RATIO	FORCE (K)	STRESS COMBO A{/ft} (ksi)
ROOF	RW1 (8.00in X 48.00in)				14	.037 < 3 > .00
	TOP	13	568	< 3 >	.08	
	BOT	3	373	< 5 >	.07	
3RD	RW1 (8.00in X 48.00in)				41	.106 < 3 > .12
	TOP	-27	1481	< 5 >	.41	
	BOT	-27	1265	< 5 >	.36	
2ND	RW1 (8.00in X 48.00in)				45	.118 < 3 > .40
	TOP	-81	1388	< 5 >	.61	
	BOT	-81	3388	< 5 >	1.01	

Sample Output from WALLER (continued)

CSI/ETABS - EXTENDED THREE DIMENSIONAL ANALYSIS OF BUILDING SYSTEMS PAGE 9
ETABS_FILE:exwmal.PST/WALLER_FILE:deswmal.WAL
/SAMPLE EXAMPLE FOR WALLER MANUAL
/CONCRETE SHEAR WALL BUILDING

WALL PROCESSING OF COLUMN ELEMENTS (UBC 1991 CONCRETE)

FRAME ID /PIER-SPANDREL WALL
COLUMN ID 2

OUTPUT FOR WALL TYPES RW1 AND RW2

ID	LEVEL	TYPE	WALL MOMENT INTERACTION-----/				WALL SHEAR DESIGN-----/			
			STA LOC	FORCE (K)	MOMENT (K-in)	COMBO < 5 >	RATIO	FORCE (K)	STRESS (Ksi)	COMBO A (ft)
ROOF	RW1	(8.00in X 48.00in)				26	.069	< 3 >	.00	
		TOP	13	791	< 5 >	.13				
		BOT	13	853	< 5 >	.14				
3RD	RW1	(8.00in X 48.00in)				62	.162	< 3 >	.35	
		TOP	40	2096	< 5 >	.33				
		BOT	40	2126	< 5 >	.34				
2ND	RW1	(8.00in X 48.00in)				56	.145	< 3 >	.37	
		TOP	34	2089	< 5 >	.34				
		BOT	34	3802	< 5 >	.68				

Sample Output from WALLER (continued)

CSI/ETABS - EXTENDED THREE DIMENSIONAL ANALYSIS OF BUILDING SYSTEMS PAGE 10
ETABS_FILE:exwal.PST/WALLER_FILE:deswal.WAL
/SAMPLE EXAMPLE FOR WALLER MANUAL
/CONCRETE SHEAR WALL BUILDING

WALL PROCESSING OF COLUMN ELEMENTS (UBC 1991 CONCRETE)

FRAME ID /PIER-SPANDREL WALL
COLUMN ID 3

OUTPUT FOR WALL TYPES RW1 AND RW2

LEVEL TYPE/-----WALL MOMENT INTERACTION-----/ -----WALL SHEAR DESIGN----/
ID STA FORCE MOMENT COMBO RATIO FORCE STRESS COMBO A(/ft)
LOC (K) (K-in) (K) (Ksi) (sqin)
ROOF
RW1 (8.00in X 48.00in) 35 .090 < 2 > .06
TOP 7 1174 < 2 > .21
BOT 1 1483 < 5 > .30

Sample Output from WALLER (continued)

CSI/ETABS - EXTENDED THREE DIMENSIONAL ANALYSIS OF BUILDING SYSTEMS PAGE 11
ETABS_FILE:exw1.PST/WALLER_FILE:desw1.WAL
/SAMPLE EXAMPLE FOR WALLER MANUAL
/CONCRETE SHEAR WALL BUILDING

WALL PROCESSING OF COLUMN ELEMENTS (UBC 1991 CONCRETE)

FRAME ID /PIER-SPANDREL WALL
COLUMN ID 4

OUTPUT FOR WALL TYPES RW1 AND RW2

ID	STA LOC	WALL MOMENT INTERACTION-----/			WALL SHEAR DESIGN----/		
		FORCE (K)	MOMENT (K-in)	COMBO RATIO	FORCE (K)	STRESS COMBO A/(ft)	(ksi)
ROOF	RW1 (8.00in X 48.00in)				22	.057 < 2>	.00
	TOP	11	1487	< 2>	.27		
	BOT	11	877	< 2>	.15		
3RD	RW1 (8.00in X 48.00in)				40	.105 < 2>	.12
	TOP	-13	1019	< 4>	.26		
	BOT	-13	1434	< 4>	.34		
2ND	RW1 (8.00in X 48.00in)				50	.129 < 2>	.33
	TOP	-32	1559	< 4>	.44		
	BOT	-32	3538	< 4>	.85		

Sample Output from WALLER (continued)

CSI/ETABS - EXTENDED THREE DIMENSIONAL ANALYSIS OF BUILDING SYSTEMS PAGE 12
 ETABS_FILE:exwal.PST/WALLER_FILE:deswal.WAL
 /SAMPLE EXAMPLE FOR WALLER MANUAL
 /CONCRETE SHEAR WALL BUILDING

SPANDREL DESIGN OF BEAM ELEMENTS (UBC 1991 CONCRETE)

FRAME ID /PIER-SPANDREL WALL
 LEVEL ID ROOF

BAY ID	WIDTH X DEPTH (in)	BEAM SIZE POINT STRESS (Ksi)	L/d	SHEAR / M(itop); M(bot); VV1/ft; VH/ft;	REQUIRED REBAR-----/				
					Avd (sqin)	(sqin)	(sqin)	(sqin)	
1	8.00 X 36.00	END I	2.3	.07	.34	.17	.14	.24	.00
		1/4-PT	2.3	.06	.14	.12	.14	.24	.00
		MIDDLE	2.3	.04	.01	.06	.14	.24	.00
		3/4-PT	2.3	.04	.06	.12	.14	.24	.00
		END J	2.3	.06	.19	.17	.14	.24	.00
2	8.00 X 36.00	END I	2.0	.11	.45	.22	.14	.24	.00
		1/4-PT	2.0	.09	.18	.14	.14	.24	.00
		MIDDLE	2.0	.08	.00	.07	.14	.24	.00
		3/4-PT	2.0	.07	.07	.25	.14	.24	.00
		END J	2.0	.05	.21	.40	.14	.24	.00
3	8.00 X 36.00	END I	2.3	.08	.39	.72	.16	.24	.00
		1/4-PT	2.3	.10	.18	.43	.14	.24	.00
		MIDDLE	2.3	.12	.00	.09	.16	.24	.00
		3/4-PT	2.3	.13	.29	.15	.23	.24	.00
		END J	2.3	.15	.75	.28	.29	.24	.00

Sample Output from WALLER (continued)

CSI/ETABS - EXTENDED THREE DIMENSIONAL ANALYSIS OF BUILDING SYSTEMS PAGE 13
 ETABS_FILE:exwsw1.PST/WALLER_FILE:deswsw1.WAL
 /SAMPLE EXAMPLE FOR WALLER MANUAL
 /CONCRETE SHEAR WALL BUILDING

SPANDREL DESIGN OF BEAM ELEMENTS (UBC 1991 CONCRETE)

FRAME ID /PIER-SPANDREL WALL
 LEVEL ID 3RD

BAY ID	BEAM WIDTH X DEPTH {in}	SIZE POINT RATIO	L/d	SHEAR STRESS (Ksi)	/-----REQUIRED REBAR-----/				
					M{top} {sqin}	M{bot} {sqin}	Vv{/ft} {sqin}	Vh{/ft} {sqin}	Avd
1	8.00 X 72.00								
		END I	1.2	.10	.73	.54	.14	.24	.00
		1/4-PT	1.2	.09	.42	.33	.14	.24	.00
		MIDDLE	1.2	.08	.14	.11	.14	.24	.00
		3/4-PT	1.2	.08	.14	.11	.14	.24	.00
		END J	1.2	.09	.40	.34	.14	.24	.00
2	8.00 X 72.00								
		END I	1.0	.11	.78	.48	.15	.24	.00
		1/4-PT	1.0	.11	.49	.38	.14	.24	.00
		MIDDLE	1.0	.10	.24	.30	.14	.24	.00
		3/4-PT	1.0	.09	.03	.23	.14	.24	.00
		END J	1.0	.08	.00	.26	.14	.24	.00
3	8.00 X 36.00								
		END I	2.3	.14	.32	.91	.25	.24	.00
		1/4-PT	2.3	.16	.06	.45	.32	.24	.00
		MIDDLE	2.3	.17	.10	.22	.38	.24	.00
		3/4-PT	2.3	.19	.63	.38	.45	.24	.00
		END J	2.3	.20	1.28	.57	.52	.24	.00

Sample Output from WALLER (continued)

CSI/ETABS - EXTENDED THREE DIMENSIONAL ANALYSIS OF BUILDING SYSTEMS PAGE 14
 ETABS_FILE:exwali.PST/WALLER_FILE:deswali.WAL
 /SAMPLE EXAMPLE FOR WALLER MANUAL
 /CONCRETE SHEAR WALL BUILDING

SPANDREL DESIGN OF BEAM ELEMENTS (UBC 1991 CONCRETE)

FRAME ID /PIER-SPANDREL WALL
 LEVEL ID 2ND

BAY ID	BEAM WIDTH X DEPTH (in)	SIZE POINT RATIO	STRESS (ksi)	L/d	SHEAR STRESS (sqin)	/-----REQUIRED REBAR-----/			
						M(top) (sqin)	M(bot) (sqin)	Vv/(ft) (sqin)	Vh/(ft) (sqin)
1	8.00 X 72.00					END I 1.2 .14 1.08 .98 .27 .24 .24 .00			
		1/4-PT	1.2 .14 .64 .62 .24 .24 .24 .00						
		MIDDLE	1.2 .13 .24 .28 .20 .24 .24 .00						
		3/4-PT	1.2 .12 .11 .15 .19 .24 .24 .00						
		END J	1.2 .13 .50 .51 .22 .24 .24 .00						
2	8.00 X 72.00					END I 2.8 .11 1.04 .94 .14 .24 .24 .00			
		1/4-PT	2.8 .10 .69 .78 .14 .24 .24 .00						
		MIDDLE	2.8 .09 .39 .62 .14 .24 .24 .00						
		3/4-PT	2.8 .08 .12 .42 .14 .24 .24 .00						
		END J	2.8 .07 .00 .25 .14 .24 .24 .00						
3	8.00 X 72.00					END I 2.8 .07 .00 .25 .14 .24 .24 .00			
		1/4-PT	2.8 .08 .23 .50 .14 .24 .24 .00						
		MIDDLE	2.8 .10 .55 .71 .14 .24 .24 .00						
		3/4-PT	2.8 .11 .91 .87 .14 .24 .24 .00						
		END J	2.8 .12 1.37 1.08 .17 .24 .24 .00						

Sample Output from WALLER (continued)

CSI/ETABS - EXTENDED THREE DIMENSIONAL ANALYSIS OF BUILDING SYSTEMS PAGE 15
ETABS_FILE:exwval.PST/WALLER_FILE:deswval.WAL
/SAMPLE EXAMPLE FOR WALLER MANUAL
/CONCRETE SHEAR WALL BUILDING

FRAME DESIGN ACTIVATION CONTROL DATA . . .

FRAME SEQUENCE NUMBER-----	2
FRAME DESIGN TYPE-----	1 (SEISMIC)
COLUMN PROPERTY REASSIGNMENT FLAG-----	0
BEAM PROPERTY REASSIGNMENT FLAG-----	0
WALL PROPERTY ASSIGNMENT FLAG-----	1

FRAME CONTROL INFORMATION FROM ETABS DATA . . .

FRAME TYPE NUMBER-----	2
NUMBER OF STORY LEVELS-----	3
NUMBER OF COLUMN LINES-----	4
NUMBER OF BAYS-----	3
NUMBER OF BRACING ELEMENTS-----	0
NUMBER OF PANEL ELEMENTS-----	8 (GIVING 4 WALL SECTIONS)
NUMBER OF COLUMN LOAD TYPES-----	0
NUMBER OF BEAM SPAN LOAD TYPES-----	2
MAXIMUM POINT LOADS PER BEAM SPAN-----	0

ASSIGNED WALL PROPERTIES AND FACTORS

WALL ID	LEVEL AT TOP	PROP ID	LIVE LD FACTOR
1	ROOF	1	1.000
1	3RD	1	1.000
1	2ND	2	1.000
2	2ND	2	1.000

Sample Output from WALLER (continued)

CSI/ETABS - EXTENDED THREE DIMENSIONAL ANALYSIS OF BUILDING SYSTEMS PAGE 16
 ETABS_FILE:exwal.PST/WALLER_FILE:deswal.WAL
 /SAMPLE EXAMPLE FOR WALLER MANUAL
 /CONCRETE SHEAR WALL BUILDING

WALL PROCESSING OF PANEL ELEMENTS (UBC 1991 CONCRETE)

FRAME ID /WALL WITH OPENINGS
 WALL ID 1

OUTPUT FOR WALL TYPES W1 AND W2

LEVEL TYPE/-----WALL OVERTURNING DESIGN-----/----WALL SHEAR DESIGN----/
 ID STA EDGE /-TENS STEEL-/-COMP STEEL-/ FORCE STRESS COMBO A{/ft)
 LOC MEMBER LEFT RIGHT LEFT RIGHT
 (in) (sqin) (sqin) (sqin) (sqin) (K) (Ksi) (sqin)
 ROOF
 W1 (8.00in x 432.00in) 72 .021 < 2> .00
 TOP 8.00 .0 .0 .0 .0
 BOT 8.00 .0 .0 .0 .0
 3RD
 W1 (8.00in x 432.00in) 119 .035 < 2> .00
 TOP 8.00 .0 .0 1.2 1.2
 BOT 8.00 .0 .0 2.5 2.5
 2ND
 W1 (8.00in x 144.00in) 83 .072 < 3> .00
 TOP 8.00 .0 .5 .0 2.1
 BOT 12.00 1.1 .0 .9 .0

Sample Output from WALLER (continued)

```
CSI/ETABS - EXTENDED THREE DIMENSIONAL ANALYSIS OF BUILDING SYSTEMS PAGE 17
ETABS_FILE:exwali.PST/WALLER_FILE:deswali.WAL
/SAMPLE EXAMPLE FOR WALLER MANUAL
/CONCRETE SHEAR WALL BUILDING

WALL PROCESSING OF PANEL ELEMENTS (UBC 1991 CONCRETE)

FRAME ID .... /WALL WITH OPENINGS
WALL ID .... 2

OUTPUT FOR WALL TYPES W1 AND W2

LEVEL TYPE/-----WALL OVERTURNING DESIGN-----//----WALL SHEAR DESIGN----/
ID STA EDGE /-TENS STEEL-/-COMP STEEL-/ FORCE STRESS COMBO A(1/ft)
LOC MEMBER LEFT RIGHT LEFT RIGHT
 (in) (sqin) (sqin) (sqin) (sqin) (K) (Ksi) (sqin)
2ND W1 (8.00in x 144.00in) 83 .072 < 2> .00
TOP 8.00 .5 .0 2.1 .0
BOT 12.00 .0 1.1 .0 .9
```

Sample Output from WALLER (continued)

CSI/ETABS - EXTENDED THREE DIMENSIONAL ANALYSIS OF BUILDING SYSTEMS PAGE 18
ETABS_FILE:exwal.PST/WALLER_FILE:deswal.WAL
/SAMPLE EXAMPLE FOR WALLER MANUAL
/CONCRETE SHEAR WALL BUILDING

FRAME DESIGN ACTIVATION CONTROL DATA . . .

FRAME SEQUENCE NUMBER-----	3
FRAME DESIGN TYPE-----	1 (SEISMIC)
COLUMN PROPERTY REASSIGNMENT FLAG-----	0
BEAM PROPERTY REASSIGNMENT FLAG-----	0
WALL PROPERTY ASSIGNMENT FLAG-----	0

FRAME CONTROL INFORMATION FROM ETABS DATA . . .

FRAME TYPE NUMBER-----	3
NUMBER OF STORY LEVELS-----	3
NUMBER OF COLUMN LINES-----	1
NUMBER OF BAYS-----	0
NUMBER OF BRACING ELEMENTS-----	0
NUMBER OF PANEL ELEMENTS-----	0 (GIVING 0 WALL SECTIONS)
NUMBER OF COLUMN LOAD TYPES-----	0
NUMBER OF BEAM SPAN LOAD TYPES-----	0
MAXIMUM POINT LOADS PER BEAM SPAN-----	0

Sample Output from WALLER (continued)

```
CSI/ETABS - EXTENDED THREE DIMENSIONAL ANALYSIS OF BUILDING SYSTEMS PAGE 19
ETABS_FILE:exwal.PST/WALLER_FILE:deswal.WAL
/SAMPLE EXAMPLE FOR WALLER MANUAL
/CONCRETE SHEAR WALL BUILDING

WALL PROCESSING OF COLUMN ELEMENTS (UBC 1991 CONCRETE)

FRAME ID .... /CANTILEVER WALL
COLUMN ID .... 1

OUTPUT FOR WALL TYPES W1 AND W2

LEVEL TYPE/-----WALL OVERTURNING DESIGN-----/----WALL SHEAR DESIGN---/
ID STA EDGE /-TENS STEEL-/ -COMP STEEL-/ FORCE STRESS COMBO A{ft}
LOC MEMBER LEFT RIGHT LEFT RIGHT
{in} {sqin} {sqin} {sqin} {sqin} {K} {Ksi} {sqin}
ROOF W1 (8.00in X 216.00in) 101 .059 < 2> .00
TOP 8.00 .0 .0 .0
BOT 8.00 1.1 1.1 .0 .0
3RD W1 (8.00in X 216.00in) 169 .098 < 2> .09
TOP 8.00 .9 .9 .0 .0
BOT 12.00 3.2 3.2 1.2 1.2
2ND W1 (8.00in X 216.00in) 201 .117 < 3> .30
TOP 12.00 3.0 3.0 1.7 1.7
BOT 16.00 5.7 5.7 4.5 4.5
```

Sample Output from WALLER (continued)

CSI/ETABS - EXTENDED THREE DIMENSIONAL ANALYSIS OF BUILDING SYSTEMS PAGE 1
 ETABS_FILE:exwai.PST/WALLER_FILE:deswal.WIN
 /SAMPLE EXAMPLE FOR WALLER MANUAL
 /CONCRETE SHEAR WALL BUILDING

COLUMN-WALL LOAD/MOMENT INTERACTION DIAGRAM

COLUMN-WALL PROPERTY ID----- 1
 COLUMN-WALL SECTION TYPE---- RW1
 WALL LENGTH----- 48.000000 (in)
 WALL THICKNESS----- 8.000000 (in)

POINT NUMBER	-----PHI INCLUDED-----/----- ULTIMATE LOAD (k) ULTIMATE MOMENT (k-in) ULTIMATE LOAD (k) ULTIMATE MOMENT (k-in)				----- PHI=1.00-----
	1	2	3	4	
1	870.6	.0	1243.7	.0	
2	870.6	2364.7	1243.7	3378.1	
3	870.6	3457.0	1243.7	4938.6	
4	864.1	4441.5	1234.4	6345.0	
5	811.5	5231.3	1159.3	7473.3	
6	753.4	6010.0	1076.2	8585.7	
7	693.7	6692.6	991.0	9560.9	
8	632.2	7285.9	903.1	10408.5	
9	568.2	7798.9	811.7	11141.3	
10	502.0	8237.7	717.1	11768.2	
11	430.6	8634.1	615.1	12334.4	BALANCE POINT
12	382.6	8536.5	546.6	12195.0	
13	333.4	8343.9	476.3	11919.8	
14	282.5	8057.2	403.5	11510.4	
15	236.0	7642.3	337.1	10917.6	
16	187.7	7108.3	268.1	10154.7	
17	136.8	6458.5	195.4	9226.4	
18	89.5	5945.3	120.4	7999.4	
19	25.4	5387.8	29.4	6252.7	
20	-102.8	2934.3	-114.2	3260.3	
21	-237.6	.0	-264.0	.0	

Sample Output from WALLER (continued)

```
CSI/ETABS - EXTENDED THREE DIMENSIONAL ANALYSIS OF BUILDING SYSTEMS PAGE 2
ETABS_FILE:exwai.PST/WALLER_FILE:dwswal.WIN
/SAMPLE EXAMPLE FOR WALLER MANUAL
/CONCRETE SHEAR WALL BUILDING

WALL PROCESSING OF COLUMN ELEMENTS (UBC 1991 CONCRETE)

FRAME ID .... /PIER-SPANDREL WALL
COLUMN ID .... 1

BACKUP DESIGN INFORMATION FOR WALL TYPES RW1 AND RW2

LEVEL TYPE/---WALL INTERACTION INFORMATION---/
ID STA /---FAILURE POINT---/
LOC FORCE MOMENT
(K) (K-in)

ROOF RW1 (8.00in X 48.00in)
TOP 155 6696
BOT 37 5490
3RD RW1 (8.00in X 48.00in)
TOP -66 3630
BOT -74 3476
2ND RW1 (8.00in X 48.00in)
TOP -133 2281
BOT -80 3365
```

Sample Output from WALLER (continued)

CSI/ETABS - EXTENDED THREE DIMENSIONAL ANALYSIS OF BUILDING SYSTEMS PAGE 3
ETABS_FILE:exwal.PST/WALLER_FILE:deswal.WIN
/SAMPLE EXAMPLE FOR WALLER MANUAL
/CONCRETE SHEAR WALL BUILDING

WALL PROCESSING OF COLUMN ELEMENTS (UBC 1991 CONCRETE)

FRAME ID /PIER-SPANDREL WALL
COLUMN ID 2

BACKUP DESIGN INFORMATION FOR WALL TYPES RW1 AND RW2

LEVEL TYPE/---WALL INTERACTION INFORMATION---/
ID STA /---FAILURE POINT---/
LOC FORCE MOMENT
(K) (K-in)

ROOF	RW1 (8.00in X 48.00in)	TOP	96	6016
		BOT	88	5930
3RD	RW1 (8.00in X 48.00in)	TOP	118	6259
		BOT	116	6236
2ND	RW1 (8.00in X 48.00in)	TOP	100	6056
		BOT	51	5608

Sample Output from WALLER (continued)

```
CSI/ETABS - EXTENDED THREE DIMENSIONAL ANALYSIS OF BUILDING SYSTEMS PAGE 4
ETABS_FILE:exwai.PST/WALLER_FILE:deswai.WIN
/SAMPLE EXAMPLE FOR WALLER MANUAL
/CONCRETE SHEAR WALL BUILDING

WALL PROCESSING OF COLUMN ELEMENTS (UBC 1991 CONCRETE)

FRAME ID .... /PIER-SPANDREL WALL
COLUMN ID .... 3

BACKUP DESIGN INFORMATION FOR WALL TYPES RW1 AND RW2

LEVEL TYPE/---WALL INTERACTION INFORMATION---/
ID STA /---FAILURE POINT---/
LOC FORCE MOMENT
      (K) (K-in)

ROOF RW1 (8.00in X 48.00in)
      TOP 34 5461
      BOT 3 4967
```

Sample Output from WALLER (continued)

CSI/ETABS EXTENDED THREE DIMENSIONAL ANALYSIS OF BUILDING SYSTEMS PAGE 5
ETABS_FILE:exwal.PST/WALLER_FILE:deswal.WIN
/SAMPLE EXAMPLE FOR WALLER MANUAL
/CONCRETE SHEAR WALL BUILDING

WALL PROCESSING OF COLUMN ELEMENTS (UBC 1991 CONCRETE)

FRAME ID /PIER-SPANDREL WALL
COLUMN ID 4

BACKUP DESIGN INFORMATION FOR WALL TYPES RW1 AND RW2

LEVEL TYPE/---WALL INTERACTION INFORMATION---/

ID	STA	/--FAILURE POINT--/	
	LOC	FORCE	MOMENT
		(K)	(K-in)
ROOF	RW1 (8.00in X 48.00in)		
	TOP	42	5535
	BOT	75	5822
3RD	RW1 (8.00in X 48.00in)		
	TOP	-50	3945
	BOT	-38	4181
2ND	RW1 (8.00in X 48.00in)		
	TOP	-73	3512
	BOT	-38	4174

Sample Output from WALLER (continued)

CSI/ETABS - EXTENDED THREE DIMENSIONAL ANALYSIS OF BUILDING SYSTEMS PAGE 6
ETABS_FILE:exwall.PST/WALLER_FILE:deswall.WIN
/SAMPLE EXAMPLE FOR WALLER MANUAL
/CONCRETE SHEAR WALL BUILDING

SPANDREL DESIGN OF BEAM ELEMENTS (UBC 1991 CONCRETE)

FRAME ID /PIER-SPANDREL WALL
LEVEL ID ROOF

BAY ID ID 1	BEAM WIDTH X DEPTH (in)	SIZE POINT (in)	-FACTORED		LOADS & -MOMENT (K-in)	COMBOS-/ +MOMENT (K-in)	SHEAR (K)
			END I	1/4-PT			
	8.00 X 36.00		612 < 3>	244 < 3>	315 < 4>	20 < 3>	
			10 < 5>	106 < 5>	217 < 4>	15 < 3>	
			3/4-PT	3/4-PT	117 < 2>	11 < 3>	
			END J	106 < 5>	212 < 2>	11 < 2>	
				344 < 3>	314 < 4>	15 < 2>	
2	8.00 X 36.00		END I	810 < 3>	390 < 4>	29 < 3>	
			1/4-PT	324 < 3>	246 < 4>	25 < 3>	
			MIDDLE	0 < 5>	131 < 2>	21 < 3>	
			3/4-PT	135 < 5>	444 < 2>	18 < 3>	
			END J	373 < 5>	726 < 2>	14 < 2>	
3	8.00 X 36.00		END I	689 < 5>	1290 < 2>	22 < 2>	
			1/4-PT	324 < 5>	777 < 2>	27 < 2>	
			MIDDLE	2 < 5>	171 < 2>	31 < 2>	
			3/4-PT	527 < 3>	277 < 4>	35 < 2>	
			END J	1318 < 3>	513 < 4>	40 < 2>	

Sample Output from WALLER (continued)

CSI/ETABS - EXTENDED THREE DIMENSIONAL ANALYSIS OF BUILDING SYSTEMS PAGE 7
 ETABS_FILE:exwal.PST/WALLER_FILE:deswal.WIN
 /SAMPLE EXAMPLE FOR WALLER MANUAL
 /CONCRETE SHEAR WALL BUILDING

SPANDREL DESIGN OF BEAM ELEMENTS (UBC 1991 CONCRETE)

FRAME ID /PIER-SPANDREL WALL
 LEVEL ID 3RD

BAY	BEAM SIZE	STRESS /-FACTORED	LOADS	COMBOS/-	
ID	WIDTH X DEPTH	POINT	-MOMENT	+MOMENT	SHEAR
	(in)	(in)	(K-in)	(K-in)	(K)
1	8.00 X 72.00	END I	2692 < 3>	2002 < 4>	57 < 3>
		1/4-PT	1557 < 3>	1225 < 4>	52 < 3>
		MIDDLE	529 < 3>	395 < 4>	46 < 3>
		3/4-PT	522 < 3>	426 < 4>	44 < 2>
		END J	1498 < 3>	1277 < 4>	49 < 2>
2	8.00 X 72.00	END I	2907 < 3>	1800 < 4>	63 < 3>
		1/4-PT	1815 < 3>	1436 < 4>	59 < 3>
		MIDDLE	880 < 5>	1111 < 2>	54 < 3>
		3/4-PT	119 < 5>	842 < 2>	50 < 3>
		END J	0 < 5>	987 < 2>	45 < 2>
3	8.00 X 36.00	END I	571 < 5>	1643 < 2>	37 < 2>
		1/4-PT	107 < 5>	815 < 2>	42 < 2>
		MIDDLE	181 < 5>	390 < 2>	46 < 2>
		3/4-PT	1119 < 3>	692 < 4>	50 < 2>
		END J	2224 < 3>	1028 < 4>	55 < 2>

Sample Output from WALLER (continued)

```
CSI/ETABS - EXTENDED THREE DIMENSIONAL ANALYSIS OF BUILDING SYSTEMS PAGE 8
ETABS_FILE:exwval.PST/WALLER_FILE:deswval.WIN
/SAMPLE EXAMPLE FOR WALLER MANUAL
/CONCRETE SHEAR WALL BUILDING

SPANDREL DESIGN OF BEAM ELEMENTS (UBC 1991 CONCRETE)

FRAME ID .... /PIER-SPANDREL WALL
LEVEL ID .... 2ND

BAY      BEAM SIZE STRESS /-FACTORED LOADS & COMBOS-/
ID WIDTH X DEPTH POINT -MOMENT +MOMENT SHEAR
  (in)    (in)      (K-in)   (K-in)    (K)
1  8.00 X 72.00
      END I  4002 < 3> 3604 < 4>  80 < 3>
      1/4-PT  2368 < 3> 2321 < 4>  75 < 3>
      MIDDLE  894 < 5> 1037 < 2>  70 < 3>
      3/4-PT  403 < 5> 575 < 2>  68 < 2>
      END J  1845 < 5> 1884 < 2>  73 < 2>
2  8.00 X 72.00
      END I  3836 < 3> 3464 < 4>  61 < 3>
      1/4-PT  2553 < 5> 2887 < 2>  56 < 3>
      MIDDLE  1459 < 5> 2288 < 2>  50 < 3>
      3/4-PT  434 < 5> 1548 < 2>  44 < 3>
      END J   0 < 5>  930 < 2>  40 < 2>
3  8.00 X 72.00
      END I   0 < 5>  930 < 2>  40 < 2>
      1/4-PT  841 < 5> 1863 < 2>  46 < 2>
      MIDDLE  2030 < 5> 2618 < 2>  53 < 2>
      3/4-PT  3349 < 3> 3238 < 4>  59 < 2>
      END J  5045 < 3> 3968 < 4>  66 < 2>
```

Sample Output from WALLER (continued)

CSI/ETABS - EXTENDED THREE DIMENSIONAL ANALYSIS OF BUILDING SYSTEMS PAGE 9
 ETABS_FILE:exwal.PST/WALLER_FILE:deawal.WIN
 /SAMPLE EXAMPLE FOR WALLER MANUAL
 /CONCRETE SHEAR WALL BUILDING

WALL PROCESSING OF PANEL ELEMENTS (UBC 1991 CONCRETE)

FRAME ID /WALL WITH OPENINGS
 WALL ID 1

BACKUP DESIGN INFORMATION FOR WALL TYPES W1 AND W2

LEVEL TYPE/-----	WALL DESIGN INFORMATION-----/			
	ID	STA/-----/ TENSION FORCE-----/	-----/ COMPRESSION FORCE-----/	
LOC	LEFT COMBO (K)	RIGHT COMBO (K)	LEFT COMBO (K)	RIGHT COMBO (K)
ROOF				
	W1 (8.00in X 432.00in)			
	TOP 0 < 5>	0 < 5>	71 < 1>	71 < 1>
	BOT 0 < 5>	0 < 5>	92 < 2>	92 < 2>
3RD				
	W1 (8.00in X 432.00in)			
	TOP 0 < 5>	0 < 5>	160 < 2>	160 < 2>
	BOT 0 < 5>	0 < 5>	201 < 2>	201 < 2>
2ND				
	W1 (8.00in X 144.00in)			
	TOP 0 < 5>	26 < 5>	122 < 2>	189 < 2>
	BOT 62 < 5>	0 < 5>	211 < 2>	100 < 2>

Sample Output from WALLER (continued)

```
CSI/ETABS - EXTENDED THREE DIMENSIONAL ANALYSIS OF BUILDING SYSTEMS PAGE 10
ETABS_FILE:exwal.PST/WALLER_FILE:deswal.WIN
/SAMPLE EXAMPLE FOR WALLER MANUAL
/CONCRETE SHEAR WALL BUILDING

WALL PROCESSING OF PANEL ELEMENTS (UBC 1991 CONCRETE)

FRAME ID .... /WALL WITH OPENINGS
WALL ID .... 2

BACKUP DESIGN INFORMATION FOR WALL TYPES W1 AND W2

LEVEL TYPE/-----WALL DESIGN INFORMATION-----/
ID STA/-----TENSION FORCE-----/ /-----COMPRESSION FORCE-----/
LOC LEFT COMBO RIGHT COMBO LEFT COMBO RIGHT COMBO
(K) (K) (K) (K)

2ND
W1 (8.00in x 144.00in)
TOP 26 < 5> 0 < 5> 189 < 2> 122 < 2>
BOT 0 < 5> 62 < 5> 100 < 2> 211 < 2>
```

Sample Output from WALLER (continued)

CSI/ETABS - EXTENDED THREE DIMENSIONAL ANALYSIS OF BUILDING SYSTEMS PAGE 11
 ETABS_FILE:exwal.PST/WALLER_FILE:deswal.WIN
 /SAMPLE EXAMPLE FOR WALLER MANUAL
 /CONCRETE SHEAR WALL BUILDING

WALL PROCESSING OF COLUMN ELEMENTS (UBC 1991 CONCRETE)

FRAME ID /CANTILEVER WALL
 COLUMN ID 1

BACKUP DESIGN INFORMATION FOR WALL TYPES W1 AND W2

LEVEL TYPE/-----		WALL DESIGN INFORMATION-----/			
ID	STA/-----	TENSION FORCE-----/	COMPRESSION FORCE-----/		
	LOC	LEFT COMBO (K)	RIGHT COMBO (K)	LEFT COMBO (K)	RIGHT COMBO (K)
ROOF	W1 (8.00in x 216.00in)				
	TOP	0 < 5>	0 < 5>	15 < 2>	15 < 2>
	BOT	60 < 5>	60 < 5>	85 < 2>	85 < 2>
3RD	W1 (8.00in x 216.00in)				
	TOP	51 < 5>	51 < 5>	100 < 2>	100 < 2>
	BOT	171 < 5>	171 < 5>	221 < 2>	221 < 2>
2ND	W1 (8.00in x 216.00in)				
	TOP	162 < 5>	162 < 5>	236 < 2>	236 < 2>
	BOT	310 < 5>	310 < 5>	385 < 2>	385 < 2>