

Education evenings 2016

Practical introduction to groundwater modelling

Computer exercises
01 04 Adding features to our model

1

Purpose

In this exercise, we will

- ✓ add a river,
- ✓ a drain,
- ✓ and constant head boundaries


to our model.

We will also

✓ visualize the fluxes from/to these model features.

Copy file previous exercise


- ✓ Copy file "/01_03_our_first_modflow_model /01_03_our_first_modflow_model. mmZLib" to folder "/01_04_adding_features_ to_our_model/"
- ✓ Change the file name to "01_04_adding_features_ to_our_model.mmZLib",
- ✓ and open the file in ModelMuse.



2

Enable MODFLOW packages


- ✓ Select Model | MODFLOW Packages and Programs...,
- ✓ and mark the checkboxes of the Flow and Head Boundary, Drain, and River packages.
- ✓ Then press **OK**.



Add a river (1/3)

- ✓ Select Object | Create | Straight Line or use the corresponding button,
- ✓ and draw a straight river in the fifth column, going from the first to the last row.






5


Add a river (2/3)

✓ In the Object Properties dialog box, change the object name to "River".



Add a river (3/3)

- ✓ Switch to the **MODFLOW**Features tab, and
- ✓ check the **River package**.
- ✓ Change Number of times to 1,
- ✓ and fill in the Starting time, Ending time, River stage, Conductance, and River bottom with, respectively, -1, 1000, -0.1, 10, -0.5.
- ✓ Then press **OK**.




-

Add a drain (1/3)


- ✓ Select Object | Create | Straight Line or use the corresponding button,
- ✓ and draw a straight drain in the 17th column, going from the first to the last row.





Add a drain (2/3)


✓ In the Object Properties dialog box, change the object name to "Drain".



C

Add a drain (3/3)


- ✓ Switch to the MODFLOW Features tab, and
- ✓ check the Drain package.
- ✓ Change Number of times to 1,
- ✓ and fill in the Starting time, Ending time, Elevation and Conductance with, respectively, -1, 1000, -0.5 and 10.
- ✓ Then press **OK**.



Add constant head boundaries (1/3)

- ✓ Select Object | Create | Straight Line or use the corresponding button,
- ✓ and draw a straight line in the first row, going from the first to the last column.
- ✓ Go through the next 2 slides and then repeat the steps for the last row.


Create straight-line object



11


Add constant head boundaries (2/3)

✓ In the **Object Properties**dialog box, change the object
name to "Constant_head_1"
or "Constant_head_2".



Add constant head boundaries (3/3)

- ✓ Switch to the **MODFLOW**Features tab, and
- check the Flow and Head Boundary package.
- ✓ Change **Number of times** to 3,
- ✓ and fill in the Time column with -1, 0, 1000, and the Head column with 0, 0, 0.
- ✓ Then press **OK**.
- ✓ Make sure you defined two constant head boundaries!



13

Run model (1/2)

- ✓ Select File | Export | MODFLOW Input Files,
- ✓ specify the file name


 "/01_04_adding_features_to_our
 _model/

 01_04_adding_features_to_our_
 model.nam", and
- ✓ click Save. ModelMuse will create
 the MODFLOW input files and
 start running MODFLOW.



Run model (2/2)


- ModelMonitor found a warning in the Listing file, but this is normal when using the Flow and Head Boundary package with transient stress periods.
- ✓ Close ModelMonitor,
- ✓ the listing file,
- ✓ and the command line window.



10

Visualize simulated heads


✓ Color the grid with the simulated heads like we did during the previous exercise.



Import flow data (1/2)

- ✓ Select File | Import | Model Results... or use the corresponding button,
- ✓ select the binary flow file "01_04_adding_features_to_our_ model.cbc", and
- ✓ click **Open**.






17


Import flow data (2/2)

- ✓ In the Select Model Results to Import dialog box, scroll down to the bottom, and
- ✓ select Constant Head, Drains, and River Leakage for Period: 2; Step: 100.
- ✓ Also, choose to color the grid with the River Leakage flows.
- ✓ Then click **OK**.



Check fluxes from/to the river

- ✓ Check the values of the fluxes from/to the river using the status bar, or Data | Show Grid or Mesh Values.
- ✓ Is the river gaining water from, or losing water to the aquifer?




10

Check fluxes to the drain (1/2)


- ✓ Now color the grid with the Drain flows, by selecting
 Data | Data visualization, or using the corresponding button,
- changing the data set to Drains_P2_S100,
- ✓ and pressing Apply.





Check fluxes to the drain (2/2)

- Check the values of the fluxes to the drain using the status bar, or Data|Show Grid or Mesh Values.
- ✓ Is the drain active over its entire length?




21

Check fluxes from/to the constant head boundaries (1/2)


- ✓ Now color the grid with the Constant Head flows, by selecting Data | Data visualization, or using the corresponding button,
- changing the data set to Constant_Head_P2_S100,
- ✓ and pressing Apply.





Check fluxes from/to the constant head boundaries (2/2)

- Check the values of the fluxes to the Constant Head cells using the status bar, or Data|Show Grid or Mesh Values.
- ✓ Why are the largest values located at the drain?



23



Education evenings 2016

Practical introduction to groundwater modelling



Questions? Found an error?
Please contact B. Rogiers at brogiers@sckcen.be.