


CROMEMCO
32K Structured Basic
Instruction Manual
Errata/Addendum

CROMEMCO, INC.
280 Bernardo Avenue
Mountain View, CA 94040

Part No. 023-0094

December 1979

COPYRIGHT © 1979
BY CROMEMCO, INC.
ALL RIGHTS RESERVED



ERRATA/ADDENDUM

Manual : Cromemco 32K Structured Basic
Publication Date : September 1979
Part No. : 023-0080

A reminder: 64K of memory is required to run Structured Basic.

BASICGEN

Basicgen is a powerful tool which allows the programmer to generate a version of Structured Basic which will occupy less than the 32K bytes required for the entire Basic interpreter. The space which is not used by Basic can be used for longer programs, larger arrays and strings, additional Basic-KSAM and normal disk buffers, etc.

The space is saved by not implementing those features of Structured Basic which are not required for a specific application. One system may not require Basic-KSAM access while another may be a run time only package which does not require the PRINT USING instruction.

Notice that a program with large arrays may be developed using shorter arrays and after the program runs properly, the DIMension statements may be changed to reflect the needed array size and the program then run under a run time only version of Sbasic.

The Sbasic which is generated by Basicgen will occupy approximately 2 to 3 K bytes more as a disk file than as a running program. This is because Basicgen saves this amount of the User Area on the disk. As an example, when Basicgen is used to create a full fledged Sbasic, the disk file will occupy 35K bytes while the same program (as supplied on your disk from Cromemco) can occupy 32K bytes. This difference is accounted for by space within Sbasic which may be used by a program (User Area.)

The following files must be present on the disk in the current drive in order for Basicgen to function properly:

B1.sbr	C2.sbr	C8.sbr
B2.sbr	C2a.sbr	C9.sbr
B3.sbr	C3.sbr	C9a.sbr
B4.sbr	C3a.sbr	C9b.sbr
B5.sbr	C4.sbr	Sbasic.sbr
Basicgen.com	C5.sbr	Sbasicio.sbr
Baslib.sbr	C6.sbr	
C1.sbr	C7.sbr	

If Basicgen cannot find any one of these files an error message will be generated and control will be returned to CDOS. If this happens the missing file must be transferred onto the disk and Basicgen executed again.

The most likely cause of this type of error is the failure of the user to rename the re-assembled Sbasicio routine from Sbasicio.rel to Sbasicio.sbr. Refer to the section of this Addendum on Modifying the Sbasic I/O Drivers for more information on this error.

To generate a new version of Sbasic enter the following command line in response to the CDOS prompt (not in Sbasic):

BASICGEN filename

where filename is the name of the file which is to be generated. Notice that no file name extension should be used with the file name, it will automatically receive an extension of COM. This is the name which will be used to call the newly generated version of Sbasic.

The Basicgen program will ask questions pertaining to the customized version of Sbasic which is to be generated. The proper response to each question is a Y or N for YES or NO respectively.

1. The first question is:

Will this be an interactive version
of SBASIC??

Notice that Basicgen prompts with a double question mark. If the user responds with an N a run-time only version of Sbasic will be generated. This will save about 5500 bytes of memory.

The only way to execute a program under a run time version of Sbasic is to declare the name of a saved Sbasic file in the CDOS command line. If RTBASIC.COM is the name of the generated run time version of Sbasic and INVENT.SAV is the name of a saved Sbasic file, the following CDOS command line will execute the program and return control to CDOS:

RTBASIC INVENT.SAV

Because the listing, editing, entering, and manual loading features are not implemented in a run time Sbasic the prompt (>>) is never displayed. The user must enter and edit a program using a version of Sbasic which is not designed for run time only use.

Notice that in this prompt the term interactive refers to the Sbasic interpreter and not to the saved program. A program running under a run-time only version of Sbasic may prompt the user and may be an interactive program.

2. The second question is:

Do you wish KSAM file access capability??

If the user responds with an N no Basic-KSAM instructions will be included in the version of Sbasic which is generated. This will save about 6500 bytes of memory.

The only instructions which are affected by the answer to this question are those listed in chapter 22 of the 32K Structured Basic Manual.

3. The third question is:

Do you wish the full text of error messages displayed??

If the user responds with an N the Sbasic which is generated will display only the appropriate error number (as listed in the appendix to the 32K Structured Basic Manual) when an error is generated. This will save about 1350 bytes of memory.

4. The fourth question is:

Do you wish editing capability??

This question will only be asked if the answer to question number one indicated that the generated Sbasic was not to be a run time only version. If the user responds with an N the In Line Basic Editor (as described on pages 74 through 78 of the 32K Structured Basic Manual) will not be included in this version of Sbasic. This will save about 770 bytes of memory.

5. The fifth question is:

Do you wish to include the PRINT USING instruction??

If the response to this question is an N, Print Using will not be implemented in the generated version of Sbasic. This will save about 900 bytes of memory.

6. The sixth question is:

Do you wish to allow user defined functions??

An N in response to this question will not allow user defined functions to be used in the generated version of Sbasic. No standard Sbasic functions will be affected by the response to this question. This will save about 190 bytes of memory.

7. The seventh question is:

Do you want to include the LOG and EXP functions and the power operator??

If the question is answered with an N, the Logarithm and Exponent functions will be inoperative and the power operator (** or ^) will not be available in the version of Sbasic which is being generated. Also, if the question is answered negatively, the square root and trigonometric functions will not be able to be implemented because they call subroutines common to the Log and Exp functions. This will save about 890 bytes of memory.

8. The eighth question is:

Do you wish to include the square root function??

An N in response to this question will disable the square root (SQR) function in Sbasic. This will save about 175 bytes of memory. Note that this question will not be asked if question number seven was answered negatively.

9. The ninth question is:

Do you wish to include the trigonometric functions??

N in response to this question will disable the trigonometric functions (SIN, COS, TAN, and ATN). This will save about 510 bytes of memory. Note that this question will not be asked if question number seven was answered negatively.

10. The last question is:

Do you wish to include the HEX, VALC, DATE,
and TIME functions and the EXPAND
instruction??

If the user types an N in response to this, the last question, the named functions and instruction will not be included in the generated version of Sbasic. This will save about 400 bytes of memory.

ADDITIONAL FEATURES

File attributes may now be established or changed from Sbasic. The format of the attribute instruction is:

Attr file-ref, "parameters"

or

Atrib file-ref, "parameters"

In the above instructions file-ref is a file reference to the file whose attributes are to be altered. File-ref may be a string or a string literal enclosed in quotation marks. Notice that ambiguous file references may be used. Parameters is one or more of the permissible parameters (+, E, R, and W), or no parameter (a null string) at all. Notice that there is no difference between the two forms of the instruction.

Please refer to the CDOS Manual, Intrinsic Commands section for further information.

In order to maintain compatibility with CDOS, an additional file renaming facility has been added to Sbasic. The new instruction reverses the two parameters of the Sbasic RENAME instruction. As in CDOS, the new instruction is called REN. The format of the instruction is:

REN new-file-ref, old-file-ref

where the file-refs are strings or string literals enclosed in quotation marks.

The DSK command now has two additional permissible parameters:

DSK "*"

and

DSK "-dr"

If the command is given in the first form, the disk

drive motors will be turned off. They will automatically be turned on again when a disk is accessed.

In the second form, dr represents one of the allowable disk drive specifiers as described in the 32K Structured Basic Manual. When dr is preceded by a dash (minus sign) the disk in the specified drive will be ejected.

Two new functions have been added to take advantage of the time and date features of CDOS and the Cromemco 3102 terminal. To set the date and time give the instructions:

Dummy\$ = Date\$("yymmdd")

and

Dummy\$ = Time\$("hhmmss")

where yymmdd are digits representing the year, month, and day and hhmmss are digits representing the hour, minute, and second.

To cause the functions to return the date and time (which will only be accurate if the system includes a Cromemco 3102 terminal) they can be called as:

Print Date\$("")

and

Print Time\$("")

Note that the functions may be assigned to string variables, printed (as above), or called in any other manner a standard function may be called.

Input to Sbasic from the terminal now takes advantage of the INPUT BUFFERED LINE system call. This will not affect most programs. Sbasic programs using the input timer must use the old (character by character) input routine. This can be invoked by giving the command:

```
SET 14,1
```

A new driver has been added to Sbasic with the name:

```
$Console
```

If this file is OPENed, a PUT instruction can invoke the CDOS call number 142 (8E hex), SET SPECIAL CRT FUNCTION:

```
OPEN\1\"$CONSOLE"  
PUT\1,d,e\ [list]
```

where d is the contents of the D register and e is the contents of the E register prior to the system call. List is the optional list of information to be displayed on the console after the system call. If e is omitted, it assumes a default value of zero.

Note that PRINT, GET, and INPUT instructions may also be used with this file following the format described above. Please refer to the CDOS manual, Programmer's Guide, system call 142, for more information.

Two additional instructions are now available for use with Basic-KSAM files:

```
KGET\pfn\var-1,...,var-n  
KPUT\pfn\exp-1,...,exp-n
```

where pfn is a Primary Data file number, var-1 through var-n is a list of variables, and exp-1 through exp-n is a list of expressions or variables.

These instructions may be used after the Current Record Pointer (CRP) has been positioned and

(optionally) after part of the current record has been written (KPUT) or read (KGET). They will cause additional fields (variables) in a long record to be written to or read from the same (current) record.

For example, the following two sets of instructions are equivalent:

```
100 Kgetfwd\1\Id'number, Year, Amount, Value
```

and

```
100 Kgetfwd\1\  
110 Kget\1\Id'number, Year  
120 Kget\1\Amount  
130 Kget\1\Value
```

A source listing of the Sbasic Input/Output routines is included at the end of this addendum. A copy of the Z80 source code for these I/O drivers is included on the Sbasic diskette under the file name SBASICIO.Z80.

Please make the following corrections to the manual:

Page : 64

Add : Add the following line to the Statistical Analysis Program:

225 If Variance < 0 Then Variance = 0

This will compensate for round-off error in the event that all numbers which are entered are the same.

Page : 73, second example

From : Dir "A:.*"

To : Dir "A:"

It is no longer necessary to follow a drive designation in this command by *.*. The drive specification alone will cause all files on that drive to be catalogued.

Page : 86, middle of page

From : (if L2 is not specified, L1=L1)

To : (if L2 is not specified, L2=L1)

Page : 184, Example Program, Line 110

From : 110 Dim A\$(21)

To : 110 Dim Text\$(21)

Page : 151, paragraph 4

From : All normal PRINT functions (such as TAB, SPC, semicolon, and comma) are overridden by the PRINT USING instruction.

To : All normal PRINT functions (such as TAB, SPC, and comma) are overridden by the PRINT USING instruction. The terminating semicolon will still suppress the generation of a new line.

Page : 235, 2nd line

From : format: SET aexp-1, aexp-2

To : format: [Ln] Set aexp-1, aexp-2

Note that this instruction may be used as a statement as well as a command (i.e., it may be used with a line number.)

Page : 240, 1st and 5th lines

From : instruction

To : function

Page : 242, 2nd line

From : format: OUT m,b

To : format: [Ln] OUT m,b

Note that this instruction may be used as a statement as well as a command (i.e., it may be used with a line number.)

Page : 244, 2nd line

From : format: POKE m,b

To : format: [Ln] POKE m,b

Note that this instruction may be used as a statement as well as a command (i.e., it may be used with a line number.)

Page : 254, 5th paragraph, 5th line

From : reference to

To : definition of

Page : 254, 6th paragraph, 3rd line

From : referenced.

To : defined.

Page : 263, first paragraph of Note, next to last line

From : Procedures.

To : files.

Page : 306, next to last line

From : 2304

To : 2560

Page : 328, last 3 lines

From : 40 Kopen \1\ Vol1\$,Vol2\$,Vol3\$,Vol4\$

Because Vol3\$ is a null string a 2 volume file (Vol1\$ and Vol2\$) are opened.

To : 40 Kaltopen \1\ Vol1\$,Vol2\$,Vol3\$,Vol4\$

Because Vol3\$ is a null string a 2 volume file (Vol1\$ and Vol2\$) is opened.

MODIFYING THE SBASIC I/O DRIVERS

A source listing of the Sbasic Input/Output routines follows. A copy of the Z80 source code for these I/O drivers is included on the Sbasic diskette under the file name SBASICIO.Z80.

Users who have the need and desire to modify these routines may modify this code, assemble it (using the Cromemco Z80 Macro Assembler), and replace the file named SBASICIO.SBR on the Sbasic diskette with the modified version.

When Basicgen is executed the new file will be used to supply the I/O routines and the user's modified drivers will automatically be incorporated into the generated Sbasic.

Notice that after assembly of the file SBASICIO.Z80 the file SBASICIO.REL will be created on the disk. This file must be renamed before executing Basicgen so that it may be properly incorporated into the generated version of Sbasic. This may be done from CDOS as follows:

```
Ren SBASICIO.SBR=SBASICIO.REL
```

Please refer to the following source listing itself for additional information.

THE FOLLOWING ROUTINES AND TABLES CONSTITUTE SBASIC'S INTERFACE
TO THE VARIOUS PERIPHERAL DEVICES.

FROM SBASIC A PERIPHERAL DEVICE IS TREATED AS IF IT WERE AN
ORDINARY DISK FILE WITH THE FOLLOWING EXCEPTIONS:

1. The 'file' (peripheral) name must start with a dollar sign.
 2. Peripheral names must be unique within the next two characters.
(i.e., "\$LPT" and "\$LPR" are seen as the same name.)
 3. Many functions within SBASIC can only refer to disk files;
examples include RENAME, ERASE, and CREATE (it doesn't
really seem logical to be able to ERASE a line printer,
anyway).
 4. Specific peripherals may or may not support all I/O operations;
one cannot GET data from a line printer, for example.
- *****

EXTERNAL ROUTINES WHICH MAY BE USED BY THE I/O ROUTINES

0027	EXT	PSHALL	; SAVE ALL REGISTERS (INCLUDING IX,IY,HL', ETC.)
0028			; ON CPU STACK
0029	EXT	POPALL	; RESTORE ALL REGISTERS
0030			; NOTE: THESE ROUTINES MUST BE ACCESSED BY A 'CALL'
0031			; DO NOT 'JP' TO THESE ROUTINES
0032	EXT	UMULT	; UNSIGNED MULTIPLY
0033			; BC * DE => HL,DE (16 BIT RESULT IN DE)
0034			; IF HL>0 (32 BIT RESULT) ROUTINE RETURNS 'NZ'
0035			; [USE CDOS CALL FOR DIVIDE, IF NEEDED.]
0036	EXT	ERTIME	; TIME-OUT ERROR FOR TIMED INPUT. DO NOT USE.
0037	EXT	ERRIO	; GENERAL I/O ERROR. TO USE, PLACE DESIRED ERROR
0038			; CODE IN THE A REGISTER AND CALL ERRIO.
0039			; NOTE: IF ERROR CODE IS 0-127, THE RESULTANT
0040			; ERROR WILL NOT BE TRAPPABLE FROM THE
0041			; SBASIC PROGRAM.
0042			; NOTE: ALSO SEE BELOW FOR SPECIAL ERROR RETURNS
0043			FROM SOME FUNCTIONS.

ENTRY POINTS WITHIN THIS MODULE

0050	ENTRY	DDLIST	; MASTER DEVICE DRIVER TABLE
0052	ENTRY	SYGETC	; GET-CHARACTER-FROM SYSTEM CONSOLE
0053			; NOTE: NOT NORMALLY USED FOR PROGRAM EDITING
0054			; AND 'INPUT'. USED BY DRIVER "\$CONSOLE"
0055			; AND BY 'GET' STATEMENT ('GET\0\...')
0056			; AND ALWAYS USED IF 'SET 14,1' USED IN SBASIC.
0058	ENTRY	SYPUTC	; PUT-A-CHARACTER TO SYSTEM CONSOLE. USED
0059			; FOR ALL CONSOLE OUTPUT.
0060	ENTRY	CHSTAT	; CHECK CONSOLE STATUS. USED FOR CHECKING TO SEE
0061			IF A KEY (PARTICULARLY AN ESCAPE) HAS BEEN PUSHED.

FIXED OFFSETS AND RAM TABLE LOCATIONS WITHIN SBASIC WHICH ARE USED
BY I/O ROUTINES.

THE EXTENDED FILE CONTROL BLOCK (EFCB)

EACH OPEN FILE IS ASSIGNED AN EFCB (AND ALL CALLS RECEIVE ADDRESS
OF THIS EFCB IN THE IY REGISTER). CERTAIN PARAMETERS ARE PASSED
TO THE I/O ROUTINES VIA THESE BLOCKS.

(0000)	0076	EFCB	EQU	0	; THE BASE ADDRESS
(0000)	0077	EFCBUS	EQU	0	; EFCB-IN-USE FLAG: SET AND RESET BY SYSTEM!
	0078				; DON'T TOUCH!
(0001)	0079	EFCBDA	EQU	1	; ADDRESS OF THE DEVICE DRIVER CURRENTLY USING
	0080				; THIS EFCB. NOTE THAT THIS IS THE ADDRESS
	0081				; OF THE HEAD OF ITS TABLE (SEE BELOW).
(0003)	0082	EFCBDD	EQU	3	; DEVICE DEPENDENT INFORMATION -- THESE TWO BYTES
	0083				; ARE COPIED FROM THE DEVICE'S ENTRY IN DDLIST.
(0005)	0084	EFCBP1	EQU	5	; PARAMETER 1 ... PASSED AT 'OPEN' TIME VIA
	0085				; 'OPEN\CHANNEL,PARM1,PARM2\...' FROM SBASIC.
(0007)	0086	EFCBP2	EQU	7	; PARAMETER 2 ... PASSED BY 'OPEN', AS ABOVE.
(0009)	0088	EFCBS1	EQU	9	; STATUS PARAMETER 1 ... PASSED AT I/O TIME VIA
	0089				; GET, PUT, PRINT, INPUT ... FOR EXAMPLE:
	0090				; 'GET\CHANNEL,STATUS1,STATUS2\...' FROM SBASIC.
(000B)	0091	EFCBS2	EQU	11	; STATUS PARAMETER 2 ... SIMILAR TO EFCBS1.
(000D)	0093	EFCBFREE	EQU	13	
(00BF)	0094	EFCBTOP	EQU	191	; THE REST OF THE 192 BYTES OF THE EFCB IS AVAILABLE
	0095				; TO THE DRIVER FOR TEMPORARY STORAGE, BUFFERED I/O,
	0096				; OR WHATEVER IS NECESSARY.

Equates for CDOS system calls, etc.

(0002)	0101	SYSPUTC	EQU	2	; 'PUT C' HARACTER TO SYSTEM CONSOLE
(000B)	0102	SYSCRDY	EQU	11	; CHECK IF CHARACTER READY AT SYSTEM CONSOLE
(0080)	0103	SYSRNE	EQU	128	; READ ONE CHARACTER FROM SYSTEM CONSOLE, WITHOUT ECHO
(008E)	0104	SYSCRT	EQU	142	; Special CRT Function (cursor addressing, fields,etc.)
(0003)	0106	SYSRDR	EQU	3	; GET BYTE FROM 'READER' DEVICE
(0004)	0107	SYSPUN	EQU	4	; PUT BYTE TO 'PUNCH' DEVICE
(0005)	0108	SYSLPT	EQU	5	; PUT BYTE TO 'LIST' OR 'PRINTER' DEVICE

FIXED RAM LOCATIONS

CAUTION! VALID ONLY FOR VERSION 03.XX SBASIC.

(0005)	0118	ABS		
	0119	CDOS:	EQU	5 ; SBASIC ALWAYS USES STANDARD CDOS ENTRY POINT!
0000	0122	ORG	0230H	
	0123	SETSYS:		; THE VARIOUS SET/SYS() PARAMETERS !
	0124			; SEE SBASIC MANUAL FOR EXPLANATION OF USAGE FROM
	0125			; SBASIC...SOME OF THESE MAY BE USEFUL TO
	0126			; AN I/O DRIVER. PARAMETERS THAT SHOULD NOT
	0127			; BE CHANGED HAVE NOT BEEN NAMED HERE.
0230 (0002)	0128	PAGESIZE DS	2	; MAX CHARACTERS PER LINE FOR OUTPUT...IF MSB
	0129			; IS SET, PAGESIZE IS INFINITE.
0232 (0002)	0130	TABSIZE DS	2	; NUMBER OF COLUMNS BETWEEN PRINT POSITIONS WHEN
	0131			; USING 'PRINT A,B,...'
0234 (0002)	0132	LASTCHAR DS	2	; LAST CHARACTER OUTPUT TO ANY DEVICE (LSB ONLY)
	0133			;
0236 (0002)	0134	LASTERR DS	2	; LAST RUNTIME ERROR NUMBER IS IN LSB. MSB NOT USED
	0135			; BY SYSTEM, BUT MOST USER PROGRAMS EXPECT
	0136			; IT TO BE ZERO.
0238 (0002)	0137	COLUMN DS	2	; CURRENT PRINT COLUMN. RESET TO ZERO ONLY BY CR
	0138			; (BUT I/O ROUTINES COULD CHANGE IF WANTED)
023A (0002)	0139	TIMER DS	2	; INPUT TIMEOUT COUNTER.
	0140			;

THE FOLLOWING LOCATIONS REFERENCE INTERNAL SBASIC FLAGS, ETC.
\$CONSOLE USES THEM TO PROVIDE I/O TRULY COMPATIBLE WITH 'SYGETC'
(SEE BELOW). NO DOCUMENTATION OF USAGE IS PROVIDED. USER-WRITTEN
DRIVERS SHOULD NOT USE THESE LABELS.

(031D)	0148	FLGECH	EQU	031DH
(0260)	0149	MODECH	EQU	0260H
(0267)	0150	MODFIL	EQU	0267H
(021F)	0151	MODRUN	EQU	021FH

0154 REL ; BEGIN ACTUAL CODE GENERATION

DDLIST -- a table of names, entry point addresses, etc. of all peripheral device drivers available to SBASIC users.

DDLIST consists of a series of 8-byte entries, each defining a separate device driver. The format of each entry must follow certain rules. The offsets of required information within each entry is shown below:

OFFSET (bytes) INFORMATION

- | | | |
|---|-----|---|
| 0 | (2) | the device name...without the '\$' that the SBASIC user needs. |
| 2 | (2) | the address of the driver that will handle I/O to this named device. |
| 4 | (2) | device dependent ... each driver may designate its own usage for these bytes.
NOTE: SBASIC will move these bytes into the bytes labeled EFCBDD within the appropriate EFCB before calling the driver's OPEN routine. |
| 6 | (2) | RESERVED for future use. Should be zero. |

the actual DDLIST:

0186 DDLIST:

first entry

0000' 434F	0190	db	'CO'	; "\$Console" -- the system console driver
0002' 3300'	0191	dw	DRCONSOLE	; address of the driver for this device
0004' 0000	0192	db	0,0	; driver does not use device dependent info
0006' 0000	0193	dw	0	; --reserved--

next entry

0008' 5359	0197	db	'SY'	; "\$System console" -- historical name
0198				; NOTE: this driver differs from \$CONSOLE in that
0199				; it directly accesses the 4FDC/TUART port
0200				; rather than going thru CDOS. CAUTION!!
000A' AC00'	0201	dw	DRTUART	; address of the general purpose TUART driver
000C' 00	0202	db	00H	; first EFCBDD byte: port address !
000D' 00	0203	db	0	; second EFCBDD byte: do not set baud rate on OPEN
000E' 0000	0204	dw	0	; --reserved--

next entry

0010' 5435	0208	db	'T5'	; "\$T50" -- tuart port 50H -- used in some systems
0209				; as a serial line printer.
0012' AC00'	0210	dw	DRTUART	; note that the driver address is the same as that

0014' 50	0211	db	50H	; used by "\$SY" !!! ; first EFCBDD byte: port address is 50H.
0015' 00	0212	db	0	; second EFCBDD byte: do not set baud rate on OPEN
0016' 0000	0213	dw	0	; --reserved--
next entry				
0018' 4C50	0218	db	'LP'	; "\$LPT" -- the line printer
001A' 0401'	0219	dw	DRLPT	; address of its driver
001C' 0000	0220	db	0,0	; no EFCBDD info
001E' 0000	0221	dw	0	; --reserved--
next entry				
0020' 5244	0225	db	'RD'	; "\$RDR" -- the CDOS 'reader device' driver
0022' 3901'	0226	dw	DRRDR	; address of driver
0024' 0000	0227	db	0,0	
0026' 0000	0228	dw	0	
next entry				
0028' 5055	0232	db	'PU'	; "\$PUNCH" -- the CDOS 'punch device' driver
002A' 2201'	0233	dw	DRPUNCH	; address of driver
002C' 0000	0234	db	0,0	
002E' 0000	0235	dw	0	
no more entries				
0030' 00	0238	db	0	; *** this zero byte must be here to signal
	0239			; the end of DDLIST ***

Just as the DDLIST must adhere to a certain format, a peripheral device driver must conform to SBASIC's rules.

The driver address specified at OFFSET 2 within any DDLIST entry must, in turn, point to a table of eight (8) two-byte addresses. Each address within this new table (known as the 'DRIVER ROUTINES TABLE') points to a sub-driver which implements a particular primitive I/O function, according to SBASIC's definition thereof.

The following shows the offset within the table (in bytes) of each subroutine address, a description of the necessary routine, and a list of what parameters are passed and where. The notation 'ERROR:' indicates what error message results if the A register contains a non-zero value upon return from the routine. Be sure to zero A if no error is encountered!!!!

OFFSET (bytes) DESCRIPTION

0 (2)	* OPEN. This routine is called when the user OPENS the device from SBASIC. It should perform any needed initialization. EFCBDD contains the device dependent bytes from the DDLIST entry. EFCBP1 and EFCBP2 contain the parameters passed by the user's OPEN request (see above). The A' register contains 0,1, or 2 -- a count of the parameters passed. (note: EFCBP1 and EFCBP2 will contain OFFFFH if the user did not specify a value.) ERROR: 134, Cannot open file.
2 (2)	* CLOSE. called when the file channel (number) is closed either implicitly or explicitly. The routine should perform any necessary cleanup (buffer flushes, etc.). NO parameters are passed. ERROR: 142, Cannot CLOSE file.
4 (2)	* SET STATUS OR POSITION. called at each usage of any file I/O statement (GET, PUT, PRINT, or INPUT). The parameters specified by the user (as in 'PUT \channel,parm1,parm2\ ...') are passed to SET STATUS for usage on a device-dependent basis. EFCBS1 and EFCBS2 contain the parameters (or OFFFFH if not specified). Register A' contains the parameter count. ERROR: 140, File position/status.
6 (2)	GET STATUS OR POSITION. called by the IOSTAT() function. Usage is device dependent, and the second value of the function may be used to select one of several returned values. Register A' contains the second value passed

to the IOSTAT function (e.g., "n" in
'IOSTAT(channel, n)').
ERROR: 140, File position/status.

- 8 (2) OUTPUT ONE BYTE or character. Currently all I/O
to peripheral devices is performed on a
byte-at-a-time basis. If buffering is desired,
the driver should provide it.
The byte to output is passed in the A register.
(No error return exists for this function --
use ERRI0 as noted above to force an error.)
- 10 (2) INPUT ONE BYTE or character. The byte is NOT masked
to 7-bits by GET, but is so masked by INPUT.
The input byte should be returned in the
A register.
(No error return exists for this function --
use ERRI0 as noted above to force an error.)
- 12 (2) --RESERVED-- not currently in use. should be zero.
14 (2) --RESERVED-- not currently in use. should be zero.

=====

NOTES: an asterisk denotes routines which MUST be included in
each driver!
for the optional routines, an omitted routine should be
be marked by an address of zero. A user attempt
to access such a routine (e.g., by trying to INPUT
from a line printer) will generate an ERROR: 130,
Invalid command for device.

dummy -- A Special Routine

Several of the device drivers have 'missing' routines...that is
they do not implement one or more of the 'required' routines
(open, close, and set status). However, SBASIC will not run
correctly with a driver if these routines are not supplied.
Since these routines are expected to return a zero in the
A register if no errors are encountered, the following routine
serves this purpose.

0343 .dummy:
0031' AF 0344 XOR A ; this zeroes the A register...
0032' C9 0345 RET ; and this ensures a no-error routine to SBASIC.

the driver for \$CONSOLE includes the routines used for SBASIC's primary console I/O.

EXCEPT: program entry from the keyboard and responses to the INPUT statement use the CDOS read-a-buffered-line system call. Usage of the CDOS routine may be overridden by the user via a 'SET 14,1' command.

NOTE that the command sequence

```
OPEN \n\ "$CONSOLE"  
INPUT \n\ ...  
will NOT use the CDOS routine, but will instead use  
this driver.
```

0364 DRCONSOLE:

0033' 3100'	0366	dw	.dummy	; the CONSOLE does not require or use an OPEN routine
0035' 3100'	0367	dw	.dummy	; nor does it use a CLOSE routine
	0368			; but NOTE that the routines must exist,
	0369			; even if they are dummies !!!
0037' 9000'	0370	dw	CONSET	; the SET STATUS routine may be used to change
	0371			; cursor position, etc.
0039' 0000	0372	dw	0	; currently, the CONSOLE does not support a status
	0373			; read (cursor read?)
	0374			; NOTE that this routine may be omitted, and
	0375			; hence the 'use of the zero 'address'.
003B' 4300'	0376	dw	SYPUTC	; master system output-a-character routine
	0377			;
003D' 5100'	0378	dw	CONGETC	; get-a-character from console: almost identical
	0379			; to master system getc...see below.
003F' 0000	0380	dw	0	; --reserved--
0041' 0000	0381	dw	0	; --reserved--

end of driver table for \$CONSOLE

start of driver routines:

put-a-character

```
0394 SYPUTC:  
0043' D5      0395    PUSH   DE      ; (NORMALLY NOT REQUIRED OF A DRIVER --  
0044' C5      0396    PUSH   BC      ; SYSTEM DRIVER IS AN EXCEPTION -- SAVES TIME  
0045' 3A3402  0397    LD     A,(LASTCHAR) ; AND SPACE MANY PLACES TO HAVE IT DO ITS  
                  ; OWN HOUSEKEEPING.)  
0048' 5F      0399    LD     E,A      ; CDOS EXPECTS THE CHARACTER HERE  
0049' 0E02      0400    LD     C,SYSPUTC ; SYSTEM CALL FOR PUTC  
004B' CD0500  0401    CALL   CDOS    ; OUTPUT THE CHARACTER  
  
004E' C1      0403    POP    BC      ; RECOVER OUR OWN REGS...  
004F' D1      0404    POP    DE  
0050' C9      0405    RET     ;AND QUIT.
```

GET-A-CHARACTER

CONGETC is specially designed to 'simulate' console I/O and hence must fool
SBASIC's get-a-line routine into believing that it called SYGETC
directly instead of via \$CONSOLE.

```
0416 CONGETC:  
0051' 3A1D03  0417    LD     A,(FLGECH)  
0054' 326002  0418    LD     (MODECH),A  
0057' 3EFF      0419    LD     A,0FFH  
0059' 326702  0420    LD     (MODFIL),A      ; GET-A-LINE IS PROPERLY FOOLED
```

NOW CONGETC SIMPLY FALLS THRU TO SYGETC...SBASIC'S STANDARD GET-A-BYTE-FROM
CONSOLE ROUTINE (SEE NOTE ABOVE ABOUT 'SET 14,1').

NOTE: SYGETC DOES SEVERAL THINGS IN ITS OWN WAY: NOT THE LEAST OF
WHICH IS HANDLING THE INPUT TIMER TIMEOUT.

```
0429 SYGETC:  
0430  
(00AF) 0431 .TIME  EQU    175    ; THIS IS THE FUNDAMENTAL WAIT-FOR-A-TENTH-OF-A-SECOND  
                  ; COUNTER VALUE...CHANGE THIS TO FIT YOUR SYSTEM  
                  ; IF YOU WISH (DIFFERENT MEMORY SPEEDS, DIFFERENT  
                  ; VERSION OF CDOS CAN AFFECT THIS).  
  
005C' E5      0436    PUSH   HL      ; AGAIN, SYGETC DOES ITS OWN HOUSEKEEPING  
005D' D5      0437    PUSH   DE  
005E' C5      0438    PUSH   BC  
  
005F' 3A1F02  0440    LD     A,(MODRUN) ; FLAG: >0 IF A PROGRAM IS RUNNING!  
0062' B7      0441    OR     A  
0063' 281F      0442    JR     Z,CHARRDY ; PROGRAM ENTRY...NO TIMED INPUT  
0065' FA8       0443    JP     M,CHARRDY ; DIRECT SEGMENT EXECUTION...TO TIMING
```

0068' 2A3A02 0445 LD HL, (TIMER)
 006B' 7C 0446 LD A, H
 006C' B5 0447 OR L ; CHECK CURRENT VALUE OF TIMER
 006D' 2815 0448 JR Z, CHARRDY ; THE TIMER IS ALREADY ZERO. MEANS ITS NOT ACTIVE

READY TO DO TIMED INPUT

006F' 06AF	0453	TIMED:		
	0454	LD	B,.TIME	
0071' CDA600'	0456	SGCLOOP:		; WAIT LOOP
0074' B7	0457	CALL	CHSTAT	; CHECK FOR CHARACTER READY...SEE BELOW
0075' 200D	0458	OR	A	
0077' 10F8	0459	JR	NZ,CHARRDY	; STOP TIMING...A CHARACTER IS READY
	0460	DJNZ	SGCLOOP	; OTHERWISE KEEP WAITING

MINOR TIMER (REG B == .TIME) HAS TIMED OUT... TICK OFF 1/10TH OF A SECOND

```

0079' 2B      0465    DEC     HL      ; COUNT DOWN BY ONE
007A' 223A02   0466    LD      (TIMER),HL ; AND PUT IT BACK FOR NEXT TIME
007D' 7C      0467    LD      A,H
007E' B5      0468    OR      L       ; AND CHECK ONCE AGAIN...
007F' CC0000#   0469    CALL    Z,ERTIME ; TIMER RAN OUT. GENERATE USER-TRAPPABLE
                                ; ERROR...NOTE THAT SYS(5) IS ALREADY SET TO 0 NOW
                                ; SO FURTHER INPUTS WON'T BE TIMED.
0082' 18EB   0470
              0471
              0472    JR      TIMED   ; AND GO TRY FOR ANOTHER TIMER TICK

```

TO HERE WHEN 1) CHARACTER IS READY OR 2) WHEN WE ARE NOT DOING TIMED INP

```

0084' 0E80      0477 CHARRDY:          LD    C,SYRSNE   ; READ FROM CONSOLE WITH NO ECHO
0086' CD0500      0478                 CALL   CDOS      ; (BECAUSE SBASIC DOES ITS OWN SPECIAL ECHOING
0089' 323402      0479                 LD    (LASTCHAR),A ; HISTORICAL
008C' CL          0480                 POP   BC
008D' DL          0481                 POP   DE
008E' E1          0482                 POP   HL       ; CLEAN UP OUR HOUSE
008F' C9          0483                 RET
                                         0484                 ; AND BACK TO CALLER

```

***** CONSOLE SET STATUS (SET CURSOR POSITION) *****

	0490	CONSET:			
0090' 08	0491	EX	AF,AF'	; GET COUNT OF PARAMETERS TO A REGISTER	
0091' B7	0492	OR	A	; IS COUNT ZERO?	
0092' C8	0493	RET	Z	; YES...SO WE DON'T DO A SET STATUS. NOTE THAT	
	0494			; WE ARE RETURNING WITH A=0...IMPLYING	
	0495			; THAT WE FOUND NO ERROR!	
0093' 1E00	0497	LD	E,0	; (IN CASE THERE IS NO SECOND PARAMETER)	
0095' FD5609	0499	LD	D,(IY+EFCBS1)	; D REGISTER GETS LSB OF FIRST PARAMETER.	
	0500			; NOTE THAT NO CHECK IS PERFORMED	
	0501			; AS TO LEGALITY OF THE VALUE...SE	

0098' FE02	0502			C DOS MANUAL FOR SIDE-EFFECTS.
009A' 2003	0503	CP	2	; NOW CHECK: DID USER PASS A SECOND PARAMETER?
	0504	JR	NZ,CSET2;	NO...SO WE USE THE ZERO IN E-REGISTER AS PARM2
009C' FD5E0B	0506	LD	E,(IY+EFCBS2)	; AND THIS IS LSB OF SECOND PARAMETER.
	0508 CSET2:			
009F' 0E8E	0509	LD	C,SYSCRT	; REQUEST SPECIAL CRT FUNCTION
00A1' CD0500	0510	CALL	CDOS	; ...FROM CDOS
00A4' AF	0512	XOR	A	; ENSURE THAT A=0 (NO ERROR ENCOUNTERED)
00A5' C9	0513	RET		; AND BACK TO USER

THE FOLLOWING ROUTINE IS REQUIRED BY SBASIC. IT IS THROUGH THIS
ROUTINE THAT SBASIC CHECKS FOR AN ESCAPE-KEY WHILE A PROGRAM
IS RUNNING. MODIFY AT YOUR OWN RISK!

	0520 CHSTAT:			
00A6' 0E0B	0521	LD	C,SYSCRDY	
00A8' CD0500	0522	CALL	CDOS	; WE LET CDOS DO ALL THE WORK!
00AB' C9	0523	RET		

DRTUART -- this is a fairly complete driver for serial I/O via
a Cromemco TUART (or the serial port of the 4FDC).

FEATURES:

One driver may be used to access any TUART port.
The DDLIST may specify a default baud rate (to 9600 baud) or
it may specify that the currently set baud rate remain
unchanged.

The SBASIC user may override any baud rate specified via the DDLIST.

0537 DRTUART: ; the driver table comes first

00AC' BC00'	0539	dw	TUOPEN	; open a tuart port
00AE' 3100'	0540	dw	.dummy	; no CLOSE routine needed
00B0' 3100'	0541	dw	.dummy	; set status not supported
00B2' 0000	0542	dw	0	; get status not legal
00B4' E800'	0543	dw	TUPUTC	; put-a-character to TUART port
00B6' F700'	0544	dw	TUGETC	; get-a-character from TUART port
00B8' 0000	0545	dw	0	; --reserved--
00BA' 0000	0546	dw	0	; --reserved--

OPEN a TUART serial port

0551 TUOPEN:

00BC' FD4E03	0552	LD	C,(IY+EFCBDD)	; THE FIRST BYTE OF THE DEVICE DEPENDENT INFO
	0553			; SPECIFIES THE TUART PORT ADDRESS.
00BF' FD7E04	0554	LD	A,(IY+EFCBDD+1)	; THE SECOND BYTE OF THE DEVICE DEPENDENT
	0555			; ENTRY...NOTE THAT SBASIC HAS MOVED IT FROM
	0556			; THE DDLIST INTO OUR OWN PERSONAL EFCB!
00C2' B7	0557	OR	A	; DID THE DDLIST SPECIFY A DEFAULT BAUD RATE?
00C3' 280A	0558	JR	Z,TUOP2	; NO...LEAVE THE BAUD RATE ALONE
00C5' ED79	0560	OUT	(C),A	; SEND OUT BAUD RATE TO TUART...NOTE THAT
	0561			; THE DDLIST ENTRY IS EXPECTED TO CONTAIN
	0562			; THE CORRECT BIT PATTERN FOR THE DESIRED
	0563			; BAUD RATE !!! CAUTION !!!
00C7' 3E00	0564	LD	A,0	; THIS IS A JUST-IN-CASE...
00C9' 0C	0565	INC	C	
00CA' 0C	0566	INC	C	; WE ADDRESS PORT n2H...THE TUART COMMAND
	0567			; REGISTER
00CB' ED79	0568	OUT	(C),A	; AND ENSURE THAT WE ARE NOT IN 'HIGH BAUD'
	0569			; (OCTUPLED BAUD RATE) MODE.
00CD' 0D	0570	DEC	C	
00CE' 0D	0571	DEC	C	; BACK TO PRIMARY PORT ADDRESS

DDLIST-SPECIFIED BAUD RATE HAS BEEN SET

0575 TUOP2:

00CF' 08	0576	EX	AF,AF'	; GET COUNT OF USER-SPECIFIED PARAMETERS
00D0' B7	0577	OR	A	
00D1' C8	0578	RET	Z	; NONE SPECIFIED...SO WE ARE DONE WITH 'OPEN'

USER REQUESTED A SPECIAL BAUD RATE/COMMAND FOR THE TUART

00D2' 0600	0582	LD	B,0	; A DEFAULT VALUE: NO OCTUPLED BAUD RATE
------------	------	----	-----	--

```

00D4' FE02      0583      CP      2          ; DID USER SPECIFY 2 PARAMETERS?
00D6' 2003      0584      JR      NZ,TUOP3   ; NO...JUST ONE.
00D8' FD460B    0585      LD      B,(IY+EFCBS2) ; YES...RETRIEVE IT...
00D8'           0586      TUOP3:               ; 
00DB' 0C         0587      INC     C          ;
00DC' 0C         0588      INC     C          ;
00DD' ED41       0589      OUT    (C),B      ; THE 2ND PARM (OR DEFAULT) IS THE TUART
00DF' 0D         0590      ; COMMAND REGISTER SPECIFIER!
00E0' 0D         0591      DEC     C          ;
00E0'           0592      DEC     C          ; BACK TO THE BAUD-RATE PORT
00E1' FD7E09    0594      LD      A,(IY+EFCBS1) ; GET USER-SPECIFIED BAUD RATE
00E4' ED79       0595      OUT    (C),A      ; AND NOW THE TUART BAUD RATE AND COMMAND ARE
00E4'           0596      ; COMPLETE!
00E6' AF         0598      XOR     A          ;
00E7' C9         0599      RET     ; RETURN WITH NO ERROR INDICATION

```

 OUTPUT ONE CHARACTER TO TUART

```

00E8' FD4E03    0604      TUPUTC:             ; 
00E8'           0605      LD      C,(IY+EFCBDD) ; GET PORT ADDRESS FROM EFCB (SEE TUOPEN)
00EB' 47         0607      LD      B,A        ; SAVE BYTE TO BE OUTPUT HERE FOR NOW
00EC'           0609      TPCLOOP:            ; 
00EC' ED78       0610      IN      A,(C)      ; GET STATUS OF THIS TUART
00EE' E680       0611      AND     080H      ; CHECK: IS TRANSMIT BUFFER EMPTY?
00F0' 28FA       0612      JR      Z,TPCLOOP ; NO...WE MUST WAIT FOR IT TO FINISH LAST
00F0'           0613      ; CHARACTER TRANSMISSION.
00F2' 0C         0615      INC     C          ; TO THE DATA PORT OF THE TUART
00F3' 78         0616      LD      A,B        ; SO THAT BYTE RETURNS STILL IN A
00F4' ED79       0617      OUT    (C),A      ; AND OUTPUT ONE BYTE TO TUART!
00F6' C9         0618      RET     ; 

```

 INPUT ONE CHARACTER FROM TUART

```

00F7' FD4E03    0624      TUGETC:             ; 
00F7'           0625      LD      C,(IY+EFCBDD) ; THE PORT ADDRESS FROM EFCB
00F7'           0627      TGCLOOP:            ; 
00FA' ED78       0628      IN      A,(C)      ; CHECK TUART STATUS PORT
00FC' E640       0629      AND     040H      ; IS DATA AVAILABLE YET?
00FE' 28FA       0630      JR      Z,TGCLOOP ; NO...WAIT FOR IT.
0100' 0C         0632      INC     C          ; TO THE DATA PORT OF THIS TUART
0101' ED78       0633      IN      A,(C)      ; GET THE BYTE
0103' C9         0634      RET     ; AND QUIT.

```

These interfaces are simple. They support only unidirectional I/O, do not allow any status passing, and (with the exception of the printer driver) do nothing at OPEN or CLOSE time.

PRINTER or LIST device --- "\$LPT" from SBASIC

0646 DRLPT: ; first, the driver address table

0104' 1401'	0648	dw	LPTOPEN ; a simple open routine
0106' 3100'	0649	dw	.dummy ; no CLOSE routine
0108' 3100'	0650	dw	.dummy ; and no SET STATUS routine
010A' 0000	0651	dw	0 ; GET STATUS is illegal here
010C' 1B01'	0652	dw	LPTPUTC ; output 1 character to the printer
010E' 0000	0653	dw	0 ; trying to get a character from a printer is illegal
0110' 0000	0654	dw	0 ; --reserved--
0112' 0000	0655	dw	0 ; --reserved--

0658 LPTOPEN:
0114' 3E0C 0659 LD A,0CH ; THIS IS AN ASCII FORM FEED...
0116' CD1B01' 0660 CALL LPTPUTC ; ...WHICH WE OUTPUT EACH TIME THE PRINTER IS OPENED

0119' AF 0662 XOR A ; ZERO TO A
011A' C9 0663 RET ; ...SAYS THAT OPEN WAS SUCCESSFUL !

0666 LPTPUTC:
011B' 5F 0667 LD E,A ; MOVE CHARACTER TO WHERE CDOS EXPECTS IT
011C' 0E05 0668 LD C,SYSLPT
011E' CD0500 0669 CALL CDOS ; AND OUTPUT ONE CHARACTER VIA CDOS
0121' C9 0670 RET ; AND THAT IS ALL

PUNCH device -- "\$PUNCH"

0676 DRPUNCH: ; the device address table

0122' 3100'	0678	dw	.dummy ; no OPEN routine
0124' 3100'	0679	dw	.dummy ; no CLOSE routine
0126' 3100'	0680	dw	.dummy ; no SET STATUS routine
0128' 0000	0681	dw	0 ; GET STATUS is illegal
012A' 3201'	0682	dw	PUNPUTC ; output 1 character to punch
012C' 0000	0683	dw	0 ; get-a-byte from punch is illegal
012E' 0000	0684	dw	0 ; --reserved--
0130' 0000	0685	dw	0 ; --reserved--

0688 PUNPUTC: ; OUTPUT ONE CHARACTER TO PUNCH
0132' 5F 0689 LD E,A ; WHERE CDOS EXPECTS THE CHARACTER
0133' 0E04 0690 LD C,SYSPUN
0135' CD0500 0691 CALL CDOS ; OUTPUT VIA CDOS SYSTEM CALL
0138' C9 0692 RET

READER driver -- "\$RDR"

0699 DRRDR: ; device driver address table

0139' 3100' 0701 dw .dummy ; nc OPEN
013B' 3100' 0702 dw .dummy ; no CLOSE
013D' 3100' 0703 dw .dummy ; no SET STATUS
013F' 0000 0704 dw 0 ; illegal to GET STATUS
0141' 0000 0705 dw 0 ; can't PUT a character to the reader
0143' 4901' 0706 dw RDRGETC ; get 1 character (byte) from reader
0145' 0000 0707 dw 0 ; --reserved--
0147' 0000 0708 dw 0 ; --reserved--

0711 RDRGETC: ; GET 1 BYTE FROM READER DEVICE
0149' 0E03 0712 LD C,SYSRDR
014B' CD0500 0713 CALL CDOS ; LET CDOS DO ALL THE WORK!
014E' C9 0714 RET

END OF SBASIC DRIVERS...ADD YOUR OWN

014F' (0000) 0719 END

Errors 0

Program Length 014F (335)

