

This document provides additional assistance with wiring your Extron IP Link Pro Control Processor to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific IP Link Pro Control Processor or the documentation supplied by the manufacturer of the controlled device.

For more information on using Global Scriptor Modules, refer to the "[Guide to Using Scriptor Modules](#)" document.

Device Specifications

Device Type: Audio Processor
Manufacturer: ClearOne
Firmware Version: N/A
Model(s): Converge Huddle

Tested on the Following Software and Firmware Versions

IP Link Pro Control Processor Firmware	Global Scriptor Version
3.04.0001-b002	2.3.1

Version History

Module Version	Date	Notes
1_0_1_0	7/30/2019	Initial Version

Module Notes

- Unidirectional variable must be set to 'True' if status is not required. Default value is 'False'.
Example: `InterfaceName.Unidirectional = 'True'`
- connectionCounter variable must be set to the number of queries that will be sent to the device before displaying 'Disconnected' if no response is received. Default value is 15.
Example: `InterfaceName.connectionCounter = 5`
- If login credentials are required, devicePassword and deviceUsername must be set accordingly. devicePassword and deviceUsername default values are 'converge' and 'clearone' respectively.
Example: `InterfaceName.devicePassword = 'extron'`

Supported Class and Example

EthernetClass

<code>InterfaceName = ModuleName.EthernetClass('192.168.254.254', 23, Model='Converge Huddle')</code>

Control Commands

Format with Qualifier:

```
InterfaceName.Set(Command, Value, {'Qualifier Key': 'Qualifier Value'})
```

Format with Qualifier:

```
InterfaceName.Set(Command, Value)
```

Command	Value	
OutputGain	-65 to 20 in steps of 0.5 dB	
Qualifier Key	Qualifier Value	
'Channel'	'1' – '2'	
# OutputGain example InterfaceName.Set('OutputGain', 20, {'Channel': '1'})		
Command	Value	Value
OutputMute	'On'	'Off'
Qualifier Key	Qualifier Value	
'Channel'	'1' – '2'	
# OutputMute example InterfaceName.Set('OutputMute', 'On', {'Channel': '1'})		
Command	Value	
SpeakerGain	-65 to 20 in steps of 0.5 dB	
Qualifier Key	Qualifier Value	
'Speaker Number'	'1' – '2'	
# SpeakerGain example InterfaceName.Set('SpeakerGain', 20, {'Speaker Number': '1'})		
Command	Value	Value
SpeakerMute	'On'	'Off'
Qualifier Key	Qualifier Value	
'Speaker Number'	'1' – '2'	
# SpeakerMute example InterfaceName.Set('SpeakerMute', 'On', {'Speaker Number': '1'})		

Status Available

For all commands, call Update to receive the latest status. ConnectionStatus does not support the Update function and is triggered by the device providing a successful response to other Update function calls.

Format with Qualifier:

```
InterfaceName.Update(Command, {'Qualifier Key': 'Qualifier Value'})
Value = InterfaceName.ReadStatus(Command, {'Qualifier Key': 'Qualifier Value'})
InterfaceName.SubscribeStatus(Command, {'Qualifier Key': 'Qualifier Value'},
```

FeedbackHandler)

FeedbackHandler will be called only when the specified qualifier gets a new status.

Format without Qualifier:

```
InterfaceName.Update(Command)
Value = InterfaceName.ReadStatus(Command)
InterfaceName.SubscribeStatus(Command, None, FeedbackHandler)
FeedbackHandler will be called when any qualifier gets a new status.
```

Command	Value	Value
ConnectionStatus	'Connected'	'Disconnected'
# ConnectionStatus example Value = InterfaceName.ReadStatus('ConnectionStatus') InterfaceName.SubscribeStatus('ConnectionStatus', None, FeedbackHandler)		
Command	Value	
FirmwareVersion	'String'	
# FirmwareVersion example InterfaceName.Update('FirmwareVersion') Value = InterfaceName.ReadStatus('FirmwareVersion') InterfaceName.SubscribeStatus('FirmwareVersion', None, FeedbackHandler)		
Command	Value	
OutputGain	-65 to 20 in steps of 0.5 dB	
Qualifier Key	Qualifier Value	
'Channel'	'1' – '2'	
# OutputGain example InterfaceName.Update('OutputGain', {'Channel': '1'}) Value = InterfaceName.ReadStatus('OutputGain', {'Channel': '1'}) InterfaceName.SubscribeStatus('OutputGain', None, FeedbackHandler)		
Command	Value	Value
OutputMute	'On'	'Off'
Qualifier Key	Qualifier Value	
'Channel'	'1' – '2'	
# OutputMute example InterfaceName.Update('OutputMute', {'Channel': '1'}) Value = InterfaceName.ReadStatus('OutputMute', {'Channel': '1'}) InterfaceName.SubscribeStatus('OutputMute', None, FeedbackHandler)		
Command	Value	
SpeakerGain	-65 to 20 in steps of 0.5 dB	
Qualifier Key	Qualifier Value	
'Speaker Number'	'1' – '2'	
# SpeakerGain example InterfaceName.Update('SpeakerGain', {'Speaker Number': '1'}) Value = InterfaceName.ReadStatus('SpeakerGain', {'Speaker Number': '1'}) InterfaceName.SubscribeStatus('SpeakerGain', None, FeedbackHandler)		
Command	Value	Value
SpeakerMute	'On'	'Off'
Qualifier Key	Qualifier Value	

'Speaker Number'	'1' – '2'
<pre># SpeakerMute example InterfaceName.Update('SpeakerMute', {'Speaker Number': '1'}) Value = InterfaceName.ReadStatus('SpeakerMute', {'Speaker Number': '1'}) InterfaceName.SubscribeStatus('SpeakerMute', None, FeedbackHandler)</pre>	

Network communication

When configuring the Ethernet module, be sure device settings match those of the Global Scriptor ethernet interface.

Port Type:	Ethernet
Default Port:	23
Logon Credentials Supported:	Yes
Default Username:	clearone
Default Password:	converge
Multi-Connection	Undetermined
Capabilities:	
Port Changeability:	Yes

Ethernet Module Configuration Description

Please refer to user manual for settings and changes to the network communication

Notes for the Device

Appendix A. Set Commands

Output Gain 20 Channel 1	EP OUTPUT 1 LEVEL GAIN 20\x0D
Output Gain 20 Channel 2	EP OUTPUT 2 LEVEL GAIN 20\x0D
Output Gain -65 Channel 1	EP OUTPUT 1 LEVEL GAIN -65\x0D
Output Gain -65 Channel 2	EP OUTPUT 2 LEVEL GAIN -65\x0D
Output Mute Off Channel 1	EP OUTPUT 1 LEVEL MUTE 0\x0D
Output Mute Off Channel 2	EP OUTPUT 2 LEVEL MUTE 0\x0D
Output Mute On Channel 1	EP OUTPUT 1 LEVEL MUTE 1\x0D
Output Mute On Channel 2	EP OUTPUT 2 LEVEL MUTE 1\x0D
Speaker Gain 20 Speaker Number 1	EP SPEAKER 1 LEVEL GAIN 20\x0D
Speaker Gain 20 Speaker Number 2	EP SPEAKER 2 LEVEL GAIN 20\x0D
Speaker Gain -65 Speaker Number 1	EP SPEAKER 1 LEVEL GAIN -65\x0D
Speaker Gain -65 Speaker Number 2	EP SPEAKER 2 LEVEL GAIN -65\x0D
Speaker Mute Off Speaker Number 1	EP SPEAKER 1 LEVEL MUTE 0\x0D
Speaker Mute Off Speaker Number 2	EP SPEAKER 2 LEVEL MUTE 0\x0D
Speaker Mute On Speaker Number 1	EP SPEAKER 1 LEVEL MUTE 1\x0D
Speaker Mute On Speaker Number 2	EP SPEAKER 2 LEVEL MUTE 1\x0D

Appendix B. Update Commands

Firmware Version	VERSION * FW 1\x0D
Output Gain Channel 1	EP OUTPUT 1 LEVEL GAIN\x0D
Output Gain Channel 2	EP OUTPUT 2 LEVEL GAIN\x0D
Output Mute Channel 1	EP OUTPUT 1 LEVEL MUTE\x0D
Output Mute Channel 2	EP OUTPUT 2 LEVEL MUTE\x0D
Speaker Gain Speaker Number 1	EP SPEAKER 1 LEVEL GAIN\x0D
Speaker Gain Speaker Number 2	EP SPEAKER 2 LEVEL GAIN\x0D
Speaker Mute Speaker Number 1	EP SPEAKER 1 LEVEL MUTE\x0D
Speaker Mute Speaker Number 2	EP SPEAKER 2 LEVEL MUTE\x0D