
## SEPTAPHONE

User Manual and Guide

**TO PLACE A CALL** Plug the cables into the corresponding ports. Numbers are dialed from left to right, with 1 being the physically highest digit and 7 being the lowest. As shown in the image on the right, these are the ports that would be plugged into to call the number 777-5555. After all cables are attached, press the button once to call the number.

**INDICATOR LIGHT** The indicator light will light up or blink at key points to assist the operator. When the switchboard is plugged in, the indicator light will blink for several seconds as the device starts. Once the light stops blinking, the switchboard is ready for use. When a call is placed, the light will be lit while the line is active. Please do not press the button again until the light is turned off!



The light is also used during reset confirmation (see instructions for resetting below).

**SEQUENCING** In order to maximize security, the numbers must be called sequentially. If you wish to redial a number, you may do so as many times as desired until you proceed to the next number. Once you've moved forward in the sequence, you cannot redial previous numbers. If you wish to call those numbers again, please reset the board to its initial state (see instructions for resetting below) and start at the beginning of the sequence.

**RESETTING** To secure the secrets of the Septagram Society, we kindly request that you reset the board after completion of the call sequence. To reset the board, unplug all cables and press the button once. After the first press of the button, the indicator light will blink for a few seconds. If you wish to proceed with the reset, press the button again to reset the board. *Note*: the switchboard will automatically reset after 15 minutes of inactivity or 5 minutes after the final number has been called. If you wish to keep the board state active, press the button again before this time period ends.

## **TROUBLESHOOTING**

"I'm sure I've dialed the right number, but my call keeps going to the wrong number!"

Make sure that all cables are plugged firmly into their ports. If the issue persists, try swapping some of the cables. If it is the first number in the sequence, try unplugging the device from the wall and plugging it back in. After the indicator light stops blinking, call again.

"I forgot what one of the calls said, can I go back and listen to it again?"

If you not yet proceeded further in the sequence, you can call the number again by pressing the call button. If you have proceeded, and still wish to hear the message again, reset the board and restart the sequence.

"I don't hear anything!"

If you don't hear any noise coming from the handset after the call button is pressed, ensure that the cable is firmly plugged into handset.

If the suggestions above do not fix your issue, or you have additional questions about the device, please contact our tech support team (vthuntoverseer@gmail.com) for assistance.

## **SYSTEM DIAGRAM**

