

# SHIELD-2AMOTOR Cytron 2A Motor Driver Shield



# User's Manual

V1.0

# **April 2014**

Information contained in this publication regarding device applications and the like is intended through suggestion only and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications. No representation or warranty is given and no liability is assumed by Cytron Technologies Incorporated with respect to the accuracy or use of such information or infringement of patents or other intellectual property rights arising from such use or otherwise. Use of Cytron Technologies's products as critical components in life support systems is not authorized except with express written approval by Cytron Technologies. No licenses are conveyed, implicitly or otherwise, under any intellectual property rights.

# **INDEX**

| 1. | Introduction                          | 3  |
|----|---------------------------------------|----|
| 2. | Packing List                          | 5  |
| 3. | Product Specification And Limitations | 6  |
| 4. | <u>Dimension</u>                      | 7  |
| 5. | Board Layout                          | 8  |
| 6. | Hardware Installation                 | 12 |
| 7  | Warranty                              | 13 |

2

#### 1. INTRODUCTION


SHIELD-2AMOTOR is an Arduino shield for controlling dual DC motor up to 2A for each channel. It is compatible with Arduino Uno, Arduino Leonardo, Arduino Mega, Arduino Due and possibly other pin compatible main boards. SHIELD-2AMOTOR uses L298P SMD IC and support for both signed magnitude and locked anti-phase. SHIELD-2AMOTOR shield has stackable side headers which allows for more Arduino shields to be stacked on top of it.

#### SHIELD-2AMOTOR come with this features:

- Bi-directional control for 2 brushed DC motor.
- Support motor voltage ranges from 5V to 26V.
- Maximum current up to 2A continuous.
- 3.3V and 5V logic level input.
- Stackable I/O header pin.
- Selectable pins for Signed Magnitude and Locked Anti-Phase.
- Test switch for both channel.
- External voltage polarity protector.

## 2. PACKING LIST

Please check the parts and components according to the packing list. If there are any parts missing, please contact us at <a href="mailto:sales@cytron.com.my">sales@cytron.com.my</a> immediately.



- 1. 1 x SHIELD-2AMOTOR shield
- 2. 5 x mini jumper


## 3. PRODUCT SPECIFICATION AND LIMITATIONS

**Absolute Maximum Rating** 


| Parameter                                  | Min | Typical | Max | Unit |
|--|-----|---------|-----|------|
| Power Input Voltage (Motor supply voltage) | 5   | -       | 26  | V    |
| IMAX (Maximum Continuous Motor Current)    | -   | -       | 2   | A    |
| IPEAK (Peak Motor Current)                 | -   | -       | 2   | A    |
| Vюн (Logic Input-High Level)               | 3.3 | -       | 5.5 | V    |
| VIOL (Logic Input - Low Level)             | 0   | 0       | 0.5 | V    |
| Maximum PWM Frequency                      | -   | -       | 10  | KHz  |

<sup>\*</sup>Must not exceed 10 seconds

# 4. DIMENSION



# 5. BOARD LAYOUT



| Label | Function  |
|-------|---|
| A     | Reset button for Arduino main board                         |
| В     | Motor connectors.   |
| С     | External power (PWRIN) connector.                           |
| D     | PWR LED.  |
| Е     | Power source selection.                                     |
| F     | External power (PWRIN) reverse polarity protection circuit. |
| G     | L298P driver motor IC.                                      |
| Н     | Motor control mode selection.                               |
| I     | Test switch.  |
| J     | LSS05 connector.  |
| K     | Arduino pinout.   |

#### Reset button

User can press this button to restart Arduino program.

#### **Motor connectors**

Connect DC motor here.

#### External power (PWRIN) connector

Connect external power source here.

#### **PWR LED**

Motor power indicator.

#### Power source selection.

User can choose power source either from external (PWRIN) or internal (VIN).

#### External power (PWRIN) reverse polarity protection circuit.

In case user wrongly connect the external power source polarity, this circuit will protect the shield from broken.

#### L298P driver motor IC.

SHIELD-2AMOTOR uses L298P driver motor IC.

#### Motor control mode selection.

User can choose motor control mode either Signed Magnitude or Locked Anti-Phase.

#### Test switch.

When button A is pressed, current flows from output A to B and motor will turn CW (or CCW depending on the connection).

When button B is pressed, current flows from output B to A and motor will turn CCW (or CW depending on the connection).

#### LSS05 connector.


LSS05 can connect directly to this shield and can be interfaced with Arduino.

#### Arduino pinout.

Other Arduino shield can be stacked on top of this shield.

## 6. HARDWARE INSTALLATION

This section shows the example of using SHIELD-2AMOTOR with Arduino Uno as the main controller to control dual brush DC motor. However, other Arduino main board controller can be used (Leonardo, Mega, Due).








Figure above shows that the SHIELD-2AMOTOR is stacked on the Arduino UNO. Please ensure that the pins alignment is correct.


Select pin mode (4 pins) to be Signed Magnitude or Locked Anti-Phase. The default setting is Signed Magnitude. Make sure correct power source is selected (VIN or PWRIN). VIN will connect to the Arduino power source, while PWRIN needs external power source connected to the PWRIN terminal block.








Connect motor to the MOTOR1 and MOTOR2 terminal block. Upload SHIELD-2AMOTOR example code to Arduino. Or you can test directly by using test switch.



SHIELD-2AMOTOR also include with LSS05 connector. Means you can plug in LSS05 directly to Arduino.



# \*Note:

<u>Arduino library and example code</u> can be downloaded from the SHIELD-2AMOTOR product page at Cytron's website.

#### 8. WARRANTY

- Product warranty is valid for 12 months.
- Warranty only applies to manufacturing defect.
- Damaged caused by misuse is not covered under warranty
- Warranty does not cover freight cost for both ways.

## Prepared by:

# Cytron Technologies Sdn. Bhd.

No. 16, Jalan Industri Ringan Permatang Tinggi 2, Kawasan Industri Ringan Permatang Tinggi, 14100 Simpang Ampat, Penang, Malaysia.

> *Tel:* +604-545 3867 *Fax:* +6018-5866083

URL: www.cytron.com.my
Email: support@cytron.com.my
sales@cytron.com.my