## This Sheet is for interfacing the EastRising ER-TFTM080-2 8" TFT Display Board Connector JP3 to the Teensy 3.1.

•	in TFTM080-2 r Pin Number	Wire Color	Input or Output	Notes
These pins are used to control the RA8875 Display Controller.				
RA8875_RESET 9	11	White	Input to TFT	This is the TFT Reset Pin
RA8875_CS 10	5	Green	Input to TFT	This is the Chip Select pin for the TFT (Teensy 3.x can use: 2,6,9,10,15,20,21,22,23)
TFT_SCLK 14	8	Grey	Input to TFT	SPI Clock, 3-wire, 4-wire Serial or I2C I/F clock.
TFT_MISO 8	6	Blue	Output from TFT	3-wire SPI Data, 4-wire SPI Data Output. If not used keep floating.
TFT_MOSI 7	7	Violet	Input to TFT	4-wire SPI data input, 3-wire SPI interface NC, I2C interface Bi-directional data.
BL_CONTROL	14			BackLight control signal input. When using the internal PWM signal this pin is floating.
These pins are used to control the Capacitive Touch Panel (CTP).				
CTP_WAKE 32	32		Input to TFT	This is the Touch Screen interrupt signal to wake the TFT.
CTP_INT 31	33	Red	Output from TFT	This is the Touch Screen Interrupt Request pin.
CTP_I2C-SDA1 30	34	Yellow	1/0	Serial data input/output.
CTP_I2C-SCL1 29	35	Orange	Input to TFT	Serial clock input.
CTP_/RST	36		Input to TFT	External low active signal resets the F5206 chip, if not used leave floating.
These pins are used to control the Built-in Resistive Touch Panel on my Weather Board.				
TFT_INT 23	10		Output from TFT	This is the Touch Screen Interrupt Request Pin
These are the Power and Ground Pins				
TFT_Ground	1	Black	Pwr Sup In Neg.	Ground Pin
TFT Ground	2	Black	Pwr Sup In Neg.	
TFT Power (Vcc +5V)	3	Red		Power Input Pin +5V
TFT Power (Vcc +5V)	4	Red	Pwr Sup In Pos.	•
TFT Ground	31		сар со.	Ground Pin
TFT_Power (Vcc +5V)	37			Power Input Pin +5V
TFT_Power (Vcc +5V)	38			Power Input Pin +5V
TFT_Ground GND1	39	Blue		Ground Pin
TFT_Ground GND2	40	Black		Ground Pin

Be sure to remove R1, R2, R3 and C1, and C2 on the ER-TFTM080-2 board, this is for the I2C Interface.