eSDK Enterprise Storage Plugins V2.2.15

User Guide (Kubernetes CSI)

Issue 02

Date 2022-04-19





Copyright © Huawei Technologies Co., Ltd. 2022. All rights reserved.

No part of this document may be reproduced or transmitted in any form or by any means without prior written consent of Huawei Technologies Co., Ltd.

Trademarks and Permissions

HUAWEI and other Huawei trademarks are trademarks of Huawei Technologies Co., Ltd. All other trademarks and trade names mentioned in this document are the property of their respective holders.

Notice

The purchased products, services and features are stipulated by the contract made between Huawei and the customer. All or part of the products, services and features described in this document may not be within the purchase scope or the usage scope. Unless otherwise specified in the contract, all statements, information, and recommendations in this document are provided "AS IS" without warranties, guarantees or representations of any kind, either express or implied.

The information in this document is subject to change without notice. Every effort has been made in the preparation of this document to ensure accuracy of the contents, but all statements, information, and recommendations in this document do not constitute a warranty of any kind, express or implied.

Huawei Technologies Co., Ltd.

Address: Huawei Industrial Base

Bantian, Longgang Shenzhen 518129

People's Republic of China

Website: https://e.huawei.com

About This Document

Intended Audience

This document is intended for:

- Technical support engineers
- O&M engineers
- Engineers with basic knowledge of storage and Kubernetes

Symbol Conventions

The symbols that may be found in this document are defined as follows.

Symbol	Description			
▲ DANGER	Indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.			
⚠ WARNING	Indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury.			
⚠ CAUTION	Indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate injury.			
NOTICE	Indicates a potentially hazardous situation which, if not avoided, could result in equipment damage, data loss, performance deterioration, or unanticipated results. NOTICE is used to address practices not related to personal injury.			
	Supplements the important information in the main text. NOTE is used to address information not related to personal injury, equipment damage, and environment deterioration.			

Change History

Issue	Date	Description	
02	2022-04-19	This issue is the second official release.	
01	2021-12-30	This issue is the first official release.	

Contents

About This Document	ii
1 Overview	1
2 Environmental Requirements	2
3 Restrictions	4
4 Installation and Deployment	8
4.1 Obtaining the Software Package	8
4.2 Components in the Software Package	8
4.3 Creating a Huawei CSI Image	9
4.4 Configuring Host Multipathing	10
4.4.1 Installing the Multipathing Tool Package	10
4.4.2 Configuring the Multipathing Service	11
4.5 Connecting to Enterprise Storage	13
4.5.1 Connecting to Enterprise Storage SAN over iSCSI	13
4.5.2 Connecting to Enterprise Storage SAN over FC	16
4.5.3 Connecting to Enterprise Storage NAS over NFS	19
4.5.4 Connecting to Enterprise Storage SAN over NVMe over RoCE (Not Supported by V2.2.15)	22
4.6 Connecting to Distributed Storage	
4.6.1 Connecting to Distributed Storage SAN over SCSI	
4.6.2 Connecting to Distributed Storage SAN over iSCSI	
4.6.3 Connecting to Distributed Storage NAS over NFS	
4.7 Starting huawei-csi Services	34
5 Upgrade Operations	40
5.1 Uninstalling Original CSI	40
5.2 Installing New CSI	40
6 Instructions for Use	42
6.1 Managing a StorageClass	42
6.1.1 Creating a StorageClass	42
6.1.1.1 Creating a LUN StorageClass	
6.1.1.2 Creating a File System StorageClass	
6.1.2 Deleting a StorageClass	
6.2 Managing a PVC	46

6.2.1 Creating a PVC	46
6.2.2 (Optional) Expanding the Capacity of a PVC	49
6.2.3 (Optional) Cloning a PVC	51
6.2.4 (Optional) Creating a PVC Using a Snapshot	53
6.2.5 Deleting a PVC	54
6.3 Managing a Pod	55
6.3.1 Creating a Pod	55
6.3.2 Deleting a Pod	56
6.4 (Optional) Managing a Snapshot	57
6.4.1 Installing the Snapshot-Dependent Component Service	57
6.4.2 Managing a VolumeSnapshotClass	58
6.4.2.1 Creating a VolumeSnapshotClass	58
6.4.2.2 Deleting a VolumeSnapshotClass	59
6.4.3 Managing a VolumeSnapshot	59
6.4.3.1 Creating a VolumeSnapshot	59
6.4.3.2 Deleting a VolumeSnapshot	61
7 Advanced Features	62
7.1 Configuring Multiple Backends	62
7.2 Creating a PVC for a Specified Backend	63
7.3 Creating a PVC for a Specified Storage Pool	64
7.4 Configuring ALUA	64
7.4.1 Configuring ALUA for OceanStor V3/V5 and OceanStor Dorado V3	64
7.4.2 Configuring ALUA for OceanStor Dorado 6.x	67
7.4.3 Configuring ALUA for Distributed Storage	70
7.5 Configuring Storage Topology Awareness	72
7.6 Advanced Features of Enterprise Storage	76
7.6.1 Configuring QoS	76
7.6.2 Configuring a vStore	79
7.6.3 Configuring NAS HyperMetro	79
7.6.4 Configuring an Application Type	82
7.7 Advanced Features of Distributed Storage	83
7.7.1 Configuring QoS	83
7.7.2 Configuring a Soft Quota	84
8 Common Operations	86
8.1 Uninstalling CSI	86
8.1.1 Uninstalling the huawei-csi-node Service	87
8.1.2 Uninstalling the huawei-csi-controller Service	87
8.1.3 Deleting the huawei-csi-configmap Object	87
8.1.4 Deleting the huawei-csi-secret Object	88
8.1.5 Deleting the RBAC Permission	88
8.1.6 Deleting the Image of the Earlier Version	89
8.2 Updating the User Name or Password of a Storage Device Configured on CSI	90

3.3 Updating the configmap Object of huawei-csi	91
3.4 Adding a Backend for huawei-csi	93
3.5 Updating the huawei-csi-controller Service	94
3.6 Updating the huawei-csi-node Service	95
3.7 Modifying the Log Output Mode	96
3.7.1 Modifying the Log Output Mode of the huawei-csi-controller Service	96
3.7.2 Modifying the Log Output Mode of the huawei-csi-node Service	97
9 FAQ	100
9.1 Viewing Log Information	
9.2 Failed to Create a Pod Because the iscsi_tcp Service Is Not Started Properly When the Kubernetes Platform Is Set Up for the First Time	
9.3 Failed to Start the huawei-csi-node Service with Error Message "/var/lib/iscsi is not a directory" Reported	. 102
9.4 After a Worker Node in the Cluster Breaks Down and Recovers, Pod Failover Is Complete but the Source Host Where the Pod Resides Has Residual Drive Letters	103
9.5 Failed to Start huawei-csi Services with the Status Displayed as InvalidImageName	105
9.6 When a PVC Is Created, the PVC Is in the Pending State	107
9.7 Before a PVC Is Deleted, the PVC Is in the Pending State	. 108
9.8 When a Pod Is Created, the Pod Is in the ContainerCreating State	110
10 Appendix	112
10.1 Example ALUA Configuration Policy of OceanStor V3/V5 and OceanStor Dorado V3	112
10.2 Example ALUA Configuration Policy of OceanStor Dorado 6.x	. 113
10.3 Example ALUA Configuration Policy of Distributed Storage	

1 Overview

This document describes how to deploy and use the Kubernetes CSI plug-in so that Huawei enterprise and distributed storage devices provide persistent volume storage capabilities for Kubernetes.

2 Environmental Requirements

- Kubernetes has been deployed and is running properly.
- A Huawei storage device is running properly.
- Drivers required for scanning disks and mounting files (such as iSCSI and DM Multipath) must be installed on all worker hosts of Kubernetes in advance. If containers and services cannot run properly due to lack of system tools, view logs by referring to 9.1 Viewing Log Information and install the tools on the hosts.

Table 2-1 Version mappings among Kubernetes, enterprise storage products, and host machine operating systems (OSs)

Kubernetes Version	Enterprise Storage Product Version	Host Machine OS Version
1.16/1.17/1.18/ 1.19/1.20/1.21	OceanStor Dorado 6.0.0/6.0.1/6.1.0/6.1.2/6.1.3RC 2 OceanStor Dorado V3 V300R002 OceanStor 6.1.3RC2 OceanStor F V5/V5 V500R007/V500R007 Kunpeng OceanStor F V3/V3 V300R006	CentOS 7.6/7.7/8.2 (x86_64) SUSE 15 SP2 (x86_64) CoreOS 4.6/4.7/4.8

Table 2-2 Version mappings among Kubernetes, distributed storage products, and host machine OSs

Kubernetes Version	Distributed Storage Product Version	Host Machine OS Version
1.16/1.17/1.18/ 1.19/1.20/1.21	FusionStorage V100R006C30 FusionStorage block storage 8.0.0/8.0.1 OceanStor Pacific series 8.1.0	CentOS 7.6/7.7/8.2 (x86_64) SUSE 15 SP2 (x86_64) CoreOS 4.6/4.7/4.8

NOTICE

If the host machine OS is CoreOS 4.6/4.7, see *Kubernetes CSI for Red Hat OpenShift User Guide*

Table 2-3 Features supported by Huawei CSI (√: supported; x: not supported)

Feature	1.16	1.17	1.18	1.19	1.20	1.21
Create PVC	√	√	√	√	√	√
Delete PVC	√	√	√	√	√	√
Create Pod	√	√	√	√	√	√
Delete Pod	√	√	√	√	√	√
Offline Resize	√	√	√	√	√	√
Online Resize	√	√	√	√	√	√
Create Snapshot	х	√	√	√	√	√
Delete Snapshot	х	√	√	√	√	√
Restore	х	√	√	√	√	√
Clone	х	√	√	√	√	√

3 Restrictions

This chapter describes the restrictions on connecting CSI to storage devices.

Table 3-1 Restrictions

Scenario	Restriction	Supported Storage	Remarks
PersistentVolume- Claim (PVC) access mode	ReadWriteOnce: SAN/NAS ReadWriteMany: NAS/SAN (If SAN needs to use this mode, the Pod service must ensure data consistency.) ReadWriteOnly: SAN/NAS	SAN: OceanStor V3/V5/V6, OceanStor Dorado V3/Dorado 6.x, FusionStorage 8.0.x, OceanStor Pacific series NAS: OceanStor V3/V5/V6, OceanStor Dorado 6.x, OceanStor Pacific series	N/A
Creating/Deleting PVCs	You are advised to create or delete a maximum of 100 items in a batch.	SAN: OceanStor V3/V5/V6, OceanStor Dorado V3/Dorado 6.x, FusionStorage 8.0.x, OceanStor Pacific series NAS: OceanStor V3/V5/V6, OceanStor Dorado 6.x, OceanStor Pacific series	The maximum number of concurrent RESTful requests is 100.

Scenario	Restriction	Supported Storage	Remarks
Creating/Deleting Pods	You are advised to create or delete a maximum of 100 items in a batch.	SAN: OceanStor V3/V5/V6, OceanStor Dorado V3/Dorado 6.x, FusionStorage 8.0.x, OceanStor Pacific series NAS: OceanStor V3/V5/V6, OceanStor Dorado 6.x, OceanStor Pacific series	N/A
Snapshot	N/A	SAN: OceanStor V3/V5/V6, OceanStor Dorado V3/Dorado 6.x, FusionStorage 8.0.x, OceanStor Pacific series NAS: OceanStor V3/V5/V6, OceanStor Dorado 6.x	N/A
Creating a PVC using a snapshot	N/A	SAN: OceanStor V3/V5/V6, OceanStor Dorado V3/Dorado 6.x, FusionStorage 8.0.x, OceanStor Pacific series NAS: OceanStor V3/V5/V6	N/A
Expanding the capacity of a PVC	 Only capacity expansion is supported. Capacity reduction is not supported. A PVC whose access mode is ROX does not support capacity expansion. 	SAN: OceanStor V3/V5/V6, OceanStor Dorado V3/Dorado 6.x, FusionStorage 8.0.x, OceanStor Pacific series NAS: OceanStor V3/V5/V6, OceanStor Dorado 6.x	N/A

Scenario	Restriction	Supported Storage	Remarks
Cloning a PVC	The StorageClasses of the source and target PVCs must be the same.	SAN: OceanStor V3/V5/V6, OceanStor Dorado V3/Dorado 6.x, FusionStorage 8.0.x, OceanStor Pacific series NAS: OceanStor V3/V5/V6	N/A
HyperMetro	PVCs and Pods can be created only when both HyperMetro storage systems are normal. If a single storage system is faulty, only the services that have been delivered are normal and new services cannot be delivered. If both storage systems are faulty, contact Huawei technical support engineers.	NAS: OceanStor V3/V5	N/A

Scenario	Restriction	Supported Storage	Remarks
Residual drive letter	Due to a node fault, containerized applications are migrated to other nodes. After the node recovers, residual drive letters exist on the node. Manually clear the residual drive letters. For details, see 9.4 After a Worker Node in the Cluster Breaks Down and Recovers, Pod Failover Is Complete but the Source Host Where the Pod Resides Has Residual Drive Letters.	SAN: OceanStor V3/V5/V6, OceanStor Dorado V3/Dorado 6.x, FusionStorage 8.0.x, OceanStor Pacific series	Condition: iSCSI/FC + Multipath

4 Installation and Deployment

- 4.1 Obtaining the Software Package
- 4.2 Components in the Software Package
- 4.3 Creating a Huawei CSI Image
- 4.4 Configuring Host Multipathing
- 4.5 Connecting to Enterprise Storage
- 4.6 Connecting to Distributed Storage
- 4.7 Starting huawei-csi Services

4.1 Obtaining the Software Package

You can obtain Huawei Kubernetes CSI through Huawei Kubernetes CSI warehouse.

- Step 1 Open a browser and enter https://github.com/Huawei/eSDK_K8S_Plugin/releases in the address box.
- **Step 2** Select the desired version package and download **eSDK_EnterPrise_Storage_Plugin_***.*.**zip. *.***indicates the release version number. (The version matching this document is 2.2.15.)
- **Step 3** Decompress the package.
- **Step 4** Find the package and documents in the directory generated after the decompression.

----End

4.2 Components in the Software Package

Decompress *eSDK_EnterPrise_Storage_Plugin_*.*.***:zip to obtain the software package and sample files required for installing and using CSI. **Table 4-1** shows the software package structure.

Component Description			
bin/huawei-csi	Implements the CSI API.		
bin/secretGenerate	Encrypts plaintext passwords and produces secret objects.		
bin/secretUpdate	Encrypts plaintext passwords and updates secret objects.		
yamls	Collection of .yaml sample files used in subsequent		

Table 4-1 Component description

4.3 Creating a Huawei CSI Image

Huawei CSI runs as a container. Currently, Huawei CSI provides only a binary package (bin/huawei-csi) which cannot be used directly. Therefore, you need to create a CSI image based on the binary file to start the Huawei CSI service.

deployment.

Prerequisites

A Linux host with Docker installed is available, and the host can access the Internet (only used to download the image package).

Procedure

- **Step 1** Log in to the Linux host.
- **Step 2** Run the **mkdir image** command to create a directory (for example, **image**) on the host.

mkdir image

- **Step 3** Run the **cd image** command to access the **image** directory.

 # cd image
- **Step 4** Copy the huawei-csi component to the **image** directory.
- **Step 5** Run the following command to create a file named **Dockerfile**.

```
# cat <<EOF > ./Dockerfile
FROM busybox:stable-glibc
ADD ["huawei-csi", "/"]
RUN ["chmod", "+x", "/huawei-csi"]
ENTRYPOINT ["/huawei-csi"]
```

NOTICE

busybox:stable-glibc indicates the basic image and its tag. It is only an example. Replace it based on site requirements.

Step 6 Run the **docker build -f Dockerfile -t huawei-csi:2.2.15** . command to create an image.

docker build -f Dockerfile -t huawei-csi:2.2.15.

MOTE

2.2.15 indicates the plug-in version number corresponding to the software package name. It is only an example. Replace it based on site requirements. If the same image already exists in the environment, use **docker image rm** <*image-id>*.

Step 7 Run the **docker image ls | grep huawei-csi** command to check whether the image is created. If the following information is displayed, it is created.

docker image ls | grep huawei-csi huawei-csi 2.2.15 c8b5726118ac About a minute ago 39 MB

Step 8 Run the **docker save huawei-csi:2.2.15 -o huawei-csi.tar** command to export the image.

docker save huawei-csi:2.2.15 -o huawei-csi.tar

2.2.15 indicates the plug-in version number corresponding to the software package name. It is only an example. Replace it based on site requirements.

Step 9 Run the **scp huawei-csi.tar** *<user>@<ip>:/<path>* command to copy the **huawei-csi.tar** image file to all worker nodes in the Kubernetes cluster and enter the password as prompted.

scp huawei-csi.tar <user>@<ip>:/<path>

- <user>: user name for logging in to a worker node in the Kubernetes cluster.
- <ip>: IP address for logging in to a worker node in the Kubernetes cluster.
- <path>: name of the folder to be copied to a worker node in the Kubernetes cluster.
- **Step 10** Log in to a worker node in the Kubernetes cluster and run the **docker load -i huawei-csi.tar** command to import the image.

docker load -i huawei-csi.tar

Step 11 After the import is complete, run the **docker image ls | grep huawei-csi** command to check whether the import is successful. If the following information is displayed, the import is successful.

docker image ls | grep huawei-csi huawei-csi 2.2.15 c8b5726118ac 10 minutes ago 39MB

Step 12 Repeat **Step 9** to **Step 11** to import the image to all worker nodes in the Kubernetes cluster.

----End

4.4 Configuring Host Multipathing

4.4.1 Installing the Multipathing Tool Package

This section describes how to install the multipathing tool package.

Prerequisites

Ensure that the worker nodes in the Kubernetes cluster can access the Internet (only used to download the multipathing tool package).

Precautions

The host multipathing service needs to be configured only when storage devices are connected over an iSCSI or FC network.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to a worker node in the Kubernetes cluster through the management IP address.
- **Step 2** Install the multipathing tool package based on the OS.
 - CentOS: yum install -y device-mapper-multipath
 - SUSE: zypper install -y multipath-tools
- **Step 3** Enable the host multipathing service.
 - CentOS:
 /sbin/mpathconf --enable
 systemctl start multipathd.service
 systemctl enable multipathd.service
 systemctl restart multipathd.service
 - SUSE: systemctl restart multipath-tools.service chkconfig multipathd on
- **Step 4** Repeat **Step 1** to **Step 3** to install the multipathing tool on all worker nodes.

----End

4.4.2 Configuring the Multipathing Service

Multipathing is configured to improve the link reliability of LUNs on SAN storage. If multipathing is incorrectly configured, I/O errors will occur when a single link is faulty. As a result, the file systems or disks in the containers managed by the Kubernetes cluster are read-only or faulty, affecting I/O delivery.

Precautions

The multipathing service needs to be configured only when storage devices are connected over an iSCSI or FC network.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to a worker node in the Kubernetes cluster through the management IP address.
- Step 2 Run the vi /etc/multipath.conf command to modify the multipath.conf file. If the file does not exist, configure or generate it by referring to the storage host connectivity guide. Press I or Insert to enter the editing mode and modify related

parameters. After the modification is complete, press **Esc** and enter :**wq!** to save the modification. This document uses Red Hat as an example. For details about other OSs, see the storage host connectivity guide.

NOTICE

Load balancing mode: During service read and write, the I/O paths from a host to all controllers on a storage device are the same. For details, see **Configuring**Multipathing > Concepts in *Huawei SAN Storage Host Connectivity Guide for Red Hat*.

Local preferred mode: When a host delivers I/Os to controllers, the storage device with better performance is accessed because the service link distances from storage devices are different. For details, see **Configuring Multipathing** > **Concepts** in *Huawei SAN Storage Host Connectivity Guide for Red Hat*.

 If enterprise storage and the load balancing mode are used, you are advised to add the following content to the devices field in the multipathing configuration file (/etc/multipath.conf). For details, see OceanStor Dorado Host Connectivity Guide for Red Hat and OceanStor Dorado Host Connectivity Guide for SUSE.

```
devices {
  device {
                               "HUAWEI"
          vendor
          product
                               "XSG1"
          path_grouping_policy
                                   multibus
          path_checker
                                 tur
          prio
                             const
          path_selector
                                "service-time 0"
          failback
                              immediate
          no_path_retry
```

 If enterprise storage and the local preferred mode are used, you are advised to add the following content to the devices field in the multipathing configuration file (/etc/multipath.conf). For details, see Huawei SAN Storage Host Connectivity Guide for Red Hat and Huawei SAN Storage Host Connectivity Guide for SUSE.

```
devices {
    device {
        vendor "HUAWEI"
        product "XSG1"
        path_grouping_policy group_by_prio
        path_checker tur
        prio alua
        path_selector "round-robin 0"
        failback immediate
        no_path_retry 15
    }
```

 If distributed storage is used, you are advised to add the following content to the devices field in the multipathing configuration file (/etc/multipath.conf). The configuration varies according to the OS. For details, see Configuring Multipathing for an Application Server (Red Hat or CentOS) in FusionStorage 8.0.1 Block Storage Basic Service Configuration Guide 08. devices {

```
devices {
    device {
        vendor "Huawei"
```

```
product "VBS fileIO"
path_grouping_policy multibus
path_checker tur
prio const
path_selector "service-time 0"
failback immediate
no_path_retry "10"
}
```

Step 3 After the configuration is complete, run the following command to restart the multipathd service.

systemctl restart multipathd.service

Step 4 Repeat **Step 1** to **Step 3** to configure the multipathing service for all worker nodes.

----End

4.5 Connecting to Enterprise Storage

This section describes how to connect the huawei-csi plug-in to Huawei enterprise storage.

4.5.1 Connecting to Enterprise Storage SAN over iSCSI

Perform this operation when you want to connect to enterprise storage SAN over iSCSI.

Prerequisites

- An iSCSI client has been installed on all worker nodes of Kubernetes.
- All worker nodes of Kubernetes communicate properly with the management IP address of the storage device to be connected.
- All worker nodes of Kubernetes communicate properly with the service IP address of the storage device to be connected.
- If a multipathing network is used, ensure that multipathing software has been installed on all worker nodes. For details, see 4.4 Configuring Host Multipathing.
- You have obtained the IP address, login account, and password of any master node in the Kubernetes cluster from the administrator.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the **vi** *huawei-csi-configmap.yaml* command to create a file named *huawei-csi-configmap.yaml*.

vi huawei-csi-configmap.yaml

Step 3 Configure the *huawei-csi-configmap.yaml* file. The following shows a template of the *huawei-csi-configmap.yaml* file. You can also refer to the **yamls/huawei-csi-configmap-oceanstor-iscsi.yaml** example file in the software package. Set related parameters based on the site requirements and save the file in yaml format. For details, see Table 4-2.

Table 4-2 Description of configuration items

Configuration Item	Format	Description	Remarks
metadata.name	String	User-defined name of a storage device. This parameter is mandatory.	User-defined character string. The value can contain uppercase letters, lowercase letters, digits, and hyphens (-).
data."csi.json".ba ckends	List	List of back-end storage devices to be connected. This parameter is mandatory.	The number of backend storage devices is not limited. For details about the fields that can be configured for a single back-end storage
			device, see Table 4-3 .

Table 4-3 Configuration items of a back-end storage device

Configuration Item	Format	Description	Remarks
storage	String	Type of the storage device to be connected. This parameter is mandatory.	In the scenario where the enterprise storage SAN is connected, the value is fixed to oceanstor-san.

Configuration Item	Format	Description	Remarks
pools	List	Name of a storage pool used on the storage device to be connected. This parameter is mandatory.	One or more storage pools on the same storage device are supported. Use commas (,) to separate multiple storage pools. You can log in to DeviceManager to obtain the storage pools that support the
			block storage service.
urls	List	Management URL of the storage device to be connected. This parameter is mandatory.	One or more management URLs of the same storage device are supported. Use commas (,) to separate multiple management URLs. Currently, only IPv4 addresses are supported. Example: https://
			NOTE A storage device has multiple controllers, and each controller has a management URL. Therefore, a storage device has multiple management URLs.

Configuration Item	Format	Description	Remarks
parameters	Dictionary	Variable parameters in scenarios where iSCSI is used. This parameter is mandatory.	In scenarios where iSCSI is used, set the protocol parameter to a fixed value: iscsi . Set the portals parameter to the iSCSI service IP addresses of the storage device. Use commas (,) to separate multiple iSCSI service IP addresses. You can log in to DeviceManager to obtain the iSCSI service IP addresses. Take OceanStor Dorado 6.x series as an example. On DeviceManager, choose Services > Network > Logical Ports and obtain the IP address whose data protocol is iSCSI. (For other series, see the corresponding operation description.)

kubectl create -f huawei-csi-configmap.yaml

Step 5 After the creation is complete, run the **kubectl get configmap -n kube-system** | **grep huawei-csi-configmap** command to check whether the creation is successful. If the following information is displayed, the creation is successful.

kubectl get configmap -n kube-system | grep huawei-csi-configmap huawei-csi-configmap 1 5s

----End

4.5.2 Connecting to Enterprise Storage SAN over FC

Perform this operation when you want to connect to enterprise storage SAN over FC.

Restrictions

To connect to enterprise storage SAN over FC, ensure that no residual drive letter exists on the host. If any residual drive letter exists, clear the drive letter by referring to 9.4 After a Worker Node in the Cluster Breaks Down and Recovers,

Pod Failover Is Complete but the Source Host Where the Pod Resides Has Residual Drive Letters.

Prerequisites

- All worker nodes of Kubernetes communicate properly with the management IP address of the storage device to be connected.
- All worker nodes of Kubernetes can communicate with the storage device to be connected over FC.
- If a multipathing network is used, ensure that multipathing software has been installed on all worker nodes of Kubernetes. For details, see 4.4 Configuring Host Multipathing.
- You have obtained the IP address, login account, and password of any master node in the Kubernetes cluster from the administrator.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the **vi** *huawei-csi-configmap.yaml* command to create a file named *huawei-csi-configmap.yaml*.

vi huawei-csi-configmap.yaml

Step 3 Configure the *huawei-csi-configmap.yaml* file. The following shows a template of the *huawei-csi-configmap.yaml* file. You can also refer to the **yamls/huawei-csi-configmap-oceanstor-fc.yaml** example file in the software package. Set related parameters based on the site requirements and save the file in yaml format. For details, see **Table 4-4**.

Table 4-4 Description of configuration items

Configuration Item	Format	Description	Remarks
metadata.name	String	User-defined name of a storage device. This parameter is mandatory.	User-defined character string. The value can contain uppercase letters, lowercase letters, digits, and hyphens (-).
data."csi.json".b ackends	con".b List List of back-end storage devices to be connected. This	The number of back- end storage devices is not limited.	
		parameter is mandatory.	For details about the fields that can be configured for a single back-end storage device, see Table 4-5 .

Table 4-5 Configuration items of a back-end storage device

Configuration Item	Format	Description	Remarks
storage	String	Type of the storage device to be connected. This parameter is mandatory.	In the scenario where the enterprise storage SAN is connected, the value is fixed to oceanstor-san.
pools	List	Name of a storage pool used on the storage device to be connected. This parameter is mandatory.	One or more storage pools on the same storage device are supported. Use commas (,) to separate multiple storage pools. You can log in to DeviceManager to obtain the storage pools that support the block storage service.

Configuration Item	Format	Description	Remarks
urls	List	Management URL of the storage device to be connected. This parameter is mandatory.	One or more management URLs of the same storage device are supported. Use commas (,) to separate multiple management URLs. Currently, only IPv4 addresses are supported. Example: https:// 192.168.125.20:8088 NOTE A storage device has multiple controllers, and each controller has a management URL. Therefore, a storage device has multiple management URLs.
parameters	Dictionary	Variable parameters in scenarios where FC is used. This parameter is mandatory.	In scenarios where FC is used, set the protocol parameter to a fixed value: fc .

kubectl create -f huawei-csi-configmap.yaml

Step 5 After the creation is complete, run the **kubectl get configmap -n kube-system** | **grep huawei-csi-configmap** command to check whether the creation is successful. If the following information is displayed, the creation is successful.

kubectl get configmap -n kube-system | grep huawei-csi-configmap huawei-csi-configmap 1 5s

----End

4.5.3 Connecting to Enterprise Storage NAS over NFS

Perform this operation when you want to connect to enterprise storage NAS over NFS.

Prerequisites

- An NFS client tool has been installed on all worker nodes of Kubernetes.
- All worker nodes of Kubernetes communicate properly with the storage device to be connected.
- All worker nodes of Kubernetes communicate properly with the NFS logical port of the storage device to be connected.

• You have obtained the IP address, login account, and password of any master node in the Kubernetes cluster from the administrator.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the **vi** *huawei-csi-configmap.yaml* command to create a file named *huawei-csi-configmap.yaml*.

vi huawei-csi-configmap.yaml

Step 3 Configure the *huawei-csi-configmap.yaml* file. The following shows a template of the *huawei-csi-configmap.yaml* file. You can also refer to the **yamls/huawei-csi-configmap-oceanstor-nfs.yaml** example file in the software package. Set related parameters based on the site requirements and save the file in yaml format. For details, see **Table 4-6**.

Table 4-6 Description of configuration items

Configuration Item	Format	Description	Remarks
metadata.name	String	User-defined name of a storage device. This parameter is mandatory.	User-defined character string. The value can contain uppercase letters, lowercase letters, digits, and hyphens (-).
data."csi.json".ba ckends	List	List of back-end storage devices to be connected. This	The number of backend storage devices is not limited.
		parameter is mandatory.	For details about the fields that can be configured for a single back-end storage device, see Table 4-7.

Table 4-7 Configuration items of a back-end storage device

Configuration Item	Format	Description	Remarks
storage	String	Type of the storage device to be connected. This parameter is mandatory.	In the scenario where the enterprise storage NAS is connected, the value is fixed to oceanstor-nas.
pools	List	Name of a storage pool used on the storage device to be connected. This parameter is mandatory.	One or more storage pools on the same storage device are supported. Use commas (,) to separate multiple storage pools. You can log in to DeviceManager to obtain the storage pools that support the file storage service.
urls	List	Management URL of the storage device to be connected. This parameter is mandatory.	One or more management URLs of the same storage device are supported. Use commas (,) to separate multiple management URLs. Currently, only IPv4 addresses are supported. Example: https:// 192.168.125.20:8088 NOTE
			A storage device has multiple controllers, and each controller has a management URL. Therefore, a storage device has multiple management URLs.

Configuration Item	Format	Description	Remarks
parameters	Dictionary	Variable parameters in scenarios where	The protocol parameter is fixed to nfs .
		NFS is used. This parameter is mandatory.	portals: logical port IP address or DNS zone of the storage device. Only one IP address or DNS zone can be configured.
			You can log in to DeviceManager to obtain the logical port IP address. Take OceanStor Dorado 6.x series as an example. On DeviceManager, choose Services > Network > Logical Ports and obtain the IP address whose data protocol is NFS. (For other series, see the corresponding operation description.)

kubectl create -f huawei-csi-configmap.yaml

Step 5 After the creation is complete, run the **kubectl get configmap -n kube-system** | **grep huawei-csi-configmap** command to check whether the creation is successful. If the following information is displayed, the creation is successful.

kubectl get configmap -n kube-system | grep huawei-csi-configmap huawei-csi-configmap 1 5s

----End

4.5.4 Connecting to Enterprise Storage SAN over NVMe over RoCE (Not Supported by V2.2.15)

Perform this operation when you want to connect to enterprise storage SAN over NVMe over RoCE.

Prerequisites

- All worker nodes of Kubernetes communicate properly with the management IP address of the storage device to be connected.
- All worker nodes of Kubernetes communicate properly with the service IP address of the storage device to be connected.

- The nyme-cli tool has been installed on all worker nodes of Kubernetes.
- You have obtained the IP address, login account, and password of any master node in the Kubernetes cluster from the administrator.
- For details about the compatibility of NVMe-related storage, hosts, and multipathing software, see https://support-open.huawei.com/en/pages/user/compatibility/support-matrix.jsf.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the **vi** *huawei-csi-configmap.yaml* command to create a file named *huawei-csi-configmap.yaml*.

vi huawei-csi-configmap.yaml

Step 3 Configure the huawei-csi-configmap.yaml file. The following shows a template of the huawei-csi-configmap.yaml file. You can also refer to the yamls/huawei-csi-configmap-oceanstor-roce.yaml example file in the software package. Set related parameters based on the site requirements and save the file in yaml format. For details, see Table 4-8.

Table 4-8 Description of configuration items

Configuration Item	Format	Description	Remarks
metadata.name	String	User-defined name of a storage device. This parameter is mandatory.	User-defined character string. The value can contain uppercase letters, lowercase letters, digits, and hyphens (-).
storage in data."csi.json". backends	String	Type of the storage device to be connected. This parameter is mandatory.	In the scenario where the enterprise storage SAN is connected, the value is fixed to oceanstor-san.

Configuration Item	Format	Description	Remarks
pools in data."csi.json". backends	List	Name of a storage pool used on the storage device to be connected. This parameter is mandatory.	One or more storage pools on the same storage device are supported. Use commas (,) to separate multiple storage pools. You can log in to DeviceManager to obtain the storage pools.
urls in data."csi.json". backends	List	Management URL of the storage device to be connected. This parameter is mandatory.	One or more management URLs of the same storage device are supported. Use commas (,) to separate multiple management URLs. Currently, only IPv4 addresses are supported. Example: https:// 192.168.125.20:8088 NOTE A storage device has multiple controllers, and each controller has a management URL. Therefore, a storage device has multiple management URLs.

Configuration Item	Format	Description	Remarks
parameters in data."csi.json". backends	Dictionary	Variable parameters in scenarios where RoCE is used. This parameter is mandatory.	In scenarios where RoCE is used, set the protocol parameter to a fixed value: roce . Set portals to the IP addresses of the logical ports when data protocol type of the storage device is NVMe over RoCE. Use commas (,) to separate the IP addresses. You can log in to DeviceManager to obtain the logical port IP address. Take OceanStor Dorado 6. <i>x</i> series as an example. On DeviceManager, choose Services > Network > Logical Ports and obtain the IP address whose data protocol is NVMe over RoCE. (For other series, see the corresponding operation description.)

kubectl create -f huawei-csi-configmap.yaml

Step 5 After the creation is complete, run the **kubectl get configmap -n kube-system** | **grep huawei-csi-configmap** command to check whether the creation is successful. If the following information is displayed, the creation is successful.

kubectl get configmap -n kube-system | grep huawei-csi-configmap huawei-csi-configmap 1 5s

----End

4.6 Connecting to Distributed Storage

This section describes how to connect the huawei-csi plug-in to Huawei distributed storage.

4.6.1 Connecting to Distributed Storage SAN over SCSI

Perform this operation when you want to connect to distributed storage SAN over SCSI.

Prerequisites

- The distributed storage VBS client has been installed on all worker nodes of Kubernetes.
- All worker nodes of Kubernetes communicate properly with the management IP address of the storage device to be connected.
- You have obtained the IP address, login account, and password of any master node in the Kubernetes cluster from the administrator.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the **vi** *huawei-csi-configmap.yaml* command to create a file named *huawei-csi-configmap.yaml*.

vi huawei-csi-configmap.yaml

Step 3 Configure the *huawei-csi-configmap.yaml* file. The following shows a template of the *huawei-csi-configmap.yaml* file. You can also refer to the **yamls/huawei-csi-configmap-fusionstorage-scsi.yaml** example file in the software package. Set related parameters based on the site requirements and save the file in yaml format. For details, see Table 4-9.

Table 4-9 Description of configuration items

Configuration Item	Format	Description	Remarks
metadata.name	String	User-defined name of a storage device. This parameter is mandatory.	User-defined character string. The value can contain uppercase letters, lowercase letters, digits, and hyphens (-).

Configuration Item	Format	Description	Remarks
data."csi.json".ba ckends	List	List of back-end storage devices to be connected. This parameter is mandatory.	The number of backend storage devices is not limited. For details about the fields that can be configured for a single back-end storage device, see Table 4-10.

Table 4-10 Configuration items of a back-end storage device

Configuration Item	Format	Description	Remarks
storage	String	Type of the storage device to be connected. This parameter is mandatory.	In the scenario where the distributed storage SAN is connected, the value is fixed to fusionstorage-san.
pools	List	Name of a storage pool used on the storage device to be connected. This parameter is mandatory.	One or more storage pools on the same storage device are supported. Use commas (,) to separate multiple storage pools. You can log in to DeviceManager to obtain the storage pools.
urls	List	Management URL of the storage device to be connected. This parameter is mandatory.	For FusionStorage, only one management URL can be configured.

Configuration Item	Format	Description	Remarks
parameters	Dictionary	Variable parameters in scenarios where SCSI is used. This parameter is mandatory.	The protocol parameter is fixed to scsi. Set portals to a pair list of host names and VBS node IP addresses. The format is [{"hostname":"****"}], where hostname indicates the host name of a worker node and ****indicates the management IP address of a distributed storage block client (only IPv4 addresses are supported currently). If there are multiple worker nodes, configure them in dictionary format and separate them with commas (,). In the preceding example, hostname01 is the host name of a worker node in Kubernetes, and 192.168.125.21 is the management IP address of a VBS node after VBS is created for the worker node.

kubectl create -f huawei-csi-configmap.yaml

Step 5 After the creation is complete, run the **kubectl get configmap -n kube-system** | **grep huawei-csi-configmap** command to check whether the creation is successful. If the following information is displayed, the creation is successful.

kubectl get configmap -n kube-system | grep huawei-csi-configmap huawei-csi-configmap 1 5s

----End

4.6.2 Connecting to Distributed Storage SAN over iSCSI

Perform this operation when you want to connect to distributed storage SAN over iSCSI.

Prerequisites

- An iSCSI client has been installed on all worker nodes of Kubernetes.
- All worker nodes of Kubernetes communicate properly with the management IP address of the storage device to be connected.
- All worker nodes of Kubernetes communicate properly with the service IP address of the storage device to be connected.
- You have obtained the IP address, login account, and password of any master node in the Kubernetes cluster from the administrator.
- If a multipathing network is used, ensure that multipathing software has been installed on all worker nodes.

Precautions

- The host name of a Kubernetes worker node consists of digits, letters, underscores (_), hyphens (-), periods (.), and colons (:), and must start with a digit, letter, or underscore (_). The name length cannot exceed 31 characters.
- Only FusionStorage 8.0.0 and later versions support iSCSI networking configuration.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the **vi** *huawei-csi-configmap.yaml* command to create a file named *huawei-csi-configmap.yaml*.
 - # vi huawei-csi-configmap.yaml
- Step 3 Configure the huawei-csi-configmap.yaml file. The following shows a template of the huawei-csi-configmap.yaml file. You can also refer to the yamls/huawei-csi-configmap-fusionstorage-iscsi.yaml example file in the software package. Set related parameters based on the site requirements and save the file in yaml format. For details, see Table 4-11.

Table 4-11 Description of configuration items

Configuration Item	Format	Description	Remarks
metadata.name	String	User-defined name of a storage device. This parameter is mandatory.	User-defined character string. The value can contain uppercase letters, lowercase letters, digits, and hyphens (-).
data."csi.json".ba ckends	List	List of back-end storage devices to be connected. This	The number of backend storage devices is not limited.
		parameter is mandatory.	For details about the fields that can be configured for a single back-end storage device, see Table 4-12.

Table 4-12 Configuration items of a back-end storage device

Configuration Item	Format	Description	Remarks
storage	String	Type of the storage device to be connected. This parameter is mandatory.	In the scenario where the distributed storage SAN is connected, the value is fixed to fusionstorage-san.
pools	List	Name of a storage pool used on the storage device to be connected. This parameter is mandatory.	One or more storage pools on the same storage device are supported. Use commas (,) to separate multiple storage pools. You can log in to DeviceManager to obtain the storage pools.
urls	List	Management URL of the storage device to be connected. This parameter is mandatory.	For FusionStorage, only one management URL can be configured.

Configuration Item	Format	Description	Remarks
parameters	Dictionary	Variable parameters in scenarios where iSCSI is used. This parameter is mandatory.	In scenarios where iSCSI is used, set the protocol parameter to a fixed value: iscsi .
			Set the portals parameter to the iSCSI service IP addresses of the storage device. Use commas (,) to separate multiple them. You can log in to DeviceManager to obtain them.
			You can log in to DeviceManager to obtain the iSCSI service IP addresses. Take OceanStor Pacific series as an example. On DeviceManager, choose Resources > Access > Service Network. (For other series, see the corresponding operation description.)

Step 4 Run the **kubectl create -f** *huawei-csi-configmap.yaml* command to create *huawei-csi-configmap*.

kubectl create -f huawei-csi-configmap.yaml

Step 5 After the creation is complete, run the **kubectl get configmap -n kube-system** | **grep huawei-csi-configmap** command to check whether the creation is successful. If the following information is displayed, the creation is successful.

kubectl get configmap -n kube-system | grep huawei-csi-configmap huawei-csi-configmap 1 5s

----End

4.6.3 Connecting to Distributed Storage NAS over NFS

Perform this operation when you want to connect to distributed storage NAS over NFS.

Prerequisites

- An NFS client tool has been installed on all worker nodes of Kubernetes.
- All worker nodes of Kubernetes communicate properly with the management IP address of the storage device to be connected.

- All worker nodes of Kubernetes communicate properly with the IP address of the NFS logical port on the storage device to be connected.
- You have obtained the IP address, login account, and password of any master node in the Kubernetes cluster from the administrator.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the **vi** *huawei-csi-configmap.yaml* command to create a file named *huawei-csi-configmap.yaml*.

vi huawei-csi-configmap.yaml

Step 3 Configure the *huawei-csi-configmap.yaml* file. The following shows a template of the *huawei-csi-configmap.yaml* file. You can also refer to the **yamls/huawei-csi-configmap-fusionstorage-nfs.yaml** example file in the software package. Set related parameters based on the site requirements and save the file in yaml format. For details, see **Table 4-13**.

Table 4-13 Description of configuration items

Configuration Item	Format	Description	Remarks
metadata.name	String	User-defined name of a storage device. This parameter is mandatory.	User-defined character string. The value can contain uppercase letters, lowercase letters, digits, and hyphens (-).

Configuration Item	Format	Description	Remarks
data."csi.json".b ackends	List	List of back-end storage devices to be connected. This parameter is mandatory.	The number of backend storage devices is not limited. For details about the fields that can be configured for a single back-end storage device, see Table 4-14.

Table 4-14 Configuration items of a back-end storage device

Configuration Item	Format	Description	Remarks
storage	String	Type of the storage device to be connected. This parameter is mandatory.	In the scenario where the distributed storage NAS is connected, the value is fixed to fusionstorage-nas.
pools	List	Name of a storage pool used on the storage device to be connected. This parameter is mandatory.	One or more storage pools on the same storage device are supported. Use commas (,) to separate multiple storage pools. You can log in to DeviceManager to obtain the storage pools.
urls	List	Management URL of the storage device to be connected. This parameter is mandatory.	For FusionStorage, only one management URL can be configured.

parameters in scenarios where storage NFS is used. This parameter is mandatory. Obtain address configuration of the parameter is parameter is mandatory. Obtain address configuration of the parameter is mandatory. Oceans as an experience of the parameter is parameter is period of the parameter is provided in the parameter is period of the parameter is provided in the parameter is parameter is provided in the parameter is provided in the parameter is parameter is parameter is parameter is parameter is parameter in the parameter is parameter is parameter is parameter is parameter is parameter is provided in the parameter is parameter is provided in the parameter is parameter is parameter is parameter in the parameter is parameter in the parameter in the parameter in the parameter is parameter in the parameter in the parameter in the parameter is parameter in the par	Manager to it. Only one IP s can be

Step 4 Run the **kubectl create -f** *huawei-csi-configmap.yaml* command to create *huawei-csi-configmap*.

kubectl create -f huawei-csi-configmap.yaml

Step 5 After the creation is complete, run the **kubectl get configmap -n kube-system** | **grep huawei-csi-configmap** command to check whether the creation is successful. If the following information is displayed, the creation is successful.

kubectl get configmap -n kube-system | grep huawei-csi-configmap huawei-csi-configmap 1 5s

----End

4.7 Starting huawei-csi Services

This section describes how to start huawei-csi services.

Precautions

An image may need to be downloaded during the procedure. Therefore, worker nodes in the Kubernetes cluster must be able to access external networks. In an intranet environment, obtain the image package in other ways and manually import it into all worker nodes.

Prerequisites

• You have obtained the user name and password of the storage device from the administrator.

• A local storage user whose role is administrator or higher and level is administrator is required.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Copy the **secretGenerate** tool in the Kubernetes CSI component package to any directory on the master node. For details about the tool path, see **4.2 Components in the Software Package**.
- **Step 3** Use an encryption tool to enter the user name and password of the storage device.
 - 1. Run the **chmod +x secretGenerate** command to grant the execute permission on the secretGenerate tool.

chmod +x secretGenerate

 Run the ./secretGenerate command to run the secretGenerate tool and enter the ID of the backend to be configured as prompted. If Configured is false, the backend is not configured. If Configured is true, the backend is configured.

```
# ./secretGenerate
Getting backend configuration information.....
Number Configured BackendName
                                           Urls
               strage-backend [https://192.168.125.25:8088]
strage-backend-02 [https://192.168.125.26:8088]
      false
      false
3
     false
               strage-backend-03 [https://192.168.125.27:8088]
4
     false
               strage-backend-04 [https://192.168.125.28:8088]
               strage-backend-05 [https://192.168.125.29:8088]
     false
               strage-backend-06 [https://192.168.125.30:8088]
     false
Please enter the backend number to configure (Enter 'exit' to exit):3
```

3. Enter the user name and password as prompted to create a **secret** object.

4. After the configuration is complete, enter **exit** to exit and save the configuration.

```
Please enter the backend number to configure (Enter 'exit' to exit): exit
Saving configuration. Please wait.......
The configuration is saved successfully.
```

5. Run the **kubectl get secret -n kube-system | grep huawei-csi-secret** command to check whether the **secret** object is successfully created. # kubectl get secret -n kube-system | grep huawei-csi-secret

```
huawei-csi-secret Opaque 1 8m

Step 4 Run the vi huawei-csi-rbac.yaml command to modify the .yaml file. Press I or
```

Insert to enter the editing mode and modify related parameters. After the modification is complete, press Esc and enter :wq! to save the modification. (For details, see sample file yamls/huawei-csi-rbac.yaml in the software package.)

□ NOTE

- The csi-resizer service is supported since Kubernetes v1.16.
 For details about the huawei-csi-rbac.yaml file, see sample file yamls/huawei-csi-resize-rbac.yaml in the software package.
- The csi-snapshotter service is supported since Kubernetes v1.17 (recommended).
 For details about the huawei-csi-rbac.yaml file, see sample file yamls/huawei-csi-resize-snapshot-rbac.yaml in the software package.
- **Step 5** Run the following command to create the RBAC permission.

 # kubectl create -f huawei-csi-rbac.yaml
- Step 6 Run the vi huawei-csi-controller.yaml command to modify the .yaml file. Press I or Insert to enter the editing mode and modify related parameters. After the modification is complete, press Esc and enter :wq! to save the modification. (For details, see sample file yamls/huawei-csi-controller.yaml in the software package.)

• In the **image** configuration item under **huawei-csi-driver** in the sample .yaml file, huawei-csi:*.** must be replaced with <Name>:<Version> of the created Huawei CSI image.

containers:

name: huawei-csi-driver image: huawei-csi:2.2.15

- In the **args** section of **liveness-probe** in the .yaml file, **--health-port** indicates the listening port number. To change its value, perform the following operations.
 - 1. In the **args** section of **liveness-probe**, modify the **health-port** parameter.
 - --csi-address=/var/lib/csi/sockets/pluginproxy/csi.sock
 - --health-port=9808
 - In the ports section of huawei-csi-driver, modify the containerPort parameter. ports:
 - containerPort: 9808 name: healthz protocol: TCP
- The csi-resizer service is supported since Kubernetes v1.16.
 - For details about the **huawei-csi-controller.yaml** file, see sample file **yamls/huawei-csi-resize-controller.yaml** in the software package.
- The csi-snapshotter service is supported since Kubernetes v1.17 (recommended).
 For details about the huawei-csi-controller.yaml file, see sample file yamls/huawei-csi-resize-snapshot-controller.yaml in the software package.
- **Step 7** Run the following command to start the controller service.

kubectl create -f huawei-csi-controller.yaml

Step 8 Run the vi huawei-csi-node.yaml command to modify the .yaml file. Press I or Insert to enter the editing mode and modify related parameters. After the modification is complete, press Esc and enter :wq! to save the modification. Compile the huawei-csi-node.yaml file. For details, see sample file yamls/huawei-csi-node.yaml in the software package.

 In the image configuration item under huawei-csi-driver in the sample .yaml file, huawei-csi: *.** must be replaced with <Name>:<Version> of the created Huawei CSI image.

containers:

- name: huawei-csi-driver image: huawei-csi:2.2.15
- In the **args** section of **liveness-probe** in the .yaml file, **--health-port** indicates the listening port number. To change its value, perform the following operations.
 - 1. In the **args** section of **liveness-probe**, modify the **health-port** parameter.
 - --csi-address=/var/lib/csi/sockets/pluginproxy/csi.sock
 - --health-port=9800
 - In the ports section of huawei-csi-driver, modify the containerPort parameter. ports:
 - containerPort: 9800 name: healthz protocol: TCP
- In the args section of huawei-csi-driver in the .yaml file, --volume-use-multipath indicates that multipathing is enabled by default. The following shows how to change the value.

args:

- "--endpoint=/csi/csi.sock"
- "--containerized"
- "--driver-name=csi.huawei.com"
- "--volume-use-multipath=false"
- **Step 9** Run the following command to start the node service.

kubectl create -f huawei-csi-node.yaml

Step 10 After the huawei-csi services are deployed, run the **kubectl get pod -A | grep huawei** command to check whether the services are started.

```
# kubectl get pod -A | grep huawei
kube-system huawei-csi-controller-695b84b4d8-tg64l 7/7 Running 0 14s
kube-system huawei-csi-node-g6f7z 3/3 Running 0 14s
```

□ NOTE

The Pod of *huawei-csi-controller-695b84b4d8-tg64l* has seven containers, including liveness-probe, csi-provisioner, csi-attacher, csi-resizer, csi-snapshotter, shapshot-controller, and huawei-csi-driver. The number of containers depends on **huawei-csi-controller.yaml**. For details, see **Step 6**. Each container has its own image repository and functions. For details about the containers, see **Table 4-15**.

The Pod of *huawei-csi-node*-*g6f7z* has three containers, including liveness-probe, csi-node-driver-registrar, and huawei-csi-driver. Each container has its own image repository and functions. For details about the containers, see **Table 4-15**.

Table 4-15 Container description

Containe r Name	Container Image	Feature Description	Remarks
liveness- probe	k8s.gcr.io/sig- storage/ livenessprobe:v2. 4.0	Monitors the health status of CSI and reports it to Kubernetes so that Kubernetes can automatically detect CSI program problems and restart the Pod to rectify the problems.	View details
csi- provisione r	quay.io/k8scsi/csi- provisioner:v1.6.0	 Calls the CSI Controller service to create a LUN or file system on the storage system as a PV and bind the PV to a PVC when creating a PVC. Calls the CSI Controller service to unbind a PV from a PVC and delete the LUN or file system corresponding to the PV when deleting a PVC. 	View details
csi- attacher	quay.io/k8scsi/csi- attacher:v1.2.1	Calls the CSI Controller service to perform the "Publish/Unpublish Volume" operation when creating or deleting a Pod.	View details
csi-resizer	quay.io/k8scsi/csi- resizer:v1.0.1	Calls CSI to provide more storage space for a PVC when expanding the capacity of the PVC.	View details
csi- snapshott er	quay.io/k8scsi/csi- snapshotter:v3.0. 2	Calls CSI to create or delete a snapshot on the storage system when creating or deleting a VolumeSnapshot.	View details

Containe r Name	Container Image	Feature Description	Remarks
shapshot- controller	quay.io/k8scsi/ snapshot- controller:v3.0.2	Listens to the VolumeSnapshot and VolumeSnapshotContent objects in the Kubernetes API and triggers csi- snapshotter to create a snapshot on the storage system when creating or deleting a VolumeSnapshot.	View details
csi-node- driver- registrar	quay.io/k8scsi/csi- node-driver- registrar:v2.0.1	Obtains CSI information and registers a node with kubelet using the plug-in registration mechanism of kubelet so that Kubernetes can detect the connection between the node and Huawei storage.	View details
huawei- csi-driver	The name and tag of huaweicsi-driver are specified in 4.3 Creating a Huawei CSI Image.	Connects to the Kubernetes platform to provide Huawei storage (centralized or distributed storage) resources for containers.	Version mappings Restrictions

----End

5 Upgrade Operations

NOTICE

- The CSI upgrade does not affect delivered resources such as PVCs, snapshots, and Pods.
- During the upgrade, CSI cannot be used to deliver new resources.

5.1 Uninstalling Original CSI

5.2 Installing New CSI

5.1 Uninstalling Original CSI

Perform this operation when you want to uninstall CSI.

Prerequisites

Before uninstalling CSI, run the **kubectl get configmap huawei-csi-configmap -n kube-system -o yaml >> huawei-csi-configmap.yaml.bak** command to back up the content of the **huawei-csi-configmap** file. (During the CSI upgrade, the **backends** parameter in **huawei-csi-configmap.yaml** must be the same as the existing value of **configmap**.)

Procedure

Step 1 For details about the uninstallation, see **8.1 Uninstalling CSI**.

----End

5.2 Installing New CSI

After the uninstallation is complete, you need to reinstall the CSI.

Prerequisites

The **huawei-csi-configmap.yaml** file of the original CSI has been backed up.

Precautions

If the template of **huawei-csi-configmap.yaml** has changed, ensure that the following parameter settings are the same as those before the upgrade. Otherwise, huawei-csi services cannot be started and created resources cannot be managed.

- The values of storage, name, and pools must be the same as those in the huawei-csi-configmap.yaml.bak file backed up in Prerequisites in 5.1 Uninstalling Original CSI.
- For details about urls and parameters, see the huawei-csi-configmap.yaml.bak file backed up in Prerequisites in 5.1 Uninstalling Original CSI and set them based on the huawei-csi-configmap.yaml template of the current version. For details about the template, see 4.5 Connecting to Enterprise Storage and 4.6 Connecting to Distributed Storage. The following command output is only an example.

Procedure

- **Step 1** Obtain the CSI software package of the new version. For details, see **4.1 Obtaining the Software Package**.
- **Step 2** Create a CSI image of the new version. For details, see **4.3 Creating a Huawei CSI Image**.
- **Step 3** Create **huawei-csi-configmap**. For details, see **4.5 Connecting to Enterprise Storage** or **4.6 Connecting to Distributed Storage**.
- **Step 4** Start huawei-csi services. For details, see **4.7 Starting huawei-csi Services**.

----End

6 Instructions for Use

This chapter describes how to manage StorageClasses, PVCs, Pods, and snapshots after connecting Kubernetes to Huawei storage.

- 6.1 Managing a StorageClass
- 6.2 Managing a PVC
- 6.3 Managing a Pod
- 6.4 (Optional) Managing a Snapshot

6.1 Managing a StorageClass

6.1.1 Creating a StorageClass

A StorageClass is a set of capabilities that can be selected when you apply for block storage resources. Kubernetes cluster users can create PVCs based on a StorageClass.

6.1.1.1 Creating a LUN StorageClass

This section describes how to create a LUN StorageClass.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the **vi** *StorageClass.yaml* command to create a file named *StorageClass.yaml.* # vi StorageClass.yaml
- **Step 3** Press I or Insert to enter the editing mode and enter the following information in the *StorageClass.yaml* file. After the modification is complete, press **Esc** and enter :wq! to save the modification.

The following shows a template of the *StorageClass.yaml* file. You can also refer to the **yamls/lun-sc-for-csi-example.yaml** example file in the software package. Set related parameters based on the site requirements and save the file in yaml format. For details, see **Table 6-1**.

kind: StorageClass apiVersion: storage.k8s.io/v1 metadata: name: "mysc" provisioner: "csi.huawei.com" parameters: volumeType: "lun" allocType: "thin" cloneSpeed: "4"

Table 6-1 Parameter description

Parameter	Description	Remarks
metadata.name	User-defined name of a StorageClass object.	User-defined character string. The value can contain uppercase letters, lowercase letters, digits, and hyphens (-).
provisioner	provisioner identifier.	The value is fixed to csi.huawei.com.
parameters.volumeType	Type of the volume to be created.	The value is fixed to lun .
parameters.allocType	Allocation type of the volume to be created.	This parameter is optional. The value can be thin or thick , and the default value is thin .
parameters.cloneSpeed	Clone speed.	This parameter is optional. The value ranges from 1 to 4 and the default value is 3. 4 indicates the highest speed. This parameter is available when you clone a PVC or create a PVC using a snapshot. For details, see 6.2.3 (Optional) Cloning a PVC or 6.2.4 (Optional) Creating a PVC Using a Snapshot.
parameters.fsType	File system type.	This parameter is optional. The value can be ext2, ext3, or ext4, and the default value is ext4.

- **Step 4** Run the following command to create a StorageClass based on the .yaml file. # kubectl create -f StorageClass.yaml
- **Step 5** Run the following command to view the information about the created StorageClass.

kubectl get sc NAME PROVISIONER RECLAIMPOLICY VOLUMEBINDINGMODE ALLOWVOLUMEEXPANSION AGE mysc csi.huawei.com Delete Immediate false 87s

----End

6.1.1.2 Creating a File System StorageClass

This section describes how to create a file system StorageClass.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the **vi** *StorageClass.yaml* command to create a file named *StorageClass.yaml*. # vi StorageClass.yaml
- **Step 3** Press I or Insert to enter the editing mode and enter the following information in the *StorageClass.yaml* file. After the modification is complete, press **Esc** and enter :wq! to save the modification.

The following shows a template of the *StorageClass.yaml* file. You can also refer to the **yamls/fs-sc-for-csi-example.yaml** example file in the software package. Set related parameters based on the site requirements and save the file in yaml format. For details, see **Table 6-2**.

```
kind: StorageClass
apiVersion: storage.k8s.io/v1
metadata:
name: "mysc"
provisioner: "csi.huawei.com"
parameters:
volumeType: "fs"
allocType: "thin"
authClient: "*"
cloneSpeed: "3"
```

Table 6-2 Parameter description

Parameter	Description	Remarks
metadata.name	User-defined name of a StorageClass object.	User-defined character string. The value can contain uppercase letters, lowercase letters, digits, and hyphens (-).
provisioner	provisioner identifier.	The value is fixed to csi.huawei.com.
parameters.volu meType	Type of the volume to be created.	The value is fixed to fs .

Parameter	Description	Remarks
parameters.auth Client	Client that can access the volume.	This parameter is mandatory. OceanStor Dorado 6.x is used as an example. You can enter the client host name (a fully qualified domain name (FQDN) is recommended), client IP address, or client IP address segment, or use an asterisk (*) to represent all client IP addresses.
		The IP addresses can be IPv4 addresses, IPv6 addresses, or a combination of IPv4 and IPv6 addresses.
		You can enter multiple host names, IP addresses, or IP address segments and separate them with semicolons (;) or spaces or by pressing Enter . Example: 192.168.0.10;192.168.0.0/24;*
parameters.alloc Type	Allocation type of the volume to be created.	This parameter is optional. The value can be thin or thick , and the default value is thin .
parameters.clone Speed	Clone speed.	This parameter is optional. The value ranges from 1 to 4 and the default value is 3. 4 indicates the highest speed. This parameter is available when you clone a PVC or create a PVC using a snapshot. For details, see 6.2.3 (Optional) Cloning a PVC or 6.2.4 (Optional) Creating a PVC Using a Snapshot.

Step 4 Run the following command to create a StorageClass based on the .yaml file.

kubectl create -f StorageClass.yaml

Step 5 Run the following command to view the information about the created StorageClass.

kubectl get sc NAME PROVISIONER RECLAIMPOLICY VOLUMEBINDINGMODE ALLOWVOLUMEEXPANSION AGE mysc csi.huawei.com Delete Immediate false 34s

----End

6.1.2 Deleting a StorageClass

This section describes how to delete a StorageClass.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the following command to guery StorageClasses in the cluster.

```
# kubectl get sc
NAME PROVISIONER RECLAIMPOLICY VOLUMEBINDINGMODE ALLOWVOLUMEEXPANSION
AGE
huawei-nas csi.huawei.com Delete Immediate false 3s
mysc csi.huawei.com Delete Immediate false 16s
```

Step 3 Run the following command to delete a StorageClass. For example, delete the StorageClass named *mysc*.

```
# kubectl delete sc mysc storageclass.storage.k8s.io "mysc" deleted
```

Step 4 Run the following command to query StorageClasses in the cluster. If the command output does not contain the name of the StorageClass you want to delete, it is successfully deleted.

```
# kubectl get sc
NAME PROVISIONER RECLAIMPOLICY VOLUMEBINDINGMODE ALLOWVOLUMEEXPANSION
AGE
huawei-nas csi.huawei.com Delete Immediate false 3s
```

----End

6.2 Managing a PVC

6.2.1 Creating a PVC

Perform this operation when you want to create a PVC.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the **vi** *PersistentVolumeClaim.yaml* command to create a file named *PersistentVolumeClaim.yaml*.

vi PersistentVolumeClaim.yaml

Step 3 Press I or Insert to enter the editing mode and enter the following information in the *PersistentVolumeClaim.yaml* file. After the modification is complete, press **Esc** and enter :wq! to save the modification.

The following shows a template of the *PersistentVolumeClaim.yaml* file. You can also refer to the **yamls/pvc-example.yaml** example file in the software package. Set related parameters based on the site requirements and save the file in yaml format. For details, see **Table 6-3**.

```
kind: PersistentVolumeClaim
apiVersion: v1
metadata:
name: "mypvc"
spec:
accessModes:
- ReadWriteMany
```

storageClassName: "mysc" resources:

requests: storage: 100Gi

Table 6-3 Parameter description

Parameter	Description	Remarks
metadata.name	User-defined name of a PVC object.	User-defined character string. The value can contain uppercase letters, lowercase letters, digits, and hyphens (-).
spec.storageClass Name	Name of the StorageClass object.	Enter the name of the StorageClass object created in 6.1 Managing a StorageClass .

Parameter	Description	Remarks
spec.resources.req uests.storage	Size of the volume to be created.	The value format is ***Gi. The unit is GiB. • The PVC capacity depends on storage specifications and host specifications. The following uses the connection between OceanStor Dorado 6.1.2/OceanStor Pacific series 8.1.0 and CentOS 7 as an example. See Table 6-4.
		 For other storage devices and hosts, check the specifications according to the value of VolumeType in StorageClass. If the value of volumeType is lun, refer to the storage specifications. For details, see https://info.support.huawei.com/storage/spec/#/home. In addition, refer to the host connectivity guide at https://support.huawei.com/enterprise/en/doc/EDOC1100113070/e067543b.
		 If the value of volumeType is fs, refer to the storage specifications. For details, see https://info.support.huawei.com/storage/spec/#/home. If the PVC capacity does not meet the specifications, a PVC or Pod may fail to be created due to the limitations of storage specifications or host file system specifications.

Parameter	Description	Remarks
spec.accessModes	Access mode of the volume.	LUN volumes support ReadWriteOnce, ReadOnlyMany, and ReadWriteMany. If the ReadWriteMany mode is used and multiple Pods access the volume at the same time, the Pod service must ensure data consistency.
		File system volumes support ReadWriteOnce, ReadOnlyMany, and ReadWriteMany.

Table 6-4 PVC capacity specifications

volumeT ype	Storage Type	Storage Specification s	ext4 Specificatio ns	CSI Specifications
lun	OceanStor Dorado 6.1.2	512Ki~256Ti	50Ti	512Ki~50Ti
	OceanStor Pacific series 8.1.0	64 Mi to 512 Ti	50 Ti	64 Mi to 50 Ti
fs	OceanStor Dorado 6.1.2	1 Gi to 32 Pi	N/A	1 Gi to 32 Pi
	OceanStor Pacific series 8.1.0	1 Ki to 256 Pi	N/A	1 Ki to 256 Pi

Step 4 Run the following command to create a PVC based on the .yaml file.

kubectl create -f PersistentVolumeClaim.yaml

Step 5 After a period of time, run the following command to view the information about the created PVC.

kubectl get pvc
NAME STATUS VOLUME CAPACITY ACCESS MODES STORAGECLASS AGE
mypvc Bound pvc-840054d3-1d5b-4153-b73f-826f980abf9e 100Gi RWX mysc 12s

□ NOTE

After the PVC is created, if the PVC is in the **Pending** state, see **9.6 When a PVC Is Created**, **the PVC Is in the Pending State**.

----End

6.2.2 (Optional) Expanding the Capacity of a PVC

This section describes how to expand the capacity of a PVC.

Prerequisites

- A PVC has been created, and the backend where the PVC is located supports capacity expansion. For details about the storage devices that support capacity expansion, see 3 Restrictions.
- The Kubernetes version is later than 1.16. You can run the **kubectl get node** command to view the version.
- The huawei-csi services are running properly.
 # kubectl get pod -A | grep huawei
 kube-system huawei-csi-controller-fd5f97768-qlldc 4/4 Running 0 16s
 kube-system huawei-csi-node-25txd 3/3 Running 0 15s

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Check whether the csi-resizer service is enabled for huawei-csi-controller.

```
# kubectl describe pod <controller-pod-name> -n kube-system | grep csi-resizer

csi-resizer:

Image: quay.io/k8scsi/csi-resizer:v1.0.1
Image ID: docker-pullable://quay.io/k8scsi/csi-
resizer@sha256:e9c13017c2a69e678012240fa6bf710e459f6a4384bbccb1a5cbb0712d25ddc4
```

- If the preceding information is displayed, the csi-resizer service is started. In this case, go to **Step 4**.
- Otherwise, the csi-resizer service is not started. In this case, go to **Step 3**.
- Step 3 (Optional) If the csi-resizer service is not started, create the RBAC permission again according to the yamls/huawei-csi-resize-snapshot-rbac.yaml file and deploy huawei-csi-controller again according to the yamls/huawei-csi-resize-snapshot-controller.yaml file. For details, see 8.5 Updating the huawei-csi-controller Service. After the deployment is complete, perform Step 2 again to check whether the csi-resizer service is successfully started.
- **Step 4** Run the **kubectl get pvc** *mypvc* command to query the StorageClass name of the PVC. In the preceding command, *mypvc* indicates the name of the PVC to be expanded.

```
# kubectl get pvc mypvc
NAME STATUS VOLUME CAPACITY ACCESS MODES
STORAGECLASS AGE
mypvc Bound pvc-3383be36-537c-4cb1-8f32-a415fa6ba384 2Gi RWX
mysc 145m
```

Step 5 Run the **kubectl get sc** *mysc* command to check the StorageClass supports capacity expansion. In the preceding command, *mysc* indicates the name of the StorageClass to be queried.

```
# kubectl get sc mysc
NAME PROVISIONER RECLAIMPOLICY VOLUMEBINDINGMODE
ALLOWVOLUMEEXPANSION AGE
mysc csi.huawei.com Delete Immediate true 172m
```

- If the value of **ALLOWVOLUMEEXPANSION** is **false**, the current StorageClass does not support capacity expansion. In this case, go to **Step 6**.
- If the value of **ALLOWVOLUMEEXPANSION** is **true**, the current StorageClass supports capacity expansion. In this case, go to **Step 7**.

Step 6 (Optional) Run the following command to change the value of **allowVolumeExpansion** to **true**. In the preceding command, *mysc* indicates the name of the StorageClass to be modified.

kubectl patch sc mysc --patch '{"allowVolumeExpansion":true}'

Step 7 Run the following command to expand the capacity.

kubectl patch pvc mypvc-p '{"spec":{"resources":{"requests":{"storage":"120Gi"}}}}'

In the preceding command, *mypvc* indicates the name of the PVC to be expanded, and *120Gi* indicates the capacity after expansion. Change the values based on the site requirements.

Ⅲ NOTE

- The PVC capacity depends on storage specifications and host specifications. The following uses the connection between OceanStor Dorado 6.1.2 or OceanStor Pacific series 8.1.0 and CentOS 7 as an example. For details, see Table 6-5.
- For other storage devices and hosts, check the specifications according to the value of VolumeType in 6.1.1 Creating a StorageClass.
 - If the value of volumeType is lun, refer to the storage specifications. For details, see https://info.support.huawei.com/storage/spec/#/home. In addition, refer to the host connectivity guide at https://support.huawei.com/enterprise/en/doc/EDOC1100113070/e067543b.
 - If the value of volumeType is fs, refer to the storage specifications. For details, see https://info.support.huawei.com/storage/spec/#/home.
- If the PVC capacity does not meet the specifications, a PVC or Pod may fail to be created due to the limitations of storage specifications or host file system specifications.

Table 6-5 PVC capacity specifications

volumeT ype	Storage Type	Storage Specification s	ext4 Specificatio ns	CSI Specifications
lun	OceanStor Dorado 6.1.2	512Ki~256Ti	50Ti	512Ki~50Ti
	OceanStor Pacific series 8.1.0	64 Mi to 512 Ti	50 Ti	64 Mi to 50 Ti
fs	OceanStor Dorado 6.1.2	1 Gi to 32 Pi	N/A	1 Gi to 32 Pi
	OceanStor Pacific series 8.1.0	1 Ki to 256 Pi	N/A	1 Ki to 256 Pi

Step 8 Run the following command to check whether the capacity changes.

kubectl get pvc
NAME STATUS VOLUME CAPACITY ACCESS MODES STORAGECLASS AGE
mypvc Bound pvc-840054d3-1d5b-4153-b73f-826f980abf9e 120Gi RWX mysc 24s

----End

6.2.3 (Optional) Cloning a PVC

Perform this operation when you want to clone an existing PVC on Kubernetes.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the **vi** *PersistentVolumeClaim.yaml* command to create a file named *PersistentVolumeClaim.yaml*.

vi PersistentVolumeClaim.yaml

Step 3 Configure the *PersistentVolumeClaim.yaml* file. The following shows a template of the *PersistentVolumeClaim.yaml* file. Set related parameters based on the site requirements and save the file in yaml format. For details, see **Table 6-6**.

kind: PersistentVolumeClaim apiVersion: v1 metadata: name: mypvc-clone spec: storageClassName: mysc dataSource: name: mypvc kind: PersistentVolumeClaim accessModes: - ReadWriteMany resources: requests: storage: 2Gi

Table 6-6 Parameter description

Parameter	Description	Remarks
metadata.name	User-defined name of a new PVC object.	User-defined character string. The value can contain uppercase letters, lowercase letters, digits, and hyphens (-).
spec.storageClass Name	Name of the StorageClass object.	Enter the name of the StorageClass object created in 6.1 Managing a StorageClass. The value must be the same as the name of the StorageClass in dataSource.
spec.dataSource. name	Name of the source PVC object.	-
spec.accessMode s	Access mode of the volume.	ReadWriteOnce: A PVC can be read and written by only one Pod.
		ReadOnlyMany: A PVC can be read by multiple Pods.
		ReadWriteMany: A PVC can be read and written by multiple Pods.

Parameter	Description	Remarks
spec.resources.re quests.storage	Size of the volume to be created.	The value must be greater than or equal to the size of the source PVC. The value format is ***Gi. The unit is GiB.

Step 4 Run the following command to create a PVC based on the .yaml file.

kubectl create -f PersistentVolumeClaim.yaml

----End

6.2.4 (Optional) Creating a PVC Using a Snapshot

Perform this operation when you want to create a PVC for an existing snapshot on Kubernetes.

Prerequisites

A snapshot has been created. For details, see **6.4 (Optional) Managing a Snapshot**.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the **vi** *PersistentVolumeClaim.yaml* command to create a file named *PersistentVolumeClaim.yaml*.

vi PersistentVolumeClaim.yaml

Step 3 Configure the *PersistentVolumeClaim.yaml* file. The following shows a template of the *PersistentVolumeClaim.yaml* file. Set related parameters based on the site requirements and save the file in yaml format. For details, see **Table 6-7**.

```
kind: PersistentVolumeClaim
apiVersion: v1
metadata:
name: ***
spec:
storageClassName: ***
dataSource:
name: ***
kind: VolumeSnapshot
apiGroup: snapshot.storage.k8s.io
accessModes:
- ReadWriteMany
resources:
requests:
storage: ***Gi
```

Table 6-7 Parameter description

Parameter	Description	Remarks
metadata.name	User-defined name of a new PVC object.	User-defined character string. The value can contain uppercase letters, lowercase letters, digits, and hyphens (-).
spec.storageClass Name	Name of the StorageClass object.	Enter the name of the StorageClass object created in 6.1 Managing a StorageClass. The value must be the same as the name of the StorageClass of the original PVC in dataSource.
spec.dataSource.n ame	Name of the source VolumeSnapshot object.	-
spec.accessModes	Access mode of the volume.	ReadWriteOnce: A PVC can be read and written by only one Pod.
		ReadOnlyMany: A PVC can be read by multiple Pods.
		ReadWriteMany: A PVC can be read and written by multiple Pods.
spec.resources.req uests.storage	Size of the volume to be created.	The value must be greater than or equal to the size of the source VolumeSnapshot. The value format is *** Gi . The unit is GiB.

Step 4 Run the following command to create a PVC based on the .yaml file.

kubectl create -f PersistentVolumeClaim.yaml

----End

6.2.5 Deleting a PVC

This section describes how to delete a PVC.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the following command to query PVCs in the cluster.

kubectl get pvc
NAME STATUS VOLUME CAPACITY ACCESS MODES STORAGECLASS AGE
mypvc Bound pvc-840054d3-1d5b-4153-b73f-826f980abf9e 100Gi RWX mysc 12s

Before deleting a PVC, if the PVC is in the **Pending** state, you are not advised to directly delete the PVC. To delete the PVC, see **9.7 Before a PVC Is Deleted, the PVC Is in the Pending State**.

Step 3 Run the following command to delete a PVC. For example, delete the PVC named *mypvc*.

```
# kubectl delete pvc mypvc
persistentvolumeclaim "mypvc" deleted
```

Step 4 Run the following command to query PVCs in the cluster. If the command output does not contain the name of the PVC you want to delete, it is successfully deleted.

```
# kubectl get pvc
No resources found in default namespace.
```

----End

6.3 Managing a Pod

6.3.1 Creating a Pod

A Pod is an original storage pool or storage function set. It function as the container of virtual volumes, which means only the storage container allocates storage space to virtual volumes. This operation enables you to quickly obtain specified storage resources.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- Step 2 Run the vi pod.yaml command to create a file named pod.yaml.

 # vi pod.yaml
- **Step 3** Press **I** or **Insert** to enter the editing mode and enter the following information in the *pod.yaml* file. After the modification is complete, press **Esc** and enter :**wq!** to save the modification.

The following shows a template of the *pod.yaml* file. You can also refer to the **yamls/pod-example.yaml** example file in the software package. Set related parameters based on the site requirements and save the file in yaml format. For details, see **Table 6-8**.

```
kind: Pod
apiVersion: v1
metadata:
name: "mypod"
spec:
containers:
- name: "mycontainer"
image: "***"
volumeMounts:
- name: mypv
mountPath: "/mnt/path/in/container"
volumes:
- name: mypv
```

persistentVolumeClaim: claimName: "mypvc"

Table 6-8 Parameter description

Parameter	Description	Remarks
metadata.name	User-defined name of a Pod object.	User-defined character string. The value can contain uppercase letters, lowercase letters, digits, and hyphens (-).
spec.containers.nam e	User-defined container name.	User-defined character string. The value can contain uppercase letters, lowercase letters, digits, and hyphens (-).
spec.containers.imag e	Container image.	Set this parameter based on the site requirements.
spec.containers.imag e.volumeMounts.mo untPath	Volume mount path in the container.	-
spec.volumes.persist entVolumeClaim.clai mName	Name of the PVC object.	Enter the name of the PVC object created in 6.2.1 Creating a PVC .

Step 4 Run the following command to create a Pod based on the .yaml file.

kubectl create -f pod.yaml

Step 5 Run the following command to view the information about the created Pod.

```
# kubectl get pod
NAME READY STATUS RESTARTS AGE
mypod 1/1 Running 0 37s
```

----End

6.3.2 Deleting a Pod

This section describes how to delete a Pod.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the following command to query Pods in the cluster.

```
# kubectl get pod
NAME READY STATUS RESTARTS AGE
mypod 1/1 Running 0 14h
```

Step 3 Run the following command to delete a Pod. For example, delete the Pod named *mypod*.

kubectl delete pod *mypod* pod "*mypod*" deleted

Step 4 Run the following command to query Pods in the cluster. If the command output does not contain the name of the Pod you want to delete, it is successfully deleted.

kubectl get pod No resources found in default namespace.

----End

6.4 (Optional) Managing a Snapshot

CSI supports snapshot v1beta1 since Kubernetes v1.17. For details, see https://kubernetes-csi.github.io/docs/external-snapshotter.html.

6.4.1 Installing the Snapshot-Dependent Component Service

Perform the following steps only on any master node.

Prerequisites

Before the installation, run the **kubectl api-resources** | **grep snapshot** | **awk** '{**print \$1**}' command on the master node to check whether the snapshot-related resource service has been installed. If the following information is displayed, you do not need to install it again.

kubectl api-resources | grep snapshot | awk '{print \$1}' volumesnapshotclasses volumesnapshotcontents volumesnapshots

If the command output does not contain the preceding service, perform the following operations to install the service.

Step 1 Compile the volumesnapshotclasses.yaml file if the volumesnapshotclasses resource is missing. You can refer to the yamls/ snapshot.storage.k8s.io_volumesnapshotclasses.yaml example file in the software package.

kubectl create -f volumesnapshotclasses.yaml

Step 2 Compile the volumesnapshotcontents.yaml file if the volumesnapshotcontents resource is missing. You can refer to the yamls/snapshot.storage.k8s.io_volumesnapshotcontents.yaml example file in the software package.

kubectl create -f volumesnapshotcontents.yaml

Step 3 Compile the volumesnapshots.yaml file if the volumesnapshots resource is missing. You can refer to the yamls/snapshot.storage.k8s.io_volumesnapshots.yaml example file in the software package.

kubectl create -f volumesnapshots.yaml

Step 4 Check whether the csi-snapshotter and snapshot-controller services are enabled for huawei-csi-controller.

kubectl describe pod <controller-pod-name> -n kube-system | grep snapshot csi-snapshotter:

Image: quay.io/k8scsi/csi-snapshotter:v3.0.2 Image ID: docker-pullable://quay.io/k8scsi/csi-

snapshotter@sha256:458bd2065adde483ff0b6ec0a30f893f0ab3043be8228d9c216989512dc5009bsnapshot-controller:

Image: quay.io/k8scsi/snapshot-controller:v3.0.2 Image ID: docker-pullable://quay.io/k8scsi/snapshot-

controller@sha256:bae4a1785d30db329a2338caa306b8a40eaebd2ad9629f0eb6d18ec9bba9bd25

If no information about csi-snapshotter and snapshot-controller is displayed, the csi-snapshotter and snapshot-controller services are not started. In this case, go to **Step 5**.

Step 5 (Optional) Start the csi-snapshotter and snapshot-controller services. Deploy huawei-csi-controller again according to the **yamls/huawei-csi-resize-snapshot-controller.yaml** file. For details, see **4.7 Starting huawei-csi Services**.

----End

6.4.2 Managing a VolumeSnapshotClass

6.4.2.1 Creating a VolumeSnapshotClass

This section describes how to create a VolumeSnapshotClass.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the **vi** *VolumeSnapshotClass.yaml* command to create a file named *VolumeSnapshotClass.yaml*.

vi VolumeSnapshotClass.yaml

Step 3 Press **I** or **Insert** to enter the editing mode and enter the following information in the *VolumeSnapshotClass.yaml* file. After the modification is complete, press **Esc** and enter :**wq!** to save the modification.

The following shows a template of the *VolumeSnapshotClass.yaml* file. You can also refer to the **yamls/snapshotclass.yaml** example file in the software package. Set related parameters based on the site requirements and save the file in yaml format. For details, see **Table 6-9**.

apiVersion: snapshot.storage.k8s.io/v1beta1 kind: VolumeSnapshotClass metadata: name: mysnapclass driver: csi.huawei.com

Table 6-9 Parameter description

deletionPolicy: Delete

Parameter	Description	Remarks
metadata. name	User-defined name of a VolumeSnapshotClass object.	User-defined character string. The value can contain uppercase letters, lowercase letters, digits, and hyphens (-).

Parameter	Description	Remarks
driver	driver identifier.	The value is fixed to csi.huawei.com .
deletionPo licy	Handles the VolumeSnapshotContent policy when a VolumeSnapshot is deleted.	This parameter is mandatory. The value can be Delete or Retain .

Step 4 Run the following command to create a VolumeSnapshotClass based on the .yaml file.

kubectl create -f VolumeSnapshotClass.yaml

Step 5 Run the following command to view the information about the created VolumeSnapshotClass.

kubectl get volumesnapshotclass NAME DRIVER DELETIONPOLICY AGE mysnapclass csi.huawei.com Delete 25s

----End

6.4.2.2 Deleting a VolumeSnapshotClass

This section describes how to delete a VolumeSnapshotClass.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the following command to query VolumeSnapshotClasses in the cluster.

kubectl get volumesnapshotclass NAME DRIVER DELETIONPOLICY AGE mysnapclass csi.huawei.com Delete 52s

Step 3 Run the following command to delete a VolumeSnapshotClass. For example, delete the VolumeSnapshotClass named *mysnapclass*.

kubectl delete volumesnapshotclass *mysnapclass* volumesnapshotclass.snapshot.storage.k8s.io "*mysnapclass*" deleted

Step 4 Run the following command to query VolumeSnapshotClasses in the cluster. If the command output does not contain the name of the VolumeSnapshotClass you want to delete, it is successfully deleted.

kubectl get volumesnapshotclass No resources found in default namespace.

----End

6.4.3 Managing a VolumeSnapshot

6.4.3.1 Creating a VolumeSnapshot

This section describes how to create a VolumeSnapshot.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the **vi** *VolumeSnapshot.yaml* command to create a file named *VolumeSnapshot.yaml*.

vi VolumeSnapshot.yaml

Step 3 Press I or Insert to enter the editing mode and enter the following information in the *VolumeSnapshot.yaml* file. After the modification is complete, press **Esc** and enter :wq! to save the modification.

The following shows a template of the *VolumeSnapshot.yaml* file. You can also refer to the **yamls/snapshot.yaml** example file in the software package. Set related parameters based on the site requirements and save the file in yaml format. For details, see **Table 6-10**.

apiVersion: snapshot.storage.k8s.io/v1beta1 kind: VolumeSnapshot metadata: name: mysnapshot spec: volumeSnapshotClassName: mysnapclass source: persistentVolumeClaimName: mypvc

Table 6-10 Parameter description

Parameter	Description	Remarks
metadata.name	User-defined name of a VolumeSnapshot object.	User-defined character string. The value can contain uppercase letters, lowercase letters, digits, and hyphens (-).
spec.volumeSnap shotClassName	Name of the VolumeSnapshotClass object.	Enter the name of the VolumeSnapshotClass object created in 6.4.2.1 Creating a VolumeSnapshotClass.
spec.source.persis tentVolumeClaim Name	Name of the source PVC object.	Enter the name of the PVC object created in 6.2.1 Creating a PVC.

- **Step 4** Run the following command to create a VolumeSnapshot based on the .yaml file. # kubectl create -f VolumeSnapshot.yaml
- **Step 5** Run the following command to view the information about the created VolumeSnapshot.

kubectl get volumesnapshot
NAME READYTOUSE SOURCEPVC SOURCESNAPSHOTCONTENT RESTORESIZE
SNAPSHOTCLASS SNAPSHOTCONTENT CREATIONTIME AGE
mysnapshot true mypvc 100Gi mysnapclass
snapcontent-1009af0a-24c2-4435-861c-516224503f2d <invalid> 78s

----End

6.4.3.2 Deleting a VolumeSnapshot

This section describes how to delete a VolumeSnapshot.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the following command to query VolumeSnapshots in the cluster.

kubectl get volumesnapshot
NAME READYTOUSE SOURCEPVC SOURCESNAPSHOTCONTENT RESTORESIZE
SNAPSHOTCLASS SNAPSHOTCONTENT CREATIONTIME AGE
mysnapshot true mypvc 100Gi mysnapclass
snapcontent-1009af0a-24c2-4435-861c-516224503f2d <invalid> 78s

Step 3 Run the following command to delete a VolumeSnapshot. For example, delete the VolumeSnapshot named *mysnapshot*.

kubectl delete volumesnapshot mysnapshot volumesnapshot.snapshot.storage.k8s.io "mysnapshot" deleted

Step 4 Run the following command to query VolumeSnapshots in the cluster. If the command output does not contain the name of the VolumeSnapshot you want to delete, it is successfully deleted.

kubectl get volumesnapshot No resources found in default namespace.

----End

Advanced Features

This chapter describes how to configure advanced features of Huawei storage.

- 7.1 Configuring Multiple Backends
- 7.2 Creating a PVC for a Specified Backend
- 7.3 Creating a PVC for a Specified Storage Pool
- 7.4 Configuring ALUA
- 7.5 Configuring Storage Topology Awareness
- 7.6 Advanced Features of Enterprise Storage
- 7.7 Advanced Features of Distributed Storage

7.1 Configuring Multiple Backends

Huawei CSI supports multiple backends. Perform this operation when you want to configure multiple backends.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Configure the **huawei-csi-configmap.yaml** file. The following shows a template of the **huawei-csi-configmap.yaml** file. Set related parameters based on the site requirements and save the file in yaml format.

Multiple backends are separated by commas (,). For details about each backend, see 4.5 Connecting to Enterprise Storage or 4.6 Connecting to Distributed Storage.

```
kind: ConfigMap
apiVersion: v1
metadata:
name: huawei-csi-configmap
namespace: kube-system
data:
csi.json: |
{
```

Step 3 Run the **kubectl create -f** *huawei-csi-configmap.yaml* command to create *huawei-csi-configmap*.

kubectl create -f huawei-csi-configmap.yaml

Step 4 After the creation is complete, run the **kubectl get configmap -n kube-system** | **grep huawei-csi-configmap** command to check whether the creation is successful. If the following information is displayed, the creation is successful.

```
# kubectl get configmap -n kube-system | grep huawei-csi-configmap huawei-csi-configmap 1 5s
```

Step 5 Start huawei-csi services. For details, see **4.7 Starting huawei-csi Services**.

----End

7.2 Creating a PVC for a Specified Backend

When multiple backends are configured, you can perform the following operations to create a PVC for a specified backend.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the **vi** *StorageClass.yaml* command to modify the .yaml file. Press **I** or **Insert** to enter the editing mode and modify parameters in the following fields. After the modification is complete, press **Esc** and enter :**wq!** to save the modification.
 - Add the **backend** configuration item under **parameters**.
 - The value of **metadata.name** is the user-defined name of a StorageClass object. The value can contain uppercase letters, lowercase letters, digits, and hyphens (-).
 - The value of **parameters.backend** is the name of a backend in **huawei-csi-configmap.yaml**.

```
kind: StorageClass
apiVersion: storage.k8s.io/v1
metadata:
name: "***"
provisioner: "csi.huawei.com"
parameters:
...
backend: "***"
```

Step 3 Run the following command to create a StorageClass based on the .yaml file.

kubectl create -f StorageClass.yaml

----End

7.3 Creating a PVC for a Specified Storage Pool

When multiple storage pools are configured, you can perform the following operations to create a PVC for a specified storage pool.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the **vi** *StorageClass.yaml* command to modify the .yaml file. Press **I** or **Insert** to enter the editing mode and modify parameters in the following fields. After the modification is complete, press **Esc** and enter :**wq!** to save the modification.
 - The value of **metadata.name** is the user-defined name of a StorageClass object. The value can contain uppercase letters, lowercase letters, digits, and hyphens (-).
 - Add the **backend** configuration item under **parameters**.
 - The value of **pool** is the name of a storage pool in **huawei-csi-configmap.yaml**.

■ NOTE

The volume to be created using the StorageClass will be created in the specified storage pool. The existing PVC will not change the storage pool information.

```
kind: StorageClass
apiVersion: storage.k8s.io/v1
metadata:
name: "***"
provisioner: "csi.huawei.com"
parameters:
...
pool: "***"
```

Step 3 Run the following command to create a StorageClass based on the .yaml file.

kubectl create -f StorageClass.yaml

----End

7.4 Configuring ALUA

7.4.1 Configuring ALUA for OceanStor V3/V5 and OceanStor Dorado V3

This section describes how to configure ALUA if multipathing is used during the connection to block storage.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the **vi** *huawei-csi-configmap.yaml* command to modify the .yaml file. Press **I** or **Insert** to enter the editing mode and modify related parameters. After the modification is complete, press **Esc** and enter :**wq!** to save the modification.

Multiple backends are separated by commas (,). For details about each backend, see 4.5 Connecting to Enterprise Storage or 4.6 Connecting to Distributed Storage.

Add ALUA parameters under the **parameters** section. For details, see **Table 7-1**.

```
{
  "backends": [
    {
        "storage": "oceanstor-san",
        ...
        "parameters": {..., "ALUA": {"<HostName>": {"MULTIPATHTYPE": "*", "FAILOVERMODE": "*",
        "SPECIALMODETYPE": "*", "PATHTYPE": "*"}, "<HostName>": {...}}}
    }
}
```

Table 7-1 ALUA parameter description

Parameter	Description	Remarks
<hostname></hostname>	The value of HostName is the host name of a worker node.	The host name can be obtained by running the cat /etc/hostname command. It can be matched by using regular expressions. For details about the configuration rules and priorities, see the following note.
MULTIPATHTYPE	Multipathing type. The value can be:	-
	• 0 : default	
	• 1: third-party multipathing	
FAILOVERMODE	Initiator switchover mode. The value can be:	This parameter needs to be specified only when third-party multipathing is used. All OceanStor V5 models do not support early-version ALUA.
	• 0 : early-version ALUA	
	• 1: common ALUA	
	• 2: ALUA not used	
	• 3: special ALUA	

Parameter	Description	Remarks
SPECIALMODETYP E	Special mode type of the initiator. The value can be: • 0: special mode 0 • 1: special mode 1 • 2: special mode 2 • 3: special mode 3	This parameter needs to be specified only when the initiator switchover mode is special ALUA.
PATHTYPE	Initiator path type. The value can be: • 0: preferred path • 1: non-preferred path	This parameter needs to be specified only when third-party multipathing is used.

□ NOTE

- The ALUA configuration may vary according to the OS. Visit https://support.huawei.com/enterprise/en/index.html, enter Host Connectivity Guide in the search box, and click the search button. In the search result, select the host connectivity guide for the desired OS and configure ALUA based on the recommended configurations in the guide.
- A node with a Pod provisioned does not proactively change ALUA information. The host ALUA configuration changes only after a Pod is provisioned again to the node.
- The value of **HostName** is a regular expression. For details about how to configure it, see **Regular expression**.

When **HostName** is set to *, the common configuration is used and takes effect on hosts with any name. When **HostName** is set to another value, the general configuration is used. When you configure **HostName**, the number of host connections is limited. For details about the limitation, see **Specifications Query** and search for **Maximum number of iSCSI connections per controller enclosure**. If the number of host connections is less than or equal to the specifications, you are advised to use the general configuration. If the number of host connections is greater than the specifications, you are advised to use the common configuration.

Configuration policy rules:

- Priority: General host name configuration > Common host name configuration. For details, see example 1 in 10.1 Example ALUA Configuration Policy of OceanStor V3/V5 and OceanStor Dorado V3.
- In the general configuration, use the first ALUA section that meets the configuration policy. For details, see example 2 in 10.1 Example ALUA Configuration Policy of OceanStor V3/V5 and OceanStor Dorado V3.
- In the general configuration, if you need to exactly match a host, refer to example 3 in 10.1 Example ALUA Configuration Policy of OceanStor V3/V5 and OceanStor Dorado V3.
- OceanStor V3/V5 and OceanStor Dorado V3 use this configuration mode. For details about related parameters, see **Table 7-2**.

Scenario	Host Type	Whether the Storage Has the Preferred Path	Recommended ALUA Configuration
HyperMetro storage	CentOS/RHEL host	Yes	ALUA="1" FAILOVERMODE="3" SPECIALMODETYPE="0" PATHTYPE="0"
		No	ALUA="1" FAILOVERMODE="3" SPECIALMODETYPE="0" PATHTYPE="1"
	SUSE/Debian host	Yes	ALUA="1" FAILOVERMODE="1" PATHTYPE="0"
		No	ALUA="1" FAILOVERMODE="1" PATHTYPE="1"
Non- HyperMetro storage	CentOS/RHEL host	N/A	ALUA="1" FAILOVERMODE="3" SPECIALMODETYPE="0" PATHTYPE="0"
	SUSE/Debian host	N/A	ALUA="1" FAILOVERMODE="1" PATHTYPE="0"

Table 7-2 Recommended ALUA parameter configurations for OceanStor V3/V5 and OceanStor Dorado V3

Step 3 Run the **kubectl create -f** *huawei-csi-configmap.yaml* command to create *huawei-csi-configmap*.

kubectl create -f huawei-csi-configmap.yaml

Step 4 After the creation is complete, run the **kubectl get configmap -n kube-system** | **grep huawei-csi-configmap** command to check whether the creation is successful. If the following information is displayed, the creation is successful.

kubectl get configmap -n kube-system | grep huawei-csi-configmap huawei-csi-configmap 1 5s

Step 5 Start huawei-csi services. For details, see **4.7 Starting huawei-csi Services**.

----End

7.4.2 Configuring ALUA for OceanStor Dorado 6.x

This section describes how to configure ALUA if multipathing is used during the connection to block storage.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the **vi** *huawei-csi-configmap.yaml* command to modify the .yaml file. Press **I** or **Insert** to enter the editing mode and modify related parameters. After the modification is complete, press **Esc** and enter :**wq!** to save the modification.

Multiple backends are separated by commas (,). For details about each backend, see 4.5 Connecting to Enterprise Storage or 4.6 Connecting to Distributed Storage.

Add ALUA parameters under the **parameters** section. For details, see **Table 7-3**.

```
{
  "backends": [
  {
    "storage": "oceanstor-san",
    ...
    "parameters": {..., "ALUA": {"<HostName>": {"accessMode": "*", "hyperMetroPathOptimized": "*"},
  "<HostName>": {...}}}
  }
}
```

Table 7-3 ALUA parameter description

Parameter	Description	Remarks
<hostname></hostname>	The value of HostName is the host name of a worker node.	The host name can be obtained by running the cat /etc/hostname command. It can be matched by using regular expressions. For details about the configuration rules and priorities, see the following note.
accessMode	Host access mode. The value can be: • 0: balanced mode • 1: asymmetric mode	
hyperMetroPath Optimized	Whether the path of the host on the current storage array is preferred in HyperMetro scenarios. The value can be: 1: yes	This parameter needs to be specified only when the host access mode is set to asymmetric.
	• 0 : no	

□ NOTE

- The ALUA configuration may vary according to the OS. Visit https://support.huawei.com/enterprise/en/index.html, enter Host Connectivity Guide in the search box, and click the search button. In the search result, select the host connectivity guide for the desired OS and configure ALUA based on the recommended configurations in the guide.
- A node with a Pod provisioned does not proactively change ALUA information. The host ALUA configuration changes only after a Pod is provisioned again to the node.
- The value of **HostName** is a regular expression. For details about how to configure it, see **Regular expression**.

When **HostName** is set to *, the common configuration is used and takes effect on hosts with any name. When **HostName** is set to another value, the general configuration is used. When you configure **HostName**, the number of host connections is limited. For details about the limitation, see **Specifications Query** and search for **Maximum number of iSCSI connections per controller enclosure**. If the number of host connections is less than or equal to the specifications, you are advised to use the general configuration. If the number of host connections is greater than the specifications, you are advised to use the common configuration.

Configuration policy rules:

- Priority: General host name configuration > Common host name configuration. For details, see example 1 in 10.2 Example ALUA Configuration Policy of OceanStor Dorado 6.x.
- In the general configuration, use the first ALUA section that meets the configuration policy. For details, see example 2 in 10.2 Example ALUA Configuration Policy of OceanStor Dorado 6.x.
- In the general configuration, if you need to exactly match a host, refer to example
 3 in 10.2 Example ALUA Configuration Policy of OceanStor Dorado 6.x.
- If a host uses only OceanStor Dorado 6.x all-flash storage, see **Table 7-4** for detailed parameters.
- If you add OceanStor Dorado 6.x all-flash storage to a host that uses OceanStor converged storage, see Table 7-5 for detailed parameters.

Table 7-4 Recommended ALUA parameter configurations for OceanStor Dorado 6.*x* all-flash storage

Scenario	Host Type	Host Access Mode	Recommended ALUA Configuration
HyperMetro storage	CentOS/RHEL/ SUSE/Debian	Load balancing mode	ALUA not required
	host	Asymmetric mode + Storage with the preferred path	ACCESSMODE="1" HYPERMETROPATHO PTIMIZED="1"
		Asymmetric mode + Storage with the non-preferred path	ACCESSMODE="1" HYPERMETROPATHO PTIMIZED="0"
Non- HyperMetro storage	CentOS/RHEL/ SUSE/Debian host	N/A	ALUA not required

vs, occursion borded vs, and occursion borded o.x			
Scenario	Host Type	Host Access Mode	Recommended ALUA Configuration
HyperMetro storage	CentOS/RHEL/ SUSE/Debian host	Load balancing mode	ACCESSMODE="1" HYPERMETROPATHOP TIMIZED="1"
		Asymmetric mode + Storage with the preferred path	ACCESSMODE="1" HYPERMETROPATHOP TIMIZED="1"
		Asymmetric mode + Storage with the non-preferred path	ACCESSMODE="1" HYPERMETROPATHOP TIMIZED="0"
Non- HyperMetro storage	CentOS/RHEL/ SUSE/Debian host	N/A	ACCESSMODE="1" HYPERMETROPATHOP TIMIZED="1"

Table 7-5 Recommended ALUA parameter configurations for hybrid OceanStor V3/V5, OceanStor Dorado V3, and OceanStor Dorado 6.*x*

Step 3 Run the **kubectl create -f** *huawei-csi-configmap.yaml* command to create *huawei-csi-configmap*.

kubectl create -f huawei-csi-configmap.yaml

Step 4 After the creation is complete, run the **kubectl get configmap -n kube-system** | **grep huawei-csi-configmap** command to check whether the creation is successful. If the following information is displayed, the creation is successful.

kubectl get configmap -n kube-system | grep huawei-csi-configmap huawei-csi-configmap 1 5s

Step 5 Start huawei-csi services. For details, see **4.7 Starting huawei-csi Services**.

----End

7.4.3 Configuring ALUA for Distributed Storage

This section describes how to configure ALUA if multipathing is used during the connection to block storage.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the **vi** *huawei-csi-configmap.yaml* command to modify the .yaml file. Press **I** or **Insert** to enter the editing mode and modify related parameters. After the modification is complete, press **Esc** and enter :**wq!** to save the modification.

Multiple backends are separated by commas (,). For details about each backend, see 4.5 Connecting to Enterprise Storage or 4.6 Connecting to Distributed Storage.

Add ALUA parameters under the parameters section. For details, see Table 7-6.

```
{
  "backends": [
  {
    "storage": "fusionstorage-san",
    ...
    "parameters": {..., "ALUA": {"<HostName>": {"switchoverMode": "*", "pathType": "*"},
  "<HostName>": {...}}}
  }
}
}
```

Table 7-6 ALUA parameter description

Parameter	Description	Remarks
<hostname></hostname>	The value of HostName is the host name of a worker node.	The host name can be obtained by running the cat /etc/hostname command. It can be matched by using regular expressions. For details about the configuration rules and priorities, see the following note.
switchoverMode	Switchover mode. The value can be:	
	• Disable_alua : disables ALUA.	
	• Enable_alua: enables ALUA.	
pathType	Path type. The value can be:	
	optimal_path: preferred path	
	• non_optimal_path: non- preferred path	

□ NOTE

- Only the iSCSI scenario of distributed storage is supported.
- A node with a Pod provisioned does not proactively change ALUA information. The host ALUA configuration changes only after a Pod is provisioned again to the node.
- The value of **HostName** is a regular expression. For details about how to configure it, see **Regular expression**.

When **HostName** is set to *, the common configuration is used and takes effect on hosts with any name. When **HostName** is set to another value, the general configuration is used.

Configuration policy rules:

- Priority: General host name configuration > Common host name configuration. For details, see example 1 in 10.3 Example ALUA Configuration Policy of Distributed Storage.
- In the general configuration, use the first ALUA section that meets the configuration policy. For details, see example 2 in 10.3 Example ALUA Configuration Policy of Distributed Storage.
- In the general configuration, if you need to exactly match a host, refer to example 3 in 10.3 Example ALUA Configuration Policy of Distributed Storage.
- **Step 3** Run the **kubectl create -f** *huawei-csi-configmap.yaml* command to create *huawei-csi-configmap*.

kubectl create -f huawei-csi-configmap.yaml

Step 4 After the creation is complete, run the **kubectl get configmap -n kube-system** | **grep huawei-csi-configmap** command to check whether the creation is successful. If the following information is displayed, the creation is successful.

```
# kubectl get configmap -n kube-system | grep huawei-csi-configmap huawei-csi-configmap 1 5s
```

Step 5 Start huawei-csi services. For details, see **4.7 Starting huawei-csi Services**.

----End

7.5 Configuring Storage Topology Awareness

In the Kubernetes cluster, resources can be scheduled and provisioned based on the topology labels of nodes and the topology capabilities supported by storage backends.

Prerequisites

- Kubernetes v1.17 and later versions support the topology awareness feature.
- You need to configure topology labels on worker nodes in the cluster. The method is as follows:
 - a. Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
 - b. Run the **kubectl get node** command to view information about worker nodes in the current cluster.

```
# kubectl get node
NAME STATUS ROLES AGE VERSION
node01 Ready controlplane,etcd,worker 42d v1.19.3
node02 Ready worker 42d v1.19.3
node03 Ready worker 42d v1.19.3
```

c. Run the kubectl label node <nodename> topology.kubernetes.io/ <key>= <value> command to configure a topology label for a worker node. In the preceding command, <nodename> indicates the name of a worker node. For details about the key and value parameters, see Table 7-7.

kubectl label node node01 topology.kubernetes.io/zone=ChengDu node/node01 labeled

Table 7-7 Parameter description

Parameter	Description	Remarks
<key></key>	Unique identifier of a topology label.	The value can be zone , region , or protocol . < <i>protocol</i> >.
		<pre><pre><pre><pre><pre><pre>can be set to iscsi, nfs, fc, or roce.</pre></pre></pre></pre></pre></pre>
<value></value>	Value of a topology label.	If key is set to zone or region , value is a user-defined parameter.
		If key is set to protocol . <pre>/protocol>, value is fixed to csi.huawei.com.</pre>

- A topology label must start with **topology.kubernetes.io**. Topology label examples:
 - Example 1: topology.kubernetes.io/region=China-west
 - Example 2: topology.kubernetes.io/zone=ChengDu
 - Example 3: topology.kubernetes.io/protocol.iscsi=csi.huawei.com
 - Example 4: topology.kubernetes.io/protocol.fc=csi.huawei.com
- A key in a topology label on a node can have only one value.
- If multiple protocols are configured in a topology label on a node, when you select a backend, the backend needs to meet only one of the protocols.
- If both the region and the zone are configured in a topology label on a node, when you select a backend, the backend must meet both of them.
- d. Run the kubectl get nodes -o=json path='{range .items[*]}
 [{.metadata.name}, {.metadata.labels}]{"\n"}{end}' | grep --color
 "topology.kubernetes.io" command to view the label information about all worker nodes in the current cluster.

kubectl get nodes -o=jsonpath='{range .items[*]}{{.metadata.name}, {.metadata.labels}]{"\n"} {end}' | grep --color "topology.kubernetes.io" [node01, {"beta.kubernetes.io/arch":"amd64","beta.kubernetes.io/os":"linux","kubernetes.io/arch":"amd64","kubernetes.io/hostname":"node01","kubernetes.io/os":"linux","node-role.kubernetes.io/controlplane":"true","node-role.kubernetes.io/etcd":"true","node-role.kubernetes.io/worker":"true","topology.kubernetes.io/zone":"ChengDu"}]

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the **vi** *huawei-csi-configmap.yaml* command to modify the .yaml file. Press **I** or **Insert** to enter the editing mode and modify related parameters. After the modification is complete, press **Esc** and enter :**wq!** to save the modification.

Multiple backends are separated by commas (,). For details about each backend, see 4.5 Connecting to Enterprise Storage or 4.6 Connecting to Distributed Storage.

Add the **supportedTopologies** field under the **backends** section in the *huawei-csi-configmap.yaml* file to configure the topology information supported by each backend. The following is a backend example.

```
{
    "backends":[
    {
        "storage": "oceanstor-san",
        ...
        "parameters": {"protocol": "iscsi", "portals": ["192.168.125.22", "192.168.125.23"]},
        "supportedTopologies": [
            {"topology.kubernetes.io/region": "China-west", "topology.kubernetes.io/zone": "ChengDu"},
            {"topology.kubernetes.io/region": "China-south", "topology.kubernetes.io/zone": "ShenZhen"}]
    }
}
```

□ NOTE

- **supportedTopologies** is a list. Each element in the list is a dictionary.
- Only topology.kubernetes.io/region or topology.kubernetes.io/zone can be configured for each element in the list. The parameter value must be the same as the topology label set in the prerequisites. (topology.kubernetes.io/protocol.protocol>
 does not need to be configured.)
- **Step 3** Run the **kubectl create -f** *huawei-csi-configmap.yaml* command to create *huawei-csi-configmap*.

```
# kubectl create -f huawei-csi-configmap.yaml
```

Step 4 After the creation is complete, run the **kubectl get configmap -n kube-system** | **grep huawei-csi-configmap** command to check whether the creation is successful. If the following information is displayed, the creation is successful.

```
# kubectl get configmap -n kube-system | grep huawei-csi-configmap huawei-csi-configmap 1 5s
```

- **Step 5** Start huawei-csi services. For details, see **4.7 Starting huawei-csi Services**.
- **Step 6** Run the **vi** *StorageClass.yaml* command to modify the .yaml file. Press **I** or **Insert** to enter the editing mode and add related parameters in the .yaml file. For details about the parameters, see **Table 7-8**. After the modification is complete, press **Esc** and enter :**wq!** to save the modification.

Add the following configuration items to the StorageClass.yaml file.

• Example 1: Configure zone and region information in the StorageClass. kind: StorageClass apiVersion: storage.k8s.io/v1 metadata:
name: example-storageclass

provisioner: csi.huawei.com

parameters: volumeType: lun allocType: thin

volumeBindingMode: WaitForFirstConsumer

allowedTopologies:

- matchLabelExpressions:
- key: topology.kubernetes.io/zone values:
- ChengDu
- key: topology.kubernetes.io/region values:
- China-west
- Example 2: Configure protocol information in the StorageClass.

kind: StorageClass

apiVersion: storage.k8s.io/v1

metadata:

name: protocol-example-storageclass

provisioner: csi.huawei.com

parameters: volumeType: lun allocType: thin

volumeBindingMode: WaitForFirstConsumer allowedTopologies:

- matchLabelExpressions:
- key: topology.kubernetes.io/protocol.iscsi values:
- csi.huawei.com

Table 7-8 Parameter description

Parameter	Description	Remarks
volumeBindi ngMode	PersistentVolume binding mode, used to control the time when PersistentVolume resources are dynamically allocated and bound.	You can set this parameter to WaitForFirstConsumer or Immediate. WaitForFirstConsumer: indicates that the binding and allocation of the PersistentVolume are delayed until a Pod that uses the PVC is created.
		Immediate: The PersistentVolume is bound and allocated immediately after a PVC is created.
allowedTopol ogies.matchL abelExpressio ns	Topology information label, which is used to filter CSI backends and Kubernetes nodes. If the matching fails, PVCs or Pods cannot be created. Both key and value must be configured in a fixed format.	key: This parameter can be set to topology.kubernetes.io/zone or topology.kubernetes.io/region. topology.kubernetes.io/ protocol. <protocol>: <protocol> indicates the protocol type and can be iscsi, fc, or nfs.</protocol></protocol>

Parameter	Description	Remarks
		value: If key is topology.kubernetes.io/ zone or topology.kubernetes.io/ region, value must be the same as the topology label set in the prerequisites.
		If key is topology.kubernetes.io/ protocol. <pre>cology.kubernetes.io/ protocol.<pre>cology.kubernetes.io/ protocol.</pre></pre>

- **Step 7** Run the following command to create a StorageClass based on the .yaml file. # kubectl create -f StorgeClass.yaml
- **Step 8** Use the StorageClass to create a PVC with the topology capability. For details, see **6.2.1 Creating a PVC**.
- **Step 9** Use the PVC to create a Pod. For details, see **6.3.1 Creating a Pod**.

7.6 Advanced Features of Enterprise Storage

7.6.1 Configuring QoS

This section describes how to create a LUN/file system volume that supports QoS.

Precautions

- The QoS feature is not a standard feature of Kubernetes and is customized by storage vendors.
- A QoS policy can be specified only when a StorageClass is created. Once the QoS policy is created, it cannot be modified because the StorageClass cannot be modified on Kubernetes.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the **vi** *StorageClass.yaml* command to modify the .yaml file. Press **I** or **Insert** to enter the editing mode and modify related parameters. After the modification is complete, press **Esc** and enter :**wq!** to save the modification.
 - The value of **metadata.name** is the user-defined name of a StorageClass object. The value can contain uppercase letters, lowercase letters, digits, and hyphens (-).
 - Add the qos configuration item under parameters. For other information about parameters, see 6.1.1.1 Creating a LUN StorageClass or 6.1.1.2 Creating a File System StorageClass.

- The value of the **qos** section is JSON character strings in dictionary format. A character string is enclosed by single quotation marks and the dictionary key by double quotation marks.
 - For details about the parameters of OceanStor V3/OceanStor V5 series storage devices, see Table 7-9.
 - For details about the parameters of OceanStor Dorado V3 series storage devices, see Table 7-10.
 - For details about the parameters of OceanStor Dorado 6.x series storage devices, see Table 7-11.

kind: StorageClass apiVersion: storage.k8s.io/v1 metadata: name: "***" provisioner: "csi.huawei.com" parameters:

qos: '{"IOTYPE": 2, "MINIOPS": 1000}'

Table 7-9 QoS parameters supported by OceanStor V3/OceanStor V5

Parameter	Description	Remarks
IOTYPE	Read/write type.	This parameter is optional. If it is not specified, the default value of the storage backend is used. For details, see related storage documents.
		The value can be:
		• 0 : read I/O
		• 1: write I/O
		• 2: read and write I/Os
MAXBANDWIDTH	Maximum bandwidth. This is a restriction policy parameter.	The value is an integer greater than 0, expressed in MB/s.
MINBANDWIDTH	Minimum bandwidth. This is a protection policy parameter.	The value is an integer greater than 0, expressed in MB/s.
MAXIOPS	Maximum IOPS. This is a restriction policy parameter.	The value is an integer greater than 0
MINIOPS	Minimum IOPS. This is a protection policy parameter.	The value is an integer greater than 0
LATENCY	Maximum latency. This is a protection policy parameter.	The value is an integer greater than 0, expressed in ms.

MAXIOPS

The value is an integer ranging

from 100 to 999999999.

ParameterDescriptionRemarksIOTYPERead/write type.The value can be:
 2: read and write I/OsMAXBANDWIDTHMaximum bandwidth. This is a restriction policy parameter.The value is an integer ranging from 1 to 999999999, expressed in MB/s.

Table 7-10 QoS parameters supported by OceanStor Dorado V3

Table 7-11 QoS parameters supported by OceanStor Dorado 6.x

Maximum IOPS. This

is a restriction policy

parameter.

Parameter	Description	Remarks
IOTYPE	Read/write type.	The value can be:
		• 2: read and write I/Os
MAXBANDWIDTH	Maximum bandwidth.	The value is an integer ranging from 1 to 999999999, expressed in MB/s.
MINBANDWIDTH	Minimum bandwidth.	The value is an integer ranging from 1 to 999999999, expressed in MB/s.
MAXIOPS	Maximum IOPS.	The value is an integer ranging from 100 to 999999999.
MINIOPS	Minimum IOPS.	The value is an integer ranging from 100 to 999999999.
LATENCY	Maximum latency.	The value can be 0.5 or 1.5 , expressed in ms.

□ NOTE

- Different protection policy parameters or restriction policy parameters can be specified at the same time. However, protection policy parameters cannot coexist with restriction policy parameters.
- vStore users do not support QoS policies.
- The QoS configuration takes effect only on the newly created PVC. QoS cannot be added automatically for PVCs with the same StorageClass name that have been provisioned.

Step 3 Run the following command to create a StorageClass based on the .yaml file.

kubectl create -f StorgeClass.yaml

Step 4 Use the StorageClass to create a PVC with the QoS capability. For details, see **6.2.1** Creating a PVC.

----End

7.6.2 Configuring a vStore

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the **vi** *huawei-csi-configmap.yaml* command to modify the .yaml file. Press **I** or **Insert** to enter the editing mode and modify related parameters. After the modification is complete, press **Esc** and enter :**wq!** to save the modification.

Multiple backends are separated by commas (,). For details about each backend, see 4.5 Connecting to Enterprise Storage or 4.6 Connecting to Distributed Storage.

Add the **vstoreName** parameter to the configuration of a backend. **vstoreName** indicates the vStore name on the storage device.

```
{
    "backends": [
    {
        ...
        "vstoreName": "***"
    }
    ]
}
```

□ NOTE

After configuring **huawei-csi-configmap.yaml**, restart huawei-csi-controller and huawei-csi-node. Otherwise, the configuration does not take effect.

Step 3 Run the **kubectl create -f** *huawei-csi-configmap.yaml* command to create *huawei-csi-configmap*.

kubectl create -f huawei-csi-configmap.yaml

Step 4 After the creation is complete, run the **kubectl get configmap -n kube-system** | **grep huawei-csi-configmap** command to check whether the creation is successful. If the following information is displayed, the creation is successful.

```
# kubectl get configmap -n kube-system | grep huawei-csi-configmap huawei-csi-configmap 1 5s
```

Step 5 Start huawei-csi services. For details, see **4.7 Starting huawei-csi Services**.

◯ NOTE

- When starting the huawei-csi services, enter the user name and password of the storage device vStore entered in **Step 3** in **4.7 Starting huawei-csi Services**.
- This feature is supported only by OceanStor V3 and OceanStor V5 storage.

----End

7.6.3 Configuring NAS HyperMetro

Perform this operation when you want to configure NAS HyperMetro.

Precautions

- To use NAS HyperMetro, you need to configure a HyperMetro relationship between two storage devices in advance. For details, see the configuration guide of Huawei storage.
- For details about the resource objects that support NAS HyperMetro and the feature description, see **Table 7-12**.

Table 7-12 Feature description

Resource Object	Operation	Supported	Remarks
PVC	Creation	Yes	This feature can be used
	Deletion	Yes	together with other features (except remote replication), such as QoS.
	Capacity expansion	Yes	-
	Synchronizing a HyperMetro pair	No	Storage supports these operations. Because
	Pausing a HyperMetro pair	No	Kubernetes cannot detect HyperMetro pairs, Kubernetes does not support
	Preferred site switchover	No	these operations.
Pod	Creation	Yes	Primary and secondary file
	Deletion	Yes	systems can be mounted to a Pod at the same time.
VolumeSnap	Creation	Yes	Snapshots can be operated
shot	Deletion Yes only for prim systems.	only for primary storage file systems.	

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the **vi** *huawei-csi-configmap.yaml* command to modify the .yaml file. Press **I** or **Insert** to enter the editing mode and modify related parameters. After the modification is complete, press **Esc** and enter :**wq!** to save the modification.

In the **backends** section of the *huawei-csi-configmap.yaml* file, add two backends with a HyperMetro relationship and add the **metrovStorePairID** configuration item for each backend. For details about the content of each backend, see **4.5 Connecting to Enterprise Storage** or **4.6 Connecting to Distributed Storage**.

```
{
    "backends":[
    {
        ...
    "name": "hyperMetro1",
```

```
"vstoreName": "***",
"metrovStorePairID": "***",
"metroBackend": "hyperMetro2"

},
{
...
"name": "hyperMetro2",
"vstoreName": "***",
"metrovStorePairID": "***",
"metrovStorePairID": "***",
"metroBackend": "hyperMetro1"

}

}
```

◯ NOTE

- NAS HyperMetro is supported only when a vStore is configured. For details about how to configure a vStore, see **7.6.2 Configuring a vStore**.
- metrovStorePairID is the ID of the HyperMetro vStore pair to which a vStore belongs.
- metroBackend is the name of a peer end in HyperMetro. The two backends form a
 HyperMetro relationship. As shown in the preceding information, the peer end of
 hyperMetro1 is hyperMetro2, and the peer end of hyperMetro2 is hyperMetro1.
- **Step 3** Run the **kubectl create -f** *huawei-csi-configmap.yaml* command to create *huawei-csi-configmap*.

kubectl create -f huawei-csi-configmap.yaml

Step 4 After the creation is complete, run the **kubectl get configmap -n kube-system** | **grep huawei-csi-configmap** command to check whether the creation is successful. If the following information is displayed, the creation is successful.

```
# kubectl get configmap -n kube-system | grep huawei-csi-configmap huawei-csi-configmap 1 5s
```

- **Step 5** Start huawei-csi services. For details, see **4.7 Starting huawei-csi Services**.
- Step 6 Run the vi StorageClass.yaml command to modify the .yaml file. Press I or Insert to enter the editing mode and add the hyperMetro parameter under parameters in the .yaml file. For details about the parameters, see Table 7-13. After the modification is complete, press Esc and enter :wq! to save the modification.

```
kind: StorageClass
apiVersion: storage.k8s.io/v1
metadata:
name: "***"
provisioner: "csi.huawei.com"
parameters:
...
volumeType: fs
hyperMetro: "true"
```

Table 7-13 Parameter description

Parameter	Description	Remarks
parameters.hyper Metro	Whether a HyperMetro volume is to be created.	If this parameter is set to true , a HyperMetro volume is to be created. If this parameter is not set or set to false , no HyperMetro volume is to be created.

- **Step 7** Run the following command to create a StorageClass based on the .yaml file.

 # kubectl create -f StorgeClass.yaml
- **Step 8** Use the StorageClass to create a PVC with the NAS HyperMetro capability. For details, see **6.2.1 Creating a PVC**.

7.6.4 Configuring an Application Type

This section describes how to create a LUN/file system volume that supports different application types.

Precautions

- The application type feature is not a standard feature of Kubernetes and is customized by storage vendors.
- An application type can be specified only when a PVC is created.
- A created PVC cannot be modified on Kubernetes.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the **vi** *StorageClass.yaml* command to modify the .yaml file. Press **I** or **Insert** to enter the editing mode and modify related parameters. After the modification is complete, press **Esc** and enter :**wq!** to save the modification.

Add the applicationType configuration item under parameters. The value of applicationType is a character string. For details, see Table 7-14. For other information about parameters, see 6.1.1.1 Creating a LUN StorageClass or 6.1.1.2 Creating a File System StorageClass.

```
kind: StorageClass
apiVersion: storage.k8s.io/v1
metadata:
name: "***"
provisioner: "csi.huawei.com"
parameters:
...
volumeType: "***"
applicationType: "***"
```

Parameter	Description	Remarks
parameters.applic ationType	Application type name on the storage device. The value is a character string.	If the value of volumeType is lun, log in to DeviceManager and choose Services > Block Service > LUN Groups > LUNs > Create to obtain the application type name. If the value of volumeType is fs, log in to DeviceManager and choose Services > File Service > File Systems > Create to obtain the application type name.

Table 7-14 Parameter description of applicationType

□ NOTE

This feature applies only to OceanStor Dorado 6.x series storage systems.

- **Step 3** Run the following command to create a StorageClass based on the .yaml file. # kubectl create -f StorgeClass.yaml
- **Step 4** Use the StorageClass to create a PVC with the application type capability. For details, see **6.2.1 Creating a PVC**.

----End

7.7 Advanced Features of Distributed Storage

7.7.1 Configuring QoS

This section describes how to create a LUN volume that supports QoS.

Precautions

- The QoS feature is not a standard feature of Kubernetes and is customized by storage vendors.
- A QoS policy can be specified only when a StorageClass is created. Once the QoS policy is created, it cannot be modified because the StorageClass cannot be modified on Kubernetes.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the **vi** *StorageClass.yaml* command to modify the .yaml file. Press **I** or **Insert** to enter the editing mode and modify related parameters. After the modification is complete, press **Esc** and enter :wq! to save the modification.

- Add the qos configuration item under parameters. For other information about parameters, see 6.1.1.1 Creating a LUN StorageClass or 6.1.1.2 Creating a File System StorageClass.
- The value of the qos section is JSON character strings in dictionary format. A
 character string is enclosed by single quotation marks and the dictionary key
 by double quotation marks. For details about the parameters, see Table 7-15.

```
kind: StorageClass
apiVersion: storage.k8s.io/v1
metadata:
name: "***"
provisioner: "csi.huawei.com"
parameters:
...
qos: '{"maxMBPS": 999, "maxIOPS": 999}'
```

Table 7-15 Parameters in gos

Parameter	Description	Remarks
maxMBPS	Maximum bandwidth.	This parameter is mandatory. The value is an integer greater than 0, expressed in MB/s.
maxIOPS	Maximum IOPS.	This parameter is mandatory. The value is an integer greater than 0

Step 3 Run the following command to create a PVC based on the .yaml file.

kubectl create -f StorageClass.yaml

----End

7.7.2 Configuring a Soft Quota

This section describes how to create a PVC that supports soft quotas.

Precautions

- This feature is supported only by OceanStor Pacific series 8.1.0 and later versions.
- This feature can be configured only when a storage pool of the file system type is connected.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the **vi** *StorageClass.yaml* command to modify the .yaml file. Press **I** or **Insert** to enter the editing mode and modify related parameters. After the modification is complete, press **Esc** and enter :**wq!** to save the modification.
 - Add the storageQuota configuration item under parameters. For other information about parameters, see 6.1.1.1 Creating a LUN StorageClass or 6.1.1.2 Creating a File System StorageClass.

• The value of the **storageQuota** section is JSON character strings in dictionary format. A character string is enclosed by single quotation marks and the dictionary key by double quotation marks. For details about the parameters, see **Table 7-16**.

```
kind: StorageClass
apiVersion: storage.k8s.io/v1
metadata:
name: "***"
provisioner: "csi.huawei.com"
parameters:
volumeType: "fs"
...
storageQuota: '{"spaceQuota": "softQuota", "gracePeriod": 100}'
```

Table 7-16 Parameters in storageQuota

Parameter	Description	Remarks
spaceQuota	File quota type.	This parameter is mandatory. Only softQuota or hardQuota can be configured.
gracePeriod	Grace period allowed when the soft quota is configured.	This parameter is conditionally optional only when spaceQuota is set to softQuota .
		The value is an integer ranging from 0 to 4294967294.

- Step 3 Run the following command to create a PVC based on the .yaml file.

 # kubectl create -f StorageClass.yaml
- **Step 4** Configure a StorageClass in the PVC according to **6.2.1 Creating a PVC** to finish creating a PVC.

8 Common Operations

- 8.1 Uninstalling CSI
- 8.2 Updating the User Name or Password of a Storage Device Configured on CSI
- 8.3 Updating the configmap Object of huawei-csi
- 8.4 Adding a Backend for huawei-csi
- 8.5 Updating the huawei-csi-controller Service
- 8.6 Updating the huawei-csi-node Service
- 8.7 Modifying the Log Output Mode

8.1 Uninstalling CSI

Perform this operation when you want to uninstall all CSIs.

Procedure

- **Step 1** Uninstall the huawei-csi-node service. For details, see **8.1.1 Uninstalling the** huawei-csi-node Service.
- **Step 2** Uninstall the huawei-csi-controller service. For details, see **8.1.2 Uninstalling the** huawei-csi-controller Service.
- **Step 3** Delete the huawei-csi-configmap object. For details, see **8.1.3 Deleting the huawei-csi-configmap Object**.
- **Step 4** Delete the huawei-csi-secret object. For details, see **8.1.4 Deleting the huawei-csi-secret Object**.
- **Step 5** Delete the RBAC permission. For details, see **8.1.5 Deleting the RBAC Permission**.
- **Step 6** Delete the image of the earlier version. For details, see **8.1.6** Deleting the Image of the Earlier Version.

8.1.1 Uninstalling the huawei-csi-node Service

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the following command:

kubectl delete daemonset huawei-csi-node -n kube-system

Step 3 Run the following command to check whether the service is successfully uninstalled. If no command output is displayed, the service is successfully uninstalled.

kubectl get daemonset -n kube-system | grep huawei-csi-node

----End

8.1.2 Uninstalling the huawei-csi-controller Service

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the following command.

kubectl delete deployment huawei-csi-controller -n kube-system

Step 3 Run the following command to check whether the service is successfully uninstalled. If no command output is displayed, the service is successfully uninstalled.

kubectl get deployment -n kube-system | grep huawei-csi-controller

----End

8.1.3 Deleting the huawei-csi-configmap Object

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the following command.

kubectl delete configmap huawei-csi-configmap -n kube-system

Step 3 Run the following command to check whether the object is successfully deleted. If no command output is displayed, the object is successfully deleted.

kubectl get configmap -n kube-system | grep huawei-csi-configmap

8.1.4 Deleting the huawei-csi-secret Object

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the following command.

kubectl delete secret huawei-csi-secret -n kube-system

Step 3 Run the following command to check whether the object is successfully deleted. If no command output is displayed, the object is successfully deleted.

kubectl get secret -n kube-system | grep huawei-csi-secret

----End

8.1.5 Deleting the RBAC Permission

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Delete the RBAC permission.
 - Method 1:

Run the following command (huawei-csi-rbac.yaml is the configuration information in Step 4 in 4.7 Starting huawei-csi Services).
kubectl delete -f huawei-csi-rbac.yaml

Method 2:

If the configuration file is not used, perform the following steps to delete the permission.

a. Run the following command to create a file named **delete-huawei-csi-rbac.sh**.

cat <<EOF > delete-huawei-csi-rbac.sh kubectl delete ServiceAccount huawei-csi-controller -n kube-system kubectl delete ServiceAccount huawei-csi-node -n kube-system kubectl delete ClusterRole huawei-csi-attacher-runner -n kube-system kubectl delete ClusterRole huawei-csi-driver-registrar-runner -n kube-system kubectl delete ClusterRole huawei-csi-provisioner-runner -n kube-system kubectl delete ClusterRole huawei-csi-resizer-runner -n kube-system kubectl delete ClusterRole huawei-csi-snapshotter-runner -n kube-system kubectl delete ClusterRole snapshot-controller-runner -n kube-system kubectl delete ClusterRoleBinding huawei-csi-attacher-role -n kube-system kubectl delete ClusterRoleBinding huawei-csi-driver-registrar-role -n kube-system kubectl delete ClusterRoleBinding huawei-csi-provisioner-role -n kube-system kubectl delete ClusterRoleBinding huawei-csi-resizer-role -n kube-system kubectl delete ClusterRoleBinding huawei-csi-snapshotter-role -n kube-system kubectl delete ClusterRoleBinding snapshot-controller-role -n kube-system kubectl delete Role huawei-csi-resizer-cfg -n kube-system kubectl delete Role huawei-csi-snapshotter-leaderelection -n kube-system kubectl delete Role snapshot-controller-leaderelection -n kube-system kubectl delete RoleBinding huawei-csi-resizer-role-cfg -n kube-system kubectl delete RoleBinding huawei-csi-snapshotter-leaderelection -n kube-system kubectl delete RoleBinding snapshot-controller-leaderelection -n kube-system FOF

b. Run the following command to delete the RBAC permission. If the **NotFound** error is reported, ignore it.

sh delete-huawei-csi-rbac.sh

Step 3 Check whether the RBAC permission has been deleted.

 Run the following command to create a file named check-huawei-csirbac.sh.

```
# cat <<EOF > check-huawei-csi-rbac.sh kubectl get ServiceAccount -n kube-system | grep huawei-csi kubectl get ClusterRole -n kube-system | grep huawei-csi kubectl get ClusterRoleBinding -n kube-system | grep huawei-csi kubectl get Role -n kube-system | grep huawei-csi kubectl get RoleBinding -n kube-system | grep huawei-csi kubectl get ClusterRole snapshot-controller-runner -n kube-system --ignore-not-found=true kubectl get ClusterRoleBinding snapshot-controller-role -n kube-system --ignore-not-found=true kubectl get Role snapshot-controller-leaderelection -n kube-system --ignore-not-found=true kubectl get RoleBinding snapshot-controller-leaderelection -n kube-system --ignore-not-found=true kubectl get RoleBinding snapshot-controller-leaderelection -n kube-system --ignore-not-found=true
```

Run the following command. If no command output is displayed, the RBAC permission has been successfully deleted.

sh check-huawei-csi-rbac.sh

----End

8.1.6 Deleting the Image of the Earlier Version

To delete the **huawei-csi** image from the cluster, you need to perform the deletion operation on all worker nodes.

To delete the image from a single node, perform the following steps.

Prerequisites

The container service that depends on the image has been stopped. Otherwise, the image cannot be deleted.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to a worker node through the management IP address.
- **Step 2** Run the following command to view all existing versions.

```
# docker image ls | grep huawei-csi
REPOSITORY TAG IMAGE ID CREATED SIZE
huawei-csi 2.2.14 b30b3a8b5959 2 weeks ago 79.7MB
huawei-csi 2.2.15 b30b3a8b5959 2 weeks ago 79.6MB
```

- **Step 3** Delete the image of the earlier version.
 - Method 1: Run the following command to delete the image of a specified version. (Change 2.2.14 to the version number of the image to be deleted.) # docker rmi huawei-csi:2.2.14
 - Method 2: Run the following command to delete the image of a specified ID. (Change b30b3a8b5959 to the ID of the image to be deleted.)
 # docker rmi b30b3a8b5959
- **Step 4** Run the following command again to check whether the image is successfully deleted. If the target version is not displayed, the image of the version is successfully deleted.

docker image ls | grep huawei-csi

----End

8.2 Updating the User Name or Password of a Storage Device Configured on CSI

When the user name or password of a storage device changes, you need to update the configuration information on CSI. Otherwise, huawei-csi services cannot work properly.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the **chmod** +**x secretUpdate** command to grant the execute permission on the secretUpdate tool.

chmod +x secretUpdate

Step 3 Run the ./secretUpdate command to run the secretUpdate tool and enter the ID of the backend to be configured as prompted. If **Configured** is **false**, the backend is not configured. If **Configured** is **true**, the backend is configured.

```
# ./secretUpdate
Getting backend configuration information.....
Number Configured BackendName
                                       Urls
             strage-backend [https://192.168.125.25:8088]
    true
              strage-backend-02 [https://192.168.125.26:8088]
3
     true
              strage-backend-03 [https://192.168.125.27:8088]
     true
              strage-backend-04 [https://192.168.125.28:8088]
              strage-backend-05 [https://192.168.125.29:8088]
     true
     true
             strage-backend-06 [https://192.168.125.30:8088]
Please enter the backend number to configure (Enter 'exit' to exit):3
```

Step 4 Enter the user name and password as prompted to update the **secret** object.

Step 5 After the configuration is complete, enter **exit** to exit and save the configuration.

```
Please enter the backend number to configure (Enter 'exit' to exit): exit
Saving configuration. Please wait......
The configuration is saved successfully.
```

- **Step 6** Run the following command to restart the huawei-csi-controller service.

 # kubectl get deployment huawei-csi-controller -o yaml -n=kube-system | kubectl replace --force -f -
- **Step 7** Run the following command to restart the huawei-csi-node service.

 # kubectl get daemonset huawei-csi-node -o yaml -n=kube-system | kubectl replace --force -f -
- **Step 8** Run the **kubectl get pod -A | grep huawei** command to check whether the services are restarted successfully.

```
# kubectl get pod -A | grep huawei
kube-system huawei-csi-controller-695b84b4d8-tg64l 4/4 Running 0 14s
kube-system huawei-csi-node-g6f7z 3/3 Running 0 14s
```

8.3 Updating the configmap Object of huawei-csi

Perform this operation when you want to add a storage pool to an existing backend or change an existing service IP address.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- Step 2 Run the kubectl edit configmap huawei-csi-configmap -n kube-system command, press I or Insert to enter the editing mode, and modify related parameters. The iSCSI networking is used as an example. For details about the parameters, see Table 8-1. After the modification is complete, press Esc and enter :wq! to save the modification.

Table 8-1 Description of configuration items

Configuratio n Item	Format	Description	Remarks
metadata.na me	String	User-defined name of a storage device.	 User-defined character string. The value can contain uppercase letters, lowercase letters, digits, and hyphens (-). This parameter cannot be modified.

Configuratio n Item	Format	Description	Remarks
storage in data."csi.jso n".backends	String	Type of the storage device to be connected.	 In the scenario where the enterprise storage SAN is connected, the value is fixed to oceanstor-san. This parameter cannot be modified.
pools in data."csi.jso n".backends	List	Name of a storage pool used on the storage device to be connected.	 One or more storage pools on the same storage device are supported. Use commas (,) to separate multiple storage pools. Currently, only storage pools can be added. You can log in to DeviceManager to obtain the storage pools that support the block storage service.
urls in data."csi.jso n".backends	List	Management URL of the storage device to be connected.	One or more management URLs of the same storage device are supported. Use commas (,) to separate multiple management URLs. Currently, only IPv4 addresses are supported. Example: https://192.168.125.20:8088 NOTE A storage device has multiple controllers, and each controller has a management URL. Therefore, a storage device has multiple management URLs.

Configuratio n Item	Format	Description	Remarks
parameters in data."csi.jso n".backends	Dictionary	Variable parameters in scenarios where iSCSI is used.	In scenarios where iSCSI is used, set the protocol parameter to a fixed value: iscsi .
			Set the portals parameter to the iSCSI service IP addresses of the storage device. Use commas (,) to separate multiple iSCSI service IP addresses.
			You can log in to DeviceManager to obtain the iSCSI service IP addresses. Take OceanStor Dorado 6.x series as an example. On DeviceManager, choose Services > Network > Logical Ports and obtain the IP address whose data protocol is iSCSI. (For other series, see the corresponding operation description.)

- **Step 3** Run the following command to restart the huawei-csi-controller service.

 # kubectl get deployment huawei-csi-controller -o yaml -n=kube-system | kubectl replace --force -f -
- Step 4 Run the following command to restart the huawei-csi-node service.

 # kubectl get daemonset huawei-csi-node -o yaml -n=kube-system | kubectl replace --force -f -
- **Step 5** Run the **kubectl get pod -A | grep huawei** command to check whether the services are restarted successfully.

```
# kubectl get pod -A | grep huawei
kube-system huawei-csi-controller-695b84b4d8-tg64l 4/4 Running 0 14s
kube-system huawei-csi-node-g6f7z 3/3 Running 0 14s
```

8.4 Adding a Backend for huawei-csi

Perform this operation when you want to add a storage device or a storage pool as an independent backend.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Configure multiple backends. For details, see **7.1** Configuring Multiple Backends.

- Step 3 Configure accounts for the new backends. For details, see 8.2 Updating the User Name or Password of a Storage Device Configured on CSI.
- **Step 4** Run the following command to restart the huawei-csi-controller service.

 # kubectl get deployment huawei-csi-controller -o yaml -n=kube-system | kubectl replace --force -f -
- **Step 5** Run the following command to restart the huawei-csi-node service.

 # kubectl get daemonset huawei-csi-node -o yaml -n=kube-system | kubectl replace --force -f -
- **Step 6** Run the **kubectl get pod -A | grep huawei** command to check whether the services are restarted successfully.

```
# kubectl get pod -A | grep huawei
kube-system huawei-csi-controller-695b84b4d8-tg64l 4/4 Running 0 14s
kube-system huawei-csi-node-g6f7z 3/3 Running 0 14s
```

8.5 Updating the huawei-csi-controller Service

Perform this operation when you need to update the huawei-csi-controller service, for example, adding the snapshot or the capacity expansion function.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Uninstall the huawei-csi-controller service. For details, see **8.1.2 Uninstalling the** huawei-csi-controller Service.
- **Step 3** Delete the RBAC permission. For details, see **8.1.5 Deleting the RBAC Permission**.
- Step 4 Run the vi huawei-csi-rbac.yaml command to modify the .yaml file. Press I or Insert to enter the editing mode and modify related parameters. After the modification is complete, press Esc and enter :wq! to save the modification. (For details, see sample file yamls/huawei-csi-rbac.yaml in the software package.)

◯ NOTE

- The csi-resizer service is supported since Kubernetes v1.16.
 For details about the huawei-csi-rbac.yaml file, see sample file yamls/huawei-csi-resize-rbac.yaml in the software package.
- The csi-snapshotter service is supported since Kubernetes v1.17.
 For details about the huawei-csi-rbac.yaml file, see sample file yamls/huawei-csi-resize-snapshot-rbac.yaml in the software package.
- **Step 5** Run the following command to create the RBAC permission.

 # kubectl create -f huawei-csi-rbac.yaml
- Step 6 Run the vi huawei-csi-controller.yaml command to modify the .yaml file. Press I or Insert to enter the editing mode and modify related parameters. After the modification is complete, press Esc and enter :wq! to save the modification. (For details, see sample file yamls/huawei-csi-controller.yaml in the software package.)

□ NOTE

 In the image configuration item under huawei-csi-driver in the sample .yaml file, huawei-csi: *.** must be replaced with <Name>:<Version> of the created Huawei CSI image.

containers:

- name: huawei-csi-driver image: huawei-csi:2.2.15
- The csi-resizer service is supported since Kubernetes v1.16.
 - For details about the **huawei-csi-controller.yaml** file, see sample file **yamls/huawei-csi-resize-controller.yaml** in the software package.
- The csi-snapshotter service is supported since Kubernetes v1.17.

 For details about the huawei-csi-controller.yaml file, see sample file yamls/huawei-csi-resize-snapshot-controller.yaml in the software package.
- **Step 7** Run the following command to start the controller service.

kubectl create -f huawei-csi-controller.yaml

Step 8 After the huawei-csi service is deployed, run the **kubectl get pod -A | grep huawei-csi-controller** command to check whether the service is started.

```
# kubectl get pod -A | grep huawei-csi-controller kube-system huawei-csi-controller-695b84b4d8-tg64l 4/4 Running 0 14s
```

----End

8.6 Updating the huawei-csi-node Service

Perform this operation when you need to update the huawei-csi-node service.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Uninstall the huawei-csi-node service. For details, see **8.1.1 Uninstalling the** huawei-csi-node Service.
- Step 3 Run the vi huawei-csi-node.yaml command to modify the .yaml file. Press I or Insert to enter the editing mode and modify related parameters. After the modification is complete, press Esc and enter :wq! to save the modification. Compile the huawei-csi-node.yaml file. For details, see sample file yamls/huawei-csi-node.yaml in the software package.
 - In the **image** configuration item under **huawei-csi-driver** in the sample .yaml file, *huawei-csi:*.*** must be replaced with *<Name>:<Version>* of the created Huawei CSI image.

containers:

- name: huawei-csi-driver image: huawei-csi:2.2.15
- In the args parameter in the huawei-csi-driver section in the .yaml file, -- volume-use-multipath indicates that multipathing is enabled by default. The following shows how to change the value.

args:

- "--endpoint=/csi/csi.sock"
- "--containerized"

- "--driver-name=csi.huawei.com"
- "--volume-use-multipath=false"
- **Step 4** Run the following command to start the node service.

kubectl create -f huawei-csi-node.yaml

Step 5 After the huawei-csi service is deployed, run the **kubectl get pod -A | grep huawei-csi-node** command to check whether the service is started.

kubectl get pod -A | grep huawei-csi-node kube-system huawei-csi-node-q6f7z 3/3 Running 0 14s

----End

8.7 Modifying the Log Output Mode

huawei-csi supports two log output modes: **file** and **console**. **file** indicates that logs are output to the fixed directory (**/var/log/huawei**), and **console** indicates that logs are output to the standard directory of the container. You can set the log output mode as required. The default mode is **file**.

8.7.1 Modifying the Log Output Mode of the huawei-csi-controller Service

Perform this operation when you want to set the log output mode of the huawei-csi-controller service.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the following command to delete the huawei-csi-controller service (huawei-csi-controller.yaml is the configuration information in Step 6 in 4.7 Starting huawei-csi Services).

kubectl delete -f huawei-csi-controller.yaml

Step 3 Run the following command to view the huawei-csi-controller service. If no command output is displayed, the deletion is complete.

kubectl get pod -A | grep huawei-csi-controller

Step 4 Run the vi huawei-csi-controller.yaml command to modify the .yaml file. Press I or Insert to enter the editing mode and modify related parameters. After the modification is complete, press Esc and enter :wq! to save the modification. (For details, see sample file yamls/huawei-csi-controller.yaml in the software package.) For details about the parameters, see Table 8-2.

aras

- "--endpoint=\$(CSI_ENDPOINT)"
- "--controller"
- "--containerized"
- "--driver-name=csi.huawei.com"
- "--loggingModule=file"
- "--logLevel=info"
- "--logFileDir=/var/log/huawei"
- "--logFileSize=20M"
- "--maxBackups=9"

Configuration Item	Description	Remarks
loggingModule	huawei-csi log output mode.	The value can be file or console . The default value is file .
logLevel	huawei-csi log output level.	Supported levels are debug , info , warning , error , and fatal . The default level is info .
logFileDir	huawei-csi log directory in file output mode.	This parameter is available only when loggingModule is set to file . The default log directory is /var/log/huawei .
logFileSize	Size of a single huawei-csi log file in file output mode.	This parameter is available only when loggingModule is set to file . The default log file size is 20 MiB.
maxBackups	Maximum number of huawei-csi log file backups in file output mode.	This parameter is available only when loggingModule is set to file . The default number of log file backups is 9.

Table 8-2 Description of log output parameters

Step 5 Run the following command to start the controller service.

kubectl create -f huawei-csi-controller.yaml

Step 6 After the huawei-csi service is deployed, run the **kubectl get pod -A | grep huawei-csi-controller** command to check whether the service is started.

kubectl get pod -A -o wide | grep huawei kube-system huawei-csi-controller-b59577886-qqzm8 4/4 Running 0 18h 10.244.1.67 node <none> <none>

- **Step 7** View the logs of the huawei-csi-controller service.
 - If **loggingModule** is set to **file**, log in to the node, go to the log directory specified by **logFileDir**, and run the following command to view the log of huawei-csi-controller.

tail -f huawei-csi-controller

 If loggingModule is set to console, run the following command to view the log of huawei-csi-controller.

kubectl logs *huawei-csi-controller* -c huawei-csi-driver -n kube-system

----End

8.7.2 Modifying the Log Output Mode of the huawei-csi-node Service

Perform this operation when you want to set the log output mode of the huawei-csi-node service.

Procedure

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- Step 2 Run the following command to delete the huawei-csi-node service (huawei-csi-node.yaml is the configuration information in Step 8 in 4.7 Starting huawei-csi Services).
 - # kubectl delete -f huawei-csi-node.yaml
- Step 3 Run the following command to view the huawei-csi-node service. If no command output is displayed, the deletion is complete.

 # kubectl get pod -A | grep huawei-csi-node
- Step 4 Run the vi huawei-csi-node.yaml command to modify the .yaml file. Press I or Insert to enter the editing mode and modify related parameters. After the modification is complete, press Esc and enter :wq! to save the modification. Compile the huawei-csi-node.yaml file. For details, see sample file yamls/huawei-csi-node.yaml in the software package. For details about the parameters, see Table 8-3.

args:

- "--endpoint=/csi/csi.sock"
- "--containerized"
- "--driver-name=csi.huawei.com"
- "--volume-use-multipath=false"
- "--loggingModule=file"
- "--logLevel=info"
- "--logFileDir=/var/log/huawei"
- "--logFileSize=20M"
- "--maxBackups=9"

Table 8-3 Description of log output parameters

Configuration Item	Description	Remarks
loggingModule	huawei-csi log output mode.	The value can be file or console . The default value is file .
logLevel	huawei-csi log output level.	Supported levels are debug , info , warning , error , and fatal . The default level is info .
logFileDir	huawei-csi log directory in file output mode.	This parameter is available only when loggingModule is set to file . The default log directory is /var/log/huawei .
logFileSize	Size of a single huawei-csi log file in file output mode.	This parameter is available only when loggingModule is set to file . The default log file size is 20 MiB.
maxBackups	Maximum number of huawei-csi log file backups in file output mode.	This parameter is available only when loggingModule is set to file . The default number of log file backups is 9.

Step 5 Run the following command to start the node service.

kubectl create -f huawei-csi-node.yaml

Step 6 After the huawei-csi service is deployed, run the **kubectl get pod -A | grep huawei-csi-node** command to check whether the service is started.

kubectl get pod -A | grep huawei-csi-node kube-system huawei-csi-node-4sfwr 3/3 Running 0 18h 10.244.1.68 node <none> <none>

- **Step 7** View the logs of the huawei-csi-node service.
 - If **loggingModule** is set to **file**, log in to the node, go to the log directory specified by **logFileDir**, and run the following command to view the log of huawei-csi-node.

tail -f huawei-csi-node

• If **loggingModule** is set to **console**, run the following command to view the log of huawei-csi-node.

kubectl logs *huawei-csi-node* -c huawei-csi-driver -n kube-system

9 FAQ

- 9.1 Viewing Log Information
- 9.2 Failed to Create a Pod Because the iscsi_tcp Service Is Not Started Properly When the Kubernetes Platform Is Set Up for the First Time
- 9.3 Failed to Start the huawei-csi-node Service with Error Message "/var/lib/iscsi is not a directory" Reported
- 9.4 After a Worker Node in the Cluster Breaks Down and Recovers, Pod Failover Is Complete but the Source Host Where the Pod Resides Has Residual Drive Letters
- 9.5 Failed to Start huawei-csi Services with the Status Displayed as InvalidImageName
- 9.6 When a PVC Is Created, the PVC Is in the Pending State
- 9.7 Before a PVC Is Deleted, the PVC Is in the Pending State
- 9.8 When a Pod Is Created, the Pod Is in the ContainerCreating State

9.1 Viewing Log Information

Viewing Logs Generated When the secret Object Is Configured

- **Step 1** Run the **cd /var/log/huawei** command to go to the log directory.
 - # cd /var/log/huawei
- **Step 2** Run the following command to view the logs of huawei-csi-install.

vi huawei-csi-install

----End

Viewing Logs of the huawei-csi-controller Service

Step 1 Run the following command to obtain the node where huawei-csi-controller is located.

kubectl get pod -A -o wide | grep huawei kube-system huawei-csi-controller-695b84b4d8-tg64l 4/4 **Running** 0 14s <host1-ip> <host1-name> <none> <none>

- **Step 2** Use a remote access tool, such as PuTTY, to log in to the huawei-csi-controller node in the Kubernetes cluster through the management IP address.
- **Step 3** Run the **cd /var/log/huawei** command to go to the log directory.

 # cd /var/log/huawei
- **Step 4** Run the following command to view the customized output logs of the container.

 # vi huawei-csi-controller
- **Step 5** Run the **cd /var/log/containers** command to go to the container directory.

 # cd /var/log/containers
- **Step 6** Run the following command to view the standard output logs of the container. # vi huawei-csi-controller-<name>_kube-system_huawei-csi-driver-<contrainer-id>.log

Viewing Logs of the huawei-csi-node Service

Step 1 Run the following command to obtain the node where huawei-csi-node is located.

kubectl get pod -A -o wide | grep huawei kube-system huawei-csi-node-g6f7z 3/3 **Running** 0 14s <host2-ip> <host2name> <none>

- **Step 2** Use a remote access tool, such as PuTTY, to log in to the huawei-csi-node node in the Kubernetes cluster through the management IP address.
- **Step 3** Run the **cd /var/log/huawei** command to go to the log directory.

 # cd /var/log/huawei
- **Step 4** Run the following command to view the customized output logs of the container.

 # vi huawei-csi-node
- **Step 5** Run the **cd /var/log/containers** command to go to the container directory.

 # cd /var/log/containers
- **Step 6** Run the following command to view the standard output logs of the container. # vi huawei-csi-node-<name>_kube-system_huawei-csi-driver-<contrainer-id>.log

----End

9.2 Failed to Create a Pod Because the iscsi_tcp Service Is Not Started Properly When the Kubernetes Platform Is Set Up for the First Time

Symptom

When you create a Pod, error Cannot connect ISCSI portal *.*.*: libkmod: kmod_module_insert_module: could not find module by name='iscsi_tcp' is reported in the /var/log/huawei-csi-node log.

Environment Configuration

Kubernetes version: 1.13 or later

Root Cause Analysis

The iscsi_tcp service may be stopped after the Kubernetes platform is set up and the iscsi service is installed. You can run the **lsmod | grep iscsi | grep iscsi_tcp** command to check whether the service is stopped.

Solution or Workaround

Run the following command to manually load the iscsi_tcp service.

```
# modprobe iscsi_tcp
# lsmod | grep iscsi | grep iscsi_tcp
iscsi_tcp 18333 6
libiscsi_tcp 25146 1 iscsi_tcp
```

9.3 Failed to Start the huawei-csi-node Service with Error Message "/var/lib/iscsi is not a directory" Reported

Symptom

The huawei-csi-node service cannot be started. When you run the **kubectl describe daemonset huawei-csi-node -n kube-system** command, error message "/var/lib/iscsi is not a directory" is reported.

Environment Configuration

Kubernetes version: 1.13 or later

Root Cause Analysis

The /var/lib/iscsi directory does not exist in the huawei-csi-node container.

Solution or Workaround

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- Step 2 Run the following command to delete the huawei-csi-node service (huawei-csi-node.yaml is the configuration information in Step 8 in 4.7 Starting huawei-csi Services).

kubectl delete -f huawei-csi-node.yaml

- Step 3 Run the following command to view the huawei-csi-node service. If no command output is displayed, the deletion is complete.

 # kubectl get pod -A | grep huawei-csi-node
- **Step 4** Run the **vi** *huawei-csi-node.yaml* command to modify the .yaml file. Press **I** or **Insert** to enter the editing mode, set **path** in *huawei-csi-node.yaml* > **volumes** >

iscsi-dir > hostPath to /var/lib/iscsi and delete the type line. After the modification is complete, press Esc and enter :wq! to save the modification. Compile the *huawei-csi-node.yaml* file. For details, see sample file yamls/huawei-csi-node.yaml in the software package.

Step 5 Run the following command to start the node service.

kubectl create -f huawei-csi-node.yaml

Step 6 After the huawei-csi service is deployed, run the **kubectl get pod -A | grep huawei-csi-node** command to check whether the service is started.

kubectl get pod -A | grep huawei-csi-node kube-system huawei-csi-node-g6f7z 3/3 Running 0 14s

----End

9.4 After a Worker Node in the Cluster Breaks Down and Recovers, Pod Failover Is Complete but the Source Host Where the Pod Resides Has Residual Drive Letters

Symptom

A Pod is running on worker node A, and an external block device is mounted to the Pod through CSI. After worker node A is powered off abnormally, the Kubernetes platform detects that the node is faulty and switches the Pod to worker node B. After worker node A recovers, the drive letters on worker node A change from normal to faulty.

Environment Configuration

Kubernetes version: 1.13 or later

Storage type: block storage

Root Cause Analysis

After worker node A recovers, Kubernetes initiates an unmapping operation on the storage, but does not initiate a drive letter removal operation on the host. After Kubernetes completes the unmapping, residual drive letters exist on worker node A.

Solution or Workaround

Currently, you can only manually clear the residual drive letters on the host. Alternatively, restart the host again and use the disk scanning mechanism during the host restart to clear the residual drive letters. The specific method is as follows:

Step 1 Check the residual drive letters on the host.

1. Run the **multipath** -**ll** command to check whether a DM multipathing device with abnormal multipathing status exists.

As shown in the following figure, the path status is **failed faulty running**, the corresponding DM multipathing device is **dm-12**, and the associated SCSI

disks are **sdi** and **sdj**. If multiple paths are configured, multiple SCSI disks exist. Record these SCSI disks.

- If yes, go to Step 1.2.
- If no, no further action is required.
- 2. Check whether the residual DM multipathing device is readable.

Run the **dd if=/dev/***dm-xx* **of=/dev/null count=1 bs=1M iflag=direct** command.

dm-xx indicates the device ID obtained in **Step 1.1**.

If the returned result is **Input/output error** and the read data is **0 bytes (0 B) copied**, the device is unreadable.

```
#dd if=/dev/dm-12 of=/dev/null count=1 bs=1M iflag=direct
dd: error reading '/dev/dm-12': Input/output error
0+0 records in
0+0 records out
0 bytes (0 B) copied, 0.0236862 s, 0.0 kB/s
```

- If yes, record the residual dm-xx device and associated disk IDs (for details, see Step 1.1) and perform the clearing operation.
- If the command execution is suspended, go to **Step 1.3**.
- If other cases, contact technical support engineers.
- 3. Log in to the node again in another window.
 - a. Run the following command to view the suspended process.

 # ps -ef | grep dm-12 | grep -w dd
 root 21725 9748 0 10:33 pts/10 00:00:00 dd if=/dev/dm-12 of=/dev/null count=1 bs=10M iflag=direct
 - b. Kill the pid. # kill -9 pid
 - c. Record the residual *dm-xx* device and associated disk IDs (for details, see **Step 1.1**) and perform the clearing operation.

Step 2 Clear the residual drive letters on the host.

1. Run the **multipath** -**f** /**dev**/*dm*-* command to delete residual multipathing aggregation device information according to the DM multipathing device obtained in **Step 1**.

```
# multipath -f /dev/dm-12
```

If an error is reported, contact technical support engineers.

2. Run the following command to clear the residual SCSI disks according to the drive letters of the residual disks obtained in the troubleshooting method. echo 1 > /svs/block/xxxx/device/delete

When multiple paths are configured, clear the residual disks based on the drive letters. The residual paths are **sdi** and **sdj**.

```
# echo 1 > /sys/block/sdi/device/delete
# echo 1 > /sys/block/sdj/device/delete
```

If an error is reported, contact technical support engineers.

3. Check whether the DM multipathing device and SCSI disk information has been cleared.

Run the multipath -ll, ls -l /sys/block/, and ls -l /dev/disk/by-id/ commands in sequence to query the path and disk information. If the residual dm-12 device and SCSI disks sdi and sdj are cleared, the clearing is complete.

```
mpathb (3618cf24100f8f457014a764c000001f6) dm-3 HUAWEI ,XSG1
size=100G features='0' hwhandler='0' wp=rw
 -+- policy='service-time 0' prio=-1 status=active
 |- 39:0:0:1
                sdd 8:48 active ready running
  - 38:0:0:1
                sde 8:64 active ready running
mpathn (3618cf24100f8f457315a764c000001f6) dm-5 HUAWEI ,XSG1
size=100G features='0' hwhandler='0' wp=rw
 -+- policy='service-time 0' prio=-1 status=active
 |- 39:0:0:2
                sdc 8:32 active ready running
 `- 38:0:0:2
                sdb 8:16 active ready running
# ls -l /sys/block/
total 0
lrwxrwxrwx 1 root root 0 Aug 11 19:56 dm-0 -> ../devices/virtual/block/dm-0
lrwxrwxrwx 1 root root 0 Aug 11 19:56 dm-1 -> ../devices/virtual/block/dm-1
lrwxrwxrwx 1 root root 0 Aug 11 19:56 dm-2 -> ../devices/virtual/block/dm-2
lrwxrwxrwx 1 root root 0 Aug 11 19:56 dm-3 -> ../devices/virtual/block/dm-3
lrwxrwxrwx 1 root root 0 Aug 11 19:56 sdb -> ../devices/platform/host35/session2/
target35:0:0/35:0:0:1/block/sdb
lrwxrwxrwx 1 root root 0 Aug 11 19:56 sdc -> ../devices/platform/host34/
target34:65535:5692/34:65535:5692:0/block/sdc
lrwxrwxrwx 1 root root 0 Aug 11 19:56 sdd -> ../devices/platform/host39/session6/
target39:0:0/39:0:0:1/block/sdd
lrwxrwxrwx 1 root root 0 Aug 11 19:56 sde -> ../devices/platform/host38/session5/
target38:0:0/38:0:0:1/block/sde
lrwxrwxrwx 1 root root 0 Aug 11 19:56 sdh -> ../devices/platform/host39/session6/
target39:0:0/39:0:0:3/block/sdh
lrwxrwxrwx 1 root root 0 Aug 11 19:56 sdi -> ../devices/platform/host38/session5/target38:0:0/38:0:0:3/
block/sdi
ls -l /dev/disk/by-id/
total 0
lrwxrwxrwx 1 root root 10 Aug 11 19:57 dm-name-mpathb -> ../../dm-3
lrwxrwxrwx 1 root root 10 Aug 11 19:58 dm-name-mpathn -> ../../dm-5
lrwxrwxrwx 1 root root 10 Aug 11 19:57 dm-uuid-mpath-3618cf24100f8f457014a764c000001f6 -> ../../
lrwxrwxrwx 1 root root 10 Aug 11 19:58 dm-uuid-mpath-3618cf24100f8f457315a764c000001f6 -> ../../
dm-5
lrwxrwxrwx 1 root root 9 Aug 11 19:57 scsi-3618cf24100f8f457014a764c000001f6 -> ../../sdd
lrwxrwxrwx 1 root root 9 Aug 11 19:57 scsi-3618cf24100f8f45712345678000103e8 -> ../../sdi
lrwxrwxrwx 1 root root 9 Aug 3 15:17 scsi-3648435a10058805278654321ffffffff -> ../../sdb
lrwxrwxrwx 1 root root 9 Aug 2 14:49 scsi-368886030000020aff44cc0d060c987f1 -> ../../sdc
lrwxrwxrwx 1 root root 9 Aug 11 19:57 wwn-0x618cf24100f8f457014a764c000001f6 -> ../../sdd
lrwxrwxrwx 1 root root 9 Aug 11 19:57 wwn-0x618cf24100f8f45712345678000103e8 -> ../../sdi
lrwxrwxrwx 1 root root 9 Aug 3 15:17 wwn-0x648435a10058805278654321ffffffff -> ../../sdb
lrwxrwxrwx 1 root root 9 Aug 2 14:49 wwn-0x6888603000020aff44cc0d060c987f1 -> ../../sdc
```

----End

9.5 Failed to Start huawei-csi Services with the Status Displayed as InvalidImageName

Symptom

The huawei-csi services (huawei-csi-controller or huawei-csi-node) cannot be started. After the **kubectl get pod -A | grep huawei** command is executed, the command output shows that the service status is **InvalidImageName**.

```
# kubectl get pod -A | grep huawei
kube-system huawei-csi-controller-fd5f97768-qlldc 6/7 InvalidImageName 0 16s
kube-system huawei-csi-node-25txd 2/3 InvalidImageName 0 15s
```

Environment Configuration

Kubernetes version: 1.13 or later

Root Cause Analysis

In **huawei-csi-controller.yaml** and **huawei-csi-node.yaml**, the Huawei CSI image version number is incorrect. For example:

```
...
- name: huawei-csi-driver
image: huawei-csi:2.2.15
...
```

Solution or Workaround

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the following command to modify the configuration file of the huawei-csi-node service. Press I or **Insert** to enter the editing mode and modify related parameters. After the modification is complete, press **Esc** and enter :wq! to save the modification.

kubectl edit daemonset huawei-csi-node -o yaml -n=kube-system

• In the **image** configuration item under **huawei-csi-driver** in the sample .yaml file, huawei-csi: *.*.* must be replaced with <Name>:<Version> of the created Huawei CSI image.

containers:

- name: huawei-csi-driver image: huawei-csi:2.2.15
- **Step 3** Run the following command to modify the configuration file of the huawei-csi-controller service: Press I or Insert to enter the editing mode and modify related parameters. After the modification is complete, press **Esc** and enter :wq! to save the modification.

kubectl edit deployment huawei-csi-controller -o yaml -n=kube-system

NOTE

 In the image configuration item under huawei-csi-driver in the sample .yaml file, huawei-csi:*.* must be replaced with <Name>:<Version> of the created Huawei CSI image.

containers:

- name: huawei-csi-driver image: huawei-csi:2.2.15
- **Step 4** Wait until the huawei-csi-node and huawei-csi-controller services are started.
- **Step 5** Run the following command to check whether the huawei-csi services are started.

```
# kubectl get pod -A | grep huawei
kube-system huawei-csi-controller-58799449cf-zvhmv 7/7 Running 0 2m29s
kube-system huawei-csi-node-7fxh6 3/3 Running 0 12m
```

----End

9.6 When a PVC Is Created, the PVC Is in the Pending State

Symptom

A PVC is created. After a period of time, the PVC is still in the **Pending** state.

Environment Configuration

Kubernetes version: 1.13 or later

Root Cause Analysis

Cause 1: A StorageClass with the specified name is not created in advance. As a result, Kubernetes cannot find the specified StorageClass name when a PVC is created.

Cause 2: The storage pool capability does not match the StorageClass capability. As a result, huawei-csi fails to select a storage pool.

Cause 3: An error code (for example, 50331651) is returned by a RESTful interface of the storage. As a result, huawei-csi fails to create a PVC.

Cause 4: The storage does not return a response within the timeout period set by huawei-csi. As a result, huawei-csi returns a timeout error to Kubernetes.

Cause 5: Other causes.

Solution or Workaround

When a PVC is created, if the PVC is in the **Pending** state, you need to take different measures according to the following causes.

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the following command to view details about the PVC. # kubectl describe pvc mypvc
- **Step 3** Perform the corresponding operation according to the **Events** information in the detailed PVC information.
 - If the PVC is in the **Pending** state due to cause 1, perform the following steps.



- a. Delete the PVC. For details, see 6.2.5 Deleting a PVC.
- b. Create a StorageClass. For details, see **6.1.1 Creating a StorageClass**.
- c. Create a PVC. For details, see 6.2.1 Creating a PVC.
- If the PVC is in the **Pending** state due to cause 2, perform the following steps.

 Events:
 Type Reason Age

Warning ProvisioningFailed 63s (x3 over 64s) csi.huawei.com_huawei-csi-controller-b59577886-qqzm8_58533e4a-884c-4c7f-92c3-6e8a7b327515 failed to provision volume with StorageClass "mysc": rpc error: code = Internal desc = **failed to select pool**, the capability filter failed, error: failed to select pool, the final filter field: **replication**, parameters map[allocType:thin replication:True size: 1099511627776 volumeType:lun]. please check your storage class

- a. Delete the PVC. For details, see **6.2.5 Deleting a PVC**.
- b. Delete the StorageClass. For details, see **6.1.2 Deleting a StorageClass**.
- c. Modify the **StorageClass.yaml** file based on the **Events** information.
- d. Create a StorageClass. For details, see 6.1.1 Creating a StorageClass.
- e. Create a PVC. For details, see 6.2.1 Creating a PVC.
- If the PVC is in the **Pending** state due to cause 3, contact Huawei engineers.

Events:
Type Reason Age
From Message

Normal Provisioning 63s (x4 over 68s) csi.huawei.com_huawei-csi-controller-b59577886-qqzm8_58533e4a-884c-4c7f-92c3-6e8a7b327515 External provisioner is provisioning volume for claim "default/mypvc"

Warning ProvisioningFailed 62s (x4 over 68s) csi.huawei.com_huawei-csi-controller-b59577886-qqzm8_58533e4a-884c-4c7f-92c3-6e8a7b327515 failed to provision volume with StorageClass "mysc": rpc error: code = Internal desc = Create volume map[ALLOCTYPE:1 CAPACITY:20 DESCRIPTION:Created from Kubernetes CSI NAME:pvc-63ebfda5-4cf0-458e-83bd-ecc PARENTID:0] error: **50331651**

• If the PVC is in the **Pending** state due to cause 4, perform the following steps. Events:

Type Reason Age
From Message

Normal Provisioning 63s (x3 over 52s) csi.huawei.com_huawei-csi-controller-b59577886-qqzm8_58533e4a-884c-4c7f-92c3-6e8a7b327515 External provisioner is provisioning volume for claim "default/mypvc"

Warning ProvisioningFailed 63s (x3 over 52s) csi.huawei.com_huawei-csi-controller-b59577886-qqzm8_58533e4a-884c-4c7f-92c3-6e8a7b327515 failed to provision volume with StorageClass "mysc": rpc error: code = Internal desc = context deadline exceeded (Client.Timeout exceeded while awaiting headers)

- a. Wait for 10 minutes and check the PVC details again by referring to this section.
- b. If it is still in the **Pending** state, contact Huawei engineers.
- If the PVC is in the **Pending** state due to cause 5, contact Huawei engineers.

----End

9.7 Before a PVC Is Deleted, the PVC Is in the Pending State

Symptom

Before a PVC is deleted, the PVC is in the **Pending** state.

Environment Configuration

Kubernetes version: 1.13 or later

Root Cause Analysis

Cause 1: A StorageClass with the specified name is not created in advance. As a result, Kubernetes cannot find the specified StorageClass name when a PVC is created.

Cause 2: The storage pool capability does not match the StorageClass capability. As a result, huawei-csi fails to select a storage pool.

Cause 3: An error code (for example, 50331651) is returned by a RESTful interface of the storage. As a result, huawei-csi fails to create a PVC.

Cause 4: The storage does not return a response within the timeout period set by huawei-csi. As a result, huawei-csi returns a timeout error to Kubernetes.

Cause 5: Other causes.

Solution or Workaround

To delete a PVC in the **Pending** state, you need to take different measures according to the following causes.

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the following command to view details about the PVC. # kubectl describe pvc mypvc
- **Step 3** Perform the corresponding operation according to the **Events** information in the detailed PVC information.
 - If the PVC is in the **Pending** state due to cause 1, run the **kubectl delete pvc** *mvpvc* command to delete the PVC.

Events:					
Type	Reason	Age	From	Message	
Warni	ng Provisio	ningFailed Os (x1	5 over 3m24s)	persistentvolume-controller	
storage	class.stora	ae.k8s.io " <i>mvsc</i> "	not found		

• If the PVC is in the **Pending** state due to cause 2, run the **kubectl delete pvc** *mypvc* command to delete the PVC.

Events:	_			
Type	Reason	Age		
From			Message	
Norma	al Provisioning	g 63s	x3 over 64s) csi.huawei.com_huawei-c	si-controller-b59577886-
qqzm8_	58533e4a-884	c-4c7f-92c3-	5e8a7b327515 External provisioner is p	provisioning volume for
claim "d	lefault/mypvc"			_
Warnir	ng Provisionin	gFailed 63	(x3 over 64s) csi.huawei.com_huawei	-csi-controller-b59577886-
ggzm8_	58533e4a-884	- c-4c7f-92c3-	6e8a7b327515 failed to provision volume	me with StorageClass
"mvsc":	rpc error: code	e = Internal d	esc = failed to select pool, the capabil	ity filter failed, error: failed
			<i>replication</i> , parameters map[allocType	
			please check your storage class	
103331	1027770 VOIGII	ie i y penanj.	ricuse check your storage class	

• If the PVC is in the **Pending** state due to cause 3, run the **kubectl delete pvc** *mypvc* command to delete the PVC.

Events:		
Type	Reason	Age
		_

From Message

---- ---
Normal Provisioning 63s (x4 over 68s) csi.huawei.com_huawei-csi-controller-b59577886-qqzm8_58533e4a-884c-4c7f-92c3-6e8a7b327515 External provisioner is provisioning volume for claim "default/mypvc"

Warning ProvisioningFailed 62s (x4 over 68s) csi.huawei.com_huawei-csi-controller-b59577886-qqzm8_58533e4a-884c-4c7f-92c3-6e8a7b327515 failed to provision volume with StorageClass "mysc": rpc error: code = Internal desc = Create volume map[ALLOCTYPE:1 CAPACITY:20 DESCRIPTION:Created from Kubernetes CSI NAME:pvc-63ebfda5-4cf0-458e-83bd-ecc PARENTID:0] error: 50331651

• If the PVC is in the **Pending** state due to cause 4, contact Huawei engineers.

Events:

Type Reason Age

From Message

---- Mormal Provisioning 63s (x3 over 52s) csi.huawei.com_huawei-csi-controller-b59577886-qqzm8_58533e4a-884c-4c7f-92c3-6e8a7b327515 External provisioner is provisioning volume for claim "default/mypvc"

Warning ProvisioningFailed 63s (x3 over 52s) csi.huawei.com_huawei-csi-controller-b59577886-qqzm8_58533e4a-884c-4c7f-92c3-6e8a7b327515 failed to provision volume with StorageClass "mysc": rpc error: code = Internal desc = context deadline exceeded (Client.Timeout exceeded while awaiting headers)

• If the PVC is in the **Pending** state due to cause 5, contact Huawei engineers.

----End

9.8 When a Pod Is Created, the Pod Is in the ContainerCreating State

Symptom

A Pod is created. After a period of time, the Pod is still in the **ContainerCreating** state. Check the log information (for details, see **9.1 Viewing Log Information**). The error message "Fibre Channel volume device not found" is displayed.

Environment Configuration

Kubernetes version: 1.13 or later

Root Cause Analysis

This problem occurs because residual disks exist on the host node. As a result, disks fail to be found when a Pod is created next time.

Solution or Workaround

- **Step 1** Use a remote access tool, such as PuTTY, to log in to any master node in the Kubernetes cluster through the management IP address.
- **Step 2** Run the following command to query information about the node where the Pod resides.

kubectl get pod -o wide

NAME READY STATUS RESTARTS AGE IP NODE NOMINATED NODE

READINESS GATES

mypod 0/1 ContainerCreating 0 51s 10.244.1.224 node1 <none> <none>

- **Step 3** Delete the Pod. For details, see **6.3.2 Deleting a Pod**.
- **Step 4** Use a remote access tool, such as PuTTY, to log in to the *node1* node in the Kubernetes cluster through the management IP address. *node1* indicates the node queried in **Step 2**.
- **Step 5** Clear the residual drive letters. For details, see **Solution or Workaround**.

----End

10 Appendix

10.1 Example ALUA Configuration Policy of OceanStor V3/V5 and OceanStor Dorado V3

10.2 Example ALUA Configuration Policy of OceanStor Dorado 6.x

10.3 Example ALUA Configuration Policy of Distributed Storage

10.1 Example ALUA Configuration Policy of OceanStor V3/V5 and OceanStor Dorado V3

Example 1: The configuration file content is as follows:

If the host name is **node1**, both of the preceding ALUA configuration sections can be used to configure initiators. According to the configuration policy rules in **7.4.1**Configuring ALUA for OceanStor V3/V5 and OceanStor Dorado V3, the priority of the second configuration section (where HostName is **node1**) is higher than that of the first configuration section (where HostName is *).

Example 2: The configuration file content is as follows:

If the host name is **node6**, both of the preceding ALUA configuration sections can be used to configure initiators. According to the configuration policy rules in **7.4.1 Configuring ALUA for OceanStor V3/V5 and OceanStor Dorado V3**, select the first ALUA configuration section to configure initiators.

Example 3: The configuration file content is as follows:

According to the configuration policy rules in **7.4.1 Configuring ALUA for OceanStor V3/V5 and OceanStor Dorado V3**: For host **node1**, select the first ALUA configuration section to configure initiators. For host **node10**, select the second ALUA configuration section to configure initiators. A matches the beginning of a character string, and \$ matches the end of a character string.

10.2 Example ALUA Configuration Policy of OceanStor Dorado 6.x

Example 1: The configuration file content is as follows:

If the host name is **node1**, both of the preceding ALUA configuration sections can be used to configure initiators. According to the configuration policy rules in **7.4.2 Configuring ALUA for OceanStor Dorado 6.x**, the priority of the second configuration section (where **HostName** is **node1**) is higher than that of the first configuration section (where **HostName** is *).

Example 2: The configuration file content is as follows:

If the host name is **node6**, both of the preceding ALUA configuration sections can be used to configure initiators. According to the configuration policy rules in **7.4.2 Configuring ALUA for OceanStor Dorado 6.x**, select the first ALUA configuration section to configure initiators.

Example 3: The configuration file content is as follows:

According to the configuration policy rules in **7.4.2 Configuring ALUA for OceanStor Dorado 6.x**: For host **node1**, select the first ALUA configuration section to configure initiators. For host **node10**, select the second ALUA configuration section to configure initiators. ^ matches the beginning of a character string, and \$ matches the end of a character string.

10.3 Example ALUA Configuration Policy of Distributed Storage

Example 1: The configuration file content is as follows:

If the host name is **node1**, both of the preceding ALUA configuration sections can be used to configure initiators. According to the configuration policy rules in **7.4.3**Configuring ALUA for Distributed Storage, the priority of the second configuration section (where **HostName** is **node1**) is higher than that of the first configuration section (where **HostName** is *).

Example 2: The configuration file content is as follows:

If the host name is **node6**, both of the preceding ALUA configuration sections can be used to configure initiators. According to the configuration policy rules in **7.4.3 Configuring ALUA for Distributed Storage**, select the first ALUA configuration section to configure initiators.

Example 3: The configuration file content is as follows:

According to the configuration policy rules in **7.4.3 Configuring ALUA for Distributed Storage**: For host **node1**, select the first ALUA configuration section to configure initiators. For host **node10**, select the second ALUA configuration section to configure initiators. ^ matches the beginning of a character string, and \$ matches the end of a character string.