
Instructions for uploading an IFC model to the BIM Server

Authorship

Update: Dr. Léon olde Scholtenhuis (<u>I.I.oldescholtenhuis@utwente.nl</u>)
First version: Prof. Timo Hartmann (TU Berlin)

1. Export a BIM into ifc format from Revit




2. Select 'modify setup', <In-session setup>.

Mind the following settings in GENERAL:


Select IFC version 2x3 coordination view

Select the option 'Split Walls, Columns, Ducts by level'




Mind the following settings in PROPERTY SETS:

Select Export Base Quantities



- 3. OK/Export
- 4. Leave/Close Revit
- 5. Open your browser and go to bim.utwente.nl:8080

6. Click bimviews, you will then see the following page:



- 7. If you are connecting the first time, you can request a new password:
 - a. Enter your user name (it is the Email address that you use on blackboard) and select 'Reset Password.

Password


Reset password

Remember me


- b. Use the link in the Email that you receive from the bimserver to select a password
- 8. Log into the bimserver user interface using your email address and your password.

Password

- 9. You should see one project named with your first name. Select this project.
- 10. Click on the arrow to the right of the project name and select 'Checkin'



11. Select the exported ifc project (the file you saved in Revit).



12. Check-in the new revision (this is your exported IFC file from Revit). Your project is now checked-in and you can browse the ifc model uploaded using the 'Browse' function or see in the 3D Viewer (turn visibility on first – see orange circle in figure below):

