
## <u>Installing ESP32 Add-on in</u> <u>Arduino IDE</u>

To install the ESP32 board in your Arduino IDE, follow these next instructions:

1. In your Arduino IDE, go to File> Preferences






2. Enter the following into the "Additional Board Manager URLs" field:

https://raw.githubusercontent.com/espressif/arduino-esp32/ghpages/package\_esp32\_index.json


Then, click the "OK" button:




**Note:** if you already have the ESP8266 boards URL, you can separate the URLs with a comma as follows:

https://raw.githubusercontent.com/espressif/arduino-esp32/gh-pages/package\_esp32\_index.json, http://arduino.esp8266.com/stable/package\_esp8266com\_index.json

3. Open the Boards Manager. Go to **Tools** > **Board** > **Boards Manager...** 




4. Search for **ESP32** and press install button for the "**ESP32** by **Espressif Systems**":



5. That's it. It should be installed after a few seconds.

ع



## **Testing the Installation**

Plug the ESP32 board to your computer. With your Arduino IDE open, follow these steps:


1. Select your Board in Tools > Board menu (in my case it's the  $DOIT\ ESP32\ DEVKIT\ V1)$ 

🥯 sketch\_dec12a | Arduino 1.8.5 File Edit Sketch Tools Help Auto Format Ctrl+T Archive Sketch sketch\_dec12; Fix Encoding & Reload 1 void se Serial Monitor Ctrl+Shift+M // pi Serial Plotter Ctrl+Shift+L un once: 3 WiFi101 Firmware Updater 4 } Board: "DOIT ESP32 DEVKIT V1" 5 Adafruit ESP32 Feather Flash Frequency: "80MHz" 6 void lo NodeMCU-32S Upload Speed: "921600" // pi MH ET LIVE ESP32DevKIT Core Debug Level: "None" MH ET LIVE ESP32MiniKit Port: "COM4" 9 } ESP32vn IoT Uno Get Board Info DOIT ESP32 DEVKIT V1 Programmer: "AVRISP mkll" OLIMEX ESP32-EVB Burn Bootloader **OLIMEX ESP32-GATEWAY** ThaiEasyElec's ESPino32 M5Stack-Core-ESP32 Heltec\_WIFI\_Kit\_32 Heltec\_WIFI\_LoRa\_32

2. Select the Port (if you don't see the COM Port in your Arduino IDE, you need to install the <u>CP210x USB to UART Bridge VCP Drivers</u>):


ESPectro32

Microduino-CoreESP32



2

3. Open the following example under File > Examples > WiFi (ESP32) > WiFiScan



4. A new sketch opens in your Arduino IDE:

```
o WiFiScan | Arduino 1.8.5
File Edit Sketch Tools Help
WiFiScan
 2 * This sketch demonstrates how to scan WiFi networks.
 3 * The API is almost the same as with the WiFi Shield library,
 4 * the most obvious difference being the different file you need to include:
 5 */
 6 #include "WiFi.h"
 8 void setup()
9 {
10
       Serial.begin(115200);
11
      // Set WiFi to station mode and disconnect from an AP if it was previously
      WiFi.mode(WIFI STA);
      WiFi.disconnect();
15
      delay(100);
16
       Serial.println("Setup done");
17
18 }
19
20 void loop()
```

5. Press the **Upload** button in the Arduino IDE. Wait a few seconds while the code compiles and uploads to your board.



6. If everything went as expected, you should see a "**Done uploading.**" message.

```
Done uploading.

Writing at 0x00050000... (89 %)

Writing at 0x00054000... (94 %)

Writing at 0x00058000... (100 %)

Wrote 481440 bytes (299651 compressed) at 0x00010000 in 4.7 secon

Hash of data verified.

Compressed 3072 bytes to 122...

Writing at 0x00008000... (100 %)

Wrote 3072 bytes (122 compressed) at 0x00008000 in 0.0 seconds (e

Hash of data verified.


Leaving...

Hard resetting...
```

7. Open the Arduino IDE Serial Monitor at a baud rate of 115200:



8. Press the ESP32 on-board **Enable** button and you should see the networks available near your ESP32:




**Troubleshooting** 

If you try to upload a new sketch to your ESP32 and you get this error message "A fatal error occurred: Failed to connect to ESP32: Timed out... Connecting...". It means that your ESP32 is not in flashing/uploading mode.

Having the right board name and COM por selected, follow these steps:

Hold-down the "BOOT" button in your ESP32 board



Press the "Upload" button in the Arduino IDE to upload your sketch:



• After you see the "Connecting...." message in your Arduino IDE, release the finger from the "BOOT" button:

æ

After that, you should see the "Done uploading" message

That's it. Your ESP32 should have the new sketch running. Press the "**ENABLE**" button to restart the ESP32 and run the new uploaded sketch.

You'll also have to repeat that button sequence every time you want to upload a new sketch. But if you want to solve this issue once for all without the need to press the **BOOT** button, follow the suggestions in the next guide:

 [SOLVED] Failed to connect to ESP32: Timed out waiting for packet header

If you experience any problems or issues with your ESP32, take a look at our in-depth <u>ESP32 Troubleshooting Guide</u>.

ع