


## **Project Target**

- Build simple module to control lights and shutters
- Must be small enough to retrofit an existing 220V electrical system (unterputz)
- Able to work standalone
- Or work centralized but then in a wireless fashion
- Upgradable over-the-air
- Remote diagnostic and test functionality
- Secure when connected wireless
- Scalable software framework for different configurations
- Low cost

# Module Structure (1/5)




### Module Structure (2/5)

- Makes use of ESP8266 module on Wemos D1 mini subassembly
  - Easy due to built-in USB interface and 5V-to-3V3 convertor
  - Doesn't require implicit boardspace due to it's leveraged mounting
  - Has Wifi client to connect to remote access point
    - Not required if you want to operate the module in standalone mode
    - Else configure SSID + security method + secret
  - Has Wifi AP accessible @ 192.168.4.1
    - Can be secured with password and/or turned off
    - If Wifi client is disabled or fails, the Wifi AP will be turned on at module boot
  - Configuration/setup can be done via HTTP
  - 9 GPIO's used
- Controllable objects included are:
  - · 4 low-voltage inputs supporting normal-open push-buttons that connect to ground when pressed
  - 4 high-voltage (220V) SSR outputs upto 1A
- System LED
  - Helps to locate a module
- 3D printed protective cover
  - Against accidental touching 220V contacts
  - For mounting in installation box
  - For attaching Niko blind frontplate

# Module Structure (3/5)

Functional Block Diagram



# Module Structure (4/5)


PCB edition 01







# Module Structure (5/5)

PCB edition 02









## Features (1/3)

- Supported emulations:
  - Output
- drives 4 individual outputs
- dedicated set of commands: off, on, toggle, ontimed, ...
- Shutter
- combines 2x2 outputs to drive 2 shutter/jalousie
- dedicated set of commands: stop, up, down, ...
- Supported modes:
  - Standalone
    - inputs control outputs locally
    - requires no extra infrastructure to operate
    - emulator has fixed logic onboard to link input events to output commands
  - MQTT
- connects to MQTT broker, so extra infrastructure is required
- allows remote operation via MQTT protocol
- Both
- combines standalone and MQTT modes
- Safe mode:
  - To be defined

### Features (2/3)

#### MQTT Client

- Not possible if there is no Wifi connection
- Not required if you want to operate the module in standalone mode
- Else configure broker IP address/port, optional username/password, optional <node-id> override
  - default <node-id> is module chipid, i.e. esp12345
  - structured <node-id> can be <location>/<floor>/<number>
- Requires an MQTT broker to be operational (i.e. Mosquitto on Synology NAS)
- Uses a request only model
- Is low on memory overhead for the system
- Also used for automatic testing
- Once connected to broker
  - the module will subscribe to command topic
    <node-id>/cmd/#
  - the module will publish it's topology and version <node-id>/boo/hw=<topo>, <node-id>/boo/<sw>=<version>
- In general
  - incoming publish messages will be handled by emulator <node-id>/cmd/<object>=<cmd> \*[.<parm>]
  - object generated events are published to broker<node-id>/evt/<object>=<event>
  - object status requests are published to broker <node-id>/sta/<object>=<state>In general
- Event/status formats
  - can be textual (default) i.e. myHouse/3/0/out0=on
  - can be numerical i.e. myHouse/3/0/out0=1

## Features (3/3)

#### HTTP Server

- Not possible if there is no Wifi connection
- Uses a request-response model
- · Has more overhead on memory for the system, can drain the system
- · Main task is to configure the module with a browser
- Also allows to send commands to the controllable objects using structured URL
  - URL: http://<ip-address>/ats?ccmd=<object>.<cmd> \*[.<parm>] [; <object>.<cmd> \*[.<parm>]]
  - command results are sent in HTTP response in terse mode
  - also used for automatic testing

#### Telnet Server

- Not possible if there is no Wifi connection
- Mainly used for remote diagnostic/support

### **Terminology**


- The module contains controllable objects
  - in0..in3
  - out0..out3 (or out0..out1 for shutter emulation)
- Objects accept commands
  - That instructs it to do something and update it's state

```
MQTT <node-id>/cmd/<object>=<cmd>*[.<parm>] *[; <cmd> *[.<parm>]]
```

- HTTP http://<ip-address>/ats?ccmd=<object>.<cmd> \*[.<parm>] \*[; <object>.<cmd> \*[.<parm>]]
  - returns current state in numerical terse format, i.e. '0', '1', '2'
  - response of multiple commands will be concatinated, i.e. '0;1'
- When an object changes state
  - It will raise an event which will be distributed depending on configuration
  - To output objects as per emulation
  - To MQTT <node-id>/evt/<object>=<event>
  - Not to HTTP !!!
- A status command will report an objects state regardless of change
  - To MQTT <node-id>/sta/<object>=<state>
  - To HTTP http://<ip-address>/ats?ccmd=<object>.status
    - returns current state in numerical terse format, i.e. '0', '1', '2'
    - response of multiple commands will be concatinated, i.e. '0;1'

## Inputs (1/2)

- Input changes are validated with an adjustable decounce period (Td), default=100ms
- Validated changes are fed into a time based state machine to generate events



### Supported events

- ingt0 (2)	input was initially closed
<ul><li>outlt1 (3)</li></ul>	input was opened after less than 1 second

- ingt1 (4) input was closed for more than 1 second

- outgt1 (5) input was opened after more than 1 but less than 2 seconds

- ingt2 (6) input was closed for more than 2 seconds

- out (7) input was opened after more than 2 seconds

## Inputs (2/2)

### Supported commands

- status return current state of input, 0=out|1=in

- ingt0 simulate input closed initially

outlt1 simulate input opened after less than 1 second
 ingt1 simulate input closed for more than 1 second

- outgt1 simulate input opened after more than 1 but less than 2 seconds

ingt2 simulate input closed for more than 2 seconds
 out simulate input opened after more than 2 seconds
 debounce [.<time>] get or set debounce time (Td) 0..3600000 ms

#### Parameters

- time 0-3600000 ms

### Outputs - Output Emulation (1/2)

### Supported commands

- status return current status of output, 0=off|1=on

on turn output onoff turn output off

onlocked turn output on and lock itofflocked turn output off and lock it

toggle output between off and on

unlock output, all commands will be executed after this

ondelayed.<delay> turn output on after <delay> secondsoffdelayed.<delay> turn output off after <delay> seconds

ontimed.<run> turn output on during <run> seconds, then back offofftimed.<run> turn output off during <run> seconds, then back on

toggledelayed.<delay> toggle output after <delay> seconds, lock it till command done
 toggletimed.<run> toggle output for <run> seconds, lock it till command done
 lock output, no command exept unlock will be executed

locktimed.<run> lock output for <run> seconds

timeset.<run> set running time again to <run> secondstimeadd.<run> add <run> seconds to running time

timeabort abort running time without unlocking or final action, will leave output as-is !!!
 blink alternate output between on and off with a 1s cadence, all outputs are synched

blinktimed.<run> blink output for <run> seconds

- emultime <def-run> set default run time for standalone emulation

# Outputs - Output Emulation (2/2)

Supported events

off (0)output was turned offon (1)output was turned on

Parameters

delay 1-3600 secondsrun, def-run 1-3600 seconds

### Outputs - Shutter Emulation (1/2)

- Uses the concept of priority level (0=highest, 5=lowest) and lock (0=no-lock, 1=lock)
  - When a command of a given level sets the lock, any lower level commands are refused
  - Useful for protecting extending sunblinds against strong winds or rain with a sensor locking the blinds in prio 0 or 1
  - Mask versus level: a priority mask has a bit per level, level 0=0x01, 1=0x02, 2=0x04, 3=0x08, 4=0x10, 5=0x20

#### Supported commands

status
 return current status of shutter, 0=stop|1=up|2=down

stop.<level> stop shutter

toggleup.<level>.<lock>.<run>toggle between stop and up for given run timetoggle between stop and down for given run time

- up.<level>.<lock>.<run> move shutter up for given run time

- down.<level>.<lock>.<run> move shutter down for given run time

tipup.<level>.<lock>.<run>tipdown.<level>.<lock>.<run>short move up to tip the lamello's on a jalousieshort move down to tip the lamello's on a jalousie

priolock.<mask> lock given levels, all non-locked levels remain operational

priounlock.<mask> unlock given levels

prioset.<mask> set given levels, only set level and higher levels remain operational

prioreset.<mask> reset given levels

delayedup.<level>.<lock>.<delay>.<run>delayeddown.<level>.<lock>.<delay>.<run>move shutter up for given run time after delaymove shutter down for given run time after delay

- tipdelayedup.<level>.<lock>.<delay>.<run>.<tip> move shutter up for given run time after delay, do reverse tip move

- tipdelayeddown.<level>.<lock>.<delay>.<run>.<tip> move shutter down for given run time after delay, do reverse tip move

- emultime <def-run> set default run time for standalone operation

## Outputs - Shutter Emulation (2/2)

### Supported Events

- upon (1)
- downon (2)
- upoff (3)
- downoff (4)

#### Parameters

- <level>
- <lock>
- <delay>
- <run>, <def-run>
- <tip>
- <mask>

shutter started moving up shutter started moving down shutter stopped moving up shutter stopped moving down

0 (highest) - 5 (lowest)

0 (no lock) – 1 (lock)

0-3600 seconds

1-3600 seconds

0-3600 1/10<sup>th</sup> seconds

bit per level, 0=0x01, 1=0x02, 2=0x04, 3=0x08, 4=0x10, 5=0x20

### System

### Supported commands

ping
 will blink the LED for about 10 seconds

version get current sw version

memory
 get current memory statistics

restart.ack restart module

loglevel [.<level>] get or set loglevel where level can be decimal or hexadecimal

emul [.<emul>]get or set emulation, 1=output | 2=shutter

mode [.<mode>]get or set mode, 1=standalone|2=MQTT|3=both

efmt [.<format>]get or set MQTT event formatting, 1=numerical|2=textual

lock [.<lock>]
 get or set lock state of system commands, when locked only get commands and ping will work

### Supported events

version4.x.y.z

memory <bytes>

• restart 1

loglevel %d or 0x%08X

emul 1-2 or output|shutter

mode
 1-3 or standalone|mqtt|both

efmt 1 or textuallock 0-1 or off|on

### Standalone Mode

- Allows module to work without further infrastructure by using input events to control outputs
- Emulation=output

```
    in%.outlt1 -> out%.toggle
    in%.ingt2 -> out%.blink (if <def-run> == 0)
    in%.ingt2 -> out%.blinktimed <emul-time> (if <def-run>!= 0)
```

Emulation=shutter

```
in0.ingt0/in1.ingt0 -> out0.stop
in0.ingt1 -> out0.up. <emul-time>
in1.ingt1 -> out0.down. <emul-time>
in2.ingt0/in3.ingt0 -> out1.stop
in2.ingt1 -> out1.up. <emul-time>
in3.ingt1 -> out1.down. <emul-time>
```


## Outstanding

- Additional timer or clock objects
- Compact mode
  - reduce required pushbuttons
  - i.e. outlt1 -> out0.toggle, ingt2 -> out1.toggle
- Variants
  - DIN rail module with 8-16 outputs...
- Telnet command interface
- Enhance shutter logic
  - introduce clocks
  - couple to internet dawn/sunset markers
- Check overall handling of Wifi / broker connection vs mode




# Niko Integration: Disassembly Blindplate/4-Fold Button












# Niko Integration: Assembly Blindplate/4-Fold Button









## Wemos D1 Mini (1/2)


ESP8266 based







BOTTOM



## Wemos D1 Mini (2/2)

