



ZTZT1P79MP

Engine Maintenance Manual

Foreword

All the materials, illustrations, photos, etc. collected in this manual are compiled according to the latest product of ZT1P79MP Euro V+ . However, due to continuous improvement of products and changes in other aspects, there may be some inconsistencies between your motorcycle and this manual. For parts upgrades, please refer to the part codes on the official website of ZONTES, which will not be listed in detail in this manual; if the names of parts in this manual are inconsistent with the official website of ZONTES, the official website of ZONTES shall prevail.

If some contents of this manual are insufficient, please refer to the "Driver's Manual" attached to the vehicle. You can download the latest version of the driver's manual as a PDF in the corresponding model introduction on the ZONTES official website.



©Guangdong Tayo Motorcycle Technology Co., Ltd.
All rights reserved

Notice to users

This manual is compiled by Guangdong Tayo Motorcycle Technology Co., Ltd. and is used to guide dealers or service personnel. This manual cannot provide more detailed knowledge about motorcycles, and is only for reference for maintenance. If you do not have the corresponding knowledge such as electrician, machine repair, etc., improper assembly or maintenance failure may occur during repair.

If you need to clean or wash the body parts of this vehicle, you should use neutral motorcycle wash liquid or tap water or diesel oil, kerosene, etc. Acidic or alkaline motorcycle wash liquid will cause irreversible corrosion to the surface paint, electroplated surface, anodized surface, etc. of parts; gasoline will cause premature aging or hardening of sealants, gaskets, rubber parts, etc., reducing the service life. It should be wiped with a non-woven cloth that will not leave residues. Ordinary rags may leave rags or wool that will affect assembly or cause other adverse effects.

Our company tries to update this manual in a timely manner after product changes.

The following are the meanings of the icons marked in this manual:

	Failure to observe will cause personal injury or death of the driver or maintenance personnel; or cause serious damage to parts and shorten the service life, etc.
	Failure to comply may result in personal injury or death of the driver or maintenance personnel; or damage to parts, abnormalities, etc.
	Failure to observe the warning will cause personal injury to the driver or maintenance personnel; or matters requiring special attention during disassembly and assembly
	Indicates that there is a requirement for torque
	Indicates that the part needs to be replaced after disassembly
	Indicates that the location needs to be measured

Table of contents

Foreword.....	2
Notice to users	3
Table of contents	4
Lubrication system.....	7
1.Diagram of lubrication system.....	7
2. Maintenance information	9
General information.....	9
Specification.....	9
Torque value	9
Tool	9
3. Common failure phenomenon/troubleshooting	9
3.1. Engine oil level is too low.....	9
3.2. The oil is dirty.....	9
4. Oil pump.....	9
Disassemble	9
Install.....	10
Disassembly/installation	11
Cylinder head cover	13
1. System components.....	13
2. Maintenance information	13
General information.....	13
Tool	14
3. Common fault phenomena/troubleshooting.....	14
4. Cylinder head cover	14
Disassembly	14
Check.....	14
Installation	14
Cylinder head	15
1. System components.....	15
2. Maintenance information	16
General information.....	16
Bolt torque value	16
Specification.....	17
ZT1P79MP standard value of engine valve clearance.....	17
Tool	17
3. Fault phenomenon/fault analysis	18
3.1. When the engine starts, the idling speed is unstable, or it is difficult to start	18
3.2. After the engine is running, there is abnormal sound	18
3.3. After the engine heats up, the exhaust gas is abnormal	18
3.4. The crankshaft rotates without cylinder pressure or with very little cylinder pressure.....	18
4. Cylinder compression test.....	18
Failure analysis:.....	18
5. Cylinder head	19
Cylinder head removal	19
Cylinder Head Disassembly	20
Inspection of cylinder head parts:	22
Cylinder head	24
Cylinder head installation	26
6. Guide bar.....	27
Guide bar removal	27
Guide bar installation.....	28
7. Tension strip.....	28
Tension strip removal	29
Examine.....	29

Tension bar installation.....	29
8. Tensioner	30
Tensioner Removal	30
Examine.....	30
Tensioner installation	30
Cylinder, piston	31
1. System components.....	31
2. Maintenance information	32
General information.....	32
Specification.....	32
Tool	32
3. Troubleshooting.....	33
4. Cylinder	33
Disassemble	33
Examine.....	34
Install.....	34
Examine.....	35
5. Piston	36
Disassemble	36
Install.....	38
Left crankcase cover, continuously variable clutch sub-assembly.....	41
1. System components.....	41
Parts information.....	42
Torque value	42
2. Maintenance information	42
General information.....	42
Tool	42
3. Common failure phenomenon/troubleshooting	43
3.1. The engine can be started, but the rear wheel does not turn when the throttle is added.....	43
3.2. The engine stalls or lacks power.....	43
3.3. Insufficient high-speed power.....	43
3.4. When the engine is idling normally, the rear wheels rotate rapidly.....	43
4. Left crankcase cover	43
Disassemble	43
Examine.....	44
Install.....	44
5. CVT clutch sub-assembly.....	45
Disassemble	45
Examine.....	45
Assembly.....	45
6. Inspection of parts and service limit values.....	47
Right crankcase cover, magneto	50
1. System components.....	50
Parts information.....	50
2. Repair information.....	51
Tool	51
3. Right crankcase cover / magneto stator	52
Disassemble	52
Install.....	53
4. Magneto rotor.....	55
Disassemble	55
Install.....	56
5. Water pump	57
Disassemble	57
Examine.....	57
Install.....	57
Gearbox.....	60
1. System components.....	60

Parts information	60
2.Maintenance information.....	61
General information.....	61
3. Fault phenomenon/fault analysis	61
4. Disassembly and decomposition of the gearbox	61
5. gearbox gear, bearing inspection.....	63
Gearbox cover bearing and oil seal inspection	63
Inspection of left crankcase bearing and oil seal.....	63
Drive shaft, output shaft, duplex gear inspection.....	63
6. Gear box assembly	64
 Crankcase.....	65
1. System components.....	65
Parts information	65
Torque value	66
2. Maintenance information.....	66
General information.....	66
Specification.....	67
Tool	67
3. Common failure phenomenon/troubleshooting	67
3.1. Abnormal noise	67
3.2. The crankshaft does not rotate.....	67
4. The decomposition of the crankcase	67
4.1. Remove the timing chain	67
4.2. Remove the tension strip	67
4.3. Disassembly and assembly of the guide bar pressure plate	68
4.4. Disassembly and assembly of the trapezoidal coarse filter	68
4.5. Disassemble the crankcase	68
4.6. Check the crankshaft.....	70
5. Assembly of the crankcase.....	71
6. Left and right crankcase suspension disassembly, inspection	73
Hanging inspection.....	73
Hanging removal	73
Hanging installation	73
7.Fine filter.....	74
Disassembly, installation.....	74
8. Hydraulic switch.....	74