

# **ZT1P52MI**

# **Engine maintenance manual**

2023-04-01

## Foreword

All the materials, illustrations, photos, etc. Collected in this manual are compiled according to the latest product of ZT1P52MI Euro IV. However, due to continuous improvement of products and changes in other aspects, there may be some inconsistencies between your motorcycle and this manual. For parts upgrades, please refer to the part codes on the official website of ZONTES which will not be listed in detail in this manual; if the names of parts in this manual are inconsistent with the official website of ZONTES, the official website of ZONTES shall prevail.

If some contents of this manual are insufficient, please refer to the " driver's manual" attached to the motorcycle. You can download the latest version of the driver's manual as a PDF in the corresponding model introduction on the ZONTES official website.



©Guangdong Tayo Motorcycle Technology Co., Ltd.  
All rights reserved

## User Notice

This manual is compiled by Guangdong TAYO Motorcycle Technology Co., Ltd. And is used to guide dealers or service personnel. This manual cannot provide more detailed knowledge about motorcycles, and is only for reference for maintenance. If you do not have the corresponding knowledge such as electrician, machine repair, etc., improper assembly or maintenance failure may occur during repair.

If you need to clean or wash the body parts of this motorcycle, you should use neutral car wash liquid or tap water or diesel oil, kerosene, etc. Acidic or alkaline car wash liquid will cause irreversible corrosion to the surface paint, electroplated surface, anodized surface, etc. Of parts; gasoline will cause premature aging or hardening of sealants, gaskets, rubber parts, etc., reducing the service life. It should be wiped with a non-woven cloth that will not leave residues. Ordinary rags may leave rags or wool that will affect assembly or cause other adverse effects.

Our company tries to update this manual in a timely manner after product changes.

The following are the meanings of the icons marked in this manual:

|  |  |
|--|--|
|  | Failure to comply will result in personal injury or death of the driver or maintenance personnel ; or serious damage to spare parts , shortened service life, etc. |
|  | Failure to comply may result in personal injury or death of the driver or maintenance personnel ; or damage to spare parts , abnormality, etc.                     |
|  | Failure to follow the warnings will result in personal injury to the driver or maintenance personnel ; or matters requiring special attention during disassembly   |
|  | Indicates that there is a requirement for torque   |
|  | Indicates that the part needs to be replaced after disassembly   |
|  | Indicates that the location needs to be measured   |

# Table of contents

|   |    |
|---|----|
| Table of contents .....   | 4  |
| Spark plug .....  | 6  |
| System components .....   | 6  |
| Cylinder compression test .....                                       | 6  |
| Water pump .....  | 7  |
| System components .....   | 7  |
| Cylinder head cover, cylinder head .....                              | 9  |
| System components .....   | 9  |
| Cylinder head cover .....   | 11 |
| Cylinder head .....   | 12 |
| Camshaft .....  | 13 |
| Guide bar .....   | 16 |
| Tensioner .....   | 17 |
| Cylinder, piston .....  | 18 |
| System components .....   | 18 |
| Cylinder, piston .....  | 19 |
| Electric starter box cover, starter mechanism, timing chain .....     | 21 |
| System components .....   | 21 |
| Electric starter box cover .....                                      | 22 |
| Start agency .....  | 23 |
| Timing chain .....  | 23 |
| Oil pump - right crankcase cover .....                                | 24 |
| System components .....   | 24 |
| Right crankcase cover .....   | 25 |
| Oil pump .....  | 25 |
| Oil filter .....  | 26 |
| System components .....   | 26 |
| Oil filter .....  | 27 |
| Magneto stator, rotor .....   | 27 |
| System components .....   | 27 |
| Magneto rotor .....   | 28 |
| Magneto stator .....  | 29 |
| Left crankcase cover, continuously variable clutch sub-assembly ..... | 30 |
| System components .....   | 30 |
| Left crankcase cover .....  | 30 |
| Continuously variable clutch sub-assembly .....                       | 31 |
| Gearbox .....   | 33 |
| System components .....   | 33 |
| Gear case cover .....   | 35 |
| Thermostat, radiator , fan case cover .....                           | 38 |
| System components .....   | 38 |
| Thermostat, radiator, fan case cover .....                            | 39 |
| Crankcase .....   | 40 |

|                         |    |
|-------------------------|----|
| System components ..... | 40 |
| Crankcase .....         | 40 |