## CSE3103 Microprocessor and Microcontroller: PWM and I2C

Dr. Mosaddek Tushar, Professor

Computer Science and Engineering, University of Dhaka

May 20, 2024



## Contents

- Documents and Video on I2C
- 2 Timer use as delay generator
- $\ \ \, \ \,$   $I^2C$  Serial Communication
  - Transfer sequence diagram for slave transmitter
  - I2C Interrupts
- 4 PWM Pulse-width modulation
  - Duty cycle and frequency
  - Steps for the PWM in STM32
  - Decide Frequency and Duty Cycle



## Documents and Video on I2C

Must See these videos (Click on the text below)

- What is I2C, Basics for Beginners
- Inter-Integrated Circuit (I2C) Basics
- 3 I2C introduction: The protocol
- Introduction to I2C: Advanced topics
- STM32F4 I2C Using Registers MAster Mode
- An introduction to the I2C Protocol for the ARM STM32 Miorcocontrollers
- **○** I2C Circuit and Initialization ARM STM32
- **8** Use I2C to Read a Device's Register
- I2C to Read a Device's Register Part 2
- I<sup>2</sup>C (I2C) Bit Banging
- I2C Bus Communication Protocol Tutorial with Example



## Timer as Delay Function: Example

- Enable timer clock:  $RCC \rightarrow APBxENR$ 
  - ▶ enable timer x on APBxENR register; See bus configuration for timer
- Set the prescaler and ARR
  - ►  $TIMx \rightarrow PSC = 90-1$ ; (stm32 will add '1')
  - ightharpoonup TIMxightharpoonupARR = 0xffff (maximum value). You can use different value.
- Enable the Timer counting and wait for update flag to ready:
  - ightharpoonup TIMx $\rightarrow$ CR1;
  - ► check TIMx→SR is timer ready?

#### Now you can create delay

Let the input clock is 90MHz and we set prescaler PSC = 89. Then each count takes – how many  $\mu$ S?


$$1 \ count \equiv \frac{1}{10^6} S \equiv 1 \mu S$$

Now we can compare CNT value and determine the delay.



## $I^2C$ Serial Communication

- Also known as Inter-Integrated Circuit (IIC) Std. 100MHz, fast upto 400 MHz
- It can connect multiple slaves to a single master (Master can send to multiple slaves)
- Multiple masters to a single slave (Masters read data from a single slave)
- SDA Serial Data Line (Bi-directional), used to transfer address, ACK and data or receive data/ACK
- SCL Serial Clock Line (bi-directional); Send Sender (master) clock
- Transmission Mode
  - ▶ Slave transmitter
  - ► Slave receiver
  - ► Master transmitter
  - Master receiver





## Transfer sequence diagram for slave transmitter

- Who is master? Master send the START and STOP condition
- Master send 7/10 bit address plus LSB set to '1' for reading
- Receiver send the ACK Here it is master
- A high to low transition of SDA at SCL high is the start condition
- A low to high transition of SDA at SCL high defines STOP condition





Figure 1: I2C message & Restart

## Master Always initiate the transmission and reception






Figure 2: Start and Stop Signal I2C




#### Slave Transmitter Contd.

#### Slave ...

- Set input clock in I2C\_CR2
- As soon as the start condition is detected
- Receive address from the SDA line to the shift register
- Compare the address of interface (ORA1) and ORA2 (for dual)
- Slave wait for another start if no address match found
- If address matched then send ACK to master
- Clear (wait for) ADDR flag and send data to master. Slave stretches SCL until ADDR flag is not clear
- The slave copy the data to DR register to send
- A end of byte transfer is detected by BTF in SR1 register

#### Slave Receiving and Transmitting



#### Slave Receiver

#### Slave Receiver

- Master send address (LSB of 8-bit or 10-bit is set to '0')
- Slave send ACK if ACK bit in I2C\_CR1 is set
- After receiving the address mactched and ADDR bit cleared slave receives byte at DR register from SDA
- An acknowledge ACK is sent if ACK in CR1 is set
- RXNE bit is set if data available in Data Register (interrupt?)
- BTF bit is set before the end of the next byte reception and until DR register is not read and RXNE is set
- BTF is cleared by a read from the I2C\_DR register, stretching SCL low




Figure 3: Slave Receiver

Closing Connection/End a Session: After send all data master send a STOP Condition (generated); STOPF bit is set and cleared by reading SR1 register for the next transmission

#### I2C Master Mode

#### I2C Master mode

- Initiate data transfer and generate clock
- A serial transmission begin with START condition and End with STOP condition
- Start condition generated on the bus with a START-bit
- Master mode required following sequence of set up
  - ▶ Program the peripheral input clock in I2C\_CR2 Register in order to generate correct timings
  - ► Configure the clock control registers
  - ▶ Configure the rise time register
  - ▶ Program the I2C\_CR1 register to enable the peripheral
  - ▶ Set the START bit in the I2C\_CR1 register to generate a Start condition



## Configuration I2C – master mode

- Enable Clock for I2C and GPIO port
  - ▶ I2C1 and GPIOB (pin 8& 9) SDA and Clock: Set APB1ENR bit-21 for I2C1; AHB1ENR bit-1 for GPIOB
- GPIOB pin setting
  - ▶ Set GPIOB MODER bit-16 & 18 to alternate function for pin-8&9
  - ▶ OTYPER bit-8&9 set to '1' for open drain
  - ▶ Set OSPEEDR bit-16&18 to 3 for high speed
  - ▶ Set pull-up resistors for pin-8&9 [PUPDR] bit-16&18
  - ▶ Set alternate function (Datasheet: table-11 & reference manual) AFR[1] bit-0&4 to 4
- I2C1 Setting
  - ► Enable and Reset I2C1: Set '1' to I2C1\_CR1 bit 15 (enable) and '0' to bit-15 (reset)
  - ► Configure Input clock I2C1\_CR2 bit-0 set 8 for 8 MHz clock (max 50 MHz) APB1 max clock 45 MHz
  - ▶ Set I2C1 clock control register CCR [11:0](See Datasheet: table 61)

$$CCR = \frac{T_w(SCLH) + T_r(SCL)}{T_{pclk1}} \equiv \frac{4000 + 1000}{\frac{1}{45}} = 225$$
 (1)

► Set I2C1 TRISE[5:0] Register – clock rising time

$$T_{rise} = \frac{T_r(SCL)}{T_{pclk1}} + 1 = \frac{1000}{\frac{1}{45}} + 1 = 46 \tag{2}$$

► Enable the peripheral I2C1\_CR1, set bit-0



## Start, Stop, Send Address and Data, Receive

#### Start, Stop, Send Address and Data, Receive

- Start Condition
  - ► Set I2C1 CR1 bit-8 for start generation
  - ▶ Wait for Status register SR1 for SB bit set
  - ▶ Clear SB of SR1 and SR2 (busy) by reading
- Generate Stop Condition
  - ▶ Set bit-9 of CR1 register
- Send a data byte
  - ▶ Wait for TxE bit (7) in SR1 to set. It indicate DR is empty
  - ► Copy data byte to the DR register
  - ▶ Wait for BTF bit (2) of SR1 to set for end of the data byte transmission
- Send Slave Address
  - ▶ Copy the address to DR register (LSB 1 for reading or 0 for writing) receive or send data
  - ▶ wait for ADDR bit in SR1 not set; In slave it indicates address matched; Master mode transmission done
  - ▶ It will set if ACK not failed from a slave
  - clear SR1 and SR2 register
- Receive/Read data byte
  - ► Wait until RxNE is set
  - ▶ Copy data byte from data register i.e.,  $tmp=I2C1 \rightarrow DR$



## I2C Stop forever!! -Communicating and Interrupt

I2C Stop because of missing acknowledgment or missing data or address

- clock stretching waiting for data or ack
- Power on/off may not reset the status
- To reset alternate SDA for atleast 9 times. The slave will release the clock

#### I2C Interrupt

• See in the next slide




## I2C Interrupts

Interrupt event	Event flag	Enable control bit			
Start bit sent (Master)	SB				
Address sent (Master) or Address matched (Slave)	ADDR				
10-bit header sent (Master)	ADD10	ITEVFEN			
Stop received (Slave)	STOPF				
Data byte transfer finished	BTF				
Receive buffer not empty	RxNE	ITEVEEN and ITEUEEN			
Transmit buffer empty	TxE	ITEVFEN and ITBUFEN			
Bus error	BERR				
Arbitration loss (Master)	ARLO				
Acknowledge failure	AF				
Overrun/Underrun	OVR	ITERREN			
PEC error	PECERR				
Timeout/Tlow error	TIMEOUT	1			
SMBus Alert	SMBALERT				

Figure 4: I2C interrupt for successfull and error communication




## Use of I2C




#### PWM - Pulse-Width Modulation


#### PWM - Pulse-Width Modulation

- PWM is a way to control the analog device using digital output
- Generated by comparing triangular reference wave to a input value
- PWM consists two components
  - ▶ Duty cycle: How much power it dissipates
  - ► frequency: define how fast it complete a cycle



#### PWM and Triangular wave







## Duty cycle and frequency

Duty cycle D and frequency f of a signal are defined as,

$$D = \frac{t_{on}}{t_{on} + t_{off}} \quad \text{and} \quad f = \frac{1}{t_{on} + t_{off}}$$
 (3)

Let energy contained of every pulse is E is a constant,  $T = T_{on} + T_{off}$ ,  $\Delta t = T_{on}$ ; then the rate of energy flow in every pulse is,

#### Peak power:

$$P_{peak} = \frac{E}{\Delta t} \tag{4}$$

#### Average power

$$P_{avg} = \frac{E}{T} \tag{5}$$

Therefore,

$$P_{peak}\Delta t = P_{avg}T\tag{6}$$

Hence, the duty cycle can also be defined re-arranging (6),

$$Duty \ Cycle = \frac{\Delta t}{T} = \frac{P_{avg}}{P_{peak}} \tag{7}$$

## Steps for the PWM in STM32

- Decide the frequency and duty cycle
- Select the timer (Here TIM1)
- Choose the number of PWM output (channels) and Related GPIO pins (Data sheet Table 10)
  - ► TIM1\_CH1:PA8, TIM1\_CH2:PA9, TIM1\_CH3:PA10, TIM1\_CH4:PA11
- Set the prescaler PSC register
- Configure GPIO port for alternate function (AF1) data sheet Table 11
- Configure TIM1 (CR1, CCMRx, CCER, BDTR, CCRx)
- ARR Register
- for Advanced configuration use DMA really fun!!



#### STM32 Timer and PWM




Figure 5: Timer CKT

#### Register Set (Exact Match TIM1&TIM8)

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Re	Ren	Ren	Res	Res	Ren	CKD[1:0]		ARPE	CMS	S[1:0]	DIR	OPM	URS	UDIS	CEN
						rw	rw	rw	rw	rw	rw	rw	rw	rw	rw

Figure 6: Control Register TIM1/8 CR1

- CEN: Enable Counter, UDIS: Update Event Disable (overflow, underflow), URS: update request source (0: DMA, CNT overflow underflow; 1: )
- CMS:'00': Edge aligned mode (up or down count); '01': center aligned mode 1 (interrupt (IE) on counting down), '10': Center-aligned mode 2 (IE counting up), '11': Center-aligned mode 3 (IE counting up or down)
- OIR: up (0) or down (1) counter
- ARPE: Auto reload preload enable (not buffered or buffered)
- OPM: One pulse mode generate a single pulse and not stopped at update event (0), stopped at next update event



Figure 7: Edge and Center Aligned Mosaddek Tushar, CSE





## Decide Frequency and Duty Cycle

#### Decide Frequency and Duty Cycle

- Frequency determine the carrier of the signal for PWM or analog signal for control
- Frequency Requirement coming from use such as rpm to run a train, car, or lift (let us assume): 10 kHz
- Duty Cycle: How much output power is needed – torque (moment of force). Let us presume 30% of available
- Timer Counting UP, Down or both
- Select or Dynamically change the output comparator (CCRx)

• Generate the triggering point for the full analog cycle







#### Timer Selection

#### Timer Selection

- Advanced Timer (TIM1 & TIM8) and General Purpose Timer (TIM2 to TIM5)
  - ▶ Output Compare
  - ▶ PWM generation (Edge and Center-aligned Mode)
  - ▶ Complementary outputs with programmable dead-time
  - ▶ Using DMA or Interrupt Update: counter overflow/underflow, counter initialization, Trigger event
  - ► Available: 4-Channels (input and output)
  - ► Complementary output : TIM1 & TIM8
- General Purpose Timer (TIM9 to TIM12)
  - ▶ No DMA, only interrupt
  - ► Two input and output channel

For other Timer, see reference manual

We select Timer 1 (TIM1)




## Example 3-Phase PWM

#### The following information should be noted:

- Use GPIOA pins PA8, PA9, and PA10 for three-phase control.
- GPIOB pins PB13, PB14, and PB15 are complementary to the above pins.
- The CCR1, CCR2, and CCR3 values are crucial in the signal generation. These values are compared with the CNT (counter register) and are used to toggle the output, providing precise control over the signal generation process.
- You can adjust the CCRx values to change the duty cycles at each update event, allowing you to customize the signal output according to your specific requirements.
- To generate a signal output on PA8 (and complement PB13) with a 50% duty cycle, the ARR register should contain 999 (+1), and the CCR1 register value should be 500. Similarly, for a 75% duty cycle, the CCR1 value would be 750. These values are then loaded to CCR1 at the next update event, demonstrating the process of generating different duty cycles.
- The updates on CCRx are stored in the shadow register until the next update event occurs.
- By using PWM, you can create various signal patterns.
- The duty cycle regulates the power delivery to the output.





## Example

#### 3-Phase PWM example

```
void Config_TIM1(void){
RCC->APB2ENR |= 1<<0; //Enable timer 1
TIM1->CR1 &= ~(1U<<0); // reset CEN and disable counter
/*
TIM1->CR1 &= ^{(3U<<5)}; //clear CMS
TIM1->CR1 &= (1U << 4); //enable upcounter
*/
/**
* Load counter range,
* input clock frequency to the counter, and
* configure enable auto reload register
**/
TIM1->ARR = 999; // counter maximum value 1000 -- expect to get 1KHz
TIM1->PSC = 179; // for 1 MHz clock input
TIM1->CR1 |= 1<<7; //ARPE -- auto preload and reload eneable
TIM1->CR1 |= 1<<5; //enable center alignment
TIM1->CR2 |= 1<<3; //Capture/Compare DMA Selection
```

```
Example
/***
* Set PWM channel
**/
/*
TIM1->CCMR1 &= (7U << 4): // CH1 clear
TIM1->CCMR1 &= ~(7U<<12); //CH2 clear
TIM1->CCMR2 &= ^{(7U << 4)}; //CH3 clear
*/
//set the output channel for the PWM mode 1
TIM1->CCMR1 \mid = 0x6<<4;
TIM1->CCMR1 \mid = 0x6<<12;
TIM1->CCMR2 \mid = 0x6<<4:
// OCxPE for allow value of CCRx is load to the active register
// when an update event occur
TIM1->CCMR1 |= 1<<3;
TIM1->CCMR1 \mid = 1 << 11;
```

Mosaddek Tushar, CSE

 $TIM1->CCMR2 \mid = 1<<3;$ 

# Example

```
// Configur channels 3+3 (complementary) for output mode; Enable output
TIM1->CCER = (1<<0) | (1<<2) | (1<<4) | (1<<6) | (1<<8) | (1<<10);
// Set active polarity for the output -- active low
TIM1->CCER |= (1<<1) | (1<<3) | (1<<5) | (1<<7) | (1<<9) | (1<<11):
//OSSR -- Off state selction for run mode low
TIM1->BDTR |= 1<<11;
TIM1->BDTR |= 0x4D<<0; // please take care of dead time for state change
\\between normal complementary output
TIM1->BDTR |= 1<<15; //main output enable
//set timer autoload preload enable
TIM1->CR1 \mid = 1<<7:
//timer 1 update DMA request enable
//TIM1->DIER |= 1<<8; //This should be uncomment to the USE of DMA
```

TIM1->CCR1 |= 500; //50% duty cycle TIM1->CCR2 |= 300; //30% duty cycle TIM1->CCR3 |= 800; //80% duty cycle

//channel 1/2/3 counter initialized (ARR 1000!!)





```
Example
//register CCR1 offset 0x34 for DMA
//Uncommet for DMA
//uint8_t offset=(&(TIM1->CCR1)-&(TIM1->CR1));
//offset \&= 0x0F;
//TIM1->DCR |= (uint8_t)(offset<<0);
//TIM1->DCR |= 13<<0;
//DMA Burst size
//uncomment for DMA
//TIM1->DCR |= 3<<8; //4-DMA transfer
// uncomment enable interrupt
TIM1->DIER |= 7<<1; //enable matching interrupt
//Finally enable counting
TIM1->CR1 \mid = 1<<0;
```

#### Example

## 3-Phase PWM example GPIO Setting

```
void Config_GPIO_TIM(void){
/* GPIO Port for Channel 1, 2 & 3, 1N, 2N, 3N
* port: GPIOA and GPIOB -> PA8, PA9, PA10, PA7/PB13, PB0/PB14, PB1/PB15
*/
RCC->AHB1ENR \mid = (1<<0) \mid (1<<1); // Enable GPIOA and GPIOB
//set Moder Register; reset and set -- optional
GPIOA->MODER &= ^{\sim}(3U<<16);
GPIOA->MODER &= ^{\sim}(3U<<18);
GPIOA->MODER &= ^{\circ}(3U<<20);
\\ Optional
GPIOB->MODER &= ^{\sim}(3U<<26);
GPIOB->MODER &= ^{\sim}(3U<<0);
GPIOB->MODER &= ^{(3U << 2)};
//set the values for Alternate function for PWM
GPIOA->MODER |= (2 < 16) | (2 < 18) | (2 < 20); //pin PA8, PA9, PA10 for output
GPIOB->MODER |= (2<<26) | (2<<0) | (2<<2); //pin PB13, PB0, PB1 for
\\complementary output
                                                               Mosaddek Tushar, CSE
                           Slide 21 of 21
```

## Example //Ouput speed GPIOA->OSPEEDR |= (3<<16) | (3<<18) | (3<<20); GPIOB->OSPEEDR |= (3<<26) | (3<<0) | (3<<2); //Set the alternate function for the PWM output //clear the alternate function and set (optional) GPIOA -> AFR[1] &= ~(15U << 0);GPIOA -> AFR[1] &= ~(15U << 4);GPIOA -> AFR[1] &= ~(15U << 8);GPIOB -> AFR[0] &= ~(15U << 0);GPIOB -> AFR[0] &= ~(15U << 8);GPIOB->AFR[1] &= $^{(15U << 20)}$ ; //Set the alternate funtion for 3-phase PWM and complements $GPIOA \rightarrow AFR[1] = (1 << 0) | (1 << 4) | (1 << 8);$ GPIOB -> AFR[0] |= (1 << 0) | (1 << 8);

GPIOB -> AFR[0] |= (1 << 20);