



# Software Safety Requirements and Architecture Lane Assistance

**Document Version: 1.1** 

Template Version 1.0, Released on 2017-06-21



## **Document history**

Date	Version	Editor	Description
Apr. 1, 2018	1.1	Yi-Ching Chung	First draft from template

## **Table of Contents**

Document history	2
Table of Contents	2
Purpose	3
Inputs to the Software Requirements and Architecture Document	3
Technical safety requirements	3
Refined Architecture Diagram from the Technical Safety Concept	5
Software Requirements	5
Refined Architecture Diagram	12

### Purpose

This document intends to identify the new requirements for the software components at a component level in order to identify potential problems on software design and architecture that could lead to a violation of safety goals. These requirements are more detail oriented than the technical safety concept requirements.

## Inputs to the Software Requirements and Architecture Document

#### Technical safety requirements

Table 1 provide the technical safety requirements for the LDW amplitude malfunction as well as the refined system architecture diagram from the technical safety concept.

Table 1 Technical Safety Requirements related to Functional Safety Requirement 01-01

ID	Technical Safety Requirement	A S I L	Fault Tolerant Time Interval	Architectur e Allocation	Safe State
Technical Safety Requireme nt 01	The Lane Departure Warning safety component shall ensure that the amplitude of the 'LDW_Torque_Request' sent to the 'Final electronic power steering Torque' component is below 'Max_Torque_Amplitude'	С	50 ms	LDW Safety	Lane Departure
Technical Safety Requireme nt 02	When the Lane Departure Warning is deactivated, the 'LDW Safety' software module shall send a signal to the Car Display ECU to	С	50 ms	LDW Safety	Lane Departure Warning torque to zero.

	turn on a warning signal.				
Technical Safety Requireme nt 03	When a failure is detected by the Lane Departure Warning functionality, it shall deactivate the Lane Departure Warning feature and set 'LDW_Torque_Request' to zero.	С	50 ms	LDW Safety	Lane Departure Warning torque to zero.
Technical Safety Requireme nt 04	The validity and integrity of the data transmission for 'LDW_Torque_Request' signal shall be ensured.	С	50 ms	LDW Safety	Lane Departure Warning torque to zero.
Technical Safety Requireme nt 05	Memory test shall be conducted at start up of the EPS ECU to check for any memory problems	A	Ignition cycle	Data Transmissio n Integrity Check	Lane Departure Warning torque to zero.

### Refined Architecture Diagram from the Technical Safety Concept




Fig. 1 refined system architecture diagram from the technical safety concept

### Software Requirements

The Lane Departure Warning (LDW) Amplitude Malfunction Software Requirements are listed in Table 2 and Table 3.

Table 2 Software safety requirements for the LDW amplitude malfunction technical safety requirement 01.

ID	Technical Safety Requirement	A S I L	Fault Tolerant Time Interval	Allocation to Architecture	Safe State
Technical Safety Requireme nt	The Lane Departure Warning safety component shall ensure that the amplitude of the 'LDW_Torque_Request'	С	50 ms	LDW Safety	Lane Departure Warning torque to zero.

01	sent to the 'Final electronic power steering Torque' component is below		
	'Max_Torque_Amplitude.'		

Table 3 Detailed Software safety requirements for the LDW amplitude malfunction technical safety requirements 01.

ID	Software Safety Requirement	A S I L	Allocation Software Elements	Safe State
Software Safety Requireme nt 01-01	The input signal 'Primary_LDW_Torq_Req' shall be read and pre-processed to determine the torque request coming from the 'Basic/Main LAFunctionality' SW Component. Signal 'processed_LDW_Torq_Req' shall be generated at the end of the processing.	С	LDW_SAGETY_INPUT _PROCESSING	N/A
Software Safety Requireme nt 01-02	In case the 'processed_LDW_Torq_Req' signal has a value greater than 'Max_Torque_Amplitude_LD W' (maximum allowed safe torque), the torque signal 'limited_LDW_Torq_Req' shall be set to zero, else 'limited_LDW_Torq_Req' shall take the value of 'processed_LDW_Torq_Req'	С	TORQUE_LIMITER	'limited_LDW_ Torq_Req' = 0 (Nm=Newton- meter)
Software Safety Requireme nt 01-03	The 'limited_LDW_Torq_Req' shall be transformed into a signal 'LDW_Torq_Req' which is suitable to be transmitted outside the LDW	С	LDW_SAFETY_OUTP UT_GENERATOR	LDW_Torq_Re q = 0 (Nm)

TOTQUE COMBONENT.		Safety component ('LDW Safety') to the 'Final EPS Torque' component.			
-------------------	--	--	--	--	--

Table 4 Software safety requirements for the LDW amplitude malfunction technical safety requirement 02.

ID	Technical Safety Requirement	A S I L	Fault Toleran t Time Interval	Allocation to Architecture	Safe State
Technical Safety Requireme nt 02	When the Lane Departure Warning is deactivated, the 'LDW Safety' software module shall send a signal to the Car Display ECU to turn on a warning signal.	С	50 ms	LDW Safety	Lane Departure Warning torque to zero.

Table 5 Detailed Software safety requirements for the LDW amplitude malfunction technical safety requirements 02.

ID	Software Safety Requirement	A S I L	Allocation Software Elements	Safe State
Software Safety Requireme nt 02-01	Any data to be transmitted outside the LDQ Safety component ('LDW Safety') including 'LDW_Torque_Req' and 'activation_status' shall be protected by an End-2-End protection mechanism.	С	E2C Calc	LDW_Torq_R eq = 0 (Nm)
Software Safety Requireme nt 02-02	The E2E protection protocol shall contain and attach the control data (alive counter (SQC) and CRC) to the data to be transmitted.	С	E2E Calc	LDW_Torq_R eq = 0 (Nm)

Table 6 Software safety requirements for the LDW amplitude malfunction technical safety requirement 03.

ID	Technical Safety Requirement	A S I L	Fault Toleran t Time Interval	Allocation to Architecture	Safe State
Technical Safety Requireme nt 03	As soon as a failure is detected by the LDW function, it shall deactivate the LDW feature and the LDW_Torque_Request shall be set to zero	С	50 ms	LDW Safety	Lane Departure Warning torque to zero.

Table 7 Detailed Software safety requirements for the LDW amplitude malfunction technical safety requirements 03.

ID	Software Safety Requirement	A S I L	Allocation Software Elements	Safe State
Software Safety Requireme nt03-01	Each Software element shall output a a signal to indicate any error which is detected by the element. Error signal = error_status_input (LDW_SAFETY_INPUT_PR OCESSING), error_status_torque_limiter(T ORQUE_LIMITER), error_status_output_gen(LD W_SAFETY_OUTPUT_GEN ERATOR)	С	All	N/A
Software Safety Requireme nt03-02	A software element shall evaluate the error status of all other software elements and in case any one of them indicates an error, it shall deactivate the Lane Departure Warning feature ('activation status'=0)	С	LDW_SAFET Y_ACTIVATI ON	Lane Departure Warning function deactivated ('activation_status' =0).

Software Safety Requireme nt03-03	In case of a no error from the software elements, the status of the Lane Departure Warning feature shall be set to activated ('activation_status'=1).	С	LDW_SAFET Y_ACTIVATI ON	N/A
Software Safety Requireme nt03-04	In case an error is detected by any of the software elements, it shall set the value to its corresponding torque to zero so that 'LDW_Torq_Req' is set to zero	С	All	LDW_Torq_Req = 0
Software Safety Requireme nt03-05	Once the Lane Departure Warning functionality has been deactivated, it shall stay deactivating until the time the ignition is switched from off to on again.	С	LDW_SAFET Y_ACTIVATI ON	Lane Departure Warning function deactivated ('activation_status' =0).

Table 8 Software safety requirements for the LDW amplitude malfunction technical safety requirement 04.

ID	Technical Safety Requirement	A S I L	Fault Toleran t Time Interval	Allocation to Architecture	Safe State
Technical Safety Requireme nt 04	The validity and integrity of the data transmission for 'LDW_Torque_Request' signal shall be ensured.	С	50 ms	LDW Safety	Lane Departure Warning torque to zero.

Table 9 Detailed Software safety requirements for the LDW amplitude malfunction technical safety requirements 04.

ID	Software Safety Requirement	A S I L	Allocation Software Elements	Safe State
Software Safety Requireme nt 04-01	When the Lane Departure Warning function is deactivated ('activation_status' set to zero), the activation_status shall be sent to the Car Display ECU.	С	LDW_SAFE TY_ACTIVA TION, Car Display ECU	N/A

Table 10 Software safety requirements for the LDW amplitude malfunction technical safety requirement 05.

ID	Technical Safety Requirement	A S I L	Fault Toleran t Time Interval	Allocation to Architecture	Safe State
Technical Safety Requireme nt 05	Memory test shall be conducted at start up of the EPS ECU to check for any faults in memory	A	Ignition cycle	Data Transmission Integrity Check	Lane Departure Warning torque to zero.

Table 11 Detailed Software safety requirements for the LDW amplitude malfunction technical safety requirements 05.

ID	Software Safety Requirement	A S I L	Allocation Software Elements	Safe State
Software Safety Requireme nt 05-01	A CRC verification check over the software code in the Flash memory shall be done every time the ignition is switched from off to on to check for any content corruption.	A	MEMORYTE ST	Activation_status = 0
Software Safety Requireme nt 05-02	Standard RAM test to check the data bus, address bus and device integrity shall be done every time the ignition is switched from off to on (e. G. walking 1s test, RAM pattern test, Refer to RAM and processor vendor recommendations)	A	MEMORYTE ST	Activation_status = 0
Software Safety Requireme nt 05-03	The test result of the RAM or Flash memory shall be indicated to the LDW_Safety component via the 'test_status' signal.	A	MEMORYTE ST	Activation_status = 0
Software	In case any fault is indicated via the 'test_status' signal the	Α	LDW_SFET	Activation_status = 0

Safety Requireme nt 05-04	INPUT_LDW_PROCESSING shall set an error on the error_status_input(=1) so that the Lane Departure Warning functionality is deactivated and the LDW_Torque_Req is set to zero.		Y_INPUT_P ROCESSIN G	
---------------------------------	--	--	----------------------------	--

## Refined Architecture Diagram

The refined system architecture should include the system architecture from the end of the software and hardware lesson, including all of the ASIL labels (in Fig. 2).




Fig. 2 Refined system architecture.