Remote Debugging with of innovation the GNU GDB Debugger using Qt Creator

MA35XX Series

江天文

2024/04/24



Introduction

- Qt Creator is the de facto standard IDE for developing applications on embedded Linux.
- Qt Creator integrates with remote debugging facility through the GNU GDB Debugger and SSH client.

Configure Buildroot

 Remote Debugging with Qt Creator requires the Buildroot configuration to meet development environment. Type make menuconfig to configure Buildroot, tailor the toolchain options and select the corresponding packages.

```
→ Toolchain
  [*] Build cross gdb for the host
       Python support (Python 3)
→ Host utilities
  * host cmake
→ Target packages → Debugging, profiling and benchmark
  [*] gdb
  -*- gdbserver
→ Target packages → Networking applications
   [*] openssh
      server
      key utilities
  [*] rsync
```

Download Qt Creator Offline Installer

- At the time of writing the version of Qt Creator is 13.0.0.
- Browse the below site to fetch Qt Creator.

https://www.qt.io/offline-installers

Qt6 source packages	Qt Creator
5.15.x source packages	Qt Creator 13.0.0 is released and it is available via Qt online installer. If you need a standalone installer, please select the file according to your operating system
5.12.x Offline Installers	from the list below to get the latest Qt Creator for your computer.
Qt Creator	• Qt Creator 13.0.0 for Windows 64-bit (330 MB) (info)
	 Qt Creator 13.0.0 for Linux 64-bit (211 MB) (info) Qt Creator 13.0.0 for Linux ARM 64-bit (285 MB) (info)
Other downloads	• Qt Creator 13.0.0 for macOS (226 MB) (info)
Pre-releases	The source code is available as a zip (71MB) (Info) or a tar.gz (60 MB) (Info). Or visit the repository at code.qt.io.
	Be sure to check if Qt is supported on your platform and read the installation notes that are located in the Qt Documentation.



Install Qt Creator

- Install package libxcb-cursor0
 \$ sudo apt install libxcb-cursor0
- Change execution permission
 \$ sudo chmod +x qt-creator-opensource-linux-x86_64-13.0.0.run
- Disconnect internet connection due to registration required during installation
- Install Qt Creator
 \$./qt-creator-opensource-linux-x86_64-13.0.0.run



Configure OpenSSH Server

Configure OpenSSH
 Server on target board.

/etc/ssh/sshd_config

PermitRootLogin yes

PasswordAuthentication yes


PermitEmptyPasswords yes



Launch Qt Creator

 From Ubuntu application launch panel, find and launch Qt Creator.








Configure Qt Creator


Click Edit →
 Preferences...





Add Remote Devices


From side list, click the
 Devices in dialog of
 Preferences, click Add to
 create a remote device.





Create Remote Linux Device


Choose Remote Linux
 Device to Start Wizard





Configure Remote Device


- Configuration name: MA35D1 Board
- IP address: 192.168.10.100
- SSH port number:22
- username: root





Configure Remote Device


Click Next to proceed





Configure Remote Device


Click Finish





Test SSH connection


 If SSH connection is established between PC and remote device, the dialog will show the result of test.





Apply Remote Device


 Click Apply to complete remote device creation.





Configure CMake


 In dialog of Preferences, choose CMake from left side panel, click Add to set CMake to \${BR2_DIR}/output/host /bin/cmake. Then click Apply to forward.






Configure Kits (Debuggers)

 In dialog of Preferences, choose Kits from left side panel, Add Debuggers as \${BR2_DIR}/output/host /bin/aarch64-linux-gdb.






 In dialog of Preferences, choose Kits from left side panel, Add Compilers (GCC: C)






 Add GCC C compiler:
 \${BR2_DIR}/output/host /bin/aarch64-linux-gcc






Add GCC C++ compiler






Add GCC C++ compiler:
 \${BR2_DIR}/output/host
 /bin/aarch64-linux-g++





Configure Kits (Qt Versions)


Add qmake





Configure Kits (Qt Versions)

 Set qmake to \${BR2_DIR}/output/host /bin/qmake.





Configure Kits

Set Kits to

Name: Embedded Qt 5.15.2 (aarch64)

Device type: Remote Linux Device

Device: MA35D1 Board

Build device: Local PC


Compiler C: GCC (C, aarch64)

Compiler C++: GCC (C++, aarch64)

GDB (aarch64) Debugger:


Qt version: Qt 5.15.2 (aarch64)

CMake Tool: **CMake (aarch64)**






Choose Non-Qt Project, **Plain C Application**






 Select Build system as CMake






Select Kit as Embedded
 Qt 5.15.2 (aarch64)





 Double click the corresponding line to set breakpoint.





Joy of innovation

NUVOTON

谢谢 謝謝 Děkuji Bedankt Thank you Kiitos Merci Danke Grazie ありがとう 감사합니다 Dziękujemy Obrigado Спасибо Gracias Teşekkür ederim Cảm ơn