PSI 9000 T/DT register list for devices with KE firmware from V3.04 (check the installed version in your device's MENU in item INFO HW, SW)												
us address	coils (0x01)	holding registers	single coil (0x05)	single register (0x06)	multiple registers		S	уре	Data length in bytes	Number of registers		
Modbus	Read	Read	Write 8	Write 8	Write	Description	Access	Data type	Data l	Numb	Data	Example or description
0		X X				Device class Device type	R R	uint(16) char	2 40	20	I ASCII	42 = PSI 9000 DT Series, 50 = PSI 9000 T PSI 9080-60 DT
21 41 61		X X				Manufacturer Manufacturer address Manufacturer ZIP code	R R R	char char char	40 40 40	20	ASCII ASCII ASCII	
81 101		X				Manufacterer phone number Manufacturer website	R R	char char	40 40	20	ASCII ASCII	
121 123 125		X X				Nominal voltage Nominal current	R R R	float float float	4 4	2	Floating point number IEEE754	80 60 1500
127 129		X				Nominal power Max. Internal resistance Min. Internal resistance	R R	float	4 4	- 2	Floating point number IEEE754	40 0.05
131 151		X X				Article no. Serial no.	R R	char char	40 40	20	ASCII ASCII	06200511 1234567890
171 191		X			Х	User text Firmware version (KE)	RW R	char char	40	20		V3.02 16.08.2016
211		X				Firmware version (HMI) Firmware version (DR)	R R	char char	40 40			V2.08 22.09.2016 V1.0.4.1 30.06.2016
402 405	_		X X			Remote mode DC output	RW RW	uint(16) uint(16)	2	_		0x0000 = off; 0xFF00 = on 0x0000 = off; 0xFF00 = on
407 408	х	х	х	х		Condition of DC output after power fail alarm Condition of DC output after powering the device	RW RW	uint(16) uint(16)	2		Reg : Power on	0x0000 = off; 0xFF00 = auto-on 0xFFFF = off; 0xFFFE = Restore
409 410 411			X X			Operation mode (UIP/UIR) Restart of the device (warm start)	RW W	uint(16) uint(16) uint(16)	2 2		Coils : Restart	0x0000 = UIP; 0xFF00 = UIR 0xFF00 = execute 0xFF00 = acknowledge
416			X			Acknowledge alarms Analog interface: Reference voltage (pin VREF) Analog interface: REM-SB level	RW RW	uint(16) uint(16) uint(16)	2		Coils : VREF	0x0000 = 10V; 0xFF00 = 5V 0x0000 = normal; 0xFF00 = inverted
418 425	X X		X X			Analog interface: REM-SB action DC output after leaving remote	RW RW	uint(16) uint(16)	2		Coils : REM-SB Action	0x0000 = DC off; 0xFF00 = DC auto 0x0000 = off; 0xFF00 = unchanged
500 501	E	x		X		Set voltage value Set current value	RW RW	uint(16) uint(16)	2			Voltage value (for translation see programming guide) Current value (for translation see programming guide)
502 503		x		X		Set power value Set resistance value	RW	uint(16) uint(16)	2	 	minimum - 0xD0E5 (x - 102%)	Power value (for translation see programming guide) Resistance value (the minimum value varies from model to model and can be
505		х				Device state	R	uint(32)	4	-		calculated from the technical specification in the manual) 0x00 = free; 0x01 = local; 0x02 = remote; 0x03 = USB; 0x04 = analog; 0x06 = Ethernet
											Bit 9-10 : Regulation mode	0 = off; 1 = on 00 = CV; 01 = CR; 10 = CC; 11 = CP
											Bit 13 : Function generator	0 = off; 1 = on 0 = stopped ; 1 = running
											Bit 15 : Alarms	0 = off; 1 = on 0 = none; 1 = active 0 = none; 1 = active
											Bit 17 : OCP	0 = none; 1 = active 0 = none; 1 = active
											Bit 21 : Power fail	0 = none; 1 = active 0 = none; 1 = active
											Bit 23 : Power fail	0 = none; 1 = active 0 = none; 1 = active 0 = none; 1 = active
											Bit 25 : OVD Bit 26 : UCD	0 = none; 1 = active 0 = none; 1 = active
											Bit 28 : OPD	0 = none; 1 = active 0 = none; 1 = active 0 = DC enabled; 1 = REM-SB disables DC output/input
507 508		X X				Actual voltage Actual current	R R R	uint(16) uint(16)	2 2		0x0000 - 0xFFFF (0 - 125%)	Actual voltage (for translation see programming guide) Actual current (for translation see programming guide)
509 520 521		X				Actual power Count of OV alarms since power up Count of OC alarms since power up	R R	uint(16) uint(16) uint(16)	2		0x0000 - 0xFFFF	Actual power (for translation see programming guide) Count Count
522 523		x x				Count of OP alarms since power up Count of OT alarms since power up	R R	uint(16) uint(16)	2		0x0000 - 0xFFFF	Count Count
524 550		X		X		Count of PF alarms since power up Overvoltage protection threshold (OVP)	R RW	uint(16) uint(16)	2	·	0x0000 - 0xE147 (0 - 110%)	Count OVP threshold (for translation see programming guide)
553 556 559		X X		X X		Overcurrent protection threshold (OCP) Overpower protection threshold (OPP) Undervoltage detection (UVD)	RW RW	uint(16) uint(16) uint(16)	2 2		0x0000 - 0xE147 (0 - 110%)	OCP threshold (for translation see programming guide) OPP threshold (for translation see programming guide) UVD threshold (for translation see programming guide)
560		х		х		Adjustable UVD notification	RW	uint(16)	2		Reg : Adjustable UVD notification	0x0000 = nothing; 0x0001 = signal; 0x0002 = warning; 0x0003 = alarm
561 562		X		X		Overvoltage detection (OVD) Adjustable OVD notification	RW	uint(16) uint(16)	2	·	Reg : Adjustable OVD notification	OVD threshold (for translation see programming guide) 0x0000 = nothing; 0x0001 = signal; 0x0002 = warning; 0x0003 = alarm
563 564		X		X		Undercurrent detection (UCD) Adjustable UCD notification	RW	uint(16) uint(16)	2		Reg : Adjustable UCD	UCD threshold (for translation see programming guide) 0x0000 = nothing; 0x0001 = signal; 0x0002 = warning; 0x0003 = alarm
565 566		X		x		Overcurrent detection (OCD) Adjustable OCD notification	RW RW	uint(16) uint(16)	2		0x0000 - 0xD0E5 (0 - 102%) Reg : Adjustable OCD	OCD threshold (for translation see programming guide) 0x0000 = nothing; 0x0001 = signal; 0x0002 = warning;
567 568		x		x		Overpower detection (OPD) Adjustable OPD notification	RW RW	uint(16) uint(16)	2		0x0000 - 0xD0E5 (0 - 102%)	0x0003 = alarm OPD threshold (for translation see programming guide) 0x0000 = nothing; 0x0001 = signal; 0x0002 = warning;
											notification	0x0003 = alarm
850 851 852	X X		X X			Function generator Arbitary: Start/stop Function generator Arbitrary: Select U Function generator Arbitrary: Select I	RW RW	uint(16) uint(16) uint(16)	2 2		Coils : Select U	0x0000 = Stop; 0xFF00 = Start 0x0000 = not assigned; 0xFF00 = Assign function to voltage 0x0000 = not assigned; 0xFF00 = Assign function to current
859 860	Ĺ	X X	^	X		Function generator Arbitrary: Start sequence Function generator Arbitrary: End sequence	RW RW	uint(16) uint(16)	2		1 0x00010x0064 1 0x00010x0064	
861 900		x		х	х	Function generator Arbitrary: Sequence cycles Function generator Arbitrary: Setup for sequence 1	RW RW	uint(16) float	2 32		0x00000x03E7 Bytes 0-3: Us/Is(AC) in V	0x0000 = infinite Floating point number in IEEE754 format, see device
											Bytes 8-11: fs(1/T) in Hz Bytes 12-15: fe(1/T) in Hz	manual for value range, chapter about function generator Integer in IEEE754 format: 010000Hz
											Bytes 20-23: Us/Is(DC) in V	Integer in IEEE754 format: 0°359° Floating point number in IEEE754 format, see device manual for value range, chapter about function generator
1	ļ	1	Ţ		ļ	↓	↓ ↓	† ↓	1	ļ	Bytes 28-31: Sequence time in μs	136000000 (36 Mio.) ↓
2468		х			х	Function generatorArbitrary: Setup for sequence 99	RW	float	32	16	Bytes 4-7: Ue/le(AC) in V	Floating point number in IEEE754 format, see device manual for value range, chapter about function generator Integer in IEEE754 format: 010000Hz
											Bytes 12-15: fe(1/T) in Hz Bytes 16-19: Angle in degrees	Integer in IEEE754 format: 0°359° Floating point number in IEEE754 format, see device
												manual for value range, chapter about function generator
9000		X		X		Upper limit of voltage set value (U-max) Lower limit of voltage set value (U-min)	RW RW	uint(16)	2			Voltage value (for translation see programming guide) Voltage value (for translation see programming guide)
9001	L	X X		X X		Upper limit of current set value (I-min) Lower limit of current set value (I-max) Lower limit of current set value (I-min)	RW RW	uint(16) uint(16) uint(16)	2 2		0x0000 - 0xD0E5 (0 - 102%) 0x0000 - 0xD0E5 (0 - 102%)	Current value (for translation see programming guide) Current value (for translation see programming guide) Current value (for translation see programming guide)
9004 9006		x		X		Upper limit of power set value (P-max) Upper limit of resistance set value (R-max)	RW RW	uint(16) uint(16)	2		0x0000 - 0xD0E5 (0 - 102%)	Power value (for translation see programming guide) Resistance value (for translation see programming guide)
10007			X X			Ethernet: TCP keep-alive Ethernet: DHCP	RW RW	uint(16) uint(16)	2	_		0x0000 = off; 0xFF00 = on 0x0000 = off; 0xFF00 = on
10010 10011		E	X			Protocol: Modbus Protocol: SCPI	RW RW	uint(16) uint(16) uint(16)	2	-	Coils: MODBUS on/off Coils: SCPI on/off	0x0000 = off; 0xFF00 = on 0x0000 = off; 0xFF00 = on
10017		X				Ethernet: DHCP status Ethernet: IP address	R RW	uint(16) uint(8)	4	- 2	Bit0: DHCP running Bytes 0 - 3: 0255	0 = manual; 1 = DHCP 192.168.0.2 (default)
10504 10506 10508		X X				Ethernet: Subnet mask Ethernet: Gateway Ethernet: Host name	RW RW	uint(8) uint(8) char	4 54	2	2 Bytes 0 - 3: 0255 2 Bytes 0 - 3: 0255 7 ASCII	255.255.255.0 (Standard) 192.168.0.1 (default) "Client" (default)
10535 10562	E	X X	E		Х	Ethernet: Domain name Ethernet: DNS	RW RW	char char uint(8)	54 54 4	2	ASCII	"Workgroup" (default) 0.0.0.0 (default)
10566 10567		X X		Х		USB: Connection timeout (in milliseconds) Ethernet: MAC	RW R	uint(16) uint(8)	2 6	;	565535 B Bytes 0 - 5: 0255	Default: 5 ms 00:50:C2:C3:12:34 or 00-50-C2-C3-12-34
10572 10573		X		X		Ethernet: Port Ethernet: TCP Socket timeout (in seconds)	RW RW	uint(16) uint(16)	2			5025 (default) Default: 5 s