PS 3000 C register list for devices with KE firmware from V2.02 (check the installed version in your device's MENU in item INFO HW, SW)												
				06)								
		ers	(90	single register (0x06)	ters							
ω.	1)	registers	(0×0)	ister	multiple registers				Data length in bytes	Number of registers		
address	(0×01)		single coil	regi	ole r				in b	egis		
ado	coils (holding	algu	algu	ultip			Φ	igth	ofr		
Modbus	р сс	q þc	e sir	e sir	te m		SSe	Data type	a ler	nber		
Mod	Read	Read	Write	Write	Write	Description	Access	Data	Data	Nun	Data	Example
0		Х		Х		Device class	R	uint(16)	2	1	ASCII	57 = PS 3000 C Series PS 3080-05 C
21		X				Device type Manufacturer	R R	char char	40	20	ASCII	PS 3080-05 C
41 61		X				Manufacturer address Manufacturer ZIP code	R R	char char	40		ASCII ASCII	
81		Х			Х	Manufacterer phone number	R	char	40	20	ASCII	
101 121		X				Manufacturer website Nominal voltage	R R	char float	40		ASCII Floating point number IEEE754	80
123		х			х	Nominal current	R	float	4	2	Floating point number IEEE754	5
125		X			X	Nominal power Article no.	R R	float char	40		Floating point number IEEE754 ASCII	160 35320209
151		х			х	Serial no.	R	char	40	20	ASCII	1234567890
171 191		x				User text Firmware version (KE)	RW R	char char	40 40		ASCII ASCII	V2.02
211		Х				Firmware version (KE) Firmware version (HMI)	R	char	40	20	ASCII	V2.02
231 402		Х			Х	Firmware version (DR) Remote mode	R RW	char	40		ASCII Coils : Remote	V2.0.1 0x0000 = off; 0xFF00 = on
402	X		x			DC output	RW	uint(16) uint(16)	2		Coil : Output/input	0x0000 = off; 0xFF00 = on
407	х		Х			Condition of DC output after power fail alarm	RW	uint(16)	2		Coils : Auto-On Coils : Power-On	0x0000 = off; 0xFF00 = auto-on
408	х	Х	х	Х		Condition of DC output after powering the device Restart of the device (warm start)	RW W	uint(16) uint(16)	2		Coils : Power-On Coils : Restart	0xFFFF = off; 0xFFFE = Restore 0xFF00 = execute
411	х		Х			Acknowledge alarms	W	uint(16)	2		Coils : Alarms	0xFF00 = acknowledge
416 417			X			Analog interface: Reference voltage (pin VREF) Analog interface: REM-SB level	RW RW	uint(16) uint(16)	2		Coils : VREF Coils : REM-SB Level	0x0000 = 10V; 0xFF00 = 5V 0x0000 = normal; 0xFF00 = inverted
418			Х			Analog interface: REM-SB action	RW	uint(16)	2	1	Coils : REM-SB Action	0x0000 = DC off; 0xFF00 = DC auto
425 500	х	х	Х	х		DC output after leaving remote Set voltage value	RW RW	uint(16) uint(16)	2		Coils : Condition 0x0000 - 0xD0E5 (0 - 102%)	0x0000 = off (default); 0xFF00 = unchanged Voltage value (for translation see programming guide)
501		X		X		Set current value	RW	uint(16)	2		0x0000 - 0xD0E5 (0 - 102%)	Current value (for translation see programming guide)
502 505		X		Х		Set power value Device state	RW R	uint(16) uint(32)	2		0x0000 - 0xD0E5 (0 - 102%) Bit 0- 4: Control location	Power value (for translation see programming guide) 0x00 = free; 0x01 = local; 0x02 = fern; 0x03 = USB; 0x04 =
303		^				Device state	IX.	uiii(32)	4			analog; 0x06 = Ethernet
											Bit 7 : DC output Bit 9-10 : Regulation mode	0 = off; 1 = on 00 = CV; 01 = CR; 10 = CC; 11 = CP
											Bit 11 : Remote control	0 = off; 1 = on
											Bit 14 : External sense Bit 15 : Alarms	0 = off; 1 = on 0 = none; 1 = active
											Bit 16 : OVP	0 = none; 1 = active
											Bit 17 : OCP Bit 18 : OPP	0 = none; 1 = active 0 = none; 1 = active
											Bit 19 : OT	0 = none; 1 = active
											Bit 21 : Power fail Bit 30 : REM-SB	0 = none; 1 = active 0 = DC enabled; 1 = REM-SB disables DC output/input
507		Х		Х		Actual voltage	R	uint(16)	2		0x0000 - 0xFFFF (0 - 125%)	Actual voltage (for translation see programming guide)
508		Х		Х		Actual current	R	uint(16)	2		0x0000 - 0xFFFF (0 - 125%) 0x0000 - 0xFFFF (0 - 125%)	Actual current (for translation see programming guide)
509 520		X				Actual power Count of OV alarms since power up	R R	uint(16) uint(16)	2		0x0000 - 0xFFFF (0 - 125%)	Actual power (for translation see programming guide) Count
521		х				Count of OC alarms since power up	R	uint(16)	2		0x0000 - 0xFFFF	Count
522 523		x				Count of OP alarms since power up Count of OT alarms since power up	R R	uint(16) uint(16)	2		0x0000 - 0xFFFF 0x0000 - 0xFFFF	Count Count
524		х				Count of PF alarms since power up	R	uint(16)	2	1	0x0000 - 0xFFFF	Count
550 553		x		X		Overvoltage protection threshold (OVP) Overcurrent protection threshold (OCP)	RW RW	uint(16) uint(16)	2		0x0000 - 0xE147 (0 - 110%) 0x0000 - 0xE147 (0 - 110%)	OVP threshold (for translation see programming guide) OCP threshold (for translation see programming guide)
556		х		Х		Overpower protection threshold (OPP)	RW	uint(16)	2	1	0x0000 - 0xE147 (0 - 110%)	OPP threshold (for translation see programming guide)
9000		x		x		Upper limit of voltage set value (U-max) Lower limit of voltage set value (U-min)	RW RW	uint(16) uint(16)	2		0x0000 - 0xD0E5 (0 - 102%) 0x0000 - 0xD0E5 (0 - 102%)	Voltage value (for translation see programming guide) Voltage value (for translation see programming guide)
9002		X		Х		Upper limit of current set value (I-max)	RW	uint(16)	2		0x0000 - 0xD0E5 (0 - 102%)	Current value (for translation see programming guide)
9003 9004		x		x		Lower limit of current set value (I-min) Upper limit of power set value (P-max)	RW RW	uint(16) uint(16)	2		0x0000 - 0xD0E5 (0 - 102%) 0x0000 - 0xD0E5 (0 - 102%)	Current value (for translation see programming guide) Power value (for translation see programming guide)
10007	х	×	Х	X		Ethernet: TCP keep-alive	RW	uint(16)	2		Coils: Keep-alive on/off	0x0000 = off; 0xFF00 = on
10008	-		Х			Ethernet: DHCP	RW	uint(16)	2		Coils: DHCP on/off Coils: MODBUS on/off	0x0000 = off; 0xFF00 = on 0x0000 = off; 0xFF00 = on
10010	x		x			Protocol: Modbus Protocol: SCPI	RW RW	uint(16) uint(16)	2		Coils: MODBUS on/off Coils: SCPI on/off	0x0000 = 0ff; 0xFF00 = on 0x0000 = off; 0xFF00 = on
10017		Х				Ethernet: DHCP status	R	uint(16)	2		Bit0: DHCP running	0 = manual; 1 = DHCP
10502 10504		x			X	Ethernet: IP address Ethernet: Subnet mask	RW RW	uint(8) uint(8)	4		Bytes 0 - 3: 0255 Bytes 0 - 3: 0255	192.168.0.2 (default) 255.255.255.0 (Standard)
10506		х			х	Ethernet: Gateway	RW	uint(8)	4	2	Bytes 0 - 3: 0255	192.168.0.1 (default)
10508 10535		x			X	Ethernet: Host name Ethernet: Domain name	RW RW	char char	54 54		ASCII ASCII	"Client" (default) "Workgroup" (default)
10562		х			X	Ethernet: DNS	RW	uint(8)	4	2	Bytes 0 - 3: 0255	0.0.0.0 (default)
10566 10567		x		Х		USB: Connection timeout (in milliseconds) Ethernet: MAC	RW RW	uint(16) uint(8)	2 6		565535 Bytes 0 - 5: 0255	Default: 5 ms 00:50:C2:C3:12:34 or 00-50-C2-C3-12-34
10572		х		Х		Ethernet: Port	RW	uint(16)	2	1	065536 (except 80)	5025 (default)
10573		Х		Х		Ethernet: TCP Socket timeout (in seconds)	RW	uint(16)	2	1	565535	Default: 5 s