

SEL-221G, -3, -4

SEL-121G, -3, -4

**Phase Distance Relay
Ground Directional
Overcurrent Relay
Fault Locator**

Instruction Manual

20070225



SCHWEITZER ENGINEERING LABORATORIES, INC.



CAUTION

Equipment components are sensitive to electrostatic discharge (ESD). Undetectable permanent damage can result if you do not use proper ESD procedures. Ground yourself, your work surface, and this equipment before removing any cover from this equipment. If your facility is not equipped to work with these components, contact SEL about returning this device and related SEL equipment for service.

WARNING

Have only qualified personnel service this equipment. If you are not qualified to service this equipment, you can injure yourself or others, or cause equipment damage.

WARNING

Use of this equipment in a manner other than specified in this manual can impair operator safety safeguards provided by this equipment.

DANGER

Disconnect or de-energize all external connections before opening this device. Contact with hazardous voltages and currents inside this device can cause electrical shock resulting in injury or death.

DANGER

Contact with instrument terminals can cause electrical shock that can result in injury or death.

ATTENTION

Les composants de cet équipement sont sensibles aux décharges électrostatiques (DES). Des dommages permanents non-décelables peuvent résulter de l'absence de précautions contre les DES. Raccordez-vous correctement à la terre, ainsi que la surface de travail et l'appareil avant d'en retirer un panneau. Si vous n'êtes pas équipés pour travailler avec ce type de composants, contacter SEL afin de retourner l'appareil pour un service en usine.

AVERTISSEMENT

Seules des personnes qualifiées peuvent travailler sur cet appareil. Si vous n'êtes pas qualifiés pour ce travail, vous pourriez vous blesser avec d'autres personnes ou endommager l'équipement.

AVERTISSEMENT

L'utilisation de cet appareil suivant des procédures différentes de celles indiquées dans ce manuel peut désarmer les dispositifs de protection d'opérateur normalement actifs sur cet équipement.

DANGER

Débrancher tous les raccordements externes avant d'ouvrir cet appareil. Tout contact avec des tensions ou courants internes à l'appareil peut causer un choc électrique pouvant entraîner des blessures ou la mort.

DANGER

Tout contact avec les bornes de l'appareil peut causer un choc électrique pouvant entraîner des blessures ou la mort.

© 1993–2007 by Schweitzer Engineering Laboratories, Inc. All rights reserved.

All brand or product names appearing in this document are the trademark or registered trademark of their respective holders. No SEL trademarks may be used without written permission. SEL products appearing in this document may be covered by US and Foreign patents.

Schweitzer Engineering Laboratories, Inc. reserves all rights and benefits afforded under federal and international copyright and patent laws in its products, including without limitation software, firmware, and documentation.

The information in this manual is provided for informational use only and is subject to change without notice. Schweitzer Engineering Laboratories, Inc. has approved only the English language manual.

This product is covered by the standard SEL 10-year warranty. For warranty details, visit www.selinc.com or contact your customer service representative.

PM221G-01

Table of Contents

List of Tables.....	iii
List of Figures.....	v
Preface.....	vii
Section 1: Introduction	
Getting Started	1.1
Relay Overview	1.1
Model Variations Covered by This Instruction Manual	1.2
Other SEL-221G Relay Model Variations.....	1.2
General Description.....	1.3
Section 2: Specifications	
Relay Standards and Input Parameters	2.1
Functional Specifications	2.2
Detailed Specifications	2.7
Functional Description	2.23
Relay Element Operating Time Curves	2.32
Time-Overcurrent Curve Equations	2.33
Section 3: Communications	
Introduction	3.1
Serial Port Connections and Configurations	3.1
Communications Protocol	3.3
Command Characteristics.....	3.4
Command Descriptions	3.6
Section 4: Event Reporting	
Event Report Generation	4.1
Summary Event Report	4.2
Long Event Report	4.2
Interpretation of Voltage and Current Data	4.3
Relays	4.4
Contact Outputs and Inputs	4.4
Example Event Reports	4.5
Firmware Identification	4.19
Section 5: Applications	
Schemes Involving Communications	5.1
Choice of Line Impedances	5.2
Choosing Current and Potential Transformer Ratios	5.2
Choice of Maximum Torque Angle (MTA).....	5.2
Selecting Distance Element Reaches.....	5.2
Choice of Zone 1 Distance Element Reach	5.3
Choice of Zone 2 Distance Element Reach.....	5.3
Choice of Zone 3 Distance Element Reach.....	5.3
Choice of Zone 2 and Zone 3 Time Delay Settings	5.4
Choice of Phase Overcurrent Pickup Settings	5.4
Choice of Residual Time-Overcurrent Pickup Setting	5.6
Choice of Zones 1, 2, and 3 Residual Overcurrent Pickup Settings.....	5.6
Switch-On-to-Fault Logic (MTO Logic Mask)	5.6
Selection of Residual Overcurrent Relay Polarization	5.8
Loss-of-Potential Logic	5.9

230 kV Setting Example for Time-Stepped Scheme	5.12
Reclose Logic	5.35
Reclosing Logic Examples	5.37

Section 6: Installation

Installing the SEL-121G, -3, -4 Relay	6.1
Installation Checkout	6.4
Installing the SEL-221G, -3, -4 Relay	6.11
Installation Checkout	6.15

Section 7: Maintenance & Testing

Test Procedures	7.1
Initial Checkout	7.3
Full Functional Test	7.10
Setting Test	7.11
Meter Test	7.12
MHO Element Testing	7.13
Directional Element Tests	7.22
Residual Overcurrent Element Tests	7.24
Residual Time-Overcurrent Element Timing Tests	7.25
Phase Overcurrent Element Tests	7.26
Memory Voltage Polarization Test	7.26
Loss-of-Potential Test	7.27
50MF, 50MFD Test	7.27
Z2DG and Z3DG Timer Tests	7.28
Z2DP and Z3DP Timer Tests	7.29
Switch-On-to-Fault Tests	7.30
Out-of-Step Blocking Test	7.31
Recloser Test	7.32
Input Circuits Test	7.32
Serial Ports Test	7.33
IRIG-B Time Code Input Test	7.33
Power Supply Voltages Test	7.33
Calibration	7.34
Troubleshooting	7.34
Factory Assistance	7.38

Appendix A: Firmware and Manual Versions

Firmware	A.1
Manual Change Information	A.2

Appendix B: SEL-221G, -3, -4 Main Board Jumper Connector and Socket Locations

Appendix C: ONEBUS: Program to Compute Test Set Settings for Testing Distance Relays

SEL-221G/121G Relay Command Summary

List of Tables

Table 2.1	Relay Word.....	2.5
Table 2.2	Directional Element Sensitivities at Maximum Torque Angle (MTA)	2.10
Table 2.3	Relay Word.....	2.17
Table 2.4	Relay Word Bit Summary	2.17
Table 2.5	Power Supply Self-Test Limits.....	2.19
Table 2.6	Self-Test Summary	2.21
Table 2.7	Directional Element Torque Equations	2.27
Table 3.1	SEL-221G Relay Serial Port Connector Pin Assignments.....	3.2
Table 3.2	SEL-121G Relay Serial Port Connector Pin Assignments.....	3.3
Table 3.3	Hexadecimal/Binary Conversion.....	3.12
Table 3.4	Target LED Assignment	3.13
Table 4.1	Event Report Triggering Actions	4.1
Table 4.2	Non-Event Report Triggering Actions	4.1
Table 5.1	Relay Word.....	5.27
Table 5.2	Relay Word Bit Summary	5.34
Table 5.3	Trace Assignments for Example 1	5.37
Table 5.4	Trace Assignments for Examples 5 and 6 (Except Figures 5.18 and 5.19)	5.41
Table 5.5	Oscillograph Trace Assignments for Figures 5.18 and 5.19	5.43
Table 5.6	Oscillograph Trace Assignments for Figure 5.22	5.46
Table 6.1	AUX INPUT Pin Definitions	6.4
Table 6.2	Pin Definitions.....	6.15
Table 7.1	Fault Locator Test Values	7.8
Table 7.2	Output Contact and Target LED Results	7.8
Table 7.3	Three-Phase Fault Voltages and Currents at MTA	7.15
Table 7.4	Zone 1 Three-Phase Element Test Quantities at MTA	7.17
Table 7.5	Zone 1 Three-Phase Test Quantities at MTA $\pm 45^\circ$	7.18
Table 7.6	Zone 1 Phase-Phase Test Voltages and Currents, BC Fault	7.21
Table 7.7	Zone 1 Phase-Phase Test Quantities at MTA $\pm 45^\circ$	7.21
Table 7.8	32Q and 32V Test Voltages	7.22
Table 7.9	32I Test Currents	7.23
Table 7.10	Current Quantities for 5IN Timing Test Example	7.25
Table 7.11	Three-Phase Close-In Fault.....	7.26
Table 7.12	Conditions for the SET LOP and CLEAR LOP Logic Equations	7.27
Table 7.13	Standard Zone 2 AG Fault Using Factory Relay Settings.....	7.28
Table 7.14	Standard Reverse Zone 3 AG Fault Using Factory Relay Settings.....	7.28
Table 7.15	Standard Zone 2 BC Fault Using Factory Relay Settings	7.29
Table 7.16	Standard Reverse Zone 3 BC Using Factory Relay Settings	7.29
Table 7.17	Zone 2 AG Fault Quantities	7.30
Table 7.18	Standard Three-Phase Faults	7.31
Table 7.19	IAG Fault.....	7.32
Table 7.20	Contact Inputs	7.33

This page intentionally left blank

List of Figures

Figure 2.1	Phase-Phase and Three-Phase Mho Element Characteristics	2.2
Figure 2.2	Residual Overcurrent Zones of Protection	2.3
Figure 2.3	Out-of-Step Blocking Characteristics	2.4
Figure 2.4	32Q and 32V Polarization Criteria.....	2.10
Figure 2.5	32I Polarization Criteria	2.10
Figure 2.6	Trip Suspicion (TS) Logic.....	2.16
Figure 2.7	Mho Element Reach at Maximum Torque Angle	2.24
Figure 2.8	Expanded Two-Phase Mho Characteristics.....	2.25
Figure 2.9	Expanded Three-Phase Mho Characteristics.....	2.26
Figure 2.10	Programmable Logic Mask Analogy	2.31
Figure 2.11	Phase Distance Speed Curves and 50H Phase Overcurrent Speed Curve.....	2.32
Figure 2.12	Residual Time-Overcurrent Element Moderately Inverse Time Characteristic	2.34
Figure 2.13	Residual Time-Overcurrent Element Inverse Time Characteristic.....	2.35
Figure 2.14	Residual Time-Overcurrent Element Very Inverse Time Characteristic	2.36
Figure 2.15	Residual Time-Overcurrent Element Extremely Inverse Time Characteristic	2.37
Figure 3.1	SEL-221G Relay Nine Pin Connector Pin Number Convention.....	3.2
Figure 3.2	SEL-121G Relay Nine Pin Connector Pin Number Convention.....	3.2
Figure 4.1	Example Transmission Line Protection	4.5
Figure 4.2	Zone 2 BC Fault 85 Miles from Breaker 1.....	4.8
Figure 5.1	System Single Line Diagram.....	5.3
Figure 5.2	52A Input and 52BT Timing Diagram	5.7
Figure 5.3	Faulted Line With All Sources In.....	5.8
Figure 5.4	Faulted Line With Breaker 2 Open	5.8
Figure 5.5	Potential Transfer Switch Logic.....	5.10
Figure 5.6	230 kV Setting Example System Single-Line Diagram.....	5.12
Figure 5.7	Successful Reclose Sequence After Zone 1 Phase-to-Phase Fault.....	5.37
Figure 5.8	Programmable Trip Logic Diagram	5.38
Figure 5.9	Unsuccessful Reclose Sequence After Zone 1 Phase-to-Phase Fault	5.38
Figure 5.10	Unsuccessful Reclose Sequence After Zone 1 Phase-to-Phase Fault	5.39
Figure 5.11	Unsuccessful Reclose Sequence, Zone 1 Phase-to-Phase to Three-Phase Fault.....	5.39
Figure 5.12	Unsuccessful Reclose Sequence, Zone 1 Three-Phase to Phase-to-Phase Fault.....	5.40
Figure 5.13	Successful Reclose Sequence, Zone 1 Phase-to-Phase Trip Initiated by Zone 2	5.41
Figure 5.14	Two-Shot Reclosing Sequence Timing Diagram	5.41
Figure 5.15	52BT and 79OI Timing Diagram	5.42
Figure 5.16	Faulted Line With All Sources In.....	5.43
Figure 5.17	Faulted Line With Breaker 2 Open	5.43
Figure 5.18	Successful Two-Shot Reclosing Sequence.....	5.44
Figure 5.19	Unsuccessful Two-Shot Reclosing Sequence.....	5.44
Figure 5.20	52BT and 52A Contact Timing Diagram #1	5.45
Figure 5.21	52BT and 52A Contact Timing Diagram #2	5.45
Figure 5.22	79RS Element Reset of the CLOSE Contact	5.46
Figure 6.1	Nine Pin Connector Pin Number Convention	6.3
Figure 6.2	Horizontal Front- and Rear-Panel Drawings.....	6.6
Figure 6.3	Vertical Front- and Rear-Panel Drawings.....	6.7
Figure 6.4	Relay Dimensions, Panel Cutout, and Drill Plan	6.8
Figure 6.5	Communications and Clock Connections – One Unit at One Location	6.9
Figure 6.6	Communications and Clock Connections – Multiple Units at One Location	6.9
Figure 6.7	SEL Relay Communications Diagram for Connection to the SEL-DTA	6.10
Figure 6.8	External AC Current and Voltage Connections.....	6.10
Figure 6.9	External DC Connection Diagram (Typical).....	6.11
Figure 6.10	Nine Pin Connector Pin Number Convention	6.14
Figure 6.11	Horizontal Front- and Rear-Panel Drawings.....	6.17
Figure 6.12	Relay Dimensions and Drill Plan	6.18

Figure 6.13	Communications and Clock Connections — One Unit at One Location.....	6.19
Figure 6.14	Communications and Clock Connections — Multiple Units at One Location	6.19
Figure 6.15	SEL Relay Communications Diagram for Connection to the SEL-DTA.....	6.20
Figure 6.16	External AC Current and Voltage Connections.....	6.20
Figure 6.17	External DC Connection Diagram (Typical).....	6.21
Figure 7.1	Relay Part Number and Hardware Identification Sticker.....	7.4
Figure 7.2	Communication Interface Setup.....	7.4
Figure 7.3	METER Test Connections.....	7.12
Figure 7.4	Example ONEBUS Input Data for Phase-Phase and Ground Faults	7.13
Figure 7.5	Example ONEBUS Result Screen for Phase-Phase and Ground Faults	7.13
Figure 7.6	Example ONEBUS Input Data for Three-Phase Faults	7.14
Figure 7.7	Example ONEBUS Result Screen for Three-Phase Faults	7.14
Figure 7.8	Three-Phase Voltage and Current Source Test Connections for Three-Phase Mho Test	7.16
Figure 7.9	Three-Phase Voltage and Two-Phase Current Source Test Connections for Three-Phase Mho Test	7.17
Figure 7.10	Three-Phase Voltage and Two-Phase Current Source Test Connections for Phase-Phase Mho Test	7.20
Figure 7.11	Three-Phase Voltage and One-Phase Current Source Test Connections for Phase-Phase Mho Test	7.20
Figure 7.12	Three Voltage vs. One Voltage for Directional Tests (current vector shown in the operate region for MTA = 90°).....	7.23
Figure 7.13	Current Polarized Directional Element Test Connection	7.24
Figure 7.14	SEL-121G Relay Nine Pin Connector Pin Number Convention.....	7.34
Figure 7.15	SEL-121G Relay Nine Pin Connector Pin Number Convention.....	7.34
Figure B.1	SEL-200 Series Main Board Troubleshooting Test Points and Jumper Locations	B.1

Preface

SEL-100 Series Addendum

The SEL-100 series relay logic inputs have been improved to prevent operation of the logic input due to the conditions described in SEL UPDATE 94.10. If you would like a copy of SEL UPDATE 94.10, please contact the SEL factory.

The new interface board also provides field-selectable input voltage selection. The operating voltages and jumper selection for each logic input are shown in the table below.

Control Voltage	Relay Terminals											
	39/40		41/42		43/44		45/46		47/48		49/50	
	JMP11	JMP12	JMP9	JMP10	JMP7	JMP8	JMP5	JMP6	JMP3	JMP4	JMP1	JMP2
250 V												
125 V												
48 V	●	●	●	●	●	●	●	●	●	●	●	●

Control Input Operating Ranges	Control Voltage	Operating Range
	250 Vdc	150–300 Vdc
125 Vdc		80–150 Vdc
48 Vdc		30–60 Vdc

Changing the input voltage jumpers requires that you disassemble the relay. The following information describes the procedure for changing the input voltage selection jumpers:

1. Remove power from relay.
2. Place relay in a static-safe work area.
3. Remove top and bottom chassis covers (eight screws total).
4. Remove the four screws securing the front panel.
5. Carefully allow the top edge of the front panel to come forward and down (exposing relay main board/power supply/interface tray assembly).
6. From the bottom of the relay, locate and remove the two 4-40 hex jack screws that secure the tray assembly to the chassis. These jack screws are located at the front corners of the draw-out tray and require a long 3/16-inch nut driver or extended socket.
7. Carefully remove the ribbon cable from the front panel LED display. The power switch/fuse assembly will remain attached to the relay and front panel.

8. Carefully remove the ribbon cable from the main board P104 connector.
9. Pull forward on the draw-out tray using the two standoffs located on the bottom of the tray. Removing the draw-out tray will require a good amount of force.
10. With the main board facing up, rotate the draw-out tray so that the back is facing you. The input jumpers are now exposed on the inside of the interface board (board below draw-out tray).
11. Make the correct jumper selection for the desired input voltages per the jumper selection table.
12. Turn board so that the main board is facing up and reinstall into relay chassis. Note guide hole alignment at the back of the draw-out tray and make sure interface pins located on the back plane board are aligned with the draw-out tray before “seating” the draw-out assembly. Inserting the draw-out tray will require a good amount of force.
13. Reattach ribbon cable to main board P104 connector.
14. Reattach ribbon cable to front panel LED assembly.
15. Replace the 4-40 hex jack screws (two only) so that the draw-out tray is secure.
16. Lift the edge of the front panel up into normal position and replace the four front panel screws. (Make sure switch/fuse cable and ribbon cables are free from any “pinch” points.)
17. Make sure power switch/fuse cable assembly is seated on the back panel connector. (During the normal removal process, it is possible to have partially or completely disconnected this cable.)
18. Carefully replace top and bottom chassis covers and screws (eight screws total).

SEL-200 Series Relay Addendum

The SEL-200 series relays with 125 Vdc optical isolator inputs now have level-sensitive inputs. These inputs compare to the original SEL-200 series relays as follows:

**Original SEL-200
Series Optical
Isolator Logic Input
Rating**

125 Vdc: 80–150 Vdc; 4 milliamps at nominal voltage

**New SEL-200 Series
Optical Isolator Logic
Input Rating**

125 Vdc: 100–150 Vdc; 6 milliamps at nominal voltage

The optical isolator input does not assert for applied voltages less than 75 Vdc. The firmware remains unchanged.

SEL Relay Instruction Manual Addendum

Jumper Installation Instructions for All 200-Series Relays Except SEL-279 and SEL-279H

The power available from these ports is limited and should be used only for SEL-RDs, SEL-DTAs, dc-powered modems, or other low-wattage devices approved by SEL.

The power is available on either Port 1 or Port 2R. Port 2F, located on the front of the relay, does NOT have power available.

To install jumpers for supplying power through the rear EIA-232 ports on all SEL-200 series relays (except SEL-279 and SEL-279H Relays), perform the following steps:

1. Remove the relay top cover or withdraw the main circuit board.
2. Locate jumpers JMP12 (+5 Vdc), JMP13 (+12 Vdc) and JMP14 (-12 Vdc) near the AUX INPUT connector.
3. Remove and install the needed jumpers in the “on” position.
4. Replace the top cover or re-insert the main circuit board.
(Ensure that the board is correctly seated and the cables to the power supply and input transformers are reconnected.)

SEL-200 Series (Shallow) Relay Hardware Addendum

The shallow SEL-200 series hardware brings a reduction in unit depth and weight. It compares to the original SEL-200 series relay hardware as follows:

Original SEL-200 Series Relay Hardware Specifications

3.47" x 19.00" x 11.66" (8.81 cm x 48.26 cm x 29.62 cm) (H x W x D)

16 pounds (7.3 kg)

SEL-200 Series (Shallow) Relay Hardware Specifications


3.47" x 19.00" x 9.00" (8.81 cm x 48.26 cm x 22.86 cm) (H x W x D)

12 pounds (5.5 kg)

Depth (dimension D) is to the end of the rear-panel terminal blocks.

This hardware is also equipped for low-level testing. The firmware remains unchanged.

The shallow SEL-200 series relay dimensions, panel cutout, and drill diagrams are on the following page. Note that the long cutout dimension has increased by 0.25" to 17.63" (44.77 cm).



SEL-200 Series (Shallow) Relay Dimensions, Panel Cutout, and Drill Diagrams

Section 1

Introduction

Getting Started

This instruction manual applies to SEL-121G, SEL-121G-3, SEL-121G-4, SEL-221G, SEL-221G-3, and SEL-221G-4 relays. The SEL-221G and SEL-121G relays have identical protection features, but use different hardware designs. Where there are differences between the two relay models, both relays are described. Consult the model variations description below for information about other models available. Firmware changes to the logic controlling front-panel targeting, communication scheme timers, command access level, rear-panel logic input function, and out-of-step mho characteristic diameter differentiate SEL-221G relay model variations.

If you are not familiar with the relay, we suggest that you read this introduction, then perform the Initial Checkout Procedure in [Section 7: Maintenance & Testing](#).

Relay Overview

The SEL-221G family of relays are designed to protect transmission, subtransmission, and distribution lines for all fault types. The following list outlines protective features, performance, and versatility gained when applying any SEL-221G relay to your installations.

- Three zones of instantaneous/definite time phase distance protection
- Residual time-overcurrent element with selectable curves
- Three instantaneous/definite time residual overcurrent elements
- Negative- or zero-sequence polarization of ground directional elements
- Versatile user programmable logic for outputs and tripping
- Programmable switch-onto-fault logic
- Out-of-step blocking of selected three-phase zones for power swings
- Loss-of-potential detection logic
- Programmable three-shot reclosing
- Fault locating
- Metering
- EIA-232 Communication ports for local and remote access

- Automatic self-testing
- Demodulated IRIG-B time code input
- Target indicators for faults and testing
- Compact and economical

Model Variations Covered by This Instruction Manual

SEL offers several optional variations of the SEL-221G Relay logic for a wide range of applications. While this introduction includes a short description of each model variation, the remainder of the instruction manual pertains only to the standard SEL-221G Relay and the -3 and -4 variations. Please consult the information sticker on the relay rear panel if you are unsure of the relay model number.

SEL-221G Relay

The basic SEL-221G Relay employs each feature outlined in the preceding Relay Overview. The front-panel target LEDs are cumulative, indicating all picked up zones instead of only the zone element picked up at the time of trip.

SEL-221G-3 Relay

SEL-221G-3 Relay front-panel LEDs are “trip only targets.” Thus, target LEDs indicate only the closest-in zone element picked up when the TRIP output contacts assert and show only the most recent fault (basic SEL-221G Relay LEDs display cumulative targets).

SEL-221G-4 Relay

The Zone 4 three-phase element diameter is two times that of the Zone 3 three-phase mho element. The Zone 4 three-phase element diameter in all other SEL-221G relays is 1.5 times the diameter of the Zone 3 three-phase element. SEL-221G-4 Relay LED targeting is identical to that of the SEL-221G-3 Relay.

Other SEL-221G Relay Model Variations

These model variation descriptions are provided for comparison purposes.

SEL-221G-5 Relay

The SEL-221G-5 Relay is intended for application in Directional Comparison Blocking (DCB) schemes. Zone 1 phase and ground timers of the basic SEL-221G Relay have been removed to provide two settable timers for the Zone 2 phase and ground elements. BT input assertion in the SEL-221G-5 Relay does not generate an event report as it would in the basic SEL-221G Relay. This eliminates event reports caused by carrier channel noise. The block trip input (BT) incorporates a one-quarter cycle block trip input signal extension to provide added security for out-of-section faults. Zone 3 pickup extension logic is included to serve as block trip transmit extension. The logic output is indicated by the Z3X bit in the Relay Word (Z3X replaces 52AT in the SEL-221G Relay Word). Front-panel LEDs are “trip only targets.” Thus, target LEDs indicate only the closest-in zone element picked up when the TRIP output contacts assert and show only the most recent fault (basic SEL-221G Relay LEDs display cumulative targets).

SEL-221G-8 Relay

The SEL-221G-8 Relay has several differences from the basic SEL-221G Relay model. A Level 2 access attempt does not pulse the ALARM contacts as in the SEL-221G Relay. Instead, the ALARM contacts pulse for four seconds after three unsuccessful Level 1 or 2 access attempts. **DATE, TIME, TRIGGER, and IRIG** command execution requires Level 2 access. In contrast, the basic SEL-221G relay requires only Level 1 access for these commands. **TARGET** command execution from Level 1 only displays targets. **TARGET** command execution from Level 2 displays targets and allows the operator to change front-panel LED assignments. Front-panel LEDs are “trip only targets.” Thus, target LEDs indicate only the closest-in zone element picked up when the TRIP output contacts assert and show only the most recent fault (basic SEL-221G Relay LEDs display cumulative targets). Excluding these differences, the SEL-221G-8 Relay is identical to the SEL-221G-5 Relay.

SEL-221G-9 Relay

The SEL-221G-9 Relay is identical to the SEL-221G-5 Relay except for permissive trip input (PT) assertion, which does not generate an event report. This feature eliminates unwanted event reports for noise bursts on the permissive trip communication channel and allows use of the input as a monitoring input only.

SEL-221G-11 Relay

The SEL-221G-11 Relay is identical to the SEL-221G-5 Relay except for the Z3XPU timer setting used for Zone 3 extension logic in the SEL-221G-11 Relay’s Directional Comparison Blocking (DCB) logic. The SEL-221G-5 has a fixed Z3XPU timer setting of 2 cycles.

General Description

Because the -3 and -4 relay variations are derived from the SEL-221G Relay, this manual refers to all three variations (standard, -3, and -4) as the SEL-221G Relay.

The SEL-221G Phase Distance and Ground Directional Overcurrent Relay with fault locator simultaneously provides high-speed and time delayed protection for transmission, subtransmission, and distribution lines. A 32-bit Relay Word combines mho distance elements, overcurrent elements, directional element, timers, and data and control bits. You can program the logic through bit combinations to control tripping, communication channel keying, reclose initiation and cancellation, and four general purpose programmable outputs.

Because of its many relay elements, large setting ranges, programmability, and low cost, the relay meets the requirements of a broad spectrum of applications. Flexible yet simple programmability provides access to relay elements (before and after time delays) and logic results. Relay features include four zones of three-phase elements, three zones of phase-to-phase elements, three zones of ground elements, time delayed backup for Zones 2 and 3 phase and ground elements, time-overcurrent element, out-of-step blocking, three shot reclosing with programmable initiate and reclose conditions, and loss-of-potential logic.

Without requiring an external initiating contact input, the relay provides time-stepped protection in parallel with communication-aided protection. The relay supports:

- Directional Comparison Blocking (DCB) schemes
- Permissive Overreach Transfer Trip (POTT) schemes
- Directional Comparison Unblocking (DCUB) schemes
- Permissive Underreaching Transfer Trip (PUTT) schemes
- Direct Underreaching Transfer Trip (DUTT) schemes
- Direct Transfer Trip (DTT) schemes

Analog inputs from current and voltage transformers are delivered to the protective relaying elements and saved for additional features such as metering and fault locating.

Relay elements process the analog data. Some intermediate logic is performed, such as overcurrent supervision of the mho elements, directional supervision of the residual overcurrent elements, and grouping of certain elements into zones.

The relay generates an 11-cycle event report starting with information captured four cycles before fault detection through seven cycles afterward. Each event report resembles a sequence-of-events report; each includes the following information every quarter cycle for 11 cycles:

- Voltages (VA, VB, and VC)
- Currents (IA, IB, IC, IR (residual), and IP (current polarizing input))
- Fault type and involved phases
- Fault location
- Secondary ohms to the fault location
- Maximum phase current measured near the middle of the fault
- Date and time of the event
- Relay element status
- External inputs (breaker status, block trip, etc.)
- Relay contact outputs

The information in each event report simplifies analysis of the most complex system operations.

The relay stores the latest 12 event reports, allowing retrieval and examination after the event. A user can retrieve any or all records remotely or locally through either of the two serial communications ports.

The metering function permits interrogation of the relay to obtain power system voltage, current, real power, and reactive power readings. The function also includes per-phase measurements of voltage and current. Metering is very valuable for unmanned or remote substations.

The CLOSE, A1, A2, A3, A4, and ALARM outputs may be specified as “a” or “b” type contacts. TRIP outputs are always an “a” type contact.

The relay is compatible with the SEL-2020 Communications Processor, the SEL-DTA Display/Transducer Adapter, and the SEL-PROFILE Transmission Line Fault Analysis Program.

ACB Phase Rotation Option

The SEL relay instruction manuals are written for standard ABC phase rotation applications. If your SEL relay is ordered with the ACB phase rotation option, references made in the instruction manual to voltage and current phase angle should be noted accordingly. The firmware identification number (FID) may be used to verify whether your relay was ordered with ABC ("B") or ACB ("C") rotation.

All current and voltage inputs are connected to the SEL relay rear panel as shown in the instruction manual.

50 Hz Options

This manual is written for relays operating at a nominal system frequency of 60 Hz. For relays which specify a nominal frequency of 50 Hz, substitute 50 Hz for each reference to 60 Hz.

References made to a sampling time of 1/240 seconds should be replaced with a time of 1/200 seconds.

Kilometer Option

The SEL-221G/121G Relay instruction manual is written for fault locations in terms of miles. If your SEL-221G/121G Relay is ordered with the kilometer line length option, references made in the instruction manual to miles should be substituted with kilometers.

One exception to the straight substitution of kilometers for miles is the reference in the instruction manual to the effect of shunt capacitance on the fault location calculation. The line length equation and associated paragraphs, corrected for a 100-kilometer line, should read:

Shunt capacitance of the transmission line is not taken into account. The capacitance causes the fault location to appear less remote by, approximately, a factor of $1/\cos(bL)$, where bL is the line length in radians at 60 Hz. One wavelength at 60 Hz is 4989 kilometers. For example, the line length of a 100-kilometer line in radians, is:

$$(100/4989) * 2 * 3.14159 = 0.1260 \text{ radians}$$

The indication neglecting capacitance is about $\cos(0.1260) = 0.992$ times the actual fault location, or about 0.8 kilometers short for a fault at the remote end of a 100-kilometer line.

This page intentionally left blank

Section 2

Specifications

This section is divided into three subsections. The first describes input parameters, mechanical specifications, and applicable standards. The second provides a functional specification, while the third details the technical features of each relay function.

Relay Standards and Input Parameters

Rated AC Input Voltage	115 V nominal phase-to-phase, three-phase four-wire connection
Rated AC Input Current	5 A per phase nominal 15 A per phase continuous 500 A for one-second thermal rating
Output Contact Current Ratings	30 A make per IEEE C37.90 para 6.7.2 6 A carry continuously MOV protection provided
Optoisolated Inputs SEL-221 Series	The following optoisolated inputs draw 4 mA when nominal control voltage is applied: 24 Vdc: 15–30 Vdc 48 Vdc: 30–60 Vdc 250 Vdc: 150–300 Vdc Fixed “Level-Sensitive” inputs are provided on relays with 125 Vdc optoisolated inputs. The 125 Vdc optoisolated inputs each draw 6 mA when nominal control voltage is applied. 125 Vdc: on for 100–150 Vdc; off below 75 Vdc
Optoisolated Inputs SEL-121 Series	The following optoisolated inputs draw 6 mA when nominal control voltage is applied: 24 Vdc: 10–30 Vdc 48 Vdc: 25–60 Vdc 125 Vdc: 60–200 Vdc 250 Vdc: 200–280 Vdc
Power Supply	24/48 V: 20–60 Vdc; 12 watts 125/250 V: 85–350 Vdc or 85–264 Vac; 12 W
Communications	Two EIA-232 serial communications ports. Port 2 has front- and rear-panel connectors.
Relay Dimensions	SEL-221G: Refer to Figure 6.12 . SEL-121G: 13.3 cm x 48.2 cm x 33.0 cm (5.25 in. x 19 in. x 13 in.) (H x W x D)
Mounting	Mounts in standard EIA 48.2 cm (19 in.) relay rack or panel cutout. Available in horizontal or vertical mounting configurations.
Operating Temperature	–40° to 70°C (–40° to 158°F)
Dielectric Strength Routine Tested	V, I inputs: 2500 Vac for 10 seconds Other: 3000 Vdc for 10 seconds (excludes EIA-232)
Interference Tests	IEEE C37.90 SWC Test (type tested) IEC 255-6 Interference Test (type tested)
Impulse Tests	IEC 255-5 0.5 J, 5000 Volt Test (type tested)

RFI Tests	Type-tested in field from a 1/4-wave antenna driven by 20 W at 150 MHz and 450 MHz randomly keyed on and off one meter from relay.
ESD Test	IEC 801-2 (type tested)
Unit Weight	SEL-221G: 5.5 kg (12 lb) SEL-121G: 9.5 kg (21 lb)
Shipping Weight	SEL-221G: 7.7 kg (17 lb), including one instruction manual SEL-121G: 11.8 kg (26 lb), including one instruction manual
Environmental Tested	IEC 68-2-30 (type tested)

Functional Specifications

Expanded Mho Characteristics for Phase-Phase and Three-Phase Faults

- Three zones of phase-phase distance protection
- Four zones of three-phase distance protection
 - Zone 4 employed for out-of-step blocking and switch-onto-fault tripping
 - Zone 4 concentric to Zone 3 and includes the origin. Zone 3 reversible, but Zone 4 always remains forward.
- Zones 1, 2, and 3 three-phase distance elements memory polarized
 - Zone 4 does not require memory polarization due to its offset
- Independent timers for Zones 1, 2, and 3 distance elements (time-step backup protection)
- Fault detector elements supervise all distance elements
- Loss-of-potential logic supervises all distance elements, when enabled
- Zone 3 reversible with a simple setting (all Zone 3 elements are reversed when ZONE3 = R in the relay settings)




Figure 2.1 Phase-Phase and Three-Phase Mho Element Characteristics

Residual Overcurrent Protection for Ground Faults

- Time-overcurrent element
 - Four curve families (moderate, inverse, very inverse, and extremely inverse)
 - Nondirectional or forward reaching as enabled in relay settings
- Three residual overcurrent elements
 - Independent timers for Zones 1, 2, and 3 elements (time-step backup protection)
 - Zone 3 reversible with a simple setting
- Choice of three polarization techniques for directional control
 - Nondirectional if no polarization method is selected
- Three methods of residual overcurrent directional polarization:
 - Negative-sequence voltage and current
 - Zero-sequence voltage and residual current
 - External zero-sequence current and residual current
- May be dual zero-sequence polarized




Figure 2.2 Residual Overcurrent Zones of Protection

Out-of-Step Blocking

- Zone 4 three-phase mho (4ABC) pickup starts out-of-step blocking timer (OSBT)
- Settable out-of-step blocking timer (OSBT)
- Selected three-phase distance elements are blocked for two seconds after out-of-step blocking timer expires




Figure 2.3 Out-of-Step Blocking Characteristics

Reclosing

- Three separate shots of reclosing with settable open interval timers
- Selectable reclose initiate and cancel conditions
- Settable reclose reset timer

Loss-of-Potential (LOP) Detection

- Detects blown secondary potential fuse(s) condition
- Enabled or disabled with a simple setting
- When enabled, an LOP condition blocks all mho distance elements
- LOP detection may be selected to close an output relay for alarming purposes

Nondirectional Phase Overcurrent Elements

- Low-set phase overcurrent elements supervise mho distance elements and release the TRIP output contacts in conjunction with the low-set residual overcurrent element
- Medium-set phase overcurrent element for loss-of-potential (LOP) logic and nondirectional phase overcurrent protection during LOP conditions (or nondirectional phase overcurrent protection when LOP is not enabled in the relay settings)
- High-set phase overcurrent element provides switch-onto-fault protection for close-in three-phase faults

Switch-Onto-Fault Protection

- User-selected elements enabled to trip for 52BT time after the line breaker closes
- Functions independently from communications channel equipment

IRIG-B Input

The relay accepts demodulated IRIG-B from an external clock source to set the internal clock automatically.

Relay Word

The Relay Word is the center of relay programmability. It consists of four rows of eight bit groups that represent the state of the relay elements (both instantaneous and timed), timer and logic outputs, and relay inputs. Each bit in the Relay Word has two states: logical 1 when the element is asserted, logical 0 when the element is deasserted.

Each quarter-cycle, the relay samples voltage and current data, performs intermediate logic to determine if an element is asserted, and sets the appropriate bit in the Relay Word.

After updating the Relay Word, the relay compares it to all programmable logic masks with a bitwise logical “AND” process. This process in turn controls the relay output contacts. Each TRIP, programmable output relay, reclose initiate and cancel condition has a corresponding logic mask (see [Programmable Logic Masks](#)). These masks determine the state of the output relay and reclosing sequence, depending on which elements are asserted in the Relay Word.

[Table 2.1](#) shows the Relay Word for the relay.

Table 2.1 Relay Word

1ABC	2ABC	3ABC	4ABC	LOP	50H	50M	50L
51NT	67N1	67N2	67N3	51NP	Z1P	Z2P	Z3P
Z2PT	Z3PT	OSB	3P50	50MF	RC	RI	DF
ALRM	TRIP	TC	DT	52BT	52AT	Z2GT	Z3GT

Logic Inputs

The relay has six opto-isolator inputs to sense external conditions: received permissive trip and block trip signals, breaker status, direct close, direct trip, and external event report trigger. Assert these logic inputs by applying control voltage to the corresponding rear-panel input terminals.

Output Contacts

The relay has seven output contacts: TRIP, CLOSE, ALARM, and four programmable outputs (A1, A2, A3, and A4). Any output contact except TRIP may be configured as either “a” or “b.” Each TRIP output contact is always “a.”

Event Reporting

The relay retains 11 cycle data records for each of the last 12 events. The long form of each event record includes the following:

1. Date and time of disturbance*
2. Terminal identifier*
3. Input voltages and currents every quarter-cycle
4. Relay element status every quarter-cycle
5. Input and output contact status every quarter-cycle
6. Fault Location*
7. Event type*
8. Maximum phase current magnitude near the middle of the fault*

9. Fault duration in cycles*

10. Relay and logic settings

* Included in the summary event report and event history listing.

An event report is triggered when certain relay elements pick up, the TRIP output contacts close, the Direct Trip, Permissive Trip, Block Trip, or External Trigger input asserts, or by **TRIGGER** or **OPEN** command execution.

If tripping occurs after the end of the event report, the trip triggers a second report. For details on the contents and analysis of relay event reports, see [Section 4: EVENT REPORTING](#).

Fault Location

The relay computes fault location using event report data stored for each fault or disturbance. The primary fault locating algorithm compensates for prefault current to improve fault locating accuracy for high-resistance faults. The relay uses two fault locating methods: the Takagi method where sound prefault data are available, or a simple reactance method when sound prefault data are not available.

Metering

The meter function shows the line-neutral and line-line ac voltage and current values, megawatts (P to represent real power), and megavars (Q to represent reactive power) in primary values. You can display these values locally or remotely with the **METER** command.

Targeting

The relay has seven target levels (0 – 6). In Target Level 0, the front-panel target LEDs correspond to front-panel markings. Under normal operating conditions, the enable (EN) LED is illuminated. SEL-221G relay targets indicate all picked up zones if the relay trips. SEL-221G-3 and SEL-221G-4 relay target LEDs illuminate for the highest priority zone and fault type at the time of trip. Target LEDs are latching, so the targets remain illuminated until you press the Target Reset button, execute the **TARGET R** command, or a trip with a different zone and fault type occurs.

The **TARGET** command and front-panel LED display allow assignment of front-panel LEDs to show the state of relay inputs, outputs, and Relay Word elements. See the **TARGET** command in [Section 3: Communications](#) for more details.

You may clear front-panel targets locally by pressing the front-panel TARGET RESET button or remotely with the **TARGET RESET (TAR R)** command when there is no trip condition. If a trip condition is present when you press the TARGET RESET button or issue the **TARGET RESET** command, front-panel targets do not clear. This feature should always be used as a test before closing the trip cutout switch on the line terminal control panel. The TARGET RESET button also unlatches TRIP output contacts to prevent relay installation with TRIP contacts closed.

Self-Testing

The relay runs exhaustive self-tests, which ensure reliable operation. If a test fails, the relay enters a warning or failure state, closes the ALARM output relay, and issues a status report to the port(s) designated automatic. The duration of ALARM output contact closure depends on which self-test warns or fails.

- Self-tests check the following items:
- Analog Channel Offset (IP, IR, IA, IB, IC, VA, VB, and VC)
- +5 V Power Supply

- ±15 V Power Supplies
- Random Access Memory (RAM)
- Read-Only Memory (ROM)
- A/D Conversion Time
- Master Offset
- Settings

See [Detailed Specifications](#) for a complete description of self-tests.

Detailed Specifications

Distance Elements

Phase-Phase Distance (Secondary Quantities)

21P1: 0.125 to 64 Ω

21P2: 0.125 to 64 Ω

21P3: 0.125 to 64 Ω

Three-Phase Distance (Secondary Quantities)

21ABC1: 0.125 to 64 Ω

21ABC2: 0.125 to 64 Ω

21ABC3: 0.125 to 64 Ω

21ABC4: offset mho with diameter 1.500 times Zone 3

Maximum Torque Angle (MTA)

Adjustable from 47 – 90 degrees.

Zone 2 and 3 Settings Are Limited as Follows:

For Zone 3 Forward: Zone 1 < Zone 2 < Zone 3

For Zone 3 Reverse: Zone 1 < Zone 2, Zone 1 < Zone 3

Accuracy

Steady-State Error

- ±5% of set reach ± 0.01 Ω at MTA for V > 5 V and I > 2 A.
- ±10% of set reach ± 0.01 Ω at MTA for 1 < V < 5 V and 0.5 < I < 2 A.

Transient Overreach

- ±5% of set reach, plus steady-state error.

Operating Speed

See operating time curves at the end of this section.

Memory Polarization

Zone 1, 2, and 3 three-phase elements are memory polarized from a four-cycle memory filter.

Distance Element Timers

NOTE: The instantaneous and time-delayed outputs of the Zone 2 and Zone 3 distance elements are separate in the Relay Word, permitting access to both. This allows use of a time delay for time-stepped backup functions while maintaining the required instantaneous outputs for communication-based schemes. Please note that any time delay set for Z1DP is included in the Zone 1 distance elements representation in the Relay Word (IABC and ZIP).

Zone 1 timer (Z1DP) range: (0 – 60 cycles in $\frac{1}{4}$ cycle steps)

Zone 2 timer (Z2DP) range: (0 – 2000 cycles in $\frac{1}{4}$ cycle steps)

Zone 3 timer (Z3DP) range: (0 – 2000 cycles in $\frac{1}{4}$ cycle steps)

Overcurrent Elements

Nondirectional Phase Overcurrent Elements (Secondary Quantities)

- 50AL, 50BL, 50CL (low-set phase fault detectors)
- 50AM, 50BM, 50CM (medium-set phase fault detectors used in LOP logic)
 - Pickup: 0.5 to 40 A, ± 0.1 A $\pm 2\%$ of setting
 - Transient overreach: 5% of set pickup
- 50AH, 50BH, 50CH (high-set phase overcurrent elements)
 - Pickup: 0.5 to 80 A, ± 0.1 A $\pm 2\%$ of setting
 - Transient overreach: 5% of set pickup

Ground Overcurrent Elements (secondary quantities)

51N residual time-overcurrent element:

- Selectable curve shape (four curve families)
 - Moderately Inverse (curve family 1)
 - Inverse (curve family 2)
 - Very Inverse (curve family 3)
 - Extremely Inverse (curve family 4)
- Time dial: 0.50 to 15.00 in 0.01 steps
- Pickup: 0.25 to 6.3 A, ± 0.05 A $\pm 2\%$ of setting
- Timing: $\pm 4\%$ and ± 1 cycle for residual current magnitude between 2 and 20 multiples of pickup
- May be directionally controlled (51NTC setting)

50N1, 50N2, 50N3 residual overcurrent elements:

- Pickup: 0.25 A to 48 times 51N pickup for 51N pickup < 3.15 A
0.5 A to 48 times 51N pickup for 51N pickup ≥ 3.15 A
- Transient overreach: 5% of set pickup
- May be directionally controlled (32Q, 32V, and 32I enables)

Ground Overcurrent Element Timers

NOTE: The instantaneous and time-delayed outputs of the ground overcurrent elements are separate in the Relay Word, permitting access to both. This allows use of a time delay for time-stepped backup functions while maintaining the required instantaneous outputs for communication-based schemes. Please note that any time delay set for ZIDG is included in the 67N1 bit of the Relay Word.

Zone 1 timer (Z1DG) range: (0 – 60 cycles in $\frac{1}{4}$ -cycle steps)

Zone 2 timer (Z2DG) range: (0 – 2000 cycles in $\frac{1}{4}$ -cycle steps)

Zone 3 timer (Z3DG) range: (0 – 2000 cycles in $\frac{1}{4}$ -cycle steps)

Ground Directional Elements

The relay provides four methods of polarizing the directional ground overcurrent elements:

1. Negative-sequence voltage and current
2. Zero-sequence voltage and measured residual current
3. External zero-sequence current and measured residual current
4. Methods 2 and 3 combined

With negative-sequence polarization selected, you may not select zero-sequence polarization. The primary setting procedure of the relay performs this check.

Negative-Sequence Directional Element

- The angle between the measured negative-sequence voltage and current adjusted by the MTA setting determines fault direction (see [Figure 2.4](#))
- Angle: MTA setting
- Sensitivity: see [Table 2.2](#)

Zero-Sequence Directional Element

Voltage polarization:

- The angle between the measured zero-sequence voltage and residual current adjusted by the MTA setting determines fault direction (see [Figure 2.4](#))
- Angle: MTA setting
- Enabled with 32VE setting in the relay setting procedure
- Does not require an external voltage polarizing source
- Sensitivity: see [Table 2.2](#)

Current polarization:

NOTE: If you want current polarization of the ground directional elements, you must wire an external zero-sequence current source to the Ipol inputs on the rear panel.

NOTE: 32V and 32I sensitivities depend on the pickup setting of the residual time-overcurrent element 5INP.

- The relay measures the angle between measured residual current and zero-sequence current from an external source to determine fault direction (see [Figure 2.5](#))
- Angle: Zero degrees
- Enabled with the 32IE setting in the relay setting procedure
- Sensitivity: see [Table 2.2](#)

Table 2.2 Directional Element Sensitivities at Maximum Torque Angle (MTA)

Element	Negative-Sequence 32Q	Zero-Sequence 32D
Sensitivity	0.10	(0.29)(51NP)
Units	(V2)(I2)	(V0)(IR)




Figure 2.4 32Q and 32V Polarization Criteria




Figure 2.5 32I Polarization Criteria

Please refer to the Functional Description portion of this section for equations to determine directional element sensitivities at fault angles other than maximum torque angle.

LOP Sequence-Component Elements

The following elements have fixed settings and are used in the loss-of-potential detection logic. All thresholds are in secondary quantities.

- Zero-sequence overvoltage element (47NL)
 - Pickup: 14 V of V0
 - Zero-sequence overcurrent element (50NL)
- Pickup: $I_0 = 0.083 \text{ A}$ for 51N pickup $< 3.15 \text{ A}$
- $$I_0 = (0.083 \text{ A})(51\text{N pickup}/3.15 \text{ A}) \text{ for 51N pickup}$$
- $$\geq 3.15 \text{ A}$$
- Positive-sequence overvoltage element (47P)
- Pickup: 14 V of V1

Miscellaneous Timers

All timers are set in cycles with 1/4-cycle resolution.

- 790I1 - Reclose relay open interval 1 : 0.0 – 10,000
- 790I2 - Reclose relay open interval 2 : 0.0 – 10,000
- 790I3 - Reclose relay open interval 3 : 0.0 – 10,000
- 79RS - Reclose relay reset time : 60.0 – 8,000
- 50MFD - Loss-of-potential enabled O/C, TDPU : 0.0 – 60
- 52BT - Switch-On-Fault timer, TDPU/TDDO : 0.5 – 10,000
- TDUR - Minimum trip duration timer : 0.0 – 2,000 (0.0 Disables the OPEN Command)
- OSBT - Out-of-step blocking timer : 0.5 – 60

TDPU ≡ Time-delayed Pickup

TDDO ≡ Time-delayed Dropout

Logic Inputs

Six logic inputs control relay functions. Assert a logic input by applying control voltage to the corresponding rear-panel contact input terminals. Control voltage polarity is not important.

Direct Trip (DT)

Asserting the DT input immediately and unconditionally sets the DT bit in the Relay Word. The DT bit remains set until the DT input deasserts, dropping out about one-half cycle after DT deasserts. Applications include test trip and Direct Underreaching Transfer Trip (DUTT) schemes. Asserting this input generates an event report.

You can also use the DT input to enable the relay reclosing functions for line breaker trips by backup protection. For instance, if you want to reclose when the backup protection trips the line breaker, the DT input should monitor the trip output from the backup protection. Mask the DT bit in the MTU logic mask to ensure satisfying the condition that the relay must trip before the reclosing functions are enabled. To make this tripping condition a reclose initiate condition, mask the DT bit in the MRI logic mask as well.

The **OPEN** command has the same effect as the DT input but instead asserts the TC bit in the Relay Word.

Direct Close (DC)

The DC input shuts the CLOSE output if no fault is detected, a trip condition is not present, and the 52A input is not asserted. The **CLOSE** command has the same effect as the DC input. Asserting this input does not trigger an event report.

Permissive Trip (PT)

The PT input is normally used in Permissive Overreaching Transfer Tripping (POTT) schemes. When asserted, additional tripping conditions are allowed, as selected in the logic setting procedure (see the **LOGIC MPT** command). Asserting this input generates an event report.

Block Trip (BT)

The BT input is normally used in Directional Comparison Blocking (DCB) schemes. When not asserted, selected tripping conditions are allowed (see the **LOGIC MTB** command). This input also triggers an event report. If you are not applying the relay to a DCB scheme, the MTB logic mask should contain all zeros to avoid tripping by the blocking logic when the BT input is not asserted.

Circuit Breaker Monitor (52A)

The 52A input indicates the state of the breaker. This input is asserted when the breaker is closed and deasserted when the line breaker is open. The recloser, **CLOSE** command, and switch-onto-fault logic use the status of this input. Asserting this input does not trigger an event report.

External Trigger for Event Report (ET)

Assertion of the external trigger input triggers an event report. Assertion does not influence the protective functions in any way. Applications include monitoring trips initiated by backup protection, breaker failure relaying, bus differential relaying, etc.

Relay Outputs

The relay has seven output relays. All outputs except the ALARM output can be programmed with the **LOGIC** command.

With the exception of the TRIP output relay, all outputs may be configured as either “a” or “b” contacts.

All relay contacts are rated for circuit breaker tripping duty.

TRIP Output

This output closes for any number of conditions you select. Conditions are grouped as follows: unconditional (MTU logic mask), subject to PT input assertion (MPT logic mask), subject to the absence of BT input assertion (MTB logic mask), or subject to the breaker being just opened or closed (MTO logic mask). The TRIP output never closes for less than the fault condition duration or the TRIP Duration timer interval. After this, it opens when the fault condition is gone, as judged by the dropout of both the low-set phase (50L) and low-set residual overcurrent (50NL) elements.

CLOSE Output

This output closes for reclose operations, DC input assertion, and **CLOSE** command execution. The CLOSE output remains closed until the 52A input asserts or the 79RS timer expires, whichever occurs first. The 79RS timer is decremented when the CLOSE output relay asserts. No event report is triggered.

ALARM Output

The ALARM output closes for the following conditions:

- Three unsuccessful Level 1 access attempts: 1-second pulse
- Any Level 2 access attempt: 1-second pulse
- Self-test failure: permanent contact closure or 1-second pulse depending on which test fails (see [Table 2.6](#))
- The ALARM output closes momentarily when relay settings, logic settings, or passwords are changed. It also closes when a date is entered, if the year stored in EEPROM differs from the year entered (see **DATE** command).

Programmable Outputs (A1, A2, A3, A4)

These four outputs may be assigned to any combination of bits in the Relay Word.

Logic Description

Relay logic includes relay elements, timers, and combinations of conditions. Many of these are recorded in the Relay Word (R), which forms the heart of the programmable mask logic. Elements and other quantities available in the Relay Word appear in boldface type.

Relay Elements

Low-set single-phase O/C relays	50AL 50BL 50CL	(fault detectors and TRIP unlatch)
Medium-set single-phase O/C relays	50AM 50BM 50CM	(selectable for loss-of-potential)
High-set single-phase O/C relays	50AH 50BH 50CH	(always available)
Zone 4 three-phase mho distance	21ABC4	(out-of-step blocking start)
Zone 3 three-phase mho distance	21ABC3	(reversible)
Zone 3 phase-phase mho distance	21P3	(reversible)
Zone 2 three-phase mho distance	21ABC2	
Zone 2 phase-phase mho distance	21P2	
Zone 1 three-phase mho distance	21ABC1	
Zone 1 phase-phase mho distance	21P1	
Residual time-overcurrent pickup	51NP	directional as enabled
Residual time-overcurrent trip	51NT	directional as enabled

Residual overcurrent	50N1	nondirectional
Residual instantaneous overcurrent	50N2	nondirectional
Residual instantaneous overcurrent	50N3	nondirectional
Negative-sequence directional	32Q	32QF=forward; 32QR=reverse
Zero-sequence dual pol. directional	32D	32DF=forward; 32DR=reverse
Zero-sequence overvoltage	47NL	LOP detection
Zero-sequence overcurrent	50NL	LOP detection and TRIP unlatch
Positive-sequence overvoltage	47P	LOP detection

Optically Coupled Contact Inputs

Direct trip	DT
Permissive trip	PT
Block trip	BT
Direct close	DC
Circuit breaker monitor	52A
External trigger for event report	EXT

Contact Outputs

Circuit breaker trip (two contacts)	TRIP
Circuit breaker close	CLOSE
Programmable output 1	A1
Programmable output 2	A2
Programmable output 3	A3
Programmable output 4	A4
System alarm	ALARM

Intermediate Logic

The logic equations below represent combinations of the relay elements and other conditions. In the following equations, “*” indicates a logical “and,” while “+” indicates a logical “or.”

Because so many binary variables are involved, we define the functioning with Boolean logic equations.

Loss-of-Potential (LOP) Logic

$$\begin{aligned}
 \text{Set LOP} &= [47NL * \text{NOT}(50NL)] \\
 &\quad + \text{NOT}(47P) * \text{NOT}(\mathbf{50M}) \\
 \text{Clear LOP} &= \text{NOT}(47NL) * 47P
 \end{aligned}$$

Zero-sequence set condition includes a three-cycle pickup delay.

Different set and clear conditions ensure that **LOP** stays latched during subsequent faults and clears when balanced voltages and currents return.

Phase Overcurrent Conditions

50L	= 50AL + 50BL + 50CL	Phase fault current supervision
3P50	= 50AL * 50BL * 50CL	Three-phase fault current supervision
50M	= 50AM + 50BM + 50CM	Medium-level overcurrent condition
50MF	= 50M * [LOP + NOT(LOPE)] * 50MFD	Asserts a settable delay after LOP and 50M overcurrent, or 50M overcurrent only if LOP is disabled
50H	= 50AH + 50BH + 50CH	High-level overcurrent condition

Out-of-Step Blocking Logic

OSB Timer reset condition = [(OSB Timer < OSBT setting) * (21ABC3 (if forward) + 21ABC2)] + NOT(21ABC4)
 OSB Timer run condition = (21ABC4) Reset takes precedence over run.
OSB = [(OSBT setting) < (OSB Timer) < (OSBT setting + 120 cycles)]
OOSB1 = **OSB** * (OSB1 = Y in relay settings)
OOSB2 = **OSB** * (OSB2 = Y in relay settings)
OOSB3 = **OSB** * (OSB3 = Y in relay settings)

Distance Relay Logic

Z4ABC	= 21ABC4 * 3P50 * NOT (LOP * LOPE)	4ABC in Relay Word
Z3ABC	= 21ABC3 * 3P50 * NOT (OOSB3 + LOP * LOPE)	3ABC in Relay Word
Z2ABC	= 21ABC2 * 3P50 * NOT (OOSB2 + LOP * LOPE)	2ABC in Relay Word
Z1ABC	= 21ABC1 * 3P50 * NOT (OOSB1 + LOP * LOPE) * Z1DP	1ABC in Relay Word
Z3P	= 21P3 * 50L * NOT (LOP * LOPE)	
Z2P	= 21P2 * 50L * NOT (LOP * LOPE)	
Z1P	= 21P1 * 50L * NOT (LOP * LOPE) * Z1DP	
Z3PT	= (Z3P + Z3ABC) * Z3PD	Zone 3 timeout-phase
Z2PT	= (Z2P + Z2ABC) * Z2PD	Zone 2 timeout-phase

Residual Overcurrent Conditions

DF	= [(32QF + LOP * LOPE) * 32QE] + [32DF * 32IE] + [(32DF + LOP * LOPE) * 32VE] + NOT(32QE + 32VE + 32IE)	Direction Forward
DR	= 32QR * 32QE + 32DR * (32IE + 32VE)	Direction Reverse
D3	= DF	If Zone 3 is forward
D3	= DR	If Zone 3 is reverse
67N1	= 50N1 * DF * Z1DG	
67N2	= 50N2 * DF	
67N3	= 50N3 * D3	

Note: When all directional elements are disabled (32QE = 32VE = 32IE = N), the **DF** (Directional Forward) bit defaults forward. Under these conditions, the Zone 3 ground element will not operate when Zone 3 is reversed.

Z3GT = 67N3 * Z3DG	Zone 3 timeout-ground
Z2GT = 67N2 * Z2DG	Zone 2 timeout-ground

Output Equations and Logic

The relay has programmable logic for controlling the **TRIP**, A1, A2, A3 and A4 output relays for flexibility and testing. Two separate masks are provided for reclose initiation and cancellation. The logic is programmed by setting masks for various conditions. These masks are applied to the general Relay Word. The form for each output equation follows:

Let R = Relay Word

MTU	= mask for trip	(unconditional)
MPT	= mask for trip	(permissive trip)
MTB	= mask for trip	(with no blocking)
MTO	= mask for trip	(with breaker just opened or closed)

then:

TRIP = [R * MTU	(unconditional tripping)
+ R * MPT * PT	(permissive tripping)
+ R * MTB * NOT (BT)	(tripping with BT input deasserted)
+ R * MTO * 52BT]	(breaker open/just closed tripping)
* NOT (TS)	(trip suspicion not detected)

$$\text{Close TRIP contact} = \text{TRIP}$$

$$\text{Open TRIP contact} = \text{NOT}(\text{TRIP}) * [\text{NOT}(\text{50NL} + \text{50L}) + \text{TARGET RESET button pushed}] * (\text{Minimum Trip Duration timer (TDUR) expired})$$

Trip Suspicion Logic

Potential transfer switches temporarily remove the polarizing potentials from the relay when a substation operator transfers the potential source from one bus to another. Because it is undesirable to parallel secondary windings of potential transformers from separate sources, this occurrence is inherent to potential transfer switch installations. This temporary removal of polarizing voltages coupled with load currents above the 50L fault detector threshold may result in a race between the three-phase loss-of-potential pickup logic and the three-phase distance element pickup. Three-phase LOP logic is included to address the loss of three secondary potential fuses, not potential transfer switch applications.

The logic developed to address potential transfer switch applications is shown in Figure 2.6.

NOTE: The 52A input contact on the rear panel of the relay must be deasserted when the operator depresses the potential transfer switch.




Figure 2.6 Trip Suspicion (TS) Logic

Please consult [Section 5: Applications](#) for a description of the Trip Suspicion (TS) logic.

Close CLOSE contact = (DC + 790I1 + 790I2 + 790I3 + CLOSE COMMAND) *
NOT (52A) * NOT (**TRIP**)

Open CLOSE contact = NOT (CLOSE) + 79RS

A1 = R * MA1

A2 = R * MA2

A3 = R * MA3

A4 = R * MA4

The “*” indicates a logical “and,” while the “+” indicates a logical “or.”

Relay Word

The Relay Word consists of four eight-bit rows containing relay elements, intermediate logic results, logic inputs, and relay outputs. Each bit in the Relay Word is either a logical 1 or logical 0.

- 1 indicates a picked up element or true logic condition
- 0 indicates a dropped out element or false logic condition

The Logic Description defines logic conditions in the Relay Word.

Table 2.3 Relay Word

1ABC	2ABC	3ABC	4ABC	LOP	50H	50M	50L
51NT	67N1	67N2	67N3	51NP	Z1P	Z2P	Z3P
Z2PT	Z3PT	OSB	3P50	50MF	RC	RI	DF
ALRM	TRIP	TC	DT	52BT	52AT	Z2GT	Z3GT

The Relay Word Bit Summary Table explains each bit in the Relay Word.

Table 2.4 Relay Word Bit Summary

1ABC	Zone 1 three-phase instantaneous element (set by Z1%) ^a
2ABC	Zone 2 three-phase instantaneous element (set by Z2%)
3ABC	Zone 3 three-phase instantaneous element (set by Z3%)
4ABC	Zone 4 three-phase instantaneous element (equal to 1.5 x Z3%)
LOP	Loss-of-potential condition
50H	High-level overcurrent element (set by 50H)
50M	Medium-level overcurrent element (set by 50M)
50L	Phase fault current supervision (set by 50L)
51NT	Residual time-overcurrent trip (set by 51NP, 51NTD, and 51NC)
67N1	Residual instantaneous-overcurrent (pickup set by 50N1P) ^{a, b}
67N2	Residual instantaneous-overcurrent (pickup set by 50N2P) ^b
67N3	Residual instantaneous-overcurrent (pickup set by 50N3P) ^b
51NP	Residual time-overcurrent pickup
Z1P	Zone 1 phase-phase element (set by Z1%) ^a
Z2P	Zone 2 phase-phase element (set by Z2%)
Z3P	Zone 3 phase-phase element (set by Z3%)

Table 2.4 Relay Word Bit Summary

Z2PT	Zone 2 timeout phase (set by Z2DP)
Z3PT	Zone 3 timeout phase (set by Z3DP)
OSB	Out-of-step block condition
3P50	Three-phase fault current supervision
50MF	Asserts a settable delay after LOP and 50M pickup (delay set by 50MFD)
RC	Reclose cancel condition
RI	Reclose initiate condition
DF	Direction forward for ground faults
ALRM	System alarm
TRIP	Follows trip condition
TC	Trip (OPEN) Command
DT	Follows DT input
52BT	Time-delayed inverse of 52A input (delay set by 52BT setting) ^a
52AT	Time-delayed 52A input (delay set by 52BT setting)
Z2GT	Zone 2 timeout-ground (set by Z2DG)
Z3GT	Zone 3 timeout-ground (set by Z3DG)

^a Includes any delay set by the respective Zone 1 time delay.^b The 50N elements are made directional by enabling any of the directional control methods, i.e., 320E = Y, or either 32VE = Y or 32IE = Y.

Programmable Logic Masks

The relay uses programmable logic masks to control the TRIP and programmable output relays and reclosing initiation and cancellation. The following four masks control the TRIP output relay:

- Mask for Trip Unconditional (MTU)
- Mask for Permissive Trip (MPT)
- Mask for Trip Blocking (MTB)
- Mask for Trip while breaker Open (MTO)

Each of the four programmable output relays have separate logic masks: MA1, MA2, MA3, and MA4. To program each logic mask, select elements of the Relay Word which, when asserted, can close the associated output relay, cancel or initiate a reclosing sequence (see **LOGIC** command). For example, if an element in the Relay Word asserts and the same element is selected in a logic mask, the output contact associated with the logic mask closes.

Serial Interfaces

The SEL-221G relay is equipped with two EIA-232-C serial communications ports. Port 2 has 9-pin connectors on both the front and rear panels, designated Port 2F and Port 2R, respectively.

Port 2R, located on the relay rear panel, is typically used with an SEL-DTA Display/Transducer Adapter, SEL-RD Relay Display, or local printer. Port 2F is always available for short-term local communications with a portable computer or printing terminal. Simply plug the device into the front-panel port. The relay automatically discontinues communications with Port 2R and addresses Port 2F. When testing or data retrieval is complete, unplug the temporary device from Port 2F. The relay automatically resumes communication with the device connected to Port 2R.

Serial communications Port 1 and the Auxiliary Input for demodulated IRIG-B time code input remain on the relay rear panel.

The SEL-121G Relay does not include a front-panel connector for PORT 2.

CAUTION

Do not select two baud rates for the same port as this can damage the relay baud rate generator. The relay is shipped with Port 1 set to 300 baud and Port 2 set to 2400 baud.

Communications port baud rate jumpers are located along the front edge of the circuit board. To select a baud rate for Port 1 or Ports 2, remove the relay front panel. The jumpers are visible near the center of the relay drawout assembly, to the right of the target LEDs. Carefully move the jumpers using needle-nosed pliers. Available baud rates are 300, 600, 1200, 2400, 4800, or 9600.

The serial data format is:

- Eight data bits
- Two stop bits (-E2 Model) or One stop bit (-E1 Model)
- No parity

This format may not be changed. The serial communications protocol appears in [Section 3: Communications](#).

Self-Tests

The relay runs a variety of self-tests. Some tests have warning and failure states; others only have failure states. The relay generates a report after any change in self-test status.

The relay closes the ALARM contacts after any self-test fails. When it detects certain failures, the relay disables the breaker control functions and places the relay output driver port in an input mode. No outputs may be asserted when the instrument is in this configuration. The relay runs all self-tests on power up and before enabling new settings. During normal operation, it performs self-tests at least every few minutes.

Offset

The relay measures the offset voltage of each analog input channel and compares the value against fixed limits. It issues a warning when offset is greater than 50 mV in any channel and declares a failure when offset exceeds 75 mV. Offset levels for all channels appear in the **STATUS** command format.

Power Supply

Power supply voltages are limit-checked. The table below summarizes voltage limits.

Table 2.5 Power Supply Self-Test Limits

Supply	Warning Thresholds		Failure Thresholds	
+5 V	+5.3 V	+4.7 V	+5.4 V	+4.6 V
+15 V	+15.8 V	+14.2 V	+16.2 V	+13.8 V
-15 V	-15.8 V	-14.2 V	-16.2 V	-13.8 V

The relay transmits a STATUS message for any self-test failure or warning. A +5 V supply failure deenergizes all output relays and blocks their operation. A ±15 V supply failure disables protective relay functions while control functions remain intact. The ALARM relay remains closed after a power supply failure.

Random Access Memory

The relay checks random access memory (RAM) to ensure that each byte can be written to and read from. There is no warning state for this test. If the relay detects a problem, it transmits a STATUS message with the socket designation of the affected RAM IC. A RAM failure disables protective and control functions and closes the ALARM output relay contacts.

Read-Only Memory

The relay checks read-only memory (ROM) by computing a checksum. If the computed value does not agree with the stored value, the relay declares a ROM failure. It transmits a STATUS message with the socket designation of the affected ROM IC. A ROM failure disables protective and control functions and closes the ALARM output relay contacts.

Analog-to-Digital Converter

The analog-to-digital converter (ADC) changes voltage signals derived from power system voltages and currents into numbers for processing by the microcomputer. The ADC test verifies converter function by checking conversion time. The test fails if conversion time is excessive or a conversion starts and never finishes. There is no warning state for this test. Though an ADC failure disables protective functions, control functions remain intact. The relay transmits a STATUS message and closes the ALARM relay contacts.

Master Offset

The master offset (MOF) test checks offset in the multiplexer/analog-to-digital converter circuit. A grounded input is selected and sampled for dc offset. The warning threshold is 50 mV; failure threshold is 75 mV. A failure pulses the ALARM contact closed for one second.

Settings

The relay stores two images of the system settings in nonvolatile memory. These are compared when the relay is initially set and periodically thereafter. If the images disagree, the setting test fails and the relay disables all protective and control functions. It transmits the STATUS message to indicate a failed test. The ALARM relay remains closed after a setting failure.

Table 2.6 shows relay actions for any self-test condition: warning (W) or failure (F).

Table 2.6 Self-Test Summary

Self-Test	Limits	Status Message	Protection Disabled	Control Disabled	Alarm Output
RAM	---	F	YES	YES	Permanent contact assertion
ROM	---				Permanent contact assertion
SETTINGS	---				Permanent contact assertion
A/D	---				Permanent contact assertion
+5 V	± 0.3 V ± 0.4 V	W F	NO YES	NO YES	No ALARM contact assertion Permanent contact assertion
+15 V	± 0.8 V ± 1.2 V	W F	NO YES	NO NO	No ALARM contact assertion Permanent contact assertion
CHANNEL OFFSETS	50 mV 75 mV	W F	NO NO	NO NO	No ALARM contact assertion One second contact pulse
MASTER OFFSET	50 mV 75 mV	W F	NO NO	NO NO	No ALARM contact assertion One second contact pulse

Targets

The front-panel targets illuminate for the following conditions:

Target LED	Conditions for Illumination
EN	Normal Operation
ϕ1	Z1P + Z1ABC + 50H + 50MF
G1	67N1
ϕ2	Z2P + Z2ABC
G2	67N2
ϕ3	Z3P + Z3ABC
G3	67N3
51N	51NT

The LEDs for the relay elements illuminate on the rising edge of the TRIP output with the following priority:

- 51N : For 51N timeout (51NT)
- G1, ϕ1 : For 67N1 + Z1P + Z1ABC + 50H + 50MF, but no 51NT
- G2, ϕ2 : For 67N2 + Z2P + Z2ABC, but no 51NT
- G3, ϕ3 : For 67N3 + Z3P + Z3ABC, but no 51NT

Press the TARGET RESET button to clear the targets if a trip condition is not present. All eight indicators illuminate for a one-second lamp test. Afterward, the fault targets clear and the enable light indicates that the relay is operational again. If a trip condition is present, the target LEDs do not clear. Pressing TARGET RESET also unlatches the TRIP output. This feature is useful during testing and reduces the possibility of relay installation with the TRIP output asserted.

IRIG-B Input Description

The port labeled J201 / AUX INPUT receives demodulated IRIG-B time code input. The IRIG-B input circuit is a $56\ \Omega$ resistor in series with an optocoupler input diode. The input diode has a forward drop of about 1.5 V. Driver circuits should put approximately 10 mA through the diode when “on.”

The IRIG-B serial data format consists of a one-second frame containing 100 pulses and divided into fields. The relay decodes second, minute, hour, month, and day fields and sets the relay clock accordingly.

When IRIG-B data acquisition is activated either manually (with the **IRIG** command) or automatically, the relay reads two consecutive frames. It updates the older frame by one second and compares the frames. If they do not agree, the relay considers the data erroneous and discards the information.

The relay reads the time code automatically about once every five minutes. It stops IRIG-B data acquisition ten minutes before midnight on New Year’s Eve so the relay clock can implement the year change without interference from the IRIG-B clock.

Signal Processing

The filtering process passes frequency information from the power system, eliminates any dc offset introduced by the analog electronics, and reduces the decaying exponential offset present following a fault. This permits the relay to operate using only analog input signals at or near the power system frequency.

The relay low-pass filters all analog input channels to remove high-frequency components. Next it samples each channel four times per power system cycle. After low-pass filtering, the relay digitally filters each sample with the CAL digital filter method.

Digital Filters

The digital filter has the properties of a double differentiator smoother and requires only addition and subtraction of data samples. Let the latest four samples of one channel be X1, X2, X3, and X4. Then the digital filter is defined:

$$P = X1 - X2 - X3 + X4.$$

This filter eliminates dc offsets. When all samples are set to the same value, the filter output is zero. It also eliminates ramps, which you may verify by setting the samples equal to 1, 2, 3, and 4. Again, the output is zero.

Every quarter cycle, the relay computes a new value of P for each input. The current value of P combines with the previous value (renamed Q) to form a Cartesian coordinate pair. This pair represents the input signal as a phasor (P, Q). The relay processes these phasor representations of the input signals.

Functional Description

Mho Elements

The following settings affect mho circles: positive-sequence line impedances (R1, X1), maximum torque angle (MTA), set reach (Z1%, Z2%, and Z3%), and positive-sequence transmission line angle ($\arctan(X1/R1)$). The non-expanded circles pass through the impedance-plane origin (except for the Zone 4 offset mho characteristic for three-phase faults). The diameter passing through the origin is at an angle of MTA (maximum torque angle) with respect to the resistance axis. The chord passing through the origin at the positive-sequence impedance (Z1) angle of the transmission line has a length equal to the set reach. Therefore, the mho circle diameter is calculated:

$$\text{DIAMETER} = \frac{\text{SET REACH}}{\cos(\text{T. L. ANGLE} - \text{MTA})}$$

where T. L. is defined as the positive-sequence transmission line angle. See [Figure 2.7](#).




Figure 2.7 Mho Element Reach at Maximum Torque Angle

Mho elements are based on the general principles of operation presented in “Compensator Distance Relaying” by W. K. Sonnemann and H. W. Lensner (AIEE Transactions, Part III, vol. 77, pp. 372-382, June 1958). These principles have been applied successfully in the electromechanical and solid-state designs of several manufacturers. Electromechanical versions use induction cylinders for a product-type phase comparison between the measurands. Solid-state analog designs use coincident-timing phase comparators. In the relay, the microprocessor uses phasor multiplication to perform phase comparison.

Phase comparator inputs for the various distance functions are:

Function	Input A	Input B
phase-phase	$V_{ab} - Z_1 \times I_{ab}$	$V_{bc} - Z_1 \times I_{bc}$
three-phase	$V_{ab} - Z_1 \times I_{ab}$	$-jV_{ab} - k \times V_c(\text{memory})$
offset three-phase	$V_{ab} - (1 + k) \times Z_1 \times I_{ab}$	$-jV_{ab} - jk \times Z_1 \times I_{ab}$

The constant Z_1 is the reach of the relay element in positive-sequence ohms. The constant k is fixed at $\frac{1}{4}$ to give a diameter of the offset circle equal to 1.5 times the diameter of the Zone 3 three-phase mho circle.

Mho Element Expansion

Self-polarized mho elements (mho elements with no expansion capabilities) provide limited coverage for faults including resistance. The relay overcomes this problem with a compensator distance principle that expands the mho distance characteristics. The phase-phase elements do not require memory polarization due to strong polarization from the non-involved phase. The three-phase elements require memory polarization to achieve expanded characteristics. [Figure 2.8](#) illustrates the expanded mho characteristics for phase-phase faults in front of the relay. [Figure 2.9](#) illustrates the expanded mho characteristics for three-phase faults in front of the relay. In both figures, the amount of mho expansion depends on the relative strength of the source behind the relay. To determine the amount of expansion that the mho characteristics experience, relay reach and positive-sequence source impedance must be known. With these quantities known, the following equations for the circle center and radius may be used to plot the mho characteristics.

Phase-Phase Elements

$$\text{CENTER} \equiv 1/2(-\text{ZS} + \text{ZR})$$

$$\text{RADIUS} \equiv 1/2(\text{ZS} + \text{ZR})$$

where:

ZS ≡ Positive-sequence source impedance behind the relay location

ZR ≡ Relay reach in positive-sequence ohms

For example, consider an application where the source impedance behind the relay is twice as great as the relay set reach. Plot the characteristics. [Figure 2.8](#) and [Figure 2.9](#) illustrate this example and compare the expanded mho characteristic with the self-polarized mho characteristics.




Figure 2.8 Expanded Two-Phase Mho Characteristics

Three-Phase Elements




Figure 2.9 Expanded Three-Phase Mho Characteristics

Time-Overcurrent Element and Curves

The 51N time-overcurrent element provides directional forward or nondirectional protection as enabled. You can program its pickup (51NP) and trip (51NT) states into any mask. The 51NP bit appears in the Relay Word to provide a means of determining residual overcurrent element pickup.

The setting procedure includes time dial and curve shape selections. Four curve shapes are available: moderately inverse, inverse, very inverse, and extremely inverse. The curves and their equations appear in this section.

The 51N characteristic is formed by a recursive sum of the magnitude or magnitude-squared of the residual current adjusted by the pickup setting.

The time dial setting determines the limit the recursive sum must reach for a trip.

Directional Elements

You can enable either the negative-sequence or zero-sequence directional element to provide directional supervision of the residual overcurrent elements. The Zone 3 direction setting determines if 50N3 is enabled for forward or reverse faults.

When no directional elements are enabled, the direction forward (DF) bit is always set and the residual overcurrent elements are nondirectional.

Directional elements are phasor-product derived. For the negative-sequence element (32Q), the product is negative-sequence voltage times negative-sequence current adjusted by the maximum torque angle setting. The relay declares a fault forward when I2 leads V2 ± 90 degrees from the maximum torque angle.

For the zero-sequence directional element (32D), the product is the residual current adjusted by the MTA setting times the sum of the residual voltage, plus the polarizing current shifted in phase by the MTA setting. The result is a dual-polarized zero-sequence directional element.

If you enable the zero-sequence voltage polarizing method (32VE = Y), the relay declares a fault forward when I₀ leads V₀ ±90 degrees from the maximum torque angle.

If you enable the zero-sequence current polarizing method (32IE = Y), the relay declares a fault forward when the residual current from the faulted line is ±90 degrees from the current measured in the Ipol input. The current in the Ipol input is typically derived from grounded-wye transformer neutrals or a transformer bank tertiary.

Table 2.7 shows the equations the relay uses to express the sensitivity of the directional elements in units of torque. These equations are useful in determining directional element sensitivities for fault angles that may differ from the MTA.

Table 2.7 Directional Element Torque Equations

$$32Q: T \equiv |V_2| \times |I_2| \times [\cos(\angle -V_2 - (\angle I_2 + MTA))]$$

$$32V: T \equiv |V_0| \times |I_R| \times [\cos(\angle -V_0 - (\angle I_R + MTA))]$$

$$32I: T \equiv |I_{pol}| \times |I_R| \times [\cos(\angle I_{pol} - \angle I_R)]$$

where:

T ≡ Torque, positive for a forward fault

V₂ ≡ Negative-sequence secondary voltage

I₂ ≡ Negative-sequence secondary current

V₀ ≡ Zero-sequence secondary voltage

I_R ≡ Residual secondary current

I_{pol} ≡ Secondary current at Ipol input

Positive values of torque (T) indicate a forward fault declaration. Please consult your fault study to determine the polarizing method best suited for each application.

Fault Locator

Several events automatically trigger the fault locator. These include: pickup of certain relay elements, assertion of certain contact inputs or outputs, and execution of certain commands. The fault locator can be either enabled or disabled with LOCAT during the setting procedure.

Triggering events are:

1. RELAY ELEMENTS (high level trigger)
 - Three-phase distance Zones 1, 2, 3, or 4
 - Phase-phase distance Zones 1, 2, or 3
 - Ground overcurrent Zones 1, 2, or 3, and 51N pickup
 - Phase overcurrent element 50H
2. CONTACT INPUTS (rising-edge trigger)
 - External Trigger (ET)
 - Direct Trip (DT)
 - Permissive Trip (PT)
 - Block Trip (BT)

3. CONTACT OUTPUTS (rising edge trigger)

> TRIP

4. USER-ENTERED COMMANDS (rising-edge trigger)

> TRIGGER

> OPEN

Relay elements trigger the fault locator in a level sensitive manner. The relay does not generate new event reports when additional relay elements pick up. Only the first relay element of any contiguous sequence triggers an event report.

All triggering relay elements must drop out for at least four cycles before they may initiate another event report. This helps eliminate triggering multiple records for boundary faults.

All other triggering events are rising edge sensitive, so for these events, the relay generates additional reports even while any or all relay elements remain picked up. This strategy permits the relay to record fault clearing even when it occurs long after completion of the initial event report.

The relay calculates a fault location for event records in which any triggering relay elements are picked up, if they are not picked up in the first seven rows of prefault data or only in the last five rows of the event report. Whenever the locator is able to determine fault location, the corresponding record is labeled according to fault type, regardless of what actually triggered the event report. Event records taken with no triggering relay elements picked up are labeled as follows:

“EXT” for reports triggered externally via input contacts or **TRIGGER** command execution

or

“TRIP” for reports triggered by “TRIP” output contact assertion.

The actual fault location algorithm is composed of two steps. First the relay determines fault type, then it calculates location.

For event reports, the relay determines fault type independently of the relay element operations. Relay elements determine only the indicated zone, while fault current comparison determines the involved phases. This differs from the target data, which are completely derived from relay element operations.

Compared currents are taken from two rows at the middle of the stored fault data. If the uncompensated current magnitudes are in large ratios between phases (4:1 or more), the fault type becomes immediately apparent as single- or two-phase. If not, the same current is load compensated by the two corresponding prefault current rows in the first cycle of the event report.

If these fault current component magnitudes are in moderate ratios (1.5:1 or more), the relay lists a single- or two-phase fault. If all ratios are less than 1.5, the relay lists a three-phase fault. Explicit fault classification logic is as follows, where “I” values are uncompensated midfault currents and “If” values are midfault currents compensated for load, yielding true fault current components:

IF (Imax > 4 x Imed) THEN Single-phase

ELSE IF (Imed > 4 x Imin) THEN Two-phase

ELSE IF (Ifmax > 1.5 x Ifmed) THEN Single-phase

```

ELSE IF (Ifmed > 1.5 x Ifmin) THEN Two-phase
ELSE IF (none of the above) THEN Three-phase

```

This algorithm is largely immune to load and system grounding variations.

Once the relay determines fault type, the fault locator uses the Takagi algorithm to locate the fault. Using prefault and fault data, it compensates for errors introduced by fault resistance in the presence of load flow. If the event record contains no sound prefault data, the relay calculates location based on a simple reactance measurement.

The fault locator depends on accurate transmission line parameters and instrument transformer ratios. Pay special attention to these potential sources of difficulty:

- Instrument transformer errors due to overburden by other devices
- Capacitive potential transformer capacitor value
- Transmission line parameter errors

Although the fault location computation takes several seconds, the relay can handle several faults in quick succession. The relay stores all fault data, then processes each fault in turn. For example, suppose three faults occur within a few seconds. The relay stores data from them as they occur. The fault location computations begin with the first (oldest) fault and proceed until all three fault records are processed. The relay transmits each summary event report when the corresponding fault location is available.

The relay does not consider shunt capacitance of the transmission line. Capacitance causes the fault location to appear more remote by a factor of approximately $1/\cos(bL)$, where bL is the line length in radians at 60 Hz. One wavelength at 60 Hz is 3100 miles. For example, the line length of a 100-mile line in radians is calculated:

$$(100/3100)(2)(3.14159) = 0.2027 \text{ radians.}$$

The indication neglecting capacitance is about $\cos(0.2027) = 0.98$ times the actual location, or about two miles short for a fault at the far end of a 100-mile line.

When compensation using shunt reactors is employed and measured current equals reactor plus line current, the shunt reactors reduce the errors due to neglecting the shunt capacitance of the transmission line.

When series capacitor compensation is used, accurate performance is obtained for faults between the relay and the capacitors, and beyond the capacitors if the capacitor protective gaps flash. If the gaps do not flash, the measured impedance includes line and capacitance impedance, and the errors can be substantial. This problem is aggravated by high-speed clearing and the excitation of eigenmodes or resonances of the line-capacitor system, which may not be much removed from 60 Hz. In cases where series capacitor gaps did not flash, we have had success with recomputing the fault location from the event-report data using a voltage equal to the measured voltage minus the capacitor voltage drop. The latter is computed from the capacitance value and measured current.

Event Report

The relay records an 11-cycle event report in response to the following:

Zone 1 fault	Zone 2 fault	Zone 3 fault	Zone 4 pickup
Direct Trip	51N pickup	External trigger	50H pickup
TRIP	Command (TRIGGER or OPEN)		

A single fault triggers a second report if the trip occurs after the first report expires. Thus, the relay records the beginning and end of each fault for which it trips. It does not generate a second event report if the TRIP output first asserts at or less than seven cycles after the first report is triggered (note that reports are triggered at the 16th quarter cycle of data).

Triggering is recorded to the nearest quarter-cycle and referenced to the 16th row of data in the report. You can compute the duration of a long fault that triggers two events. Simply calculate the time difference between the report generated at fault inception and the report generated at the TRIP. The event report contains voltages, currents, system settings, and other information. See [Section 4: Event Reporting](#) for additional details.

Executing the **CLOSE** command does not trigger an event. Asserting the **DIRECT CLOSE** input does not trigger an event.

The last 12 event reports are stored in memory and may be retrieved with the **EVENT** command. Use the **HISTORY** command to view summary reports for the last 12 events.

Programmable Logic Mask Concept

Figure 2.10 illustrates programmable logic mask concept by comparing it to the connections of discrete relay elements. At the top, the figure shows relay element contacts X, Y, and Z connected to a common reference, such as the positive pole of the battery. The other ends of these contacts pass through knife switches, while the other side of the switches are connected to drive an auxiliary relay labeled A1. The knife switch positions select relay elements which can pick up the auxiliary relay.

In the figure, switches SX and SY are closed, so closure of either contact X or Y causes A1 to pick up. By connecting the X, Y, and Z contacts in parallel, their operation performs a logical “OR” function: if one contact closes, the A1 coil is energized. The figure expresses this process in Boolean terms next to the A1 output contact with the notation $X + Y$. The “+” indicates a logical “OR” operation.

The A1 contact control logic scheme may be modified by setting switches SX, SY, and SZ to other positions. If an application requires combinations of contacts X, Y, and Z to control other auxiliary relays, diodes must be used in each contact path. This ensures that the logic settings for this scheme do not affect other auxiliary relays. Since each output contact has a separate logic mask, this step is unnecessary in the microprocessor based relay.

In the programmable mask logic, the states of all relay elements are collected into a single word of binary digits called the Relay Word. Each bit position reports the state of one relay element. 0 indicates the element is not picked up; 1 indicates that the element is picked up.

[Figure 2.10](#) shows a three-bit Relay Word with elements X, Y, and Z. Each bit corresponds to one relay element contact in the contact logic equivalent. The operator sets or clears bits in the mask for the A1 output, rather than using switches to select relay elements that control the A1 output (see [LOGIC n on page 3.15](#)). In the figure, the operator sets the logic mask to bits (1,1,0), selecting only assertion of the X and Y elements.

The Z element is not selected, so its assertion cannot close the A1 output contact due to an open path from the positive to negative bus. The computer ANDs each bit in the Relay Word with the corresponding bit the operator set in the mask. Next it ORs all three outputs together, forming the condition that drives the output relay A1. A convenient shorthand expression for this bitwise AND followed by an OR operation is:

$$A1 = R * MA1$$

$$R = X + Y + Z$$

where R is the Relay Word (X,Y,Z), MA1 is the mask (1,1,0), “*” indicates the bitwise AND, and “+” indicates the bitwise OR operation.

While the mask elements are fixed, the Relay Word is updated each quarter-cycle. In this example, if the X or Y element is set to (1) in the Relay Word, the A1 contact will be closed. The A1 contact state is independent of the Z element state in the Relay Word because the corresponding Z element in the mask equals zero.

The user-programmable logic masks in this relay control the TRIP and programmable output contacts. Logic masks are saved in nonvolatile memory with the other settings and retained through loss of control power.

The masking concept provides more flexibility than switch-selectable logic, is more convenient than making wiring changes to hard-wired discrete relay systems, and provides noticeable benefits during commissioning and routine testing.




Figure 2.10 Programmable Logic Mask Analogy

Relay Element Operating Time Curves

Figure 2.11 shows operating times for the relay phase-phase mho distance elements and the 50H instantaneous phase overcurrent element. At each reach percentage or current multiple, ten tests were run. The diagrams show maximum, average, and minimum operating times at each test point. Operating times include output contact closure time.

For the distance element test, a phase-phase fault was applied at a location representing a percentage of the Zone 1 relay reach setting. Tests were performed for source impedance ratios (SIR) of 0.1, 1.0, and 5.0. No prefault load current was included. System frequency is 60 Hz.

Balanced three-phase currents and no voltages were applied to the relay for the 50H overcurrent element tests. This test simulates a bolted 3f fault in front of the relay location when line side PTs are employed. Test currents are shown as a multiple of the pickup setting. No prefault load current was included. System frequency is 60 Hz.




Figure 2.11 Phase Distance Speed Curves and 50H Phase Overcurrent Speed Curve

Time-Overcurrent Curve Equations

These time curve equations are valid for the phase and residual time-overcurrent elements. Plots showing operating time versus multiples of pickup current are shown on the following pages.

Let t = operating time in seconds,

TD = time dial setting,

M = multiples of pickup.

Curve 1: Moderately Inverse

$$t_M = TD \left(0.157 + \frac{0.668}{M - 1} \right)$$

Curve 2: Inverse

$$t_M = TD \left(0.180 + \frac{5.95}{M^2 - 1} \right)$$

Curve 3: Very Inverse

$$t_M = TD \left(0.0963 + \frac{3.88}{M^2 - 1} \right)$$

Curve 4: Extremely Inverse

$$t_M = TD \left(0.0352 + \frac{5.67}{M^2 - 1} \right)$$




Figure 2.12 Residual Time-Overcurrent Element Moderately Inverse Time Characteristic




Figure 2.13 Residual Time-Overcurrent Element Inverse Time Characteristic




Figure 2.14 Residual Time-Overcurrent Element Very Inverse Time Characteristic






Figure 2.15 Residual Time-Overcurrent Element Extremely Inverse Time Characteristic



SEL-121G RELAY LOSS-OF-POTENTIAL LOGIC DIAGRAM


SEL-121G RELAY OUT-OF-STEP-BLOCKING LOGIC DIAGRAM



SEL-121G RELAY RESIDUAL TIME-OVERCURRENT (5IN) LOGIC DIAGRAM




USED ON
SEL-121G
SEL-121G-3
SEL-121G-4





USED ON

SEL-121G RELAY GROUND DIRECTIONAL AND GROUND OVERCURRENT LOGIC DIAGRAM



SEL-121G RELAY THREE-PHASE MHO, LINE-LINE MHO, AND PHASE OVERCURRENT LOGIC DIAGRAM





Section 3

Communications

Introduction

The relay is set and operated via serial communications interfaces connected to a computer terminal and/or modem or the SEL-PRTU. Communication serves these purposes:

1. The relay responds to commands spanning all functions, e.g., setting, metering, and control operations.
2. The relay generates an event record for TRIP output assertions, for an event triggering command, or for pickup of any relay element that triggers an event record.
3. The relay transmits messages in response to changes in system status, e.g., self-test warning.

It is impossible to disable any relaying or control functions via communications, unless a user enters erroneous or improper settings with the **SET** or **LOGIC** commands.

NOTE: In this manual, commands to type appear in bold/uppercase: **OTTER**. Keys to press appear in bold/brackets: <Enter>.

Relay output appears boxed and in the following format:

Example 230 KV Line	Date 1/1/91	Time: 01:01:01
---------------------	-------------	----------------

Serial Port Connections and Configurations

The SEL-221G relay is equipped with two EIA-232 serial communications ports. Port 2 has 9-pin connectors on both the front and rear panels, designated Port 2F and Port 2R, respectively.

Port 2R, located on the relay rear panel, is typically used with an SEL-DTA Display/Transducer Adapter, SEL-RD Relay Display, or local printer. Port 2F is always available for short-term local communications with a portable computer or printing terminal. Simply plug the device into the front-panel port. The relay automatically discontinues communications with Port 2R and addresses Port 2F. When testing or data retrieval is complete, unplug the temporary device from Port 2F. The relay automatically resumes communication with the device connected to Port 2R.

Serial communications Port 1 and the Auxiliary Input for demodulated IRIG-B time code input remain on the relay rear panel.

Communications port baud rate jumpers are located along the front edge of the circuit board. To select a baud rate for Port 1 or Ports 2, remove the relay front panel. The jumpers are visible near the center of the relay drawout

assembly, to the right of the target LEDs. Carefully move the jumpers using needle-nosed pliers. Available rates are 300, 600, 1200, 2400, 4800, and 9600 baud.

CAUTION

Do not select two baud rates for the same port as this can damage the relay baud rate generator. The relay is shipped with Port 1 set to 300 baud and Port 2F/2R set to 2400 baud.

The serial data format is:

- Eight data bits
- Two stop bits (-E2 model) or one stop bit (-E1 model)
- No parity bit

This format cannot be altered.

The SEL-121G relay does not include a front-panel serial interface port.




Figure 3.1 SEL-221G Relay Nine Pin Connector Pin Number Convention




Figure 3.2 SEL-121G Relay Nine Pin Connector Pin Number Convention

Table 3.1 lists SEL-221G relay port pin assignments and signal definitions.

Table 3.1 SEL-221G Relay Serial Port Connector Pin Assignments

Pin	Port 1, Port 2R	Port 2F	Description
1	+5 Vdc	N/C	
2	RXD	RXD	Receive data input.
3	TXD	TXD	Transmit data output.
4	+12 Vdc	N/C	
5	GND	GND	
6	-12 Vdc	N/C	
7	RTS	RTS	The SEL-221G relay asserts this line under normal conditions. When its received-data buffer is full, the line is deasserted, and asserts again when the buffer has sufficient room to receive more data. Connected devices should monitor RTS (usually with their CTS input) and stop transmission whenever the line deasserts. If transmission continues, data may be lost.
8	CTS	CTS	The SEL-221G relay monitors CTS, and transmits characters only if CTS is asserted.
9	GND	GND	Ground for ground wires and shields

Table 3.2 lists SEL-121G relay port pin assignments and signal definitions.

Table 3.2 SEL-121G Relay Serial Port Connector Pin Assignments

Pin	Name	Description
2	TXD	Transmit data output.
3	RTS	The relay asserts this line under normal conditions. When its received-data buffer is full, the line deasserts until the buffer has room to receive more data. Connected devices should monitor RTS (usually with their CTS input) and stop transmitting characters whenever the line deasserts. If transmission continues, data may be lost.
4	RXD	Receive data input.
5	CTS	The relay monitors CTS and transmits characters only when CTS is asserted.
6	+5 V	
7	+12 V	
8	-12 V	
1, 9	GND	Ground for ground wires and shields.

Communications Protocol

Communications protocol consists of hardware and software features. Hardware protocol includes the control line functions described above. The following software protocol is designed for manual and automatic communications.

1. All commands received by the relay must be of the form:

<command><CR> or <command><CRLF>

Thus, a command transmitted to the relay should consist of the command followed by either a carriage return or a carriage return and line feed. You may truncate commands to the first three characters. Thus, **EVENT 1 <Enter>** would become **EVE 1 <Enter>**. Upper and lowercase characters may be used without distinction, except in passwords.

2. The relay transmits all messages in the following format:

<STX><MESSAGE LINE 1><CRLF>

<MESSAGE LINE 2><CRLF>

•
•
•

<LAST MESSAGE LINE><CRLF><PROMPT><ETX>

Each message begins with the start-of-transmission character (ASCII 02) and ends with the end-of-transmission character (ASCII 03). Each line of the message ends with a carriage return and line feed.

NOTE: The <Enter> key on most keyboards is configured to send the ASCII character 13 (^M) for a carriage return. This manual instructs you to press the <Enter> key after commands, which should send the proper ASCII code to the relay.

3. The relay indicates the volume of data in its received data buffer through an XON/XOFF protocol.

The relay transmits XON (ASCII hex 11) and asserts the RTS output when the buffer drops below ¼ full.

The relay transmits XOFF (ASCII hex 13) when the buffer is more than ¾ full. The relay deasserts the RTS output when the buffer is approximately 95% full. Automatic transmission sources should monitor for the XOFF character so they do not overwrite the buffer. Transmission should terminate at the end of the message in progress when XOFF is received and may resume when the relay sends XON.

4. You can use an XON/XOFF procedure to control the relay during data transmission. When the relay receives XOFF during transmission, it pauses until it receives an XON character. If there is no message in progress when the relay receives XOFF, it blocks transmission of any message presented to its buffer. Messages will be accepted after the relay receives XON.

The CAN character (ASCII hex 18) aborts a pending transmission. This is useful in terminating an unwanted transmission.

5. Control characters can be sent from most keyboards with the following keystrokes:

- XON: <CTRL+Q> (hold down the Control key and press Q)
- XOFF: <CTRL+S> (hold down the Control key and press S)
- CAN: <CTRL+X> (hold down the Control key and press X)

Command Characteristics

The relay responds to commands sent to either serial communications interface. A two-level password system provides security against unauthorized access.

When the power is first turned on, the relay is in Access Level 0 and honors only the **ACCESS** command. It responds Invalid command or Invalid access level to any other entry.

You may enter Access Level 1 with the **ACCESS** command and first password. The Level 1 password is factory-set to OTTER and may be changed with the **PASSWORD** command in Access Level 2. Most commands may be used in Access Level 1.

Critical commands such as **SET** operate only in Access Level 2. You may enter Access Level 2 with the **2ACCESS** command and second password. The Level 2 password is factory-set to TAIL and may be changed with the **PASSWORD** command.

Startup

Immediately after power is applied, the relay transmits the following message to the port(s) designated automatic:

Example 230 KV Line	Date 1/1/91	Time: 01:01:01
SEL - 121G	=	

The ALARM relay should pull in.

The = represents the Access Level 0 prompt.

The relays are shipped with PORT 2 designated automatic; you may use the **SET** command to change this designation (see **SET** command, AUTO setting). This allows you to select PORT 1, PORT 2, or both ports to transmit automatic responses from the relay.

To enter Level 1, type the following on a terminal connected to PORT 2:

```
=Access <Enter>
```

The response is:

```
Password: ? @@@@@
```

Enter the Level 1 password: **OTTER** and press <Enter>. The response is:

Example 230 KV Line	Date 1/1/91	Time: 01:01:44
Level 1	=>	

The Access Level 1 prompt is =>. Now you can execute any Level 1 command.

Use a similar procedure to enter Access Level 2:

Type **2ACCESS <Enter>**. The relay pulses the ALARM relay contact closed for approximately one second, indicating an attempt to enter Access Level 2. Enter the password **TAIL** when prompted. After you enter the second password, the relay opens access to Level 2, as indicated by the following message and Level 2 prompt (=>>):

```
=>2ACCESS <Enter>
Password: TAIL <Enter>
```

Example 230 KV Line	Date 1/1/91	Time: 01:03:32
Level 2	=>>	

You can enter any command at this prompt.

Command Format

Commands consist of three or more characters; only the first three characters of any command are required. You may use upper or lowercase characters without distinction, except in passwords.

Items in square brackets [...] are optional.

You must separate arguments from the command by spaces, commas, semicolons, colons, or slashes.

You can enter commands any time after the terminal displays an appropriate prompt.

Command Descriptions

Access Level 0 Command

ACCESS

ACCESS allows you to enter Access Level 1. The password is required unless you install jumper JMP103. The first password is set to OTTER at the factory; use the Level 2 command **PASSWORD** to change passwords.

The following display indicates successful access:

```
=ACCESS <Enter>
Password: OTTER <Enter>

Example 230 kV Line           Date 1/1/91           Time: 14:03:57
Level 1
=>
```

The => prompt indicates Access Level 1.

If you enter incorrect passwords during three consecutive attempts, the relay pulses the ALARM contact closed for one second. This feature can alert personnel to an unauthorized access attempt if the ALARM contact is connected to a monitoring system.

Access Level 1 Commands

2ACCESS

2ACCESS allows you to enter Access Level 2. The password is required unless you install jumper JMP103. The second password is set to TAIL at the factory; use the Level 2 command **PASSWORD** to change passwords.

The following display indicates successful access:

```
=>2ACCESS <Enter>
Password: TAIL <Enter>

Example 230 kV Line           Date 1/1/91           Time: 14:12:01
Level 2
=>>
```

You may use any command from the =>> prompt. The relay pulses the ALARM contact closed for one second after any Level 2 access attempt (unless an alarm condition exists).

DATE mm/dd/yy

DATE displays the date stored by the internal calendar/clock. To set the date, type **DATE mm/dd/yy <Enter>**.

To set the date to June 28, 1991, enter:

```
=>DATE 6/28/91 <Enter>
6/28/91
=>
```

The relay sets the date, pulses the ALARM relay closed as it stores the year in EEPROM (if the year input differs from the year stored), and displays the new date.

EVENT n

EVENT displays an event report. Type **EVENT n <Enter>** to display an event report for the *n*th event. The parameter *n* ranges from 1 for the newest event through 12 for the oldest event stored in the relay memory. If *n* is not specified, the default value is 1 and the relay displays the newest event report.

You can control transmissions from the relay with the following keystrokes:

- <**CTRL+S**> Pause transmission
- <**CTRL+Q**> Continue transmission
- <**CTRL+T**> Terminate transmission

The following incidents clear the event buffers:

- Interruption of control power
- Changing any relay setting
- Changing any logic mask setting

All event data are lost when event buffers are cleared. If an event buffer is empty when you request an event, the relay returns an error message:

```
=>EVENT 12 <Enter>
Invalid event
=>
```

Section 4: Event Reporting explains the generation and analysis of event reports.

HISTORY

HISTORY displays the date, time, and type of event for each of the last 12 events. If the event is a fault, the distance, duration, and maximum phase current appear in the History readout.

```
=>HISTORY <Enter>

Example 230 kV Line                               Date 1/1/91           Time: 07:38:12
#   DATE        TIME      TYPE    DIST   DUR   CURR
1  1/01/91    07:36:52.150  1AG    74.93  5.00  1070.1
2  1/01/91    07:36:18.400  1BC    74.53  4.75  1567.2
3  1/01/91    07:35:42.970  2BC    84.68  4.25  1411.8
4  1/01/91    07:35:23.783  EXT
5  1/01/91    07:35:07.958  TRIP
6
7
8
9
10
11
12
=>
```

Note that only five events have occurred since the relay was set or powered on.

The time is saved to the nearest quarter-cycle (4.17 ms) and referenced to the 16th row of data in the report. All reports trigger at row 16. If a long fault triggers two event reports, you can still determine its duration. Simply calculate the time difference between the first report generated at fault inception and the second report generated at the TRIP.

The TYPE column provides an abbreviated indication of the event type. These are the same data presented for EVENT in the event summary automatically generated for each fault.

For faults, the indication includes zone and phase involvement information. The zone is determined from the relay elements asserted at the middle of the first contiguous sequence of relay elements picked up in the report. For example, if relay elements are contiguously picked up from the 15th to the 24th rows, the zone is determined from the 20th row. The zone is indicated by the left-most character of the TYPE string, and is one of the following:

- 1 : For faults in which a Zone 1 element picked up
- 2 : For Zone 2, but not Zone 1
- 3 : For Zone 3, but not Zone 2 or 1
- 4 : For Zone 4, but not Zone 3, 2, or 1
- 5 : For 51N pickup, but not Zone 4, 3, 2, or 1
- H : For 50H pickup, but not 51N or Zone 4, 3, 2, or 1
- ? : For none of the above picked up at midfault

Phase involvement is shown by the characters subsequent to the zone indication and is determined independently from relay elements. Phase involvement is determined solely from uncompensated and load-compensated current magnitudes. These magnitudes are measured at the midpoint of the first contiguous relay pickup sequence in the event report (see [Fault Locator on page 2.27](#) for algorithmic details). The phase involvement is indicated as one of the list below.

- AG : For A-phase to ground faults
- BG : For B-phase to ground faults
- CG : For C-phase to ground faults
- AB : For A-B two-phase faults

BC : For B-C two-phase faults
 CA : For C-A two-phase faults
 ABG : For A-B two-phase to ground faults
 BCG : For B-C two-phase to ground faults
 CAG : For C-A two-phase to ground faults
 ABC : For three-phase faults

Zone and phase involvement data are concatenated into a single string, completing the TYPE designation, as in 3BG for a Zone 3 B-phase to ground fault. For event reports triggered by TRIP output assertion, the TYPE designation is appended with a T. This aids in determining clearing times for faults which persist beyond the end of the first event report. For example, if the relay trips for a 3BG fault after completion of the initial report, the second report shows 3BGT for TYPE.

For events other than faults, TYPE indication is either TRIP or EXT. The TYPE is TRIP when the relay generates an event report in response to TRIP output assertion. This can occur after **OPEN** command execution during a no-fault condition. For all other events, TYPE shows EXT, indicating a report generated in response to ET (External Trigger) input assertion or **TRIGGER** command execution.

The DIST column presents the equivalent distance to a fault in miles or kilometers. This is calculated using the Takagi algorithm or a reactance measurement, depending on whether prefault data are available in the event report. For some boundary faults of long duration, the fault locator may not be able to locate the fault for every report generated when relay operation is sporadic. The DIST column may contain 999999 in such cases. While this behavior can be contrived under test conditions, it is extremely rare in actual practice.

The DUR column gives a fault duration measurement for each event report. This is determined from the first pickup of a Zone 1, 2, 3, 4, 51N, or 50H relay element until the first dropout of all said relay elements. In other words, it is the duration of the first contiguous pickup of relay elements found in the long event report converted to units of cycles.

The CURR column shows the magnitude of the maximum phase current measured at the middle of the fault in primary amperes. This information is useful for determining the row pair used by the relay for fault location calculations.

IRIG

IRIG directs the relay to read the demodulated IRIG-B time code input at J201 on the rear panel if a time code signal is input.

If the relay reads the time code successfully, it updates the internal clock/calendar time and date to the time code reading and the relay transmits a message with relay ID string, date, and time.

NOTE: Normally, it is not necessary to synchronize using this command because the relay automatically synchronizes every few minutes. The command is provided to prevent delays during testing and installation.

=>IRIG <Enter>

Example 230 kV Line

Date 1/8/91

Time: 01:45:40

=>

If no IRIG-B signal is present or the code cannot be read successfully, the relay sends the error message IRIGB DATA ERROR.

METER n

METER displays the phase-to-neutral and phase-to-phase voltages and currents in primary kilovolts and amperes. **METER** also displays real and reactive power in megawatts and megavars.

```
=>METER <Enter>
Example 230 kV Line          Date 1/8/91          Time: 07:56:36
                                A      B      C      AB     BC     CA
I (A)        202    198    197    349    339    344
V (kV)       134.0   133.8   133.6  231.5  230.9   231.9
P (MW)       78.61
Q (MVAR)    13.85
=>
```

P and Q are derived from the total power S. S is calculated from the sum of the phasor multiplication of each phase-to-neutral voltage and current:

$$S = (Va)(Ia) + (Vb)(Ib) + (Vc)(Ic)$$

P and Q are then taken as the real and imaginary components of S.

An example is 134 kV in positive-sequence with 200 A of load current lagging the voltages by 10 degrees.

$$S = (134,000)(202) + (133,800)(198) + (133,600)(197) = 79.88 \text{ MVA}$$

$$P = (S)(\cos(10^\circ)) = 78.67 \text{ MW}$$

$$Q = (S)(\sin(10^\circ)) = 13.87 \text{ MVAR}$$

P and Q are positive when the power flows in the direction of relay reach or out from the bus and into the line.

The optional parameter *n* selects the number of times the relay displays meter data. To display a series of eight meter readings, type **METER 8 <Enter>**.

QUIT

QUIT returns control to Access Level 0 from Level 1 or 2 and resets targets to the Relay Targets (TAR 0). The command displays the relay I.D., date, and time of **QUIT** command execution.

Use this command when you finish communicating with the relay to prevent unauthorized access. Control returns to Access Level 0 automatically after a settable interval of no activity (see the TIME1 and TIME2 settings of the **SET** command).

```
=>QUIT <Enter>
Example 230 kV Line          Date 1/8/91          Time: 01:45:40
=
```

SHOWSET

SHOWSET displays the current relay and logic settings. Settings cannot be entered or modified with this command. The **SET** command description provides complete information about changing settings.

```
=>SHOWSET <Enter>

Settings for: Example 230 KV Line

R1    =8.56   X1    =77.77   R0    =35.12   X0    =236.96   LL    =100.00
CTR   =200.00  PTR   =2000.00  MTA   =83.72   LOCAT=Y
790I1=40.00  790I2=60.00  790I3=80.00  79RS  =240.00
Z1%   =80.00   Z2%   =120.00   Z3%   =120.00
Z1DP  =0       Z2DP  =20.00    Z3DP  =60.00
50L   =275.00  50M   =500.00   50MFD=20.00  50H   =3420.00
51NP  =230.00  51NTD=4.00   51NC   =3      51NTC=Y
50N1P=835.00  50N2P=276.00  50N3P=282.00
Z1DG  =0       Z2DG  =30.00    Z3DG  =60.00   TDUR  =9.00
52BT  =20.00   ZONE3=R     32QE  =Y       32VE  =N       32IE  =N
OSB1  =Y       OSB2  =Y       OSB3  =Y       OSBT  =30.00   LOPE  =Y
TIME  =5       TIME2=0      AUTO   =2      RINGS=7

Logic settings:

MTU   MPT   MTB   MTO   MA1   MA2   MA3   MA4   MRI   MRC
80    00    00    D4    20    00    00    08    00    E4
C4    00    00    E6    11    00    00    00    44    80
C8    00    00    00    00    01    20    00    00    C8
33    00    00    00    00    00    00    00    00    33

=>
```

A brief line-by-line description of the settings follows:

- Line 1: Positive- and zero-sequence impedances of the transmission line (primary ohms) and line length (miles) for which the impedances are given.
- Line 2: Current and voltage transformer ratios, maximum torque angle, and fault locator enable.
- Line 3: Three reclosing open interval delays and recloser reset delay.
- Line 4: Zone 1, 2, and 3 reach settings as percents of the positive-sequence line impedances.
- Line 5: Zone 1, 2, and 3 time delay settings for phase faults.
- Line 6: Phase overcurrent element low, medium, and high pickup settings, and the time delay setting for 50M to trip with a loss-of-potential condition (LOPE = Y).
- Line 7: Residual time-overcurrent pickup, time dial, curve, and torque control enable.
- Line 8: Zone 1, 2, and 3 instantaneous residual overcurrent element pickup settings.
- Line 9: Zone 1, 2, and 3 time delay settings for ground faults detected by the residual overcurrent elements and Trip Duration timer.
- Line 10: 52B time delay, Zone 3 direction, and the enables for the negative-sequence directional, voltage-polarized zero-sequence directional, and current-polarized zero-sequence directional elements.
- Line 11: Enables for out-of-step blocking of Zones 1, 2, and 3 three-phase mhos, out-of-step timer, and the loss-of-potential enable.
- Line 12: PORT 1 and 2 timeouts, the port(s) designated for automatically transmitted messages and the number of rings after which the relay instructs the modem to answer.

The **SET** command description includes a complete description of settings. [Section 5: Applications](#) provides explanations and descriptions of setting calculations.

The **LOGIC** command description includes a detailed explanation of the logic settings.

Each logic settings display column shows the masks for the four rows of the Relay Word as follows:

Row 1, of any column:	1ABC	2ABC	3ABC	4ABC	LOP	50H	50M	50L
Row 2, of any column:	51NT	67N1	67N2	67N3	51NP	Z1P	Z2P	Z3P
Row 3, of any column:	Z2PT	Z3PT	OSB	3P50	50MF	RC	RI	DF
Row 4, of any column:	ALRM	TRIP	TC	DT	52BT	52AT	Z2GT	Z3GT

Logic settings appear in hexadecimal format. *Table 3.3* provides equivalencies between hexadecimal (hex) and binary numbers. Use the table when you examine logic settings in event reports and the **SHOWSET** display.

Table 3.3 Hexadecimal/Binary Conversion

Hexidecimal	Binary	Hexidecimal	Binary
0	0000	8	1000
1	0001	9	1001
2	0010	A	1010
3	0011	B	1011
4	0100	C	1100
5	0101	D	1101
6	0110	E	1110
7	0111	F	1111

For example, consider Row 2 of mask MTU, which is set to C4 hex format. Using the table, convert C4 to binary:

C4 -> 1100 0100.

Now, build Row 2 of the Relay Word for the MTU mask as follows:

51NT	67N1	67N2	67N3	51NP	Z1P	Z2P	Z3P
1	1	0	0	0	1	0	0
_____	C	_____	_____	_____	4	_____	_____

STATUS

STATUS allows inspection of self-test status. The relay automatically executes the **STATUS** command whenever a self-test enters a warning or failure state. If this occurs, the relay transmits a STATUS report from the port(s) designated automatic (see **SET** command, AUTO setting).

The STATUS report format appears below.

```
=>STATUS <Enter>
Example 230 kV Line          Date 1/8/91          Time: 01:08:44
SELF TESTS
W=Warn F=Fail
      IP   IR   IA   IB   IC   VA   VB   VC
OS    0     0     0     0     0     2     0     2
PS    5.11  15.15 -14.91
RAM   ROM   A/D   MOF   SET
OK    OK    OK    OK    OK
=>
```

The OS row indicates measured dc offset voltages in millivolts for the eight analog channels. An out-of-tolerance offset is indicated by a W (warning) or F (failure) following the displayed offset value.

The PS row indicates power supply voltages in volts for the three power supply outputs.

If a RAM or ROM test fails, the IC socket number of the defective part replaces OK.

The A/D self-test checks the analog-to-digital conversion time.

The MOF test checks dc offset in the MUX-PGA-A/D circuit when a grounded input is selected.

The SET self-test calculates a checksum of the settings stored in nonvolatile memory and compares it to the checksum calculated when settings were last changed.

[Section 2: Specifications](#) provides full definitions of the self-tests, their warning and failure limits, and the results of test warnings and failures.

TARGET n k

TARGET selects the information displayed on the target LEDs and communicates the state of the selected elements.

When the relay power is on, the LED display indicates the functions marked on the front panel. The default display shows fault information from the RELAY TARGETS row of the following table.

Using the **TARGET** command, you may select any one of the following seven sets of data to display on the LEDs.

Table 3.4 Target LED Assignment

LED:	1	2	3	4	5	6	7	8	
N									
O	EN	PH1	G1	PH2	G2	PH3	G3	51N	RELAY TARGETS
1	1ABC	2ABC	3ABC	4ABC	LOP	50H	50M	50L	RELAY WORD row 1
2	51NT	67N1	67N2	67N3	51NP	Z1P	Z2P	Z3P	RELAY WORD row 2
3	Z2PT	Z3PT	OSB	3P50	50MF	RC	RI	DF	RELAY WORD row 3
4	ALRM	TRIP	TC	DT	52BT	52AT	Z2GT	Z3GT	RELAY WORD row 4
5	52AT	.	ET	52A	DC	BT	PT	DT	CONTACT INPUTS
6	.	TRIP	CLOS	A1	A2	A3	A4	ALRM	CONTACT OUTPUTS

These selections are useful in testing, checking contact states, and reading targets remotely. A value of 1 indicates an asserted element; a value of 0 indicates a deasserted element.

The optional command parameter *k* selects the number of times the relay displays target data for parameter *n*. The example below shows a series of ten target readings for Relay Word Row 3. Target headings repeat every eight rows.

```
=>TARGET 3 10 <Enter>
Z2PT Z3PT OSB 3P50 50MF RC RI DF
0 0 0 0 0 0 0 1
0 0 0 0 0 0 0 1
0 0 0 0 0 0 0 1
0 0 0 0 0 0 0 1
0 0 0 0 0 0 0 1
0 0 0 0 0 0 0 1
0 0 0 0 0 0 0 1
0 0 0 0 0 0 0 1
0 0 0 0 0 0 0 1
0 0 0 0 0 0 0 1

Z2PT Z3PT OSB 3P50 50MF RC RI DF
0 0 0 0 0 0 0 1
0 0 0 0 0 0 0 1

=>
```

When finished, type **TAR 0 <Enter>** to return to fault targets so field personnel do not misinterpret displayed data. Also, if the relay sends an automatic message to a timed out port, it clears the target display and displays the TAR 0 data.

Press the front-panel **TARGET RESET** button to clear the TAR 0 data and illuminate all target LEDs for a one-second lamp test.

You can reset front-panel targets to TAR 0 and clear them remotely or locally with the **TARGET** command. Type **TARGET R <Enter>** to reset and clear the targets as shown below.

```
=>TARGET R <Enter>
Targets reset

EN PH1 G1 PH2 G2 PH3 G3 51N
1 0 0 0 0 0 0 0

=>
```

If you place the relay in service with the target level other than Level 0, it automatically reverts to target level 0 when an automatic message transmits to a timed-out port. While this feature prevents confusion among station operators and readers, it can be inconvenient if the relay tester requires targets to remain on another level. Targets remain in the specified level if you assign the AUTO setting to a port with zero timeout or set both TIME1 and TIME2 to zero. This halts automatic message transmission to a port that may be timed out.

TIME hh:mm:ss

TIME checks the internal clock. To set the clock, type **TIME** and the desired setting, then press **<Enter>**. Separate the hours, minutes, and seconds with colons, semicolons, spaces, commas, or slashes. To set the clock to 23:30:00, enter:

```
=>TIME 23:30:00 <Enter>
23:30:00
=>
```

A quartz crystal oscillator provides the time base for the internal clock. You can set the time clock automatically with the relay time code input and a source of demodulated IRIG-B time code.

TRIGGER

TRIGGER generates an event record. After command entry, the relay responds Triggered, and displays a record summary.

```
=>TRIGGER <Enter>
Triggered

=>

Example 230 KV Line           Date 1/8/91           Time: 01:11:17.304
Event   : EXT    Location   :      mi      ohms sec
Duration:          Flt Current:

=>
```

Use **TRIGGER** to inspect the input voltages. For example, when the relay is first installed, execute the **TRIGGER** command, draw the phasors ([Section 4: Event Reporting](#) gives an example of how to do this), and check for the proper polarity and phase-sequence of the inputs.

Access Level 2 Commands

While all commands are available from Access Level 2, the commands below are available only from Access Level 2. Remember, the relay pulses the ALARM contact closed for one second after any Level 2 access attempt.

CLOSE

The **CLOSE** command asserts the CLOSE output relay. You can also accomplish this by asserting the DIRECT CLOSE input as long as the 52A input or TRIP outputs are not asserted. The CLOSE output relay then remains closed until the 52A input is asserted (indicating that the circuit breaker is closed) or until the reclose reset timer (79RS) expires.

To close the circuit breaker with this command, type **CLOSE <Enter>**. The prompting message **Close BREAKER (Y/N) ?** is displayed. **Y <Enter>** yields a second prompting string: **Are you sure (Y/N) ?** Type **Y <Enter>** to assert the CLOSE output relay, as long as the TRIP output and 52A input are not asserted. The relay transmits the message **Breaker CLOSED** once the breaker closes, or if it is already closed (as determined by the state of the 52A input). Typing **N <Enter>** after either of the above prompts aborts the closing operation with the message **Aborted**.

```
=>>CLOSE <Enter>
Close BREAKER (Y/N) ? Y <Enter>
Are you sure (Y/N) ? Y <Enter>
Breaker CLOSED
=>
```

LOGIC n

The **LOGIC** command programs the masks that control outputs and event report triggering.

The parameter *n* specifies a mask to program.

n	Mask
MTU	Mask for trip unconditional
MPT	Mask for trip with permissive trip asserted
MTB	Mask for trip with block trip deasserted
MTO-	Mask for trip with breaker open (Switch-On-To-Fault logic)
MA1	Mask for A1 relay control
MA2	Mask for A2 relay control
MA3	Mask for A3 relay control
MA4	Mask for A4 relay control
MRI	Mask for reclose initiate
MRC	Mask for reclose cancel

The logic programming procedure requires you to enter changes to the mask or press <Enter> to indicate no change. Each mask listed above is split into sections that correspond to the four rows of the Relay Word as follows:

Row 1	1ABC	2ABC	3ABC	4ABC	LOP	50H	50M	50L
Row 2	51NT	67N1	67N2	67N3	51NP	Z1P	Z2P	Z3P
Row 3	Z2PT	Z3PT	OSB	3P50	50MF	RC	RI	DF
Row 4	ALRM	TRIP	TC	DT	52BT	52AT	Z2GT	Z3GT

The **LOGIC** command displays a header and settings for each row of the Relay Word. Next it displays a question mark prompt and waits for input. Enter only ones and zeros with no separating spaces as input; one selects and zero deselects a member of the Relay Word. Press <Enter> when a group is satisfactory. If you want to change any member of a group, you must reenter all eight members, even if some remain the same. The relay repeats logic settings and the question mark prompt after entry of each row to allow corrections.

When all data are entered for each row, the relay displays the new settings and prompts for approval to enable the relay with them. **Y <Enter>** enters the new data, pulses the ALARM contacts closed momentarily, and clears the event buffers. **N <Enter>** retains the old settings.

The following shows a **LOGIC** command example for the MTU mask:

```

>>>LOGIC MTU <Enter>
1 selects, 0 deselects.

1ABC 2ABC 3ABC 4ABC LOP 50H 50M 50L
0     0     0     0     0     0     0     0
? 10000000 <Enter>
1     0     0     0     0     0     0     0
? <Enter>
51NT 67N1 67N2 67N3 51NP Z1P Z2P Z3P
0     0     0     0     0     0     0     0
? 11001000 <Enter>
1     1     0     0     0     1     0     0
? <Enter>
Z2PT Z3PT OSB 3P50 50MF RC RI DF
0     0     0     0     0     0     0     0
? 11001000 <Enter>
1     1     0     0     1     0     0     0
? <Enter>
ALRM TRIP TC DT 52BT 52AT Z2GT Z3GT
0     0     0     0     0     0     0     0
? 00110011 <Enter>
0     0     1     1     0     0     1     1
? <Enter>

New MTU :

1ABC 2ABC 3ABC 4ABC LOP 50H 50M 50L
1     0     0     0     0     0     0     0
51NT 67N1 67N2 67N3 51NP Z1P Z2P Z3P
1     1     0     0     0     1     0     0
Z2PT Z3PT OSB 3P50 50MF RC RI DF
1     1     0     0     1     0     0     0
ALRM TRIP TC DT 52BT 52AT Z2GT Z3GT
0     0     1     1     0     0     1     1

OK (Y/N) ? Y <Enter>
Enabled

```

The previous example selects unconditional tripping for assertion of the Zone 1 three-phase, phase-phase, and ground elements, 51N element timeout, timeout of Zones 2 and 3 phase and ground timers, executing the **TRIP OPEN**) command, and DT input assertion. The 50MF selection enables unconditional tripping for loss-of-potential (LOP, when LOPE is enabled) and 0M overcurrent conditions that persist for a settable time delay (50MFD).

Set the MPT, MTB, MTO, MA1, MA2, MA3, MA4, MRI, and MRC masks in a similar manner.

OPEN

The TRIP output relay closes in response to the **OPEN** command, as long as the TC (**OPEN** command) bit is selected in an appropriate trip mask (one or more of MTU, MPT, MTB, or MTO). The TRIP relay remains closed for a minimum duration (TDUR setting) starting with the rising edge of the trip output. The TRIP output drops out only if there is no low set overcurrent condition (50L or 50NL) or if you push the **TARGET RESET** button on the front panel.

If the TDUR setting is zero, the **OPEN** command is disabled.

To open the power circuit breaker by command, type **OPEN <Enter>**. The prompt Open BREAKER (Y/N) ? is transmitted. Answering **Y <Enter>** yields a second prompt: Are you Sure (Y/N) ? Answering **Y <Enter>** again closes the TRIP output relay as described above. The **OPEN** command aborts unless the remote open/close jumper (JMP104) is in place on the main board.

Date Code 20070225

Instruction Manual

SEL-221G, -3, -4/121G, -3, -4 Relay

```
=>>OPEN <Enter>
Open BREAKER (Y/N) ? Y <Enter>
Are you sure (Y/N) ? Y <Enter>
Breaker OPEN
=>

Example 230 KV Line           Date 1/8/91           Time: 23:36:10.887
Event   : TRIP    Location   :      mi      ohms sec
Duration:                  Flt Current:

=>
```

PASSWORD (1 or 2) [password]

PASSWORD allows you to inspect or change existing passwords. To inspect passwords, type **PASSWORD <Enter>** as the following example shows:

```
=>>PASSWORD <Enter>
1: OTTER
2: TAIL
=>
```

To change the password for Access Level 1 to BIKE enter the following:

```
=>>PASSWORD 1 BIKE <Enter>
Set
=>
```

The relay sets the password, pulses the ALARM relay closed, and transmits the response Set.

After entering new passwords, type **PASSWORD <Enter>** to inspect them. Make sure they are what you intended, and record the new passwords.

Passwords can be any length up to six numbers, letters, or any other printable characters except delimiters (space, comma, semicolon, colon, slash). Upper and lowercase letters are treated as different characters. Examples of valid, distinct passwords include:

OTTER otter Ot3456 +TAIL+ !@#\$%^ 123456 12345. 12345

If the passwords are lost or you want to operate the relay without password protection, install JMP103 on the main board. With no password protection, you can gain access without knowing the passwords and view or change current passwords and settings.

SET n

SET allows entry of relay settings. At the setting procedure prompts, enter new data or press **<Enter>** to indicate no change. You can jump to a specific setting by entering the setting name as parameter *n*. If no setting is entered as an argument, the procedure initiates at the first setting, Relay ID.

The **SET** command prompts you for each setting. The relay checks new settings against established limits twice. If the setting is within primary setting range, the relay prompts you for the next setting. Press **<Enter>** to retain an existing setting.

The first check is a primary setting limit check, the second is a secondary setting limit check. The primary check is intended as a rough guideline for individual settings and ensures that settings fall within a reasonable range. The secondary check compares the entire group of settings against the individual secondary setting limits shown in [Section 2: Specifications](#).

When you finish entering setting changes, it is not necessary to scroll through the remaining settings. Type **END <Enter>** after your last change to display the new settings and enable prompt. Do not use the END statement at the Relay ID setting; use **<CTRL+X>** to abort the SET procedure from this point.

After you enter all data, the relay displays the new settings and prompts for approval to enable them. Answer **Y <Enter>** to approve the new settings. Error messages notify you when entry combinations result in an out-of-range secondary setting. If all settings are acceptable, the relay enables them, closes the ALARM contact momentarily, and clears the event buffer.

A list of relay settings and the primary limit checks follows. Please note that each setting must also be within the secondary setting limit of the relay.

ID	39-character string to identify relay in event reports and SEL-DTA LCD display.
R1, X1	Positive-sequence primary impedance of line (0 – 9,999 Ω).
R0, X0	Zero-sequence primary impedance of line (0 – 9,999 Ω).
LL	Line length (0.1 – 999 miles).
CTR	CT ratio (e.g., for 600/5, enter 120) (1 – 5,000).
PTR	PT ratio (e.g., 1,200/1, enter 1200) (1 – 10,000).
MTA	Maximum torque angle (47 – 90 degrees).
LOCAT	Do you want the fault locator enabled? (Y or N).
790I1	Reclosing relay open interval 1 ($\frac{1}{4}$ to 10,000 cycles; 0 disables shots 1, 2, and 3).
790I2	Reclosing relay open interval 2 ($\frac{1}{4}$ to 10,000 cycles; 0 disables shots 2 and 3).
790I3	Reclosing relay open interval 3 ($\frac{1}{4}$ to 10,000 cycles; 0 disables shot 3).
79RS	Reclosing relay reset time (60 to 8,000 cycles).
Z1%	Zone 1 reach (percent of positive-sequence line impedance: 0 – 2,000%).
Z2%	Zone 2 reach (percent of positive-sequence line impedance: 0 – 3,200%).
Z3%	Zone 3 reach (percent of positive-sequence line impedance: 0 – 3,200%).
Z1DP	Zone 1 delay for phase and three-phase faults (0 – 60 cycles in $\frac{1}{4}$ cycle steps).
Z2DP	Zone 2 delay for phase and three-phase faults (0 – 2,000 cycles in $\frac{1}{4}$ cycle steps).
Z3DP	Zone 3 delay for phase and three-phase faults (0 – 2,000 cycles in $\frac{1}{4}$ cycle steps).

50L	Phase overcurrent element low pickup (0.25 – 50,000 primary amperes).
50M	Phase overcurrent element medium pickup (0.25 – 50,000 primary amperes).
50MFD	Phase overcurrent delay on loss-of-potential (0 – 60 cycles in ¼ cycle steps).
50H	Phase overcurrent element high pickup (0.25 – 50,000 primary amperes).
51NP	Residual time-overcurrent pickup (0.25 – 50,000 primary amperes).
51NTD	Residual time-overcurrent time dial (0.5 – 15).
51NC	Residual time-overcurrent curve index. Choices are as follows: 1 selects a moderately inverse curve 2 selects an inverse curve 3 selects a very inverse curve 4 selects an extremely inverse curve
51NTC	Do you want residual time-overcurrent torque control? (Y or N).
50N1P	Zone 1 instantaneous residual overcurrent pickup (0.25 – 50,000 primary amperes).
50N2P	Zone 2 instantaneous residual overcurrent pickup (0.25 – 50,000 primary amperes).
50N3P	Zone 3 instantaneous residual overcurrent pickup (0.25 – 50,000 primary amperes).
Z1DG	Zone 1 delay for ground faults (0 – 60 cycles in ¼ cycle steps).
Z2DG	Zone 2 delay for ground faults (0 – 2,000 cycles in ¼ cycle steps).
Z3DG	Zone 3 delay for ground faults (0 – 2,000 cycles in ¼ cycle steps).
TDUR	Minimum Trip Duration Timer (0 – 2,000 cycles in ¼ cycle steps).
52BT	52B time delay (0.5 to 10,000 cycles)
ZONE3	Zone 3 direction setting (F = forward or R = reverse).
32QE	Do you want negative-sequence directional supervision of the ground overcurrent elements? (Y or N).
32VE	Do you want to enable voltage polarization for the zero-sequence directional element? (Y or N).
32IE	Do you want to enable current polarization for the zero-sequence directional element? (Y or N).
OSB1	Do you want to block Zone 1 for out-of-step conditions? (Y or N).
OSB2	Do you want to block Zone 2 for out-of-step conditions? (Y or N).
OSB3	Do you want to block Zone 3 for out-of-step conditions? (Y or N).
OSBT	Out-of-step blocking timer (0.5 to 60 cycles in ¼ cycle steps).
LOPE	Block mho element tripping when loss-of-potential is detected? (Y or N).

TIME1	Timeout for PORT 1 communications (0 – 30 minutes, 0 = infinite time-out).
TIME2	Timeout for PORT 2 communications (0 – 30 minutes, 0 = infinite time-out).
AUTO	Destination for automatic messages (1 = PORT 1; 2 = PORT 2; 3 = both ports).
RINGS	Number of rings after which modem on PORT 1 answers (1 – 30 rings).

Refer to the functional description and be sure the settings you choose result in relay performance appropriate to your application.

The AUTO setting selects PORT 1, PORT 2, or both serial ports for automatically transmitted messages. If PORT 2 of the relay is connected to an SEL-DTA or SEL-PRTU, the AUTO setting must direct automatic messages to that port. The following table shows the effect of each possible setting:

Auto Setting	Automatic Message Destination Port
1	1
2	2
3	1 and 2

Event summaries and self-test warning and failure reports are automatically transmitted from port(s) designated automatic regardless of access level, if the designated port is not timed out. Enter zero as the timeout setting of the appropriate port if automatic transmissions will be monitored by a dedicated channel or printed on a dedicated printer.

This page intentionally left blank

Section 4

Event Reporting

Event Report Generation

NOTE: The relay need not trip to generate an event report.

The relay generates a summary and long event report in response to actions listed in [Table 4.1](#). The summary event report allows a quick review of the information necessary to determine the location and type of fault. The long event report displays 11 cycles of information for analyzing system and scheme performance.

Table 4.1 Event Report Triggering Actions

- Fault in any zone
 - OPEN command execution (if a trip results)
 - TRIGGER command execution
 - DIRECT TRIP input assertion
 - PERMISSIVE TRIP input assertion
 - BLOCK TRIP input assertion
 - EXTERNAL TRIGGER input assertion
 - TRIP output contact assertion
-

The relay generates a second summary and long event report for the same fault if the trip occurs after the end of the first report.

Actions listed in [Table 4.2](#) do not trigger an event report.

Table 4.2 Non-Event Report Triggering Actions

- CLOSE command execution
 - DIRECT CLOSE input assertion
 - 52A input status changes
 - Pickup of the 50L overcurrent element
 - Pickup of the 50M overcurrent element
-

Relay elements that trigger event reports must drop out for at least four cycles before they can initiate another event report. This helps to eliminate multiple records for boundary faults.

Triggering is recorded to the nearest quarter cycle (4.17 ms) and referenced to the 16th row of data in the report. All reports trigger at Row 16. This system allows you to determine the total duration of a long fault that triggers two event reports. Simply calculate the time difference between the report generated at fault inception and the report generated by the TRIP.

Summary Event Report

The summary report is automatically transmitted from port(s) designated AUTOMATIC regardless of access level, as long as the designated port has not timed out. If automatic transmissions are monitored by a dedicated channel or printed on a dedicated printer, enter a timeout setting of zero for the appropriate port.

Due to the length of the full report, it is not automatically transmitted. You can display the full report with the **EVENT** command.

The summary event report includes:

- Relay terminal identifier
- Date and time
- Event type
- Fault location
- Secondary ohms from relay to fault location
- Duration relay elements are picked up
- Maximum phase current measured near the middle of fault

The following shows an example summary event report.

```
Bus B, 230 kV Line 2          Date: 1/17/91          Time: 15:57:06.329
Event : 1AG      Location : 76.04 mi 6.11 ohms sec
Duration: 7.25   Flt Current: 1024.1
=>
```

The relay clears the event report and history buffer for the following conditions:

- Loss of control power
- Entry of a new setting via the **SET** or **LOGIC** commands

Long Event Report

The long event report contains 44 quarter-cycles of prefault, fault, and post fault voltage and current information. For each quarter-cycle of voltage and current information, the relay also records the states of all fault measuring elements, outputs, and inputs. This information is useful in reviewing fault inception and duration, relay element response, fault evolution, interaction with the communications equipment, and breaker reaction time.

The last 12 event records are stored in volatile memory. You can review the stored summary reports quickly with the **HISTORY** command; use the **EVENT** command to display the long form of each event report.

Interpretation of Voltage and Current Data

Voltage and current data in the event report are determined using the following steps. The process uses secondary quantities presented to the rear panel of the relay.

1. Input analog signals are filtered by two-pole, low-pass filters with cutoff frequencies of approximately 85 Hz.
2. Filtered analog signals are sampled four times per power system cycle and converted to numerical values.
3. A digital filter processes the sampled data and removes dc and ramp components. The unit sample response of this filter is:

1, -1, -1, 1

The filter has the property of a double differentiator smoother.

4. The latest four samples are processed through the digital filter every quarter-cycle. Successive outputs of the filter arrive every 90 degrees. With respect to the present value of the filter output, the previous value was taken one quarter-cycle earlier and appears to be leading the present value by 90 degrees.

Filter output values can be used to represent the signals as phasors:

- The previous value of the output is the Y-component.
- The present value of the output is the X-component.

It may seem confusing to refer to the older data as the leading component of the phasor. The following example may help.

Consider a sinewave having zero phase shift with respect to t=0 and a peak amplitude of 1. Now consider two samples, one taken at t=0, the other taken 90 degrees later. They have values 0 and 1, respectively. By the above rules, the phasor components are (X, Y) = (1,0).

Now consider a cosine function. Its samples taken at t=0 and t+90 degrees are 1 and 0; its phasor representation is (0,1). The phasor (0,1) leads the phasor (1,0) by 90 degrees. This coincides with a 90 degree lead of the cosine function over the sine function.

To construct a phasor diagram of voltages and currents, select a pair of adjacent rows from an area of interest in the event report. On Cartesian coordinates, plot the lower row (newer data) as the X-components and the upper row (older data) as the Y-components. Rotate the completed diagram to any angle of reference. The magnitude of any phasor equals the square root of the sum of its squares.

Note that moving forward one quarter-cycle rotates all phasors 90 degrees. You can verify this by plotting the phasor diagram with rows 1 and 2, then rows 2 and 3 of an event report. Example Event 1 shows the process of converting the rectangular format voltages and currents displayed in the event report to polar format.

Relays

The states of all relay elements are indicated in the six columns headed “Relays.” Active states of the various relay elements are indicated by designator symbols that correspond with the relay element names. The contents of the columns for active relay elements appear below. Assertion of the 50M, 50L, and LOP elements do not trigger an event report.

50P	:	Phase overcurrent elements	:	H = 50H	high set picked up
				M = 50M	medium set picked up
				L = 50L	low set picked up
213	:	Three-phase distance units	:	1 = Z1	Zone 1 picked up
				2 = Z2	Zone 2 picked up
				3 = Z3	Zone 3 picked up
				4 = Z4	Zone 4 picked up
21P	:	Two-phase distance units	:	1 = Z1	Zone 1 picked up
				2 = Z2	Zone 2 picked up
				3 = Z3	Zone 3 picked up
67N	:	Residual overcurrent units	:	1 = 67N1	high set picked up
				2 = 67N2	medium set picked up
				3 = 67N3	low set picked up
51N	:	Residual time-overcurrent	:	P = 51NP	51N element picked up
				T = TRIP	51N trip threshold reached
LOP	:	Loss-of-Potential detect	:	*	= LOP

Contact Outputs and Inputs

The next two columns (“Outputs” and “Inputs”) show the states of all output and input contacts. The report indicates assertion of an output or input contact with an asterisk (*) in the corresponding column; a period indicates deassertion. The following list shows the contents of these columns.

OUTPUTS

- TP : TRIP output
- CL : CLOSE output
- A1 : Programmable output #1
- A2 : Programmable output #2
- A3 : Programmable output #3
- A4 : Programmable output #4
- AL : ALARM output

INPUTS

- DT : DIRECT TRIP input
- PT : PERMISSIVE TRIP input
- BT : BLOCK TRIP input
- DC : DIRECT CLOSE input
- 52A : BREAKER AUXILIARY 52A SWITCH input
- ET : EXTERNAL TRIGGER input

Example Event Reports

One possible relay application is a time-stepped distance scheme as shown in [Figure 4.1](#). This figure shows two parallel transmission lines, each line protected by two SEL-121G or SEL-221G relays.

Zone 3 elements on each relay are reversed for use as backup and bus fault protection. Each relay is set to trip unconditionally as directed by the elements masked in the Mask for Unconditional Trip (MTU). Elements masked in the MTU logic mask include the instantaneous Zone 1 phase-phase (Z1P) and three-phase distance elements (1ABC), Zone 1 residual instantaneous element (67N1), the non-directional time-delayed 50MF element to protect the transmission line following a blown secondary potential fuse, Zone 2 and 3 phase distance and residual overcurrent timed elements (Z2PT, Z3PT, Z2GT, and Z3GT, respectively), and the residual time-overcurrent element (51NT). This logic provides time-graded backup protection. The MTU logic mask also includes the TC bit, which asserts after **OPEN** command execution, and the DT bit, which follows rear-panel DT input assertion.

During line tests, each relay is enabled to trip from elements masked into the Mask for Trip while breaker Open (MTO). This logic serves as the switch-onto-fault protection. MTO elements include Zones 1, 2, and 4 three-phase distance elements (1ABC, 2ABC, and 4ABC), the high-set 50H phase overcurrent element, Zone 1 and 2 instantaneous residual overcurrent elements (67N1 and 67N2), and Zones 1 and 2 phase-phase distance elements (Z1P and Z2P).




Figure 4.1 Example Transmission Line Protection

Externally Triggered Event Report

Recall from [Section 3: Communications](#) that the relay records an 11-cycle “snapshot” event report when you issue the **TRIGGER** command. This command does not affect the protective functions of the relay. The event type listing EXT signifies an externally triggered event. For events triggered by this

command, the report does not include a fault location, fault impedance in secondary ohms, fault duration, or maximum fault current. Use the **TRIGGER** command to generate an event report for plotting voltage and current phasors during normal load conditions prior to releasing the relay for service.

Example Event Report 1 shows the first cycle of normal operating conditions for Breaker 1. The event report was generated with the **TRIGGER** command. From this excerpt, you can immediately see that load currents are balanced by the lack of current in the IR column. Also, note that the line breaker is closed, as signified by the asterisk in the 52A column.


Example Event Report 1

Bus B, 230 kV Line 2								Date: 1/18/91	Time: 09:43:06.395	
FID=SEL-121G-R401-V656mptr12syzz-D901227										
IPOL	Currents (amps)				Voltages (kV)			Relays Outputs Inputs		
	IR	IA	IB	IC	VA	VB	VC	52265L	TCAAAAA	DPBD5E
							011710	PL1234L	TTTC2T	P3PNNP
										A
0	-2	-101	195	-104	-85.4	131.5	-46.4*
0	2	-170	0	176	-103.1	-22.1	125.8*
0	2	101	-195	101	85.4	-131.5	46.4*
0	-2	170	0	-176	103.1	22.1	-125.8*
Event : EXT Duration:				Location : mi Flt Current:				ohms sec		

SEL DIRECTION AND POLARITY CHECK FORM

STATION	Bus A - Breaker 1	DATE	1/20/92	TESTED BY																																																										
SWITCH NO.	1	EQUIPMENT	SEL-221G Relay																																																											
INSTALLATION	X ROUTINE	OTHER																																																												
LOAD CONDITIONS:																																																														
STATION READINGS:	MW (OUT)(IN)	MVAR (OUT)(IN)	VOLTS	AMPS																																																										
SEL READINGS:	78.75 MW (X)	13.33 MVAR (X)																																																												
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>AS SEEN ON SCREEN</th> <th>I_a</th> <th>I_b</th> <th>I_c</th> <th>V_a</th> <th>V_b</th> <th>V_c</th> </tr> <tr> <th>COMPANY NOTATION</th> <th>I(a)</th> <th>I(b)</th> <th>I(c)</th> <th>V(a)</th> <th>V(b)</th> <th>V(c)</th> </tr> </thead> <tbody> <tr> <td>1st LINE CHOSEN (Y COMPONENT)</td> <td>-101</td> <td>195</td> <td>-104</td> <td>-85.4</td> <td>131.5</td> <td>-46.4</td> </tr> <tr> <td>2nd LINE CHOSEN (X COMPONENT)</td> <td>-170</td> <td>0</td> <td>176</td> <td>-103.1</td> <td>-22.1</td> <td>125.8</td> </tr> <tr> <td>CALCULATED MAGNITUDE $\sqrt{x^2 + y^2}$</td> <td>197.74</td> <td>195.00</td> <td>204.43</td> <td>133.88</td> <td>133.34</td> <td>134.08</td> </tr> <tr> <td>ANGLE IN DEGREES ARCTAN Y/X</td> <td>-149.28</td> <td>+90</td> <td>-30.58</td> <td>-140.36</td> <td>+99.54</td> <td>-20.25</td> </tr> <tr> <td>VALUE OF V_a DEGREES TO SUBTRACT TO OBTAIN V_a DEGREES = 0</td> <td>-219.64</td> <td>-219.64</td> <td>-219.64</td> <td>-219.64</td> <td>-219.64</td> <td>-219.64</td> </tr> <tr> <td>@ V_a DEGREES = 0, ANGLE USED TO DRAW PHASOR DIAGRAM</td> <td>-8.92</td> <td>-129.64</td> <td>-250.22</td> <td>0</td> <td>-120.10</td> <td>-239.89</td> </tr> </tbody> </table>							AS SEEN ON SCREEN	I _a	I _b	I _c	V _a	V _b	V _c	COMPANY NOTATION	I(a)	I(b)	I(c)	V(a)	V(b)	V(c)	1st LINE CHOSEN (Y COMPONENT)	-101	195	-104	-85.4	131.5	-46.4	2nd LINE CHOSEN (X COMPONENT)	-170	0	176	-103.1	-22.1	125.8	CALCULATED MAGNITUDE $\sqrt{x^2 + y^2}$	197.74	195.00	204.43	133.88	133.34	134.08	ANGLE IN DEGREES ARCTAN Y/X	-149.28	+90	-30.58	-140.36	+99.54	-20.25	VALUE OF V _a DEGREES TO SUBTRACT TO OBTAIN V _a DEGREES = 0	-219.64	-219.64	-219.64	-219.64	-219.64	-219.64	@ V _a DEGREES = 0, ANGLE USED TO DRAW PHASOR DIAGRAM	-8.92	-129.64	-250.22	0	-120.10	-239.89
AS SEEN ON SCREEN	I _a	I _b	I _c	V _a	V _b	V _c																																																								
COMPANY NOTATION	I(a)	I(b)	I(c)	V(a)	V(b)	V(c)																																																								
1st LINE CHOSEN (Y COMPONENT)	-101	195	-104	-85.4	131.5	-46.4																																																								
2nd LINE CHOSEN (X COMPONENT)	-170	0	176	-103.1	-22.1	125.8																																																								
CALCULATED MAGNITUDE $\sqrt{x^2 + y^2}$	197.74	195.00	204.43	133.88	133.34	134.08																																																								
ANGLE IN DEGREES ARCTAN Y/X	-149.28	+90	-30.58	-140.36	+99.54	-20.25																																																								
VALUE OF V _a DEGREES TO SUBTRACT TO OBTAIN V _a DEGREES = 0	-219.64	-219.64	-219.64	-219.64	-219.64	-219.64																																																								
@ V _a DEGREES = 0, ANGLE USED TO DRAW PHASOR DIAGRAM	-8.92	-129.64	-250.22	0	-120.10	-239.89																																																								

USE THE VALUES IN ROWS 1 AND 2 ABOVE TO DRAW PHASOR DIAGRAMS BELOW



Event report data for the voltages and currents are displayed in rectangular format. You can easily convert these rectangular values to polar format as described under [Interpretation of Voltage and Current Data on page 4.3](#). [Section 6: Installation](#) includes a blank voltage and current polarity check form for plotting voltage and current phasors. A completed direction and polarity check form using the first two rows of data from the event report follows Example Event Report 1.

Using the voltage and current phasor diagrams at the end of the SEL Direction and Polarity Check Form, note that the current and voltage phase rotation is ABC in the counterclockwise direction. This phase rotation must match the rotation of your system. In addition, note that the load is flowing out from Breaker 1, as indicated by each phase current lagging the respective phase voltage by the load flow angle.

In-Section Zone 2 BC Fault

Example 2 contains two event reports for an in-section BC fault as viewed from Breaker 1 at Bus A. The first event report (2.1) shows the inception of the fault. This event report was generated by the pickup of the Zone 2 phase-phase distance element. The second event report (2.2) was generated by the assertion of the TRIP output. Notice that this sequence of event reports captures the beginning and the end of the fault.

Event Report 2.1

This event report was generated by assertion of the Zone 2 phase-phase distance element in the 16th row of information. Date and time tags at the top of the event report are referenced to this row of data. The relay labeled the event a Zone 2 BC fault (2BC) and calculated a fault location of 85.76 miles from the relay terminal. The relay is expected to trip for this fault if it persists for 20 cycles. Because the event report is 11 cycles in duration, the tripping of the breaker must be captured during a subsequent event report. [Figure 4.2](#) shows the fault placement on Line 1.




Figure 4.2 Zone 2 BC Fault 85 Miles from Breaker 1

Example Event Report 2.1

BUS B, 230 kV LINE 2 Date: 1/19/91 Time: 01:58:37.820

FID=SEL-121G-R403-V656mpac11sy52-D910322

IPOL	IR	Currents (amps)		Voltages (kV)			Relays Outputs		Inputs	
		IA	IB	IC	VA	VB	VC	52265L TCAAAA DPBD5E		P3PNP
								0111710	PL1234L	
0	4	-47	-50	98	-37.4	-91.2	129.4	*
0	4	85	-85	3	127.9	-95.8	-31.8	*
0	-4	47	47	-98	37.4	91.2	-129.4	*
0	-4	-85	85	-3	-127.9	95.8	31.8	*
0	4	-47	-47	98	-37.4	-91.2	129.4	*
0	4	85	-88	3	127.9	-95.7	-31.8	*
0	-4	50	50	-98	37.4	91.2	-129.4	*
0	-4	-88	88	0	-127.9	95.8	31.8	*
0	4	-50	-50	94	-37.3	-91.3	129.5	*
0	4	88	-85	0	127.8	-95.8	-32.0	*
0	-4	47	50	-98	37.3	91.2	-129.4	*
0	-18	-85	346	-277	-127.9	91.3	36.4	L.....	*
0	-11	-47	25	9	-37.2	-83.6	121.6	L.....	*
0	58	85	-941	909	127.9	-88.1	-39.3	M.....	*
0	35	47	-157	148	37.2	73.7	-111.5	M.....	*
0	-88	-85	1312	-1312	-127.9	89.2	38.0	M.2....**	*
0	-44	-47	223	-223	-37.2	-71.0	108.7	M.2....**	*
0	93	85	-1359	1365	127.9	-89.3	-37.9	M.2....**	*
0	44	47	-233	233	37.2	70.6	-108.3	M.2....**	*
0	-93	-85	1365	-1372	-127.9	89.3	37.9	M.2....**	*
0	-44	-47	233	-233	-37.2	-70.6	108.3	M.2....**	*
0	93	85	-1365	1372	127.9	-89.3	-37.9	M.2....**	*
0	44	47	-233	233	37.1	70.7	-108.3	M.2....**	*
0	-93	-85	1365	-1372	-127.9	89.3	37.9	M.2....**	*
0	-44	-47	233	-233	-37.1	-70.7	108.2	M.2....**	*
0	93	85	-1365	1372	127.9	-89.3	-37.9	M.2....**	*
0	44	47	-233	233	37.1	70.7	-108.3	M.2....**	*
0	-93	-85	1365	-1372	-127.9	89.3	38.0	M.2....**	*
0	-44	-47	233	-233	-37.1	-70.7	108.3	M.2....**	*
0	93	85	-1365	1372	127.9	-89.3	-38.1	M.2....**	*
0	44	47	-233	233	37.1	70.7	-108.3	M.2....**	*
0	-93	-85	1365	-1372	-127.9	89.3	38.1	M.2....**	*

```

0 -46 -47 233 -230 -37.1 -70.7 108.3 M.2... ...*... ....*.  

0 95 85 -1365 1369 127.9 -89.3 -38.1 M.2... ...*... ....*.  

0 46 47 -233 230 37.1 70.7 -108.3 M.2... ...*... ....*.  

0 -95 -85 1365 -1369 -127.9 89.3 38.1 M.2... ...*... ....*.  

0 -44 -47 233 -233 -37.1 -70.7 108.3 M.2... ...*... ....*.  

0 93 85 -1365 1372 127.9 -89.2 -38.1 M.2... ...*... ....*.  

0 44 47 -233 233 37.1 70.8 -108.3 M.2... ...*... ....*.  

0 -93 -85 1365 -1372 -127.9 89.2 38.2 M.2... ...*... ....*.  

0 -44 -47 233 -233 -37.0 -70.8 108.2 M.2... ...*... ....*.  

0 93 85 -1365 1372 127.9 -89.2 -38.2 M.2... ...*... ....*.  

0 44 50 -233 233 37.0 70.8 -108.2 M.2... ...*... ....*.  

0 -93 -88 1365 -1372 -127.9 89.2 38.2 M.2... ...*... ....*.  

Event : 2BC Location : 85.76 mi 6.71 ohms sec  

Duration: 7.25 Flt Current: 1391.3  

R1 =8.56 X1 =77.77 R0 =35.12 X0 =236.96 LL =100.00  

CTR =200.00 PTR =2000.00 MTA =83.72 LOCAT=Y  

790I1=40.00 790I2=60.00 790I3=80.00 79RS =240.00  

Z1% =80.00 Z2% =120.00 Z3% =120.00  

Z1DP =0.00 Z2DP =20.00 Z3DP =60.00  

50L =275.00 50M =500.00 50MF=20.00 50H =3420.00  

51NP =230.00 51NTD=4.00 51NC =3 51NTC=Y  

50N1P=835.00 50N2P=276.00 50N3P=282.00  

Z1DG =0.00 Z2DG =30.00 Z3DG =60.00 TDUR =9.00  

52BT =20.00 ZONE3=R 32QE =Y 32VE =N 32IE =N  

OSB1 =Y OSB2 =Y OSB3 =Y OSBT =30.00 LOPE =Y  

TIME1=5 TIME2=0 AUTO =2 RINGS=7  

Logic settings:  

MTU MPT MTB MTO MA1 MA2 MA3 MA4 MRI MRC  

80 00 00 D4 20 00 00 08 00 E4  

C4 00 00 E6 11 00 00 00 44 80  

C8 00 00 00 00 01 20 00 00 C8  

33 00 00 00 00 00 00 00 00 33

```

Example Event Report 2.2

BUS B, 230 kV LINE 2 Date: 1/19/91 Time: 01:58:38.154
 FID=SEL-121G-R403-V656mpac11sy52-D910322

IPOL	IR	Currents (amps)			Voltages (kV)			Relays Outputs Inputs		
		IA	IB	IC	VA	VB	VC	52265L	TCAAAA	DPBD5E
							011710	PL1234L	TTTC2T	
							P3PNP		A	
0	-44	-47	227	-227	-36.6	-71.0	108.2	M.2... ...*...*		
0	93	85	-1372	1372	128.0	-88.9	-38.5	M.2... ...*...*		
0	44	47	-227	227	36.6	71.1	-108.1	M.2... ...*...*		
0	-93	-85	1372	-1372	-128.1	88.8	38.6	M.2... ...*...*		
0	-44	-47	223	-227	-36.4	-71.1	108.0	M.2... ...*...*		
0	93	85	-1369	1372	128.0	-88.8	-38.6	M.2... ...*...*		
0	44	47	-223	227	36.4	71.1	-108.0	M.2... ...*...*		
0	-93	-85	1369	-1375	-128.0	88.8	38.6	M.2... ...*...*		
0	-44	-47	227	-223	-36.4	-71.1	108.0	M.2... ...*...*		
0	93	85	-1372	1375	128.1	-88.8	-38.6	M.2... ...*...*		
0	44	47	-223	223	36.4	71.1	-108.0	M.2... ...*...*		
0	-93	-85	1369	-1375	-128.1	88.8	38.6	M.2... ...*...*		
0	-44	-47	223	-223	-36.4	-71.1	108.0	M.2... ...*...*		
0	93	85	-1369	1375	128.2	-88.8	-38.6	M.2... ...*...*		
0	44	47	-227	223	36.3	71.1	-108.0	M.2... ...*...*		
0	-93	-85	1372	-1375	-128.1	88.8	38.6	M.2... ...*...*		
0	-44	-47	223	-223	-36.3	-71.1	108.1	M.2... ...*...*		
0	93	85	-1369	1375	128.1	-88.8	-38.6	M.2... ...*...*		
0	44	47	-223	223	36.3	71.1	-108.1	M.2... ...*...*		
0	-93	-85	1369	-1375	-128.1	88.9	38.7	M.2... ...*...*		
0	-44	-47	227	-223	-36.3	-71.2	108.0	M.2... ...*...*		
0	93	85	-1372	1375	128.1	-88.8	-38.8	M.2... ...*...*		
0	44	47	-227	220	36.3	71.3	-107.9	M.2... ...*...*		
0	-93	-85	1372	-1372	-128.2	88.7	38.7	M.2... ...*...*		
0	-44	-47	223	-220	-36.2	-71.2	108.0	M.2... ...*...*		
0	91	85	-1369	1372	128.2	-88.8	-38.8	M.2... ...*...*		
0	46	47	-223	223	36.2	71.4	-108.1	M.2... ...*...*		
0	-77	-72	1076	-1082	-128.2	93.1	34.5	M.2... ...*...*		

4.10 | Event Reporting
Example Event Reports

```

0   -31   -31   173   -170   -36.2   -79.0   115.8   M.2... *..*... ....*.
0    38    31  -444    444   128.2   -96.3   -31.5   L..... *..*... ....*.
0     9    13   -66    66   36.2   89.0  -126.0   L..... *..*... ....*.
0    -7    -3    53   -53  -128.2   95.0   33.0   ..... *..*... ....*.

0    -2    -6     9   -9   -36.2   -91.7   128.7   ..... *..*... ....*.
0     2     3    -3     6   128.2   -94.9   -33.1   ..... *.... ....*.
0     0     3    -3     0   36.2   92.1  -129.0   ..... *.... ....*.
0     0    -3    -3     0  -128.3   94.8   33.1   ..... *.... ....*.

0     0     0     0     0   -36.1   -92.2   129.2   ..... *.... ....*.
0     0     0     6     0   128.3   -94.8   -33.2   ..... *.... ....*.
0     0    -3     0     0   36.1   92.2  -129.2   ..... *.... ....*.
0     0     3    -6     0  -128.2   94.8   33.2   ..... *.... ....*.

0     0     3     0     0   -36.0   -92.3   129.1   ..... *.... ....*.
0     0    -3     6     0   128.2   -94.8   -33.2   ..... *.... ....*.
0     0     0    -3     0   36.0   92.3  -129.1   ..... *.... ....*.
0     0     0    -3     0  -128.2   94.8   33.2   ..... *.... ....*.

Event : 2BCT Location : 85.52 mi 6.69 ohms sec
Duration: 7.25 Flt Current: 1392.9

R1 =8.56 X1 =77.77 R0 =35.12 X0 =236.96 LL =100.00
CTR =200.00 PTR =2000.00 MTA =83.72 LOCAT=Y
79011=40.00 79012=60.00 79013=80.00 79RS =240.00
Z1% =80.00 Z2% =120.00 Z3% =120.00
Z1DP =0.00 Z2DP =20.00 Z3DP =60.00
50L =275.00 50M =500.00 50MFD=20.00 50H =3420.00
51NP =230.00 51NTD=4.00 51NC =3 51NTC=Y
50N1P=835.00 50N2P=276.00 50N3P=282.00
Z1DG =0.00 Z2DG =30.00 Z3DG =60.00 TDUR =9.00
52BT =20.00 ZONE3=R 32OE =Y 32VE =N 32IE =N
OSB1 =Y OSB2 =Y OSB3 =Y OSBT =30.00 LOPE =Y
TIME1=5 TIME2=0 AUTO =2 RINGS=7

Logic settings:

MTU MPT MTB MTO MA1 MA2 MA3 MA4 MRI MRC
80 00 00 D4 20 00 00 08 00 E4
C4 00 00 E6 11 00 00 00 44 80
C8 00 00 00 00 01 20 00 00 C8
33 00 00 00 00 00 00 00 00 33

```

The following is the first four cycles (quarter-cycles 1 – 16) of Event Report 2.1, showing the prefault and fault inception conditions.

IPOL	Currents (amps)				Voltages (kV)			Relays Outputs Inputs				Quarter Cycles
	IR	IA	IB	IC	VA	VB	VC	52265L	TCAAAA	DPBD5E		
								011710	PL1234L	TTTC2T	A	
P3PNP												
0	4	-47	-50	98	-37.4	-91.2	129.4*		1
0	4	85	-85	3	127.9	-95.8	-31.8*		2
0	-4	47	47	-98	37.4	91.2	-129.4*		3
0	-4	-85	85	-3	-127.9	95.8	31.8*		4
0	4	-47	-47	98	-37.4	-91.2	129.4*		5
0	4	85	-88	3	127.9	-95.7	-31.8*		6
0	-4	50	50	-98	37.4	91.2	-129.4*		7
0	-4	-88	88	0	-127.9	95.8	31.8*		8
0	4	-50	-50	94	-37.3	-91.3	129.5*		9
0	4	88	-85	0	127.8	-95.8	-32.0*		10
0	-4	47	50	-98	37.3	91.2	-129.4*		11
0	-18	-85	346	-277	-127.9	91.3	36.4	L.....*		12
0	-11	-47	25	9	-37.2	-83.6	121.6	L.....*		13
0	58	85	-941	909	127.9	-88.1	-39.3	M.....*		14
0	35	47	-157	148	37.2	73.7	-111.5	M.....**		15
0	-88	-85	1312	-1312	-127.9	89.2	38.0	M.2....**		16

The event report uses a sequence of event format that allows performance analysis of the system by quarter-cycles. Through the analysis, you can observe the prefault voltages and currents prior to the fault, determine whether or not the breaker was closed by the 52A Inputs column and line current magnitudes, and learn when the Zone 2 element asserted. The following outline lists the observed incidents in Example Event Report 2.1. Please note that event report cycles after Row 16 are identical to Row 16 and require no additional explanation.

Quarter Cycle	Event Report Shows:
1–11	<p>Prefault Conditions:</p> <ul style="list-style-type: none"> ➤ Nearly zero residual current in IR column indicates balanced load currents. ➤ No protective relay elements are picked up, as indicated by periods in all columns under Relays heading. ➤ * in the 52A Inputs column verifies breaker closure (as does load current flow). Note that 52A input remains asserted for the remainder of this event report.
12–13	<p>Fault Inception:</p> <ul style="list-style-type: none"> ➤ L in 50P column shows fault current reached 50L element pickup threshold.
14	<ul style="list-style-type: none"> ➤ M in 50P column shows fault current reached 50M element pickup threshold.
15	<ul style="list-style-type: none"> ➤ M in 50P column shows fault current is above the 50M element pickup threshold. ➤ * in A2 Outputs indicates that the negative-sequence polarized directional element declares the fault to be in the forward direction. This contact remains asserted for the remainder of the event report.
16	<ul style="list-style-type: none"> ➤ 2 in 21P column shows when the Zone 2 phase-phase element picked up. By observing the current magnitudes and sign of each current sample, you can immediately determine two things: <ol style="list-style-type: none"> 1. After comparing the current magnitudes, you should notice that phases B and C are involved. 2. The sign of B-phase current is opposite that of C-phase. As the magnitudes are approximately equal and the signs are opposite. This indicates that the B-and C-phase currents are 180° out-of-phase.

The Z2P element remained picked up for the duration of this event report.

Event Report 2.2

This event report was generated by assertion of TRIP output contacts in Row 16. Recall that this type of event report generation is rising edge sensitive. The date and time tags at the top of the event report are referenced to this row of data. Closure of the TRIP output is a result of Zone 2 phase distance timer expiration. Use the time tags at the top of Example Event Reports 2.1 and 2.2 to verify the operation of the Z2PT timer as follows:

Event Report 2.2 Time Tag: 01:58:38.154

Event Report 2.1 Time Tag: -01:58:37.820

0.334 sec or 20 cycles

This calculation matches the Z2DP timer setting at the bottom of the event report.

The relay labeled the event a Zone 2 BC fault (2BCT) and calculated a fault location of 85.52 miles from the relay terminal. The relay is expected to trip for this fault because the BC phase-phase fault persisted for 20 cycles. Note in the event type tag that 2BC is appended with a T. This T signifies that the event report was generated by TRIP output contact assertion.

The following is the first four cycles (quarter-cycles 1 – 16) of Event Report 2.2, showing the fault condition and tripping action dictated by the relay.

4.12 | Event Reporting
Example Event Reports

IPOL	Currents (amps)				Voltages (kV)			Relays Outputs		Inputs		Quarter Cycles	
	IR	IA	IB	IC	VA	VB	VC	52265L TCAAAA DPBD5E					
								P011710	PL1234L	TTTC2T	A		
0	-44	-47	227	-227	-36.6	-71.0	108.2	M.2....**	1	
0	93	85	-1372	1372	128.0	-88.9	-38.5	M.2....**	2	
0	44	47	-227	227	36.6	71.1	-108.1	M.2....**	3	
0	-93	-85	1372	-1372	-128.1	88.8	38.6	M.2....**	4	
0	-44	-47	223	-227	-36.4	-71.1	108.0	M.2....**	5	
0	93	85	-1369	1372	128.0	-88.8	-38.6	M.2....**	6	
0	44	47	-223	227	36.4	71.1	-108.0	M.2....**	7	
0	-93	-85	1369	-1375	-128.0	88.8	38.6	M.2....**	8	
0	-44	-47	227	-223	-36.4	-71.1	108.0	M.2....**	9	
0	93	85	-1372	1375	128.1	-88.8	-38.6	M.2....**	10	
0	44	47	-223	223	36.4	71.1	-108.0	M.2....**	11	
0	-93	-85	1369	-1375	-128.1	88.8	38.6	M.2....**	12	
0	-44	-47	223	-223	-36.4	-71.1	108.0	M.2....**	13	
0	93	85	-1369	1375	128.2	-88.6	-38.6	M.2....**	14	
0	44	47	-227	223	36.3	71.1	-108.0	M.2....**	15	
0	-93	-85	1372	-1375	-128.1	88.8	38.6	M.2....	*..**	16	

Quarter Cycle	Event Report Shows:
1–15	Fault Conditions: <ul style="list-style-type: none"> ➤ M in 50P column indicates current above the 50M element pickup threshold. ➤ 2 in 21P column shows the Zone 2 phase-phase element picked up. ➤ * in A2 Outputs column indicates the DF bit of the Relay Word is asserted. ➤ * in 52A Inputs column verifies breaker closure (as does current flow).
16	TRIP Issued: <ul style="list-style-type: none"> ➤ 2 in 21P column shows when the Zone 2 phase-phase element picked up. ➤ * in TP Outputs indicates TRIP contact closure. ➤ * in A2 Outputs column indicates the DF bit of the Relay Word is asserted. ➤ * in 52A Inputs column verifies breaker closure.

The relay closed the TRIP output in Row 16 because the Zone 2 phase-phase distance element was picked up for Z2PT time. The remaining quarter-cycles show the breaker clearing the fault after it was directed to trip.

The following excerpt from Example Event Report 2.2 shows cycles eight through 11 (quarter-cycles 29 – 44). These cycles represent the post fault conditions.

IPOL	Currents (amps)			Voltages (kV)			Relays		52265L TCAAAA DPBD5E 011710 PL1234L TTTC2T P3PNP A	Outputs Inputs	
	IR	IA	IB	IC	VA	VB	VC				
	Quarter	Cycle									
0	-31	-31	173	-170	-36.2	-79.0	115.8	M.2... *..*....*		29	
0	38	31	-444	444	128.2	-96.3	-31.5	L..... *..*....*		30	
0	9	13	-66	66	36.2	89.0	-126.0	L..... *..*....*		31	
0	-7	-3	53	-53	-128.2	95.0	33.0 *..*....*		32	
0	-2	-6	9	-9	-36.2	-91.7	128.7 *..*....*		33	
0	2	3	-3	6	128.2	-94.9	-33.1 *....*		34	
0	0	3	-3	0	36.2	92.1	-129.0 *....*		35	
0	0	-3	-3	0	-128.3	94.8	33.1 *....*		36	
0	0	0	0	0	-36.1	-92.2	129.2 *....*		37	
0	0	0	6	0	128.3	-94.8	-33.2 *....*		38	
0	0	-3	0	0	36.1	92.2	-129.2 *....*		39	
0	0	3	-6	0	-128.2	94.8	33.2 *....*		40	
0	0	3	0	0	-36.0	-92.3	129.1 *....*		41	
0	0	-3	6	0	128.2	-94.8	-33.2 *....*		42	
0	0	0	-3	0	36.0	92.3	-129.1 *....*		43	
0	0	0	-3	0	-128.2	94.8	33.2 *....*		44	

Quarter Cycle	Event Report Shows:
29	<p>Post-fault Conditions:</p> <ul style="list-style-type: none"> ➤ M in 50P column indicates current above the 50M element pickup threshold. ➤ 2 in 21P column shows the Zone 2 phase-phase element picked up. ➤ * in A2 Outputs indicates the DF bit of the Relay Word is asserted. ➤ * in 52A Inputs column verifies breaker closure (as does current flow).
30–31	<ul style="list-style-type: none"> ➤ L in 50P column indicates that current has dropped below the 50M element threshold (which is greater than the 50L threshold) but remains above the 50L element pickup threshold. ➤ A period in 21P column indicates that the Z2P element has dropped out. ➤ * in TP Outputs indicates TRIP contact closure. TRIP contacts remain closed for the duration of this event report due to the TDUR setting of nine cycles. ➤ * in A2 Outputs indicates the DF bit of the Relay Word is asserted. ➤ * in 52A Inputs column verifies breaker closure.
32–33	<ul style="list-style-type: none"> ➤ A period in the 50P column indicates currents have dropped below the 50L element pickup threshold. ➤ * in A2 Outputs indicates the DF bit of the Relay Word is asserted. ➤ A period in the 52A Inputs column verifies that the breaker has opened as does the dropout of current sensing elements in the 50P Relays Column.

Reverse Out-of-Section Fault

Example Event Report 3 shows a reverse A-phase ground fault that does not result in a trip at Breaker 1. Referring to [Figure 4.1](#), faults on Line 2 should be cleared by Breakers 3 and 4.

The relay at Breaker 1 sees the initial fault on Line 2 with a reverse Zone 3 67N3 ground overcurrent element. The relay at Breaker 3 trips instantaneously to clear its contributions to the fault. Because the reverse element asserts for less than 60 cycles, no trip results at Breaker 1. Had Breaker 3 failed, Breaker 1 would have tripped 60 cycles after detection by the 67N3 element.

Example Event Report 3

Date: 1/19/91

Time: 09:39:22.579

FID=SEL-121G-R401-V656mptr12syz2-D901227

Currents (amps)				Voltages (kV)				Relays Outputs			
IPOL	IR	IA	IB	IC	VA	VB	VC	52265L	TCAAAA	DPBD5E	
								011170	PL1234L	TTTC2T	A
P3PNP											
0	0	13	79	-91	-15.3	122.6	-107.0	.	.	.	*
0	-4	-94	60	35	-133.1	53.2	79.0	.	.	.	*
0	0	-13	-79	91	15.5	-122.6	107.0	.	.	.	*
0	4	98	-60	-35	133.1	-53.2	-79.0	.	.	.	*
0	0	9	79	-91	-15.5	122.6	-107.0	.	.	.	*
0	-4	-98	60	35	-133.1	53.0	79.0	.	.	.	*
0	0	-9	-79	91	15.5	-122.6	107.0	.	.	.	*
0	4	94	-60	-35	133.1	-53.0	-79.0	.	.	.	*
0	0	13	79	-91	-15.5	122.6	-107.0	.	.	.	*
0	-4	-94	60	35	-133.0	53.0	79.0	.	.	.	*
0	0	-13	-79	91	15.5	-122.6	107.0	.	.	.	*
0	4	94	-60	-35	132.7	-53.0	-79.2	.	.	.	*
0	-44	-28	79	-91	-16.2	122.3	-107.2	.	.	.	*
0	-18	-110	60	35	-97.8	61.3	87.5	.	.	.	*
0	316	299	-79	91	7.9	-123.3	105.5	L	.	.	*
0	-100	-3	-60	-35	35.6	-76.4	-102.5	L	..	*	*
0	-606	-595	79	-91	0.8	124.2	-103.8	M	..	*	*
0	246	148	60	35	-4.5	84.4	110.0	M	..	*	*
0	677	667	-79	91	-0.3	-123.8	104.0	M	..	*	*
0	-263	-164	-60	-35	0.6	-85.4	-111.1	M	..	*	*
0	-688	-676	79	-91	0.1	123.8	-104.0	M	..	*	*
0	268	167	60	35	-0.1	85.5	111.2	M	..	*	*
0	688	680	-79	91	0.0	-123.8	104.0	M	..	*	*
0	-268	-170	-60	-35	0.1	-85.5	-111.3	M	..	*	*
0	-688	-680	79	-91	0.0	123.8	-104.0	M	..	*	*
0	268	170	60	35	-0.1	85.5	111.3	M	..	*	*
0	688	676	-79	91	0.0	-123.8	104.0	M	..	*	*
0	-268	-167	-60	-35	0.4	-85.3	-111.2	M	..	*	*
0	-644	-632	76	-85	0.7	124.2	-103.8	M	..	*	*
0	281	201	35	35	-35.4	77.0	102.9	M	..	*	*
0	372	365	-41	50	7.7	-123.2	105.4	L	..	*	*
0	-164	-132	-6	-19	97.6	-61.9	-88.0	L	..	*	*
0	-82	-79	6	-13	-16.5	122.3	-107.2	.	.	.	*
0	18	13	0	0	-128.5	53.9	80.4	.	.	.	*
0	0	-13	-79	91	15.5	-122.6	107.0	.	.	.	*
0	4	98	-60	-35	133.1	-53.2	-79.0	.	.	.	*
0	0	13	79	-91	-15.3	122.6	-107.0	.	.	.	*
0	-4	-94	60	35	-133.1	53.2	79.0	.	.	.	*
0	0	-13	-79	91	15.5	-122.6	107.0	.	.	.	*
0	4	98	-60	-35	133.1	-53.2	-79.0	.	.	.	*
0	0	9	79	-91	-15.5	122.6	-107.0	.	.	.	*
0	-4	-98	60	35	-133.1	53.0	79.0	.	.	.	*
0	0	-9	-79	91	15.5	-122.6	107.0	.	.	.	*
0	4	94	-60	-35	133.1	-53.0	-79.0	.	.	.	*

Event : 3AG Location : -0.08 mi -0.01 ohms sec
Duration: 4.25 Flt Current: 700.5

R1	=8.56	X1	=77.77	R0	=35.12	X0	=236.96	LL	=100.00
CTR	=200.00	PTR	=2000.00	MTA	=83.72	LOCAT=Y			
79011=40.00		79012=60.00	79013=80.00			79RS	=240.00		
Z1%	=80.00	Z2%	=120.00	Z3%	=120.00				
Z1DP	=0.00	Z2DP	=20.00	Z3DP	=60.00				
50L	=275.00	50M	=500.00	50MFD	=20.00	50H	=3420.00		
51NP	=230.00	51NTD	=4.00	51NC	=3	51NTC	=Y		
50N1P=835.00		50N2P=276.00		50N3P=282.00					
Z1DG	=0.00	Z2DG	=30.00	Z3DG	=60.00	TDUR	=9.00		
52BT	=20.00	ZONE3=R		32QE	=Y	32VE	=N	32IE	=N
OSB1	=Y	OSB2	=Y	OSB3	=Y	OSBT	=30.00	LOPE	=Y
TIME1=5		TIME2=0		AUTO	=2	RINGS	=7		

Logic settings:

MTU	MPT	MTB	MTO	MA1	MA2	MA3	MA4	MRI	MRC
80	00	00	D4	20	00	00	08	00	E4
C4	00	00	E6	11	00	00	00	44	80
C8	00	00	00	00	01	20	00	00	C8
33	00	00	00	00	00	00	00	00	33

The following excerpt shows the first 16 quarter-cycles of prefault data for Example Event Report 3.

IPOL	Currents (amps)			Voltages (kV)			Relays		Outputs	Inputs	Quarter Cycle
	IR	IA	IB	IC	VA	VB	VC	52265L	TCAAAA	DPBD5E	
								P3PNNP	011710	PL1234L	
0	0	13	79	-91	-15.3	122.6	-107.0	*.
0	-4	-94	60	35	-133.1	53.2	79.0	*.
0	0	-13	-79	91	15.5	-122.6	107.0	*.
0	4	98	-60	-35	133.1	-53.2	-79.0	*.
0	0	9	79	-91	-15.5	122.6	-107.0	*.
0	-4	-98	60	35	-133.1	53.0	79.0	*.
0	0	-9	-79	91	15.5	-122.6	107.0	*.
0	4	94	-60	-35	133.1	-53.0	-79.0	*.
0	0	13	79	-91	-15.5	122.6	-107.0	*.
0	-4	-94	60	35	-133.0	53.0	79.0	*.
0	0	-13	-79	91	15.5	-122.6	107.0	*.
0	4	94	-60	-35	132.7	-53.0	-79.2	*.
0	-44	-28	79	-91	-16.2	122.3	-107.2	*.
0	-18	-110	60	35	-97.8	61.3	87.5	*.
0	316	299	-79	91	7.9	-123.3	105.5	L.....	*.
0	-100	-3	-60	-35	35.6	-76.4	-102.5	L..3..	.*..	*.

Quarter Cycle	Event Report Shows:
1–14	Prefault Conditions: <ul style="list-style-type: none">➤ No residual current in IR column indicates balanced load currents.➤ No protective relay elements are picked up.➤ * in 52A Inputs column verifies breaker closure (as does load current flow).
15	Fault Inception <ul style="list-style-type: none">➤ L in 50P column shows that fault current reached 50L element pickup threshold.➤ L in 50P column shows that fault current reached 50L element pickup threshold.
16	<ul style="list-style-type: none">➤ 3 in 67N column shows 67N3 element pickup. Relay settings shown near the end of the event report indicate that the Zone 3 elements are reversed. These notes indicate that the fault is behind Breaker 1.➤ * in A1 Outputs indicates a Zone 3 element is asserted (67N3 in this event).➤ * in 52A Inputs column verifies that breaker was closed (as does load and fault current flow).

Starting at quarter-cycle 31 of the same event report, you can see the fault current begin to decrease. This indicates that Breaker 3 is clearing its contribution to the fault. Quarter-cycles 33 through 44 show the 52A input assertion that indicates that the breaker is still closed.

IPOL	Currents (amps)			Voltages (kV)			Relays Outputs Inputs			Quarter Cycle	
	IR	IA	IB	IC	VA	VB	VC	52265L	TCAAAA	DPBD5E	
								P3PNP	0111710	PL1234L	
0	372	365	-41	50	7.7	-123.2	105.4	L..3...	...*....*	31
0	-164	-132	-6	-19	97.6	-61.9	-88.0	L..3...	...*....*	32
0	-82	-79	6	-13	-16.5	122.3	-107.2*	33
0	18	13	0	0	-128.5	53.9	80.4*	34
0	0	-13	-79	91	15.5	-122.6	107.0*	35
0	4	98	-60	-35	133.1	-53.2	-79.0*	36
0	0	13	79	-91	-15.3	122.6	-107.0*	37
0	-4	-94	60	35	-133.1	53.2	79.0*	38
0	0	-13	-79	91	15.5	-122.6	107.0*	39
0	4	98	-60	-35	133.1	-53.2	-79.0*	40
0	0	9	79	-91	-15.5	122.6	-107.0*	41
0	-4	-98	60	35	-133.1	53.0	79.0*	42
0	0	-9	-79	91	15.5	-122.6	107.0*	43
0	4	94	-60	-35	133.1	-53.0	-79.0*	44

Quarter Cycle	Event Report Shows:
31–32	<p>Post-fault Conditions:</p> <ul style="list-style-type: none"> ➤ * in 52A Inputs column indicates breaker auxiliary contacts are still closed. ➤ L in 50P column indicates that 50M element is dropped out (50L is now the only overcurrent element picked up). ➤ 3 in 67N column indicates Zone 3 instantaneous overcurrent element is picked up. ➤ * in A1 Outputs column indicates that this contact is closed. If you examine the logic masks at the end of the event report, you can see the 67N3 element pickup is masked for this contact. ➤ * in 52A Inputs column indicates breaker auxiliary contacts are still closed.
33–34	<ul style="list-style-type: none"> ➤ Period in 50P column indicates that phase current is below 50L setting threshold. ➤ Period in the 67N column indicates dropout of all 67N elements. ➤ * in 52A Inputs column indicates breaker auxiliary contacts are still closed. ➤ Period in A1 Outputs column indicates that all Zone 3 elements have dropped out.

No trip occurred at Breaker 1, because the reverse Zone 3 67N3 element did not stay picked up for 60 cycles.

Switch-On-Fault Example

NOTE: As a result of the operator (or SCADA) manually closing the line breaker, the 79 functions of the relay are blocked for 79RS time after the 52A input was energized. This feature permits the operator (or SCADA) to retain control.

Example Event Report 4 shows an example of Breaker 1 closing into a bolted three-phase fault during a manual line test. This type of fault often occurs when maintenance grounds are left on a transmission line. Note that Breaker 2 is open when Breaker 1 closes. Thus, Breaker 1 is testing the line on a radial basis. In this case, the protection at Breaker 1 has no coordination requirements except to remove the SOTF logic a fixed time after breaker closure.

The 52A Inputs column is the primary indicator that the relay operated for a switch-onto-fault condition. Note that the 52A input was deasserted prior to the relay detecting fault current. This indicates that Breaker 1 was open and then closed into a fault.

Example Event Report 4

Example 230 kV Line Date: 1/19/91 Time: 09:48:17.491

FID=SEL-121G-R401-V656mptr12syzz-D901227

IPOL	IR	IA	IB	IC	Voltages (kV)			Relays Outputs			Inputs
					VA	VB	VC	52265L	TCAAAA	DPBD5E	
0	-4	0	0	0	133.7	-60.5	-72.6	
0	0	0	0	0	-7.4	119.1	-111.6	
0	4	0	0	0	-133.7	60.5	72.6	
0	0	0	0	0	7.4	-119.1	111.6	
0	-4	0	0	0	133.7	-60.4	-72.6	
0	0	0	0	0	-7.4	119.0	-111.6	
0	4	0	0	0	-133.7	60.4	72.6	
0	0	0	0	0	7.5	-119.0	111.7	
0	-4	0	0	0	133.6	-60.4	-72.7	
0	0	0	0	0	-7.5	119.0	-111.6	
0	4	0	0	0	-133.6	60.4	72.7	
0	0	0	0	0	7.5	-119.0	111.6	
0	-4	0	0	0	133.4	-59.4	-73.5	
0	-2	286	9	-296	-8.8	112.4	-103.7	L.....	*
0	18	321	950	-1262	-99.3	29.3	69.7	M.....	*
0	-7	-2290	626	1658	3.7	-62.9	59.2	M4.....	*.....	*
0	-38	-35	-3156	3165	36.7	-0.4	-36.4	H1.....	*.....	*
0	22	4505	-1457	-3017	1.6	11.2	-12.9	H1.....	*.....	*
0	46	-749	4631	-3860	-4.5	0.3	4.3	H1.....	*.....	*
-3	-29	-5040	1759	3247	-0.3	-1.4	1.8	H1.....	*.....	*
3	-49	834	-4810	3958	0.5	-0.1	-0.6	H1.....	*.....	*
3	31	5109	-1806	-3278	0.1	0.1	-0.3	H1.....	*.....	*
-3	49	-840	4839	-3967	0.0	0.0	0.1	H1.....	*.....	*
0	-31	-5122	1809	3281	0.0	0.0	0.0	H1.....	*.....	*
0	-49	843	-4842	3967	0.3	-1.0	0.8	H1.....	*.....	*
0	31	4848	-1746	-3071	1.3	6.7	-7.9	H1.....	*.....	*
0	35	-1240	3929	-2671	-34.3	31.0	3.1	H1.....	*.....	*
0	-15	-2832	1145	1674	3.8	-56.3	52.2	H1.....	*.....	*
0	-15	906	-1696	780	96.8	-59.9	-36.5	M1.....	*.....	*
0	-2	617	-346	-274	-9.3	107.8	-98.5	M2.....	*.....	*
0	7	-98	208	-104	-129.0	59.9	68.5	M.....	*.....	
0	4	-82	50	35	8.1	-117.8	109.7	*	
0	-7	9	-25	9	133.1	-60.0	-72.4	*	
0	-2	9	-6	-3	-7.9	119.0	-111.2	*	
0	7	0	3	0	-133.6	60.2	72.9	*	
0	0	0	0	0	7.8	-119.2	111.4	*	
0	-4	0	0	0	133.6	-60.2	-73.0	*	
0	0	0	0	0	-7.8	119.3	-111.4	*	
0	4	0	0	0	-133.6	60.2	73.0	*	
0	0	0	0	0	7.8	-119.3	111.4	*	
0	-4	0	0	0	133.6	-60.2	-73.1	*	
0	0	0	0	0	-7.9	119.4	-111.3	*	
0	4	0	0	0	-133.6	60.0	73.1	*	
0	2	3	0	0	7.9	-119.4	111.4	*	

Event : 1ABC Location : 0.04 mi 0.00 ohms sec
Duration: 3.75 Flt Current: 5148.5

```
R1 =8.56   X1 =77.77   R0 =35.12   X0 =236.96   LL =100.00
CTR =200.00 PTR =2000.00 MTA =83.72   LOCAT=Y
790I1=40.00 790I2=60.00 790I3=80.00 79RS =240.00
Z1% =80.00 Z2% =120.00 Z3% =120.00
Z1DP =0.00 Z2DP =20.00 Z3DP =60.00
50L =275.00 50M =500.00 50MFD=20.00 50H =3420.00
51NP =230.00 51NTD=4.00 51NC =3 51NTC=Y
50N1P=835.00 50N2P=276.00 50N3P=282.00
Z1DG =0.00 Z2DG =30.00 Z3DG =60.00 TDUR =9.00
52BT =20.00 ZONE3=R 32OE =Y 32VE =N 32IE =N
OSB1 =Y OSB2 =Y OSB3 =Y OSBT =30.00 LOPE =Y
TIME1=5 TIME2=0 AUTO =2 RINGS=7
```

Logic settings:

MTU	MPT	MTB	MTO	MA1	MA2	MA3	MA4	MRI	MRC
80	00	00	D4	20	00	00	08	00	E4
C4	00	00	E6	11	00	00	00	44	80

4.18 | Event Reporting
Example Event Reports

C8 00 00 00 00 01 20 00 00 C8
 33 00 00 00 00 00 00 00 00 33

This excerpt from Example Event Report 4 shows the first 17 rows of data the relay recorded.

IPOL	Currents (amps)				Voltages (kV)			Relays Outputs			Inputs		
	IR	IA	IB	IC	VA	VB	VC	52265L TCAAAAA DPBD5E			A	Quarter	Cycle
								011710	PL1234L	TTTC2T			
0	-4	0	0	0	133.7	-60.5	-72.6	1	
0	0	0	0	0	-7.4	119.1	-111.6	2	
0	4	0	0	0	-133.7	60.5	72.6	3	
0	0	0	0	0	7.4	-119.1	111.6	4	
0	-4	0	0	0	133.7	-60.4	-72.6	5	
0	0	0	0	0	-7.4	119.0	-111.6	6	
0	4	0	0	0	-133.7	60.4	72.6	7	
0	0	0	0	0	7.5	-119.0	111.7	8	
0	-4	0	0	0	133.6	-60.4	-72.7	9	
0	0	0	0	0	-7.5	119.0	-111.6	10	
0	4	0	0	0	-133.6	60.4	72.7	11	
0	0	0	0	0	7.5	-119.0	111.6	12	
0	-4	0	0	0	133.4	-59.4	-73.5	13	
0	-2	286	9	-296	-8.8	112.4	-103.7	L.....	*.*	14	
0	18	321	950	-1262	-99.3	29.3	69.7	M.....	*.*	15	
0	-7	-2290	626	1658	3.7	-62.9	59.2	M4.....	*.*	*.*	16	
0	-38	-35	-3156	3165	36.7	-0.4	-36.4	H1.....	*.*	*.*	17	

Quarter Cycle	Event Report Shows:
1–13	Prefault Conditions: <ul style="list-style-type: none"> ➤ No current in any current column indicates an open breaker. ➤ No protective relay elements are picked up. ➤ Period in 52A Inputs column verifies that breaker was open.
14	Breaker closure and fault inception: <ul style="list-style-type: none"> ➤ L in 50P column indicates fault current reached 50L element pickup threshold. ➤ * in 52A Inputs column indicates breaker closure (as does the current in the IA, IB, and IC current columns).
15	<ul style="list-style-type: none"> ➤ M in 50P column indicates fault current reached 50M element pickup threshold. ➤ * in 52A Inputs column verifies breaker closure (as does load and fault current flow).
16	<ul style="list-style-type: none"> ➤ 4 in 213 column indicates pickup of the Zone 4 three-phase distance element. ➤ * in TP column indicates TRIP output contact assertion. Trip was initiated by the 4ABC element in the MTO logic. TRIP contacts remain closed for the duration set by the TDUR timer. This contact remains closed for the remainder of this event report. ➤ * in 52A Inputs column verifies that the breaker was still closed.
17	<ul style="list-style-type: none"> ➤ Fault current reached 50H pickup threshold, as shown by H in 50P column. ➤ 1 in 213 column indicates pickup of the Zone 1 three-phase distance element. ➤ * in TP column indicates TRIP output contacts are closed. ➤ * in 52A Inputs column verifies breaker closure.

Rows 14 –16 of the event report show that a trip signal was initiated 0.75 cycles after the line breaker closed into the fault.

Firmware Identification

The relay provides a means of interpreting Firmware Identification Data (FID). The FID string is included near the top of each full-length event report. The string format is as follows:

$$\text{FID} = [\text{PN}] - \text{R}[\text{RN}] - \text{V}[\text{VS}] - \text{D}[\text{RD}] - \text{E}[\text{ER}],$$

Where:

[PN] = Product Name (e.g.: SEL-221G)

[RN] = Revision Number (e.g.: 403)

[VS] = Version Specifications (e.g.: 656mpacllsy52)

[RD] = Release Date (e.g.: YYMMDD=901227)

[ER] = Version Specification: EEROM

For the SEL-121G Relay family, version specifications are as follows:

$$\text{V}[\text{VS}] = \text{V}[\text{ABCDEFHIJKLMNOP}]$$

Option	Specifier	Specifier Meaning	Option Description
A	5, 6	50 Hz, 60 Hz	Power System Frequency
B	1, 5	1 A, 5 A	Nominal Amps per Phase
C	1, 6	120 V, 67 V	Nominal Volts per Phase
D	m, k	miles, kilometers	Fault Locator Distance Units
E	p, n	positive, negative	Phase-Sequence of Power System
F	a, t	all, trip only	Zones Reported on Target LEDs
G	c, r	cumulative, recent	Target LED Update Logic
H	1, 2	1.5, 2.0	Zone 4 Size = [H] x Zone 3
I	1, 2	Zone 1, Zone 2	Zone with Carrier Coordinating Timer
J	s, m	standard, modified	Command Access Level
K	y, n	yes, no	PT Input Triggers Event Report
L	Z, 5	Z3X, 52AT	Relay Word Bit is Z3X or 52AT
M	f, r	Forward, Reverse	Zone 4 Direction
N	s, d	Standard, Dropout	TDUR Timer Implementation
O	1, 2	rev. 1, rev. 4	Main Board Configuration

EEROM version specifications are interpreted as follows:

$$\text{E}[\text{ER}] = \text{E}[\text{Z}]$$

Option	Specifier	Specifier Meaning	Option Description
Z	1, 2	1 stop bit, 2 stop bits	Communications Protocol Stop Bits

Please contact Schweitzer Engineering Laboratories, Inc. for more information concerning available versions of the SEL-121G and SEL-221G relays. [*Section 1: Introduction*](#) includes a description of all available configurations. Version specifications provided previously are not intended for ordering purposes, but to simplify identification of software installed in a relay.

Section 5

Applications

Schemes Involving Communications

The relay is ideal for communications-based schemes. Dedicated trip masks allow selection of relay elements to perform specific functions when external conditions are met. In addition to the communication scheme logic, the relay provides time-stepped backup protection without external wiring modifications or dedicated input contacts.

Event reporting and fault-locating features provide an important system performance analysis tool. The event report shows voltages, currents, relay elements, inputs and outputs. This information simplifies scheme performance evaluation.

Replacement of Outdated Protective Relays

The relay is an ideal replacement for aging or obsolete electromechanical relays. If protective relays are to be upgraded at one terminal only, it is important that relays have measuring principles compatible with surrounding terminals. The relay meets this requirement by using the widely accepted compensator distance measuring principles for phase distance elements. It also includes residual instantaneous and time-overcurrent elements. The residual time-overcurrent element curve shape is selectable from four curve families to permit the best possible coordination with residual time-overcurrent protection at other line terminals. The relay also provides three means of polarizing the residual overcurrent elements to match the polarizing method with the rest of the system.

Compact size and simple field wiring make replacing electromechanical relays with this relay especially convenient in crowded substations. Both horizontal and vertical mounting configurations are available.

Event reporting and fault-locating features economically provide valuable engineering and operating information, eliminating the need for event recorders and oscilloscopes in most applications. A negligible instrument transformer burden makes the SEL-221G relay an attractive alternative for overburdened current and potential transformers.

Time-Step Relaying

This relay provides three zones of time-step protection with separate timers for phase and ground faults in Zones 1, 2, and 3. In such applications, this relay is the only instrument necessary for primary relaying. Please note that while a communications scheme may not be required, the standard logic provided by the relay allows you to expand the time-stepped protective scheme to a communications-aided scheme simply by adding communications equipment. Exhaustive self-testing and communications capabilities reduce dependence on local and remote backup schemes.

Choice of Line Impedances

For optimal performance, the relay requires accurate values of positive- and zero-sequence impedances for the protected transmission line. The relay uses positive-sequence impedance settings in establishing mho distance element reaches and calculating fault location. Similarly, the relay uses zero-sequence impedances in conjunction with positive-sequence impedances to calculate line-ground fault location.

You can obtain values for the positive- and zero-sequence line impedances from transmission line modeling programs, existing fault studies, or hand calculations. Only the positive- and zero-sequence impedances for the protected transmission line are entered as relay settings R1, X1, R0, and X0. Values entered for R1 and X1 represent the positive-sequence resistance and reactance for the entire transmission line. The R0 value represents transmission line zero-sequence resistance; the X0 value represents transmission line zero-sequence reactance.

Choosing Current and Potential Transformer Ratios

Current transformer ratio (CTR) selection for line protection is often based on the transmission line current carrying capability. CTR selections also determine the magnitude of secondary fault current presented to the relay.

It is desirable to keep secondary CT currents between 50 and 100 A during maximum short-circuit conditions. This reduces the likelihood of CT saturation and allows the current transformer to deliver a reliable secondary representation of the primary current during a fault condition.

The potential transformer ratio (PTR) setting should match the primary voltage ratio (l-n) to 66.4 V_{l-n}.

Choice of Maximum Torque Angle (MTA)

The maximum torque angle (selected in the setting procedure) is common for all protective elements. A typical maximum torque angle setting is at or less than the positive-sequence transmission line angle.

Selecting Distance Element Reaches

The following subsections refer to the system shown in [Figure 5.1](#). Percentage reaches listed are provided only as guidelines. Actual distance element reaches for your application may differ from these figures. For every installation, consult a fault study to determine optimum relay settings.




Figure 5.1 System Single Line Diagram

Choice of Zone 1 Distance Element Reach

The Zone 1 reach is typically set short of the forward remote terminal. Thus, the Zone 1 elements can provide instantaneous protection for phase-phase and three-phase faults in the first 80–90 percent of the transmission line, independently from the communication scheme selected. Please note that the Z1DP timer introduces a settable delay in the Zone 1 distance element outputs. The remainder of the line is protected by the overreaching Zone 2 elements. While the percent error of the impedance element reach is less than five percent, errors in the CT and PT ratios, modeled transmission line data, and fault study data do not permit Zone 1 element settings of 100 percent.

Choice of Zone 2 Distance Element Reach

The Zone 2 elements provide protection for the transmission line portion not included in Zone 1. These elements also serve as backup protection for close-in faults on the next line section. In three-terminal applications this relates to detecting faults at both remote terminals. This example uses a two-terminal line application. To ensure detection of end-of-line faults where parallel source infeeds may increase the apparent impedance to the fault location, set the Zone 2 elements to reach at least 50 percent into the next shortest line section. Zone 2 elements should never extend past the Zone 1 reach of the next line terminal. This prevents race conditions between Zone 2 time-delayed elements of the two line terminals. Typical settings for the Zone 2 phase distance elements are 120 – 130 percent of the protected line. When Zone 2 reach settings exceed 150 percent of the protected line impedance, you must address current reversal conditions for sequentially cleared faults on parallel lines if the relay is applied to a communications-aided tripping scheme.

Choice of Zone 3 Distance Element Reach

Time-delayed outputs of the Zone 3 elements can serve as remote backup for faults behind the relay location.

In DCB applications, the Zone 3 element reach setting must be long enough to detect any fault sensed by the overreaching Zone 2 elements at the remote terminal. Typically, Zone 3 element reaches are set to match the reach setting of remote terminal Zone 2 elements.

When set to reach forward, the time-delayed Zone 3 elements provide remote backup for faults at remote buses two line sections from the local terminal.

Choice of Zone 2 and Zone 3 Time Delay Settings

Time-delayed Zone 2 and Zone 3 elements provide time-step backup protection. Time delay selections must coordinate with protection at the remote terminal and local bus. Instantaneous and time-delayed outputs of the phase distance and residual overcurrent elements are available in the Relay Word. You can include the time-delayed output of the Zone 2 and 3 elements in the Mask for Trip Unconditional (MTU). You can include the instantaneous Zone 2 elements in the Mask for Permissive Trip (MPT), the Mask for Trip Block (MTB), or the Mask for Trip while breaker Open (MTO), depending on the scheme selected. A typical setting for Zone 2 phase time delay is 20 to 30 cycles. This allows time for remote Zone 1 elements to pick up plus breaker operating time. Settings for the Zone 2 residual overcurrent element depend on the strength of zero-sequence current sources behind the relay location.

The Zone 3 time delay must coordinate with the Zone 2 protection at the local bus when Zone 3 is reversed. It must also coordinate with the remote Zone 2 elements when Zone 3 is forward reaching. A typical Zone 3 phase distance time delay setting is 60 cycles.

Choice of Phase Overcurrent Pickup Settings

The relay has three phase overcurrent element levels: low, medium, and high set. The following descriptions explain the use of each phase overcurrent element in the relay logic.

50L, Low Set Phase Overcurrent Elements

The 50L element provides fault detector supervision of the mho distance elements and must pick up for all fault conditions where a distance element is expected to operate. The ideal setting for the 50L element is above load but below minimum fault duty. For instance, when Zone 3 is reversed, the 50L element must pick up for minimum fault duty on either side of the relay. Although it is not ideal, you can set 50L below load to permit distance element operation for end-of-line faults with magnitudes below load.

For phase-phase faults, at least one current magnitude must exceed the 50L pickup threshold before the phase-phase distance elements are allowed to output. For three-phase faults, the current magnitude in all three phases must exceed the 50L pickup threshold before the three-phase distance elements give an output.

The 50L elements are also used in the trip unlatch logic (see [Section 2: Specifications](#)). Before the TRIP output can open, the trip condition must vanish and the current in all phases must drop below the 50L and 50NL element thresholds. This ensures that the TRIP output contact does not attempt to interrupt full trip coil current for the full duration of the fault.

50M, Medium Set Phase Overcurrent Element

The 50M element is a conditional in the loss-of-potential (LOP) logic for three blown PT fuses. The 50M element provides non-directional phase overcurrent protection after an LOP condition is declared. When enabled, an LOP condition blocks mho distance elements from operating because of the loss of a sound voltage reference for these elements. To protect the transmission line locally until the blown potential fuse condition can be remedied, non-directional time-delayed phase overcurrent protection is enabled if the 50MF bit in the Relay Word is masked to trip.

The relay requires that phase current exceed the 50M pickup threshold to ensure that three-phase loss-of-potential conditions are not confused with fault conditions. Once an LOP condition is declared, it remains latched until balanced three-phase voltages are restored. The following LOP logic equation shows the role of the 50M element in the SET LOP logic:

$$\text{SET LOP} = \text{NOT}(47P) * \text{NOT}(50M)$$

where the 47P element picks up for the positive-sequence voltage greater than 14 V secondary.

The 50M element setting must be above load, but below the minimum phase-phase or three-phase fault duty for a protected transmission line where the positive-sequence voltage is below 14 V of V1. If the maximum load is above minimum phase fault duty, the 50M setting must still be below the fault duty where the positive-sequence voltage is reduced to 14 V of V1. The below fault duty setting requirement prevents setting LOP during a fault. In most applications, a fault location close enough to reduce the positive-sequence voltage below the 47P setting of 14 V also brings a large magnitude of current from the local terminal. Thus, the 50M setting can still be above load current.

To allow time coordination with the surrounding line terminals, 50M element pickup after a loss-of-potential condition starts the definite timer 50MFD. Once 50MFD expires, the 50MF bit in the Relay Word is set and may be used for tripping the local breaker. The 50MF bit is typically included in the MTU logic mask.

50H, High Set Phase Overcurrent Element

The 50H element is intended for use as a high-set, non-directional phase overcurrent detector in the switch-onto-fault logic (see [Switch-On-to-Fault Logic \(MTO Logic Mask\)](#)). If closing a line breaker into a close-in three-phase bolted fault where line-side potential transformers are used, the level of polarizing voltage required by the three-phase distance elements is never established. In this situation, the distance elements are blocked from operating. The 50H element is provided to prevent such a failure to trip the line breaker. The 50H element measures current magnitude in each phase with no dependence on polarizing voltages. This element is non-directional and should be used only in the switch-onto-fault logic mask (MTO) where the line breaker is testing the line on a radial basis. However, if fault duty in front of the line terminal is much greater than behind it, the 50H element can also be used in the unconditional trip logic mask (MTU) to provide rapid clearance of close-in faults.

Typical 50H settings are one-half to one-third of three-phase fault duty at the local bus.

Choice of Residual Time-Overcurrent Pickup Setting

Consult a fault study to select the residual time-overcurrent element pickup setting. The residual time-overcurrent element provides current-dependent, time-delayed clearance of faults along the protected line and serves as backup protection for remote terminals. Because the measure of residual current varies with system switching configuration, fault location, and fault resistance, a complete fault study is necessary to determine the minimum pickup setting, appropriate time dial, and curve characteristic. When enabled as directional, consider only faults in front of the line terminal for coordinating purposes.

Choice of Zones 1, 2, and 3 Residual Overcurrent Pickup Settings

The relay provides three separate instantaneous residual overcurrent elements: 50N1P, 50N2P, and 50N3P. You can make these overcurrent elements directional by selecting a residual polarizing method: 32QE, 32VE, or 32IE. Zones 1, 2, and 3 have an associated timer to provide time-stepped protection.

The Zone 1 residual overcurrent element is always forward looking. The pickup setting for this element should always be greater than the maximum end-of-line (EOL) ground fault current level. A typical setting for the 50N1P element is 120% of this maximum EOL single-line-to-ground (SLG) fault duty.

The Zone 2 residual overcurrent element is always forward looking. This element provides protection for the transmission line portion the Zone 1 element does not protect and time-delayed backup protection for close-in faults on the next line section(s). A typical setting for the 50N2P element is 50 – 60% of the minimum EOL SLG fault duty to account for fault resistance and fault study modeling errors.

The Zone 3 residual overcurrent element may be either forward or reverse looking, as directed by the ZONE3 setting. Whether Zone 3 is forward or reverse, the time-delayed output of the 67N3 element can provide backup protection for local or remote buses. The pickup setting requirement for the 50N3P element depends on the direction of Zone 3. If Zone 3 is reversed, the 67N3 element must (at a minimum) pick up for all SLG faults detected by the remote terminal Zone 2 residual elements. If Zone 3 is forward, the 67N3 element must pick up for SLG faults at the farthest remote bus that the Zone 3 element is expected to protect.

Switch-Onto-Fault Logic (MTO Logic Mask)

The relay has switch-onto-fault logic for use during testing. This logic allows you to enable very sensitive overreaching elements for a short duration after line breaker closure. Switch-onto-fault logic permits instantaneous line breaker tripping for end-of-line faults that would normally be cleared in Zone 2 time. The following list specifies the four tripping masks and differences in their qualifying logic:

- MTU ≡ Mask for Trip Unconditional (no logic qualifiers)
- MPT ≡ Mask for trip with the Permissive Trip input asserted
- MTB ≡ Mask for Trip with the Block trip input not asserted
- MTO ≡ Mask for Trip while the 52BT element is asserted

Elements selected in the MTO mask are typically non-time delay overreaching elements. The 52BT time-delay setting dictates the interval during which switch-on-fault logic is enabled. The 52BT element may be considered an inverted time-delayed follower of the 52A input. When the 52A input changes from the asserted (breaker closed) to deasserted state (breaker open), the 52BT element remains low for 52BT time. After the 52BT timer expires, the 52BT element changes its logic state from 0 to 1 and enables the switch-on-fault logic. When the breaker is closed (from an open state) to test the line, 52BT remains high for 52BT time. Thus, for 52BT time after breaker closure, assertion of any element selected in the MTO logic mask closes the TRIP output contacts. This logic provides Switch-On-Fault (SOTF) protection.

Figure 5.2 illustrates the timing relationship of the 52A input and 52BT element.




Figure 5.2 52A Input and 52BT Timing Diagram

MTO logic is enabled during the time period shown for Regions 1 and 2. During Region 1, the MTO logic is enabled to protect the open line breaker. For line breaker tank faults, the relay can issue the trip signal required for breaker failure schemes. Any time delay associated with the circuit breaker auxiliary contact opening occurs during the time shown in Region 1.

Region 2 shows the time period where MTO logic is performing true switch-on-fault protection for the transmission line. The 52BT element serves as a permissive signal for very sensitive elements to trip the line breaker during the 52BT time interval. Tripping occurs after the line breaker is closed. Normally, these sensitive elements are used only for tripping with a qualifying permissive signal from the remote line end (POTT schemes), during the absence of a block trip signal (DCB schemes), or are time delayed to provide coordination.

For example, the circuit shown in *Figure 5.3* has a phase-phase fault close to Breaker 2. Suppose that Breaker 1 is the preferred source for testing the line (Breaker 2 is to remain open until Breaker 1 energizes the line). If standard time-stepped distance protection is employed without SOTF protection, the fault would have to be cleared in Zone 2 time. Using the relay MTO logic, the non-time delayed Zone 2 phase elements detect the fault and instantly issue a trip signal. This reduces the amount of time the transmission line is exposed to the fault energy. There is no possibility of overreaching the remote terminal with the instantaneous Zone 2 element, because Breaker 2 is open while the Breaker 1 MTO logic is enabled (see *Figure 5.4*). If the fault is not present when Breaker 1 tests the line, the MTO logic of Breaker 1 resets after 52BT

time. Then Breaker 2 can synchronize and close. This emphasizes the need to limit the time during which MTO mask elements can trip the breaker. Remember: the 52BT time setting must be long enough for the sensitive elements in the MTO logic mask to assert, yet shorter than the time allowed for Breaker 2 to parallel.

When setting the 52BT timer, you must consider the three-shot reclosing feature. The 52BT timer start is keyed from the 52A input state change, whereas each open interval timer is started when the breaker has opened and the trip output contacts open. Because the open interval timer can start after the 52BT timer, a coincidence state is possible. In this state, the 52BT and open interval timers expire. As a result, the 52BT timer that eliminates switch-onto-fault tripping logic for that reclosing shot is reset.

If switch-onto-fault protection is required for all reclose shots, remember to set the 52BT time interval equal to or shorter than the first reclose interval. If you want to cancel switch-onto-fault logic for a particular shot, set the 52BT timer longer than the open interval timer by the maximum expected breaker opening time. Typical 52BT settings are 15 – 20 cycles, where high-speed reclosing is not required.




Figure 5.3 Faulted Line With All Sources In




Figure 5.4 Faulted Line With Breaker 2 Open

Selection of Residual Overcurrent Relay Polarization

The relay offers three different methods of polarizing the residual overcurrent elements:

- Negative-sequence voltage (V_2) and negative-sequence current (I_2)
- Zero-sequence voltage (V_0) with measured residual current (I_R)
- Zero-sequence current from external source (I_{pol}) with measured residual current (I_R)

Methods 2 and 3 may be combined to achieve a fourth dual polarized zero-sequence characteristic.

The three methods use distinctly separate measurands, each with their own benefits.

Negative-Sequence Polarization

1. Where strong zero-sequence mutual coupling exists between adjacent transmission lines, consider the negative-sequence method if sufficient polarizing quantities exist.
2. If there is a possibility that one end of a transmission line is a strong positive- and negative-sequence source but a weak zero-sequence source while the other end of the same line is a weak positive- and negative-sequence source but a strong zero-sequence source, consider negative-sequence again.

One example of such an arrangement is a three-winding autotransformer at a weak positive-sequence bus with the other end of the same line connected to a strong generation source. When a parallel circuit has a double-line-to ground fault in a double circuit line configuration, the strong positive- and negative-sequence source end of the healthy line can issue a permissive signal from its phase distance relaying. Meanwhile, the other end of the healthy line issues a permissive signal from its ground-relaying elements polarized from zero sequence. This scenario is only of concern where the ground overcurrent relaying is polarized from zero-sequence quantities.

Zero-Sequence Voltage Polarization

If protection at one line terminal is being upgraded without upgrading the remote terminal, it is desirable to match the polarization methods at both ends of the transmission line. If the existing ground overcurrent polarization method is zero-sequence and will remain zero-sequence for at least one terminal, retain zero sequence. This assumes adequate levels of polarizing quantities exist at all terminals.

Zero-sequence voltage polarization is a viable method where adequate levels of residual voltage may be measured for all ground faults to give proper discrimination and the conditions outlined for negative-sequence polarization methods are not valid for your application.

Zero-Sequence Current Polarization

If measured zero-sequence voltage or negative-sequence quantities are insufficient to polarize residual elements for ground faults, polarization can be achieved with the residual current from an external source. Typical external sources are the neutral of a local transformer connected in grounded-wye, the tertiary winding of a grounded transformer, or the neutral current from a grounding transformer.

Before selecting zero-sequence current polarization, examine fault studies to see that the residual current in the polarizing source always flows in the proper direction. This requirement ensures that, for forward faults, the external current source is in the proper phase orientation with the measured residual current of the faulted line.

Loss-of-Potential Logic

Fuses or molded case circuit breakers often protect the secondary windings of the power system potential transformers. A failure of one or more fuses or molded case circuit breaker operation results in a loss-of-potential of

polarizing inputs to the relay. Loss of one or more phase voltages disables relay distance elements and directional decisions; it can no longer discriminate fault direction properly.

While loss-of-potential to the relay is unavoidable, detection of this condition is desirable. Once a true loss-of-potential condition is detected, you can elect to block distance element operation and issue an alarm. To do so, set LOPE = Y in the relay settings. Set the relay to alarm by programming the LOP bit in the Relay Word to an output relay contact. The relay discriminates between faults (which may reduce the voltage magnitude(s) to nearly zero) and loss-of-potential conditions. The following equation shows the loss-of-potential (LOP) detection logic for the relay:

$$\begin{aligned} \text{SET LOP} = & [47NL * \text{NOT}(50NL)] : \text{Detects the presence of zero-sequence} \\ & \text{voltage in the absence of zero-sequence current} \\ & + [\text{NOT}(47P) * \text{NOT}(50M)] : \text{Detects the absence of positive-} \\ & \text{sequence voltage without measuring} \\ & \text{current above the 50M setting} \end{aligned}$$

where:

- 47NL ≡ Low set zero-sequence overvoltage detector
- 50NL ≡ Low set zero-sequence overcurrent detector
- 47P ≡ Low set positive-sequence overvoltage detector
- 50M ≡ Medium set phase overcurrent element

For one or more blown PT fuses, the relay declares a loss-of-potential condition when the measured zero-sequence voltage exceeds 14 V of V0 and measured zero-sequence current is below 0.083 A secondary (for $51NP<3.15$ A secondary). For three blown PT fuses, the relay declares an LOP condition when the measured positive-sequence voltage is below 14 V of V1 and the medium set phase overcurrent detector (50M) is not picked up.

Installations Employing Potential Transfer Switches

NOTE: The 52A input contact on the rear panel must be deasserted when the operator depresses the potential transfer switch.

Potential transfer switches temporarily remove the polarizing potentials from the relay when a substation operator transfers the potential source from one bus to another. Because it is undesirable to parallel secondary windings of potential transformers from separate sources, this occurrence is inherent to potential transfer switch installations. This temporary removal of polarizing voltages coupled with load currents well above the 50L fault detector threshold can result in a race between the three-phase loss-of-potential pickup logic and the three-phase distance element pickup. Three-phase LOP logic is included to address the loss of three secondary potential fuses, not potential transfer switch applications.

Figure 5.5 shows the solution developed to address this race condition. A description of the circuit follows the figure.




Figure 5.5 Potential Transfer Switch Logic

The following two scenarios illustrate Trip Suspicion logic:

- Scenario 1) A trip issued by the relay for an actual fault on the transmission line.
- Scenario 2) A trip resulting from the temporary loss-of-potential created by an operator moving a bus potential transfer switch from one bus position to another.

Scenario 1: Actual Transmission Line Fault

When the relay issues a trip with the 52A input energized, the five-second timer (T1) is not loaded because of relay-initiated trip cancellation. Thus, this new logic does not interfere with the normal relay trip operation.

Scenario 2: Potential Transfer Operation

When the relay senses the falling edge of a 52A input without a trip issued by the relay in the previous 255 quarter cycles, the T1 timer is loaded and begins to decrement. The T1 timer allows the operator five seconds after depressing the potential transfer switch to transfer the relay potentials from one bus to another. Remember that the loss-of-potential condition only occurs when the potential transfer switch is twisted left or right while the switch is fully depressed. Rather than try to detect when potentials are lost, the relay identifies a window of possible potential loss using the deasserted 52A input with no trip condition present. This prevents any possible race conditions between voltage detect logic and distance element assertion. If the relay issues a trip during this five-second window, tripping is restrained for three cycles. This three-cycle time period is greater than the time required for the three-phase LOP logic to assert or for the polarizing potential magnitude of the second bus to stabilize.

Trip suspicion (TS) logic output is included in the Boolean logic for the TRIP output. The new close TRIP output contact logic is as follows:

$$\text{close TRIP contact} \equiv [(R * \text{MTU}) + (R * \text{MPT} * \text{PT}) + (R * \text{MTB} * \text{NOT BT}) + (R * \text{MTO} * 52\text{BT})] * \text{NOT(TS)}$$

The Trip Suspicion logic adds the critical level of security necessary for bus arrangements using a potential transfer switch. This logic does not depend upon the speed of the actual potential transfer operation, but it does require that the procedure last less than five seconds.

This potential transfer switch logic presents an additional benefit if an operator inadvertently transfers potentials to a deenergized or “dead” bus. When the relay is transferred to a dead bus, assuming LOPE = Y and the LOP bit in the Relay Word is masked to an output relay contact, an alarm condition results and the TRIP outputs do not close. If the relay is connected to an alarm, output contact closure alerts the operator of the dead-bus condition rather than tripping the relay.

230 kV Setting Example for Time-Stepped Scheme

Purpose

This example shows the steps for setting the relay at Breaker 3 to protect Line 2 in [Figure 5.6](#) between Buses B and C. The basic criteria for protecting this line appear below:

- Time-stepped protection scheme (no communications equipment)
- Zone 1 protection is instantaneous
- Zones 2 and 3 serve as time-step backup
- The maximum expected load is less than 450 A.




Figure 5.6 230 kV Setting Example System Single-Line Diagram

System Data

Nominal System Voltage : 230 kV (132.8 kV line-neutral)

Line Length : 100 miles

Line Impedances:

Positive-sequence : $Z_1 = 78.24 \angle 83.72^\circ$ (primary Ω)
 $= 8.56 + j77.77$ (primary Ω)

Zero-sequence : $Z_0 = 239.55 \angle 81.56^\circ$ (primary Ω)
 $= 35.12 + j236.96$ (primary Ω)

Source Impedances:

Source S = Source R : $Z_{1S} = Z_{1R} = 29.34 \angle 83.72^\circ$ (primary Ω)
 $: Z_{0S} = Z_{0R} = 3 \times Z_{1S}$

Current Transformer : 1200/5 multi-ratio

Potential Transformer Ratio : 2000:1

Relay Settings

Fault voltages and currents in this example were derived from a fault study of the system in [Figure 5.6](#).

Values to enter during the actual setting procedure appear in bold immediately after the = prompt in the dashed boxes.

Identifier

The relay tags each event report with a label in the identifier string. This allows you to distinguish the event report as one generated for a specific breaker and substation. Typical identifiers include an abbreviation of the substation name and line terminal. Where an SEL-DTA is used in conjunction with the relay, the identifier string is displayed on the screen. This feature helps in recognizing the associated line terminal when multiple SEL-DTAs are stacked behind an operator console.

ID = BUS B, 230 KV LINE 2

Setting Limit Check

The identifier string is limited to 39 characters. Characters entered after the 39th character are ignored.

Other Settings Affected

None.

R1, X1, R0, X0, and Line Length (LL)

The positive- and zero-sequence primary impedance values should match those calculated for Line 2. The line length should also match the distance between Bus B and Bus C.

R1 = 8.56
X1 = 77.77
R0 = 35.12
X0 = 236.96
LL = 100.00

Setting Limit Check

The primary limit check performed while entering the relay settings allows primary values of R1, X1, R0, and X0 in the range of 0 – 9999 Ω and a line length between 0.1 and 999 miles.

There are no secondary setting limits for the impedance or line length settings. However, you should perform a cursory check to be sure the minimum Zone 1, Zone 2, or Zone 3 secondary reaches at MTA are not below the minimum setting of 0.125 Ω secondary or above the maximum setting limit of 64 Ω secondary.

Other Settings Affected

Z1%, Z2%, Z3%

Current and Potential Transformer Ratio Selection

The current transformer ratio must be selected from those available in the multi-ratio current transformer. The ratio selected for this example is 1000/5 or 200:1. This ratio allows 1000 A of load to flow without exceeding 5 A of secondary current, while limiting the secondary current to below 50 A for the maximum available fault duty.

CTR = 200.00

The system voltage is 230 kV line-line or 132.8 kV line-neutral. The relay requires a nominal phase voltage of approximately 66.4 V_{l-n} or 115 V_{l-l}. The PTR selected for this example is 2000:1.

$$\text{PTR} = \frac{(230 \text{ kV})}{(115 \text{ V})} = 2000:1$$

PTR = 2000.00

Setting Limit Check

The primary limit check for the CTR and PTR settings allows you to enter values from 1 – 5000 and 1 – 10,000 respectively.

There are no secondary setting range checks for these settings.

Other Settings Affected

CTR: All overcurrent pickup settings Ratio of PTR/CTR: Z1%, Z2%, Z3%

Maximum Torque Angle (MTA)

The Maximum Torque Angle (MTA) setting should be below the positive-sequence angle of the transmission line to extend the amount of resistive coverage for the mho circles (this is also true for the expanded mho characteristics). MTA selected for this example is 83.72 degrees. Note that this value matches the positive-sequence line angle of 83.72 degrees.

MTA = 83,72

Setting Limit Check

The primary setting range check allows MTA settings from 47–90 degrees. There is no secondary check for this setting.

Other Settings Affected

Zone 1, Zone 2, and Zone 3 reach if MTA does not equal the positive-sequence transmission line angle.

Fault Locator Enable (LOCAT)

This setting allows you to enable or disable the fault locating ability of the relay. In this example, as with most applications, fault locating is desired.

LOCAT = Y

Setting Limit Check

There is no limit check for this setting. The fault locator is either enabled (Y) or disabled (N).

Other Settings Affected

None.

Reclosing Open Intervals and Reset Time (790I1, 790I2, 790I3, and 79RS)

Open interval timers control each of the three reclosing shots. The recloser must coordinate with remote reclosing schemes.

The first open interval must be longer than 52BT time (SOTF time). For this example, the first reclose attempt is 40 cycles after the TRIP condition is gone. Second and third reclose attempts are 60 and 80 cycles after the second and third TRIPs, respectively.

The reset time (79RS) must be at least as long as it takes the breaker to completely close. The 79RS timer also serves to block automatic reclosing for 79RS time period after an operator (or SCADA) closes the line breaker. This feature serves to maintain control of the line breaker with the local operator. For this example, the 79RS timer is set for 240 cycles or four seconds. For more information, please refer to [Reclose Logic on page 5.35](#).

790I1 = 40	790I2 = 60	790I3 = 80	79RS = 240
------------	------------	------------	------------

Setting Limit Check

790I1, 790I2, and 790I3 have primary limit checks of 0 to 10,000 cycles. 79RS has a primary limit check of 60 to 8,000 cycles. There is no secondary limit check for 790I1, 790I2, 790I3, or 79RS. For this example, each open interval and 79 reset timer setting lies within the relay setting limits.

Other Settings Affected

Please note that the 52BT timer setting should be less than the shortest open interval timer to ensure that the switch-onto-fault logic is enabled for each shot.

Zone 1 Reach Setting (Z1%)

The required reach for the Zone 1 three-phase and phase-phase elements is 80 percent of the positive-sequence impedance of Line 2 between Bus B and Bus C.

$$\text{Z1 Reach} = 0.80 \times 78.24 \Omega \text{ primary} @ 83.72^\circ = 62.59 \Omega \text{ primary} @ 83.72^\circ$$

The reach settings for the mho distance elements are a percentage of the positive-sequence line impedance settings along the line angle. When the MTA setting differs from the positive-sequence line angle, the relay calculates the mho circle diameter with the following equation:

$$\text{Diameter} = \frac{\text{Set Reach}}{\cos(\text{Angle of Z1} - \text{MTA})}$$

For this example, the diameter of the Zone 1 mho circle along the MTA is:

$$\begin{aligned} \text{Diameter} &= \frac{62.59 \Omega}{\cos(83.72^\circ - 83.72^\circ)} \\ &= 62.59 \Omega \text{ primary along the MTA} \end{aligned}$$

Z1% = 80.00

Setting Limit Check

The primary limit check allows Zone 1 percent reach settings of 0 – 2000 percent. The secondary setting check allows secondary reach settings of 0.125 – 64 Ω secondary along the MTA.

Calculations: PTR = 2000:1
CTR = 200:1

$$\text{Secondary Ohms} = \frac{62.59\Omega_{\text{primary}}}{10} = 6.259 \Omega \text{ secondary along the MTA}$$

The Z1% setting of 80 for this example lies within primary and secondary setting limits.

Other Settings Affected

Zone 1 must be less than Zone 2 and Zone 3. The 1ABC and Z1P bits of the Relay Word depend on the Z1% setting.

Zone 2 Reach Setting (Z2%)

The Zone 2 elements must have adequate reach to detect all phase faults along Line 2, but cannot overreach the Zone 1 elements for faults on Line 3 or Line 6. In this example, the impedances for Lines 3 and 6 are identical.

$$ZL \text{ for Line 2} = 78.24 \Omega \text{ primary} \quad Z1L \text{ for Line 3} = Z1L \text{ for Line 6} = 39.12 \Omega \text{ primary}$$

Zone 2 element settings with a reach of 120 percent of protected line impedance account for the effects of infeed. This point must be verified by using a fault study to calculate the apparent ohms at the local terminal for a fault at the remote end of the transmission line. In the example system, 120 percent is selected for the Zone 2 elements with assurance that all faults in Line 2 are detectable, even with infeed from the remote terminals.

Assuming Zone 1 reach for the line protection at Breakers 5 and 11 is set for 80 percent of the line impedances of Lines 3 and 6 respectively, verify that a Zone 2 reach of 120 percent for Breaker 3 does not overreach the Zone 1 elements at Breakers 5 and 11.

$$\begin{aligned} \text{Line 2 Impedance} + [0.8 \times \text{Line 3 Impedance}] &= 78.24 \Omega + [0.8 \times 39.12 \Omega] \\ &= 109.54 \Omega \text{ primary} \end{aligned}$$

When Zone 2 at Breaker 3 has a set reach of 120 percent, the effective reach is:

$$\text{Zone 2 @ Bkr. 3} = 1.20 \times 78.24 \Omega = 93.89 \Omega \text{ along the line angle}$$

Because $93.89 \Omega < 109.54 \Omega$, the Zone 2 setting of 120 percent at Breaker 3 does not overreach the Zone 1 protection of Lines 3 and 6. Any effect of infeed tends to increase the apparent ohms seen at Breaker 3 for faults on Lines 3 and 6.

As for the Zone 1 element, the MTA setting is the same as the positive-sequence line angle. Calculate the diameter of the Zone 2 mho circle with the following equation:

$$\text{Diameter} = \frac{\text{Set Reach}}{\cos(\text{Angle of Z1} - \text{MTA})}$$

For this example, the Zone 2 mho circle diameter along the MTA becomes:

$$\begin{aligned} \text{Diameter} &= \frac{93.89\Omega}{\cos(83.72^\circ - 83.72^\circ)} \\ &= 93.89\Omega \text{ along the MTA} \end{aligned}$$

Z2% = 120.00

Setting Limit Check

The primary limit check allows Zone 2 percent reach settings of 0 – 3200 percent with the requirement that the Zone 2 reach be equal to or greater than that of Zone 1. The secondary check allows secondary reach settings of 0.125–64 Ω secondary along the MTA.

$$\begin{array}{ll} \text{Calculations: PTR} & = 2000:1 \quad \text{PTR/CTR} = 10 \\ & \text{CTR} = 200:1 \end{array}$$

$$\text{Secondary Ohms} = \frac{93.89\Omega_{\text{primary}}}{10} = 9.389 \Omega \text{ secondary along the MTA}$$

The Z2% setting of 120 for this example lies within the secondary setting limits of the relay.

Other Settings Affected

If Zone 3 is forward, Zone 2 must be less than Zone 3. The 2ABC, Z2P, and Z2PT bits of the Relay Word depend on the Z2% setting.

Zone 3 Reach Setting (Z3%)

The reverse-looking Zone 3 elements must serve as time-delayed backup protection for faults on Lines 1 and 4. Therefore, reverse-looking Zone 3 elements must see faults along the entire length of Lines 1 and 4. Considering this requirement, the Zone 3 elements should be set for 120 percent of the apparent impedance for faults at Bus A. The impedances of Lines 1 and 4 are identical and equal to the impedance of Line 2.

Z3% = 120.00

Setting Limit Check

The primary limit check allows Zone 3 percent reach settings of 0 – 3200%, with the requirement that Zone 3 reach exceed Zone 1 reach when Zone 3 is reversed. When Zone 3 is selected as forward, the Zone 3 distance element reach must exceed that of Zone 2. The secondary check allows secondary reach settings of 0.125 – 64 Ω secondary along the MTA.

$$\begin{array}{ll} \text{Calculations: PTR} & = 2000:1 \quad \text{PTR/CTR} = 10 \\ & \text{CTR} = 200:1 \end{array}$$

$$\text{Secondary Ohms} = \frac{93.89\Omega_{\text{primary}}}{10} = 9.389 \Omega \text{ secondary along the MTA}$$

The Z3% setting of 120 for this example is within primary and secondary setting limits.

Other Settings Affected

This setting affects Zone 4 reach. Zone 4 is internally set to 1.5 x Zone 3. The 3ABC, 4ABC, Z3PT, and Z3P bits in the Relay Word depend on the Z3% setting.

Zone 1 Phase Time Delay (Z1DP)

The Z1DP timer adds a settable delay to the Zone 1 phase-phase (Z1P) and three-phase (1ABC) elements. A typical setting for this time range is zero cycles.

Z1DP = 0.00

Setting Limit Check

The primary limit check allows Zone 1 time-delay settings of 0 – 60 cycles. The Z1DP setting of 0.00 cycles lies within relay setting limits. There is no secondary limit check for this setting.

Other Settings Affected

1ABC and Z1P bits in the Relay Word.

Zone 2 Phase Time Delay (Z2DP)

The Z2DP timer adds a settable delay to the Zone 2 phase-phase and three-phase distance element instantaneous outputs. The time-delayed output of the Zone 2 phase-phase and three-phase distance elements is represented by the Z2PT bit in the Relay Word. The time selection should coordinate with the protection at Bus C. The Zone 2 phase distance delay selected in this example is 20 cycles.

Z2DP = 20.00

Setting Limit Check

The limit check allows Zone 2 time delays of 0 – 2000 cycles. The Z2DP of 20 cycles lies within the relay setting limits. There is no secondary limit check for this setting.

Other Settings Affected

Z2PT bit in the Relay Word.

Zone 3 Phase Time Delay (Z3DP)

The Z3DP timer adds a settable delay to the instantaneous outputs of the Zone 3 phase-phase (Z3P) and three-phase (3ABC) elements. The time-delayed output of the Zone 3 phase-phase and three-phase distance elements are represented by the Z3PT bit in the Relay Word. The time selection should coordinate with the Zone 2 protection at Bus B to provide time-step backup protection for Lines 1 and 4. The Zone 3 phase delay selected in this example is one second or 60 cycles.

Z3DP = 60.00

Setting Limit Check

The limit check allows Zone 3 time delays of 0 – 2000 cycles. The Z3DP of 60 cycles lies within the relay setting limits. There is no secondary limit check for this setting.

Other Settings Affected

Z3PT bit in the Relay Word.

Low-Set Phase Overcurrent Setting (50L)

The primary function of the 50L element is to supervise the phase distance elements. For three-phase faults, the current in each phase must exceed the 50L setting. Recall from the intermediate logic for the mho distance elements that the three-phase distance elements are logically ANDed with the 3P50 element (the 3P50 element is asserted when the current magnitude in each phase exceeds the 50L setting threshold). For phase-phase faults, the current in at least one phase must exceed the 50L setting threshold. Again, recall from the intermediate logic that the phase-phase elements are logically ANDed with the 50L element.

For the system shown in [Figure 5.6](#), the governing fault condition is a phase-phase fault at Bus A. The fault study revealed that the lowest phase fault current equals 452 A primary for this fault. To ensure that the 50L element picks up for the calculated fault current, select some current value below the calculated 452 ampere value for the 50L setting. This setting must account for arc resistance, errors in fault study calculations, and CT performance errors. This value for the 50L setting may be below load. In this example, the value selected for the 50L setting is 275 A (approximately 60 percent of the minimum three-phase fault current).

50L = 275.00

Setting Limit Check

The primary limit check allows for 50L settings of 0.25 – 50,000 A. The secondary check allows for a secondary Amp setting of 0.5 – 40 A.

Calculations: CTR = 200:1

$$\text{50L Secondary Amps} = \frac{275 \text{ A primary}}{200} = 1.38 \text{ A secondary}$$

The 50L setting of 275 A for this example lies within the relay setting limits.

Other Settings Affected

50L bit in the Relay Word and all phase distance mhos: Relay Word bits 1ABC, 2ABC, 3ABC, 4ABC, Z1P, Z2P, and Z3P.

Medium-Set Phase Overcurrent Setting (50M)

The setting for the 50M pickup value requires that the element must never be picked up for load current conditions. The setting must also be below the minimum fault current level for which the relay is required to trip following an LOP condition. In this example, the application should detect a fault at Bus C after an LOP condition is detected. It is important to remember that the 50M element is non-directional and requires a coordinating time-delay setting for

the 50MF bit to use in tripping. The maximum expected load for this circuit is 450 A. The minimum fault current level for a fault at Bus C is 535 A. Faults at Bus C do not drop the positive-sequence voltage at Bus B below 14 V. With a small margin for fault study and CT performance error, the 50M setting for this example is 500 A.

$$50M = 500.00$$

Setting Limit Check

The primary limit check allows 50M settings of 0.25 – 50,000 A. The secondary check allows secondary Amp settings of 0.5 – 40 A.

Calculations: CTR = 200:1

$$50M \text{ Secondary Amps} = \frac{500 \text{ A primary}}{200} = 2.5 \text{ A secondary}$$

The 50M setting of 500 A for this example lies within the relay setting limits.

Other Settings Affected

50M and 50MF bits in the Relay Word.

High-Set Phase Overcurrent Setting

The 50H setting requirement dictates that this element asserts when the line circuit breaker is reclosed into a bolted fault close to Bus B. In *Figure 5.6*, the difference in fault duty on either side of Breaker 3 is small. This requires the 50H element be masked only in the MTO logic mask.

The three-phase fault duty for a fault at Bus B is 6842 A primary. To ensure rapid clearance of this fault, a 50H setting of 3420 A is selected for this example.

$$50H = 3420.00$$

Setting Limit Check

The primary limit check allows 50H settings of 0.25 – 50,000 A. The secondary check allows a secondary Amp setting of 0.5 – 80 A.

Calculations: CTR = 200:1

$$50H \text{ Secondary Amps} = \frac{3420 \text{ A primary}}{200} = 17.10 \text{ A secondary}$$

The 50H setting of 3420 A for this example lies within the setting limits of the relay.

Other Settings Affected

50H bit in the Relay Word.

Residual Time-Overcurrent Settings (51NP, 51NC, 51NTD, 51NTC)

In this example, a single-line-to-ground fault at Bus C dictates the sensitivity required for the residual time-overcurrent pickup. The residual current magnitude for this fault is 460.3 A primary. To allow for ground fault

resistance, a value of 50 percent of 460.3 A is selected as the residual time-overcurrent element pickup. The pickup (51NP), time dial (51NTD), and family of curves (51N) selections are assumed to coordinate with the remaining residual time-overcurrent elements of the example system.

51NP = 230.00
51NTD= 4.00
51NC = 3
51NTC= Y

Setting Limit Check

The primary limit check for the residual time-overcurrent element allows 51NP settings of 0.25 – 50,000 A. The secondary check allows for secondary Amp settings of 0.25 – 6.3 A. The 51NC setting check allows settings of 1, 2, 3, or 4 for the family of curves. The 51NTD setting check allows settings from 0.5 to 15 in increments of 0.01. The 51NTC setting allows the residual time-overcurrent element to be torque controlled (Y for directional) or non-torque controlled (N for non-directional).

Calculations: CTR = 200:1

$$51NP \text{ Secondary Amps} = \frac{230 \text{ A primary}}{200} = 1.15 \text{ A secondary}$$

The 51NP, 51NTD, 51NC, and 51NTC settings are all within the setting limits of the relay.

Other Settings Affected

The 51NP setting affects the 50N1P, 50N2P, 50N3P, and 50NL pickup setting range. The 51NP setting dictates the sensitivity of the ground directional element when either 32V or 32I is selected. Relay Word bit 51NT and 51NP depend on the 51NP, 51NTD, 51NC and 51NTC settings.

50N1P Residual Overcurrent Setting (50N1P)

The 50N1P setting requirement dictates that this element must not overreach Bus C under the maximum single-line-to-ground fault conditions because it serves as the pickup of the ground instantaneous element. The maximum residual current measured at Breaker 3 for a fault at Bus C equals 695 A. To ensure that the instantaneous element does not overreach Bus C, the 50N1P setting should be 120 percent of 695 A. This 120 percent factor accounts for differences between the modeled and actual system, CT ratio errors, etc.

50N1P = 835.00

Setting Limit Check

The primary limit check allows 50N1P settings of 0.25 – 50,000 A. The secondary check allows a secondary Amp setting of 0.25 A to 48 times the 51NP setting if the 51NP setting is below 3.15 A secondary. If the 51NP setting equals or exceeds 3.15 A secondary, the lower setting limit of the 50N1P element becomes 0.5 A secondary.

Calculations: CTR = 200:1

$$50N1P \text{ Secondary Amps} = \frac{835 \text{ A primary}}{200} = 4.18 \text{ A secondary}$$

The 50N1P setting of 835 A for this example is greater than 0.25 A secondary ($51NP < 3.15$ A secondary) and less than 48 times the 51NP setting.

Other Settings Affected

67N1 bit in the Relay Word.

50N2P Residual Overcurrent Setting (50N2P)

The 50N2P setting requirement dictates that this element must overreach Bus C under the minimum single-line-to-ground fault conditions. Based on fault study, the minimum residual current measured at Breaker 3 for a fault at Bus C equals 460.3 A with all sources in. To ensure that this element overreaches Bus C, the 50N2P setting should be 60 percent of 460 A. This 60 percent factor accounts for differences between the modeled and actual system, CT ratio errors, fault resistance, etc. The setting must be checked against the protection for Lines 3, 5, and 6 to ensure that it does not reach past the instantaneous pickup of the ground fault protection on these lines. In this example, it is assumed to coordinate.

$$50N2P = 276.00$$

Setting Limit Check

The primary limit check allows 50N2P settings of 0.25 – 50,000 A. The secondary check allows secondary Amp settings of 0.25 A to 48 times the 51NP setting if 51NP is less than 3.15 A secondary. If 51NP equals or exceeds 3.15 A secondary, the lower setting threshold becomes 0.5 A secondary.

Calculations: CTR = 200:1

$$50N2P \text{ Secondary Amps} = \frac{276 \text{ A primary}}{200} = 1.38 \text{ A secondary}$$

The 50N2P setting of 276 A for this example is greater than 0.25 A secondary and less than 48 times the 51NP setting.

Other Settings Affected

67N2 bit in the Relay Word.

50N3P Residual Overcurrent Setting (50N3P)

The 50N3P setting requirement dictates that this element must detect all faults sensed by the overreaching Zone 2 ground fault protection at Bus C under the minimum single-line-to-ground fault conditions. Based on fault study, the minimum residual current measured at Breaker 3 for a fault at Bus A equals 470 A with all sources in. To ensure this element overreaches Bus A, the 50N3P setting should be 60 percent of 470 A. This 60 percent factor accounts for differences between the modeled and actual system, CT ratio errors, fault resistance, etc.

$$50N3P = 282.00$$

Setting Limit Check

The primary limit check allows 50N3P settings of 0.25 – 50,000 A. The secondary check allows secondary Amp settings of 0.25 A to 48 times the 51NP setting if 51NP is less than 3.15 A secondary. If 51NP equals or exceeds 3.15 A secondary, the lower setting limit becomes 0.5 A secondary.

Calculations: CTR = 200:1

$$50\text{N3P Secondary Amps} = \frac{282 \text{ A primary}}{200} = 1.41 \text{ A secondary}$$

The 50N3P setting of 282 A for this example is greater than 0.25 A secondary ($51\text{NP} < 3.15 \text{ A secondary}$) and less than 48 times the 51NP setting.

Therefore, the 282 A setting for the 50N3P element lies within the secondary setting limits of the relay.

Other Settings Affected

67N3 bit in the Relay Word.

Zone 1 Residual Overcurrent Time Delay (Z1DG)

The Z1DG timer adds a settable delay to the Zone 1 instantaneous residual overcurrent element (67N1). A typical setting for this timer is 0.00 cycles.

Z1DG = 0.00

Setting Limit Checks

The primary limit check allows Zone 1 time delays of 0 – 60 cycles. The Z1DG setting of 0.00 cycles lies within the relay setting limits. There is no secondary limit check for this setting.

Other Settings Affected

67N1 bit in the Relay Word.

Zone 2 Residual Overcurrent Time Delay (Z2DG)

This Zone 2 timer adds a settable definite delay to the overreaching Zone 2 instantaneous residual overcurrent element (67N2). The timer must coordinate with the residual overcurrent protection at Bus C. For this example, a time delay of 30 cycles is selected and assumed to coordinate.

Z2DG = 30.00

Setting Limit Check

The primary limit check allows Zone 2 time delay settings of 0 – 2000 cycles. The Z2DG of 30 cycles lies within the relay setting limits. There is no secondary limit check for this setting.

Other Settings Affected

Z2GT bit in the Relay Word.

Zone 3 Residual Overcurrent Time Delay (Z3DG)

This Zone 3 timer adds a settable definite time delay to the Zone 3 instantaneous residual overcurrent element (67N3). The timer must coordinate with the local residual overcurrent protection at Bus B to provide time-delay backup protection for faults at Bus A (Zone 3 reversed for this example). For this example, a time delay of 60 cycles is selected and assumed to coordinate.

Z3DG = 60.00

Setting Limit Check

The primary limit check allows Zone 3 time delays of 0 – 2000 cycles. The Z3DG of 60 cycles lies within the relay setting limits. There is no secondary limit check for this setting.

Other Settings Affected

Z3GT bit in the Relay Word.

Trip Duration Timer (TDUR)

The trip duration timer setting is determined by the minimum length of time you want to close the TRIP output contacts. The TRIP output contacts close for the greater of the TDUR time or the duration of the trip condition. Typical settings for this timer are 150 ms or nine cycles.

TDUR = 9.00

Setting Limit Check

The primary limit check allows TDUR time delay settings of 0 – 2000 cycles. The TDUR setting of 9.00 cycles lies within the relay setting limits. There is no secondary limit check for this setting.

Other Settings Affected

TRIP bit in the Relay Word.

52BT Setting (52BT)

The 52BT timer setting determines the length of time switch-onto-fault logic is enabled. The 52BT timer setting must be shorter than the time for the first reclose attempt or line breaker closure at the remote terminal. At the same time, it must be long enough for the fault detecting elements to assert and generate a trip output. Typical high-speed reclosure times are 20 – 30 cycles to allow dispersal of ionized fault gases. In this example, the first reclose occurs at 40 cycles. To ensure that the 52BT element is asserted before the line breaker recloses, a 52BT time of 20 cycles is selected.

52BT = 20.00

Setting Limit Check

The limit check allows 52BT time-delay settings of 0.5 – 10,000 cycles. The 52BT setting of 20.00 cycles lies within the relay setting limits. There is no secondary limit check for this setting.

Other Settings Affected

52BT bit in the Relay Word, the lesser of 79OI1, 79OI2, and 79OI3 settings.

Zone 3 Direction Setting

The Zone 3 elements must be reversed in this application because of the role of the reverse-looking elements in the time-step backup scheme for Bus A protection.

ZONE3 = R

Setting Limit Check

The ZONE3 setting must be set for either F (forward) or R (reverse).

Other Settings Affected

Z2% and Z3% reach limitations.

Residual Overcurrent Polarization Method Selection (32QE, 32VE, 32IE)

The polarization method selected for this example is negative-sequence. This prevents the influences of zero-sequence mutual coupling with Line 5. For all single-line-to-ground faults, the negative-sequence polarizing volt-amperes exceed 0.10 VA secondary and are sufficient to polarize the ground directional element. It is further assumed that the residual overcurrent protection of the surrounding system is negative-sequence polarized.

32QE = Y
32VE = N
32IE = N

Setting Limit Check

The relay allows you to select between three methods of residual overcurrent polarization. When you select negative-sequence, you cannot use zero-sequence methods. When you select zero-sequence polarization, you can use one or both of the zero-sequence voltage and current polarization methods.

Other Settings Affected

None.

Loss-of-Potential (LOP) Enable Setting, (LOPE)

The loss-of-potential logic detects blown potential transformer PT secondary fuse conditions. If an LOP condition is detected, the mho distance elements are blocked from operating and the ground directional element defaults

forward. Loss-of-potential is enabled with the setting LOPE = Y. With LOP enabled, the 50MF bit in the Relay Word is set after the following conditions are met:

1. A loss-of-potential condition is detected
2. Current exceeds the 50M pickup
3. 50MFD timer expires (requires conditions 1 and 2 to start timing; only Condition 2 is required if LOPE=N)

When LOP is not enabled, LOPE = N. The 50MFD timer is initiated when the current exceeds the 50M pickup. For this example, both LOP detection and non-directional phase overcurrent protection after an LOP condition are desired.

LOPE = Y

Setting Limit Check

The primary limit check allows LOPE settings of Y (enabled) or N (not enabled).

Other Settings Affected

The operating mode of the 50MF bit in the Relay Word. If LOPE=N, the mho distance elements are not blocked from operating during an LOP condition.

Serial Port(s) Timeout Settings (TIME1, TIME2)

The TIME1 and TIME2 settings allow their respective ports to time out after the relay detects a period of inactivity for that port. After timing out, access for the port returns to Level 0 and no automatic messages are transmitted to it. In this example, a modem is connected to PORT 1. This requires a definite time setting for the port to prevent accumulation of toll charges if an operator does not hang up. PORT 2 is to be connected to an SEL-DTA and must never time out. This allows the SEL-DTA to receive any automatic message transmitted by the relay.

TIME1= 5 TIME2 = 0

Setting Limit Check

The TIME1 and TIME2 limit check allows settings of 0 – 30 minutes. A zero setting signifies that the port never times out. There is no secondary limit check for this setting.

Other Settings Affected

None.

Autoport Designation Setting (AUTO)

The AUTO setting specifies the port to which the relay directs automatically generated messages. The example has a modem connected to PORT 1 and an SEL-DTA connected to PORT 2. Because only the SEL-DTA is required to receive automatic messages, the AUTO setting is 2.

AUTO = 2

Setting Limit Check

The limit check allows messages to be sent to PORT 1 only, (AUTO = 1), PORT 2 only (AUTO = 2), or both ports (AUTO = 3).

Other Settings Affected

None.

Modem Answer Ring Setting (RINGS)

The RINGS setting specifies the number of rings a modem connected to PORT 1 waits to answer. This permits use of a single substation telephone line by both substation personnel and the relay. In this example, personnel have seven rings to answer the phone before the modem answers.

RINGS = 7

Setting Limit Check

The limit check allows for the modem to answer between 1 and 30 rings.

Other Settings Affected

None.

Programmable Output Contact Mask Settings

The Relay Word is the center of relay programmability. It contains four rows of eight bit groups that represent the state of relay elements, timer and logic outputs, and relay inputs. Each bit in the Relay Word has two states: logical 1 when the element is asserted, logical 0 when the element is deasserted.

Each quarter-cycle, the relay samples voltage and current data, performs intermediate logic to determine if an element is asserted, and sets the appropriate bit in the Relay Word.

After updating the Relay Word, the relay compares it to all programmable logic masks with a logical “AND” process. This process in turn controls the relay output contacts. Each TRIP and programmable output relay has a corresponding logic mask. In addition to these masks, the relay has two masks to control initiation and cancellation of the three-shot recloser. These masks determine the state of the output contacts and reclosing progression.

Table 5.1 Relay Word

1ABC	2ABC	3ABC	4ABC	LOP	50H	50M	50L
51NT	67N1	67N2	67N3	51NP	Z1P	Z2P	Z3P
Z2PT	Z3PT	OSB	3P50	50MF	RC	RI	DF
ALRM	TRIP	TC	DT	52BT	52AT	Z2GT	Z3GT

The Relay Word Bit Summary Table explains each bit in the Relay Word.

The relay employs ten separate logic masks. Four of these masks are directly related to controlling the TRIP output contacts (MTU, MPT, MTB, and MTO). The masks labelled MA1, MA2, MA3, and MA4 control the four programmable output contacts. The masks for reclose initiation (MRI) and reclose cancel (MRC) are used as inputs for controlling the three-shot recloser.

Communication Scheme Use of Logic Masks

The relay supports a large variety of protective schemes, some of which are shown below:

- Time-stepped distance
- Permissive-overreaching transfer trip (POTT) schemes
- Directional comparison blocking (DCB) schemes
- Directional comparison unblocking (DCUB) schemes
- Direct underreaching transfer trip (DUTT) schemes
- Permissive underreaching transfer trip (PUTT) schemes
- Direct transfer trip (DTT) schemes

The Relay Word and programmable masks provide great flexibility in applying the relay without rewiring panels or changing jumpers on circuit boards. Interfacing the relay with each of the various schemes involves three simple steps: 1) connecting the communications equipment to the appropriate logic input (DT, PT, or BT) on the relay rear panel, 2) selecting the appropriate mask and bits for the tripping scheme (MTU, MPT, MTB, or MTO), and 3) depending on which scheme is selected, determining the number of programmable output contacts required to interface with the communications equipment and the appropriate Relay Word bit. Please note that each mask is independent from the other tripping masks. This allows multiple schemes to function simultaneously.

The following guideline shows typical usage of bits in each mask.

Please note that each application requires a careful study of the bit used in each mask. This guideline is included as a reference of typical Relay Word bit usage.

MTU: Mask for Trip Unconditional

NOTE: Never mask the TRIP bit into the MTU logic mask. This causes an undesirable seal-in of TRIP output contacts.

Elements selected in this mask do not require that external conditions be met to initiate a trip. If an element masked in the MTU logic mask picks up, the TRIP output contacts close. You must be certain that elements used in this mask coordinate with the remainder of the power system. Unless your application permits, it is not advisable to mask non-directional elements into the MTU logic mask.

Typical bits masked in the MTU logic mask include Zone 1 instantaneous elements (1ABC, Z1P, and 67N1) if they underreach the remote terminal, time-delayed Zone 2 elements (Z2PT and Z2GT), time-delayed Zone 3 elements (Z3PT and Z3GT), 50MF, the TC bit to close TRIP output contacts upon **OPEN** command execution, and the Direct Trip (DT) bit if an external tripping source energizes the DT input. The external tripping source is often a backup protective relay, breaker failure relaying, or a direct trip signal from communications equipment. In each example listed (except breaker failure), energizing the DT input allows you to use the reclosing functions by forcing the relay to trip.

MPT: Mask for Trip With Permissive Trip Input Asserted

NOTE: Never mask the TRIP bit into the MPT logic mask. This causes an unwanted seal-in of TRIP output contacts upon PT input assertion.

MTB: Mask for Trip With Block Trip Input Deasserted

NOTE: Never mask the TRIP bit into the MTB logic mask. This causes an unwanted seal-in of the TRIP output contacts when the BT input is not asserted.

MTO: Mask for Trip With the 52BT Element Asserted

NOTE: Never mask the TRIP bit into the MTO logic mask. This causes an unwanted seal-in of TRIP output contacts when the 52BT element is asserted.

MA1, MA2, MA3, and MA4 Programmable Output Contact Masks

Elements selected in this mask are permitted to close the TRIP output contacts when they pick up in conjunction with Permissive Trip (PT) input assertion. PT input assertion serves as an external qualifying condition. As with the MTU logic mask, it is not advisable to mask non-directional elements in the MPT logic mask unless your application permits.

Typical bits masked in the MPT logic mask include Zone 2 instantaneous elements (2ABC, Z2P, and 67N2).

Elements selected in this mask are permitted to close the TRIP output contacts when they are picked up and the Block Trip (BT) input is not asserted. BT input assertion serves as an external qualifying condition. As with the MTU logic mask, it is not advisable to mask non-directional elements in the MTB logic mask unless your application permits.

Typical bits masked in the MTB logic mask include Zone 2 instantaneous elements (2ABC, Z2P, and 67N2).

Elements selected in this mask are permitted to close the TRIP output contacts when they are picked up and the 52BT element is asserted. The 52BT element is a time-delayed, inverted follower of the 52A input (see switch-onto-fault logic explanation for a detailed timing explanation of the 52BT element). This tripping mask differs from the MTU, MPT, and MTB tripping masks because it is acceptable to mask sensitive non-directional elements into MTO. Such masking is advisable except in applications where the line breaker is closed into a line energized from the remote terminal (i.e. synchronized closures).

Typical bits masked in the MTO logic mask include Zone 1 instantaneous elements (1ABC, Z1P, and 67N1), the non-directional high-set element (50H), Zone 2 instantaneous elements (2ABC, Z2P, and 67N2), the Zone 4 three-phase distance element (4ABC), and the Direct Trip (DT) bit if an external tripping source energizes the DT input of the relay.

Any element listed in the Relay Word may be masked into these programmable output contacts. Guidelines to follow when masking elements into each mask depends on equipment wired to the contact outputs. If external connections are not wired to the contact outputs, it is advisable to mask elements into these masks to enhance event report analysis. For example, masking the DF (ground overcurrent direction forward declaration) into one of the programmable output contacts informs you when the relay declares a fault to be in the forward direction.

For commissioning purposes, you may mask the TC bit into an individual output contact and use the **OPEN** command to verify contact closure.

MRI: Mask for Reclose Initiation

If an element masked in the MRI mask is asserted when the TRIP output contacts close, reclosing is initiated unless a reclose cancel condition invalidates initiation. Reclose initiation is subordinate to reclose cancel. See [Reclose Logic on page 5.35](#) for more details.

MRC: Mask for Reclose Cancellation

If an element masked in the MRC mask is asserted when the TRIP output contacts close, reclosing is cancelled even if a reclose initiate condition is present. Reclose initiation is subordinate to reclose cancellation. See [Reclose Logic on page 5.35](#) for more details.

Relay Word Bits Intended for Relay Testing

Each bit in the Relay Word has a designated purpose. The following bits are included to assist in relay testing: 50M, 50L, 51NP, OSB, 3P50, TC, and DF. This does not exclude the use of these bits in one of four trip or programmable output contacts if required by your application.

Mask for Trip Unconditional (MTU)

NOTE: Each mask must be properly configured for your application.

								Event Report Hexadecimal Code
1ABC	2ABC	3ABC	4ABC	LOP	50H	50M	50L	
1	0	0	0	0	0	0	0	80
51NT	67N1	67N2	67N3	51NP	Z1P	Z2P	Z3P	
1	1	0	0	0	1	0	0	C4
Z2PT	Z3PT	OSB	3P50	50MF	RC	RI	DF	
1	1	0	0	1	0	0	0	C8
ALRM	TRIP	TC	DT	52BT	52AT	Z2GT	Z3GT	
0	0	1	1	0	0	1	1	33

The example Mask for Unconditional Trip (MTU) selects tripping by the Zone 1 three-phase (1ABC), Zone 1 phase-phase (Z1P), Zone 1 residual instantaneous overcurrent element (67N1), 51N element (51NT) timeout, Zone 2 and 3 phase distance (Z2PT and Z3PT) timeout, residual overcurrent element (Z2GT and Z3GT) timeout, the 50MF element, the **OPEN** command (TC ≡ Trip Command), and Direct Trip (DT) input assertion.

In this example, the DT input is energized by the trip output of the local breaker failure protection for event report generation. Where primary and secondary protection trip output contacts are routed to separate trip coils of the line breaker, cross tripping is achieved by routing the trip output of each set of protection to trip the other. When cross tripping is desirable, route the trip output from the secondary line protection relays to the DT input.

Mask for Permissive Trip (MPT)

								Event Report Hexadecimal Code
1ABC	2ABC	3ABC	4ABC	LOP	50H	50M	50L	
0	0	0	0	0	0	0	0	00
51NT	67N1	67N2	67N3	51NP	Z1P	Z2P	Z3P	
0	0	0	0	0	0	0	0	00
Z2PT	Z3PT	OSB	3P50	50MF	RC	RI	DF	
0	0	0	0	0	0	0	0	00
ALRM	TRIP	TC	DT	52BT	52AT	Z2GT	Z3GT	
0	0	0	0	0	0	0	0	00

The example mask for permissive tripping contains all zeros because POTT is not selected.

Mask for Trip Block (MTB)

								Event Report Hexadecimal Code
1ABC	2ABC	3ABC	4ABC	LOP	50H	50M	50L	
0	0	0	0	0	0	0	0	00
51NT	67N1	67N2	67N3	51NP	Z1P	Z2P	Z3P	
0	0	0	0	0	0	0	0	00
Z2PT	Z3PT	OSB	3P50	50MF	RC	RI	DF	
0	0	0	0	0	0	0	0	00
ALRM	TRIP	TC	DT	52BT	52AT	Z2GT	Z3GT	
0	0	0	0	0	0	0	0	00

This mask contains all zeros because DCB is not selected.

Mask for Trip Breaker Open (MTO)

								Event Report Hexadecimal Code
1ABC	2ABC	3ABC	4ABC	LOP	50H	50M	50L	
1	1	0	1	0	1	0	0	D4
51NT	67N1	67N2	67N3	51NP	Z1P	Z2P	Z3P	
1	1	1	0	0	1	1	0	E6
Z2PT	Z3PT	OSB	3P50	50MF	RC	RI	DF	
0	0	0	0	0	0	0	0	00
ALRM	TRIP	TC	DT	52BT	52AT	Z2GT	Z3GT	
0	0	0	0	0	0	0	0	00

The MTO mask selects elements to trip when 52BT is asserted. The example mask for trip while breaker open (MTO) selects tripping by Zone 1, 2, and 4 instantaneous three-phase elements (1ABC, 2ABC, and 4ABC), high set phase overcurrent element (50H), instantaneous Zone 1 and 2 phase-phase elements (Z1P and Z2P), residual instantaneous overcurrent elements (67N1 and 67N2), and timeout of the 51N element (51NT).

Mask for the A1 Output Contact (MA1)

								Event Report Hexadecimal Code
1ABC	2ABC	3ABC	4ABC	LOP	50H	50M	50L	
0	0	1	0	0	0	0	0	20
51NT	67N1	67N2	67N3	51NP	Z1P	Z2P	Z3P	
0	0	0	1	0	0	0	1	11
Z2PT	Z3PT	OSB	3P50	50MF	RC	RI	DF	
0	0	0	0	0	0	0	0	00
ALRM	TRIP	TC	DT	52BT	52AT	Z2GT	Z3GT	
0	0	0	0	0	0	0	0	00

The example mask setting for the A1 contact permits A1 output contact closure when the reverse-looking instantaneous elements set.

The A1 output contact is not connected to any external circuits. Therefore, in this application the Zone 3 elements may be masked in this output contact to give a visual indication in the event report of reverse direction faults.

Mask for the A2 Output Contact (MA2)

								Event Report Hexadecimal Code
1ABC	2ABC	3ABC	4ABC	LOP	50H	50M	50L	
0	0	0	0	0	0	0	0	00
51NT	67N1	67N2	67N3	51NP	Z1P	Z2P	Z3P	
0	0	0	0	0	0	0	0	00
Z2PT	Z3PT	OSB	3P50	50MF	RC	RI	DF	
0	0	0	0	0	0	0	1	01
ALRM	TRIP	TC	DT	52BT	52AT	Z2GT	Z3GT	
0	0	0	0	0	0	0	0	00

The A2 output contact is masked to indicate when the ground directional element declares a fault in the forward direction. As with the A1 output contact, this contact is not connected to external circuitry.

Mask for the A3 Output Contact (MA3)

								Event Report Hexadecimal Code
1ABC	2ABC	3ABC	4ABC	LOP	50H	50M	50L	
0	0	0	0	0	0	0	0	00
51NT	67N1	67N2	67N3	51NP	Z1P	Z2P	Z3P	
0	0	0	0	0	0	0	0	00
Z2PT	Z3PT	OSB	3P50	50MF	RC	RI	DF	
0	0	1	0	0	0	0	0	20
ALRM	TRIP	TC	DT	52BT	52AT	Z2GT	Z3GT	
0	0	0	0	0	0	0	0	00

The A3 output contact is masked to show an out-of-step block condition in the event report. The example mask setting for the A3 contact permits closure of the A3 output contact when the OSB bit is set.

Mask for the A4 Output Contact (MA4)

								Event Report Hexadecimal Code
1ABC	2ABC	3ABC	4ABC	LOP	50H	50M	50L	
0	0	0	0	1	0	0	0	08
51NT	67N1	67N2	67N3	51NP	Z1P	Z2P	Z3P	
0	0	0	0	0	0	0	0	00
Z2PT	Z3PT	OSB	3P50	50MF	RC	RI	DF	
0	0	0	0	0	0	0	0	00
ALRM	TRIP	TC	DT	52BT	52AT	Z2GT	Z3GT	
0	0	0	0	0	0	0	0	00

The A4 output contact connects to the local annunciator panel to alarm for loss-of-potential conditions. The example mask setting for the A4 contact permits A4 output contact closure when the LOP bit is set.

Mask for Reclose Initiation (MRI)

									Event Report Hexadecimal Code
1ABC	2ABC	3ABC	4ABC	LOP	50H	50M	50L		
0	0	0	0	0	0	0	0	00	
51NT	67N1	67N2	67N3	51NP	Z1P	Z2P	Z3P		
0	1	0	0	0	1	0	0	44	
Z2PT	Z3PT	OSB	3P50	50MF	RC	RI	DF		
0	0	0	0	0	0	0	0	00	
ALRM	TRIP	TC	DT	52BT	52AT	Z2GT	Z3GT		
0	0	0	0	0	0	0	0	00	

The mask for Reclose Initiation (RI) selects elements from the Relay Word to start the reclosing relay. The example mask for reclose initiation selects the Zone 1 residual instantaneous-overcurrent (67N1) element and the Zone 1 phase-phase element (Z1P) for reclose initiation.

Mask for Reclose Cancel (MRC)

									Event Report Hexadecimal Code
1ABC	2ABC	3ABC	4ABC	LOP	50H	50M	50L		
1	1	1	0	0	1	0	0	E4	
51NT	67N1	67N2	67N3	51NP	Z1P	Z2P	Z3P		
1	0	0	0	0	0	0	0	80	
Z2PT	Z3PT	OSB	3P50	50MF	RC	RI	DF		
1	1	0	0	1	0	0	0	C8	
ALRM	TRIP	TC	DT	52BT	52AT	Z2GT	Z3GT		
0	0	1	1	0	0	1	1	33	

The mask for Reclose Cancel (RC) selects elements from the Relay Word to cancel the reclosing relay. The example mask for reclose cancel stops reclosing for three-phase faults in Zones 1, 2, and 3, a 50H high-set overcurrent condition, timeout of the residual overcurrent element 51NT, timeout of the Zone 2 and Zone 3 phase timers Z2PT and Z3PT, a loss-of-potential with a medium-set overcurrent condition (50MF), the Trip Command (TC), assertion of the Direct Trip (DT) input, and timeout of the Zone 2 and Zone 3 ground timers (Z2GT and Z3GT, respectively).

Table 5.2 Relay Word Bit Summary (Sheet 1 of 2)

1ABC	Zone 1 three-phase instantaneous element (set by Z1%)
2ABC	Zone 2 three-phase instantaneous element (set by Z2%)
3ABC	Zone 3 three-phase instantaneous element (set by Z3%)
4ABC	Zone 4 three-phase instantaneous element (equal to 1.5 x Z3%)
LOP	Loss-of-potential condition
50H	High-level overcurrent element (set by 50H)
50M	Medium-level overcurrent element (set by 50M)

Table 5.2 Relay Word Bit Summary (Sheet 2 of 2)

50L	Phase fault current supervision (set by 50L)
51NT	Residual time-overcurrent trip (set by 51NP, 51NTD, and 51NC)
67N1	Residual instantaneous-overcurrent (set by 50N1P) ^a
67N2	Residual instantaneous-overcurrent (set by 50N2P) ^a
67N3	Residual instantaneous-overcurrent (set by 50N3P) ^a
51NP	Residual time-overcurrent pickup
Z1P	Zone 1 phase-phase element (set by Z1%)
Z2P	Zone 2 phase-phase element (set by Z2%)
Z3P	Zone 3 phase-phase element (set by Z3%)
Z2PT	Zone 2 phase-phase or three-phase timeout (set by Z2DP)
Z3PT	Zone 3 phase-phase or three-phase timeout (set by Z3DP)
OSB	Out-of-step block
3P50	Three-phase fault current supervision
50MF	Asserts a settable delay after LOP and 50M pickup (delay set by 50MFD)
RC	Reclose cancel
RI	Reclose initiate
DF	Direction forward for ground faults
ALRM	System alarm
TRIP	Trip condition
TC	Trip (OPEN) Command
DT	Direct Trip (or other user-defined external purposes)
52BT	Inverted time-delayed 52A follower (delay set by 52BT setting)
52AT	Time-delayed 52A follower (delay set by 52BT setting)
Z2GT	Zone 2 timeout-ground (set by Z2DG)
Z3GT	Zone 3 timeout-ground (set by Z3DG)

^a The 50N elements are made directional by enabling any of the directional control methods, i.e. 32QE = Y, or either 32VE = Y or 32IE = Y.

Reclose Logic

Introduction

All SEL-221G series relays include a reclosing relay capable of one to three shots of automatic reclosing for selectable fault types. The relay uses a mask logic principle to allow programmable output contact for tripping and communication equipment interfaces. It uses the same logic to control initiation or cancellation of a reclosing sequence.

Reclosing schemes have traditionally required a separate reclosing relay for each terminal. These relays controlled the timing of the breaker reclosing scheme. The reclosing sequence was cancelled using one of two methods: 1) a reclose block signal sent to the recloser from protective relays, or 2) external relays to control a reclose block contact in series with the recloser close contact. The reclosing function of the SEL-221G relay eliminates the need for a separate recloser and the associated external cancellation/initiation circuitry.

Basic Automatic Reclosing Philosophy

Most faults occurring on transmission line networks are transient. Thus, after the circuit breakers on either end of the transmission line have removed the fault energy, the line may be successfully re-energized. A short time period is required between opening of the circuit breaker poles and the reclose to allow dispersal of the fault arc. This reclosing time can also be used to coordinate line testing from designated sources. The time period is usually controlled by the reclosing dead time for each automatic shot.

Automatic reclosing schemes substantially improve the continuity of transmission line service without requiring operator intervention.

For faults such as three-phase faults, automatic reclosing may not be desirable. The chance of such faults being permanent is much greater than phase-to-phase or single-line-to-ground faults. A permanent three-phase fault can occur when line crews do not remove safety grounds after working on a transmission line. Other instances for which reclosing may not be desirable include faults cleared by either time-delayed Zone 2 or 3 elements or a ground time-overcurrent element in a communications-aided protection scheme. Programmable logic masks permit you to select a fault type and/or zone for which you wish to initiate/cancel circuit breaker reclosure.

Basic SEL-221G Relay Recloser Operating Logic

The SEL-221G reclosing relay allows one to three shots of automatic reclosing for selectable fault types. Reclosure timing is controlled by three open interval timers (79OI1, 79OI2, and 79OI3). If a reclose is unsuccessful because of external constraints, a timer (79RS) resets the recloser to prevent a standing close (please see *Example 7: 79RS Timer Eliminates Standing Close on page 5.46* for a detailed explanation of the 79RS timer function). Each timer is individually settable.

Selecting conditions for reclose initiation and cancellation is similar to output relay programming. This method provides application flexibility for various reclosing schemes.

$$RI = R * MRI$$

$$RC = R * MRC,$$

where MRI is the mask for reclose initiation and MRC is the mask for reclose cancellation.

Four conditions must be met before any reclosing cycle begins:

1. the SEL-221G Relay must issue a trip
2. the relay must sense a change in the 52A input state (close to open)
3. a reclose initiate must be issued
4. a reclose cancel must not be issued

The 79OI time interval begins when all four conditions are met for that reclose shot.

Reclosing Logic Examples

This discussion provides seven examples to demonstrate the reclosing features of the SEL-221G Relay. Examples include oscillograph traces to illustrate the status of various relay elements.

- Example 1: Deassertion of Trip Output Criteria
- Example 2: Reclose Cancel (RC) Hierarchy Over Reclose Initiation (RI)
- Example 3: Reclose Sequence Cancellation Due to Breaker Open
- Example 4: Evolving Fault Reclose Cancellation
- Example 5: Recloser Interval Time References
- Example 6: Coordination of the 52BT and 79OI Timers
- Example 7: 79RS Timer Elimination of Standing Close

Example 1: Deassertion of Trip Output Criteria

The oscillograph in [Figure 5.7](#) shows a successful reclosing sequence for a Zone 1 phase-to-phase fault. The 79OI1 timer is set for 0.25 cycles to show the close contact closure as soon as possible after all conditions required for reclosure are established. [Table 5.3](#) outlines trace assignments for this example.

Table 5.3 Trace Assignments for Example 1

Trace Assignment	Description of Trace
A	Trip
B	Close
C	Reclose Initiate, RI
D	Reclose Cancel, RC




Figure 5.7 Successful Reclose Sequence After Zone 1 Phase-to-Phase Fault

The oscillograph in [Figure 5.7](#) shows that the reclose sequence does not begin until after the trip output deasserts, even though the RI was issued much earlier (also note that reclose cancel never asserted). For this example, the Z1P is enabled in the RI mask, while 3ABC is enabled in the RC mask.

TRIP output duration is always a minimum of TDUR cycles. This feature allows you to determine the minimum TRIP contact closure duration to ensure that the circuit breaker trip coil receives a strong, steady trip signal. Thus, the open interval timing may start several milliseconds after the fault clears and the breaker opens. [Figure 5.8](#) shows the edge-triggered Trip Duration Timer (TDUR) in the close TRIP logic.




Figure 5.8 Programmable Trip Logic Diagram

Example 2: Reclose Cancel Hierarchy Over Reclose Initiate

The oscillograph in [Figure 5.9](#) shows an unsuccessful reclosing sequence for the same Zone 1 phase-to-phase fault used in Example 1. Relay settings were the same as for Example 1, except that the element initiating reclose in the MRI mask now also initiates cancel in the MRC mask. This shows that the reclose cancel mask MRC has hierarchy over the reclose initiate mask. The following examples explain this feature.




Figure 5.9 Unsuccessful Reclose Sequence After Zone 1 Phase-to-Phase Fault

Example 3: Reclose Cancel Due to Breaker Open (52A Contact Not Asserted)

The oscillograph in [Figure 5.10](#) shows an unsuccessful reclosing sequence for the same Zone 1 phase-to-phase fault used in Example 1 with the breaker open (52A input not asserted). This fulfills the requirement that the recloser must see a change in 52A contact state before the 79OI timer can start. Trace assignments are identical to those in [Figure 5.3](#). Note that the RI signal is initiated as in Example 1, but no close signal is ever issued to the CLOSE output contact.




Figure 5.10 Unsuccessful Reclose Sequence After Zone 1 Phase-to-Phase Fault

Example 4: Evolving Fault Reclose Cancellation

The oscillograph in [Figure 5.11](#) shows an unsuccessful reclosing sequence for a Zone 1 phase-to-phase fault evolving into a Zone 1 three-phase fault. Note that the relay issues the RI signal, followed by an RC signal. No close signal is issued for this case. The RC was issued before the trip output deasserted, cancelling the reclosing sequence. This action is based on the precedence of the MRC mask over the MRI mask. Trace assignments are the same as those in [Table 5.3](#) for Example 1.




Figure 5.11 Unsuccessful Reclose Sequence, Zone 1 Phase-to-Phase to Three-Phase Fault

The oscillograph in [Figure 5.12](#) also shows an unsuccessful reclosing sequence for a Zone 1 three-phase fault evolving into a Zone 1 phase-to-phase fault. Although this is a highly unlikely situation, it is included to demonstrate the recloser cancellation logic. Note that the RC signal is issued, followed by an RI signal. No close signal is issued for this case. The RC is issued while the trip output is asserted, cancelling the reclosing sequence. Trace assignments are identical to those in [Table 5.3](#) for Example 1.

The reclose-initiating condition in the MRI mask is the Zone 1 phase-to-phase element. The reclose-cancelling condition in the MRC mask is the Zone 3 three-phase instantaneous element (Zone 3 forward). When a reclose-cancelling condition becomes true while the trip output is asserted, the reclosing cycle is cancelled.




Figure 5.12 Unsuccessful Reclose Sequence, Zone 1 Three-Phase to Phase-to-Phase Fault

In this case, problems can occur if a user masks a Zone 1 element in the RI mask and the same fault type Zone 2 instantaneous element in the RC mask, expecting the Zone 1 element to initiate a reclose. Because the Zone 2 element has a greater forward reach than the Zone 1 element, it picks up before the Zone 1 element. It remains picked up while the Zone 1 element is picked up and cancels reclosing. However, if the Zone 2 (or forward Zone 3, or Zone 4) instantaneous element is not masked into the RC mask and the fault is within Zone 1 reach, the reclosing cycle proceeds as expected (providing no other reclose cancelling conditions are met). This is true even if the Zone 2 instantaneous element initiates the trip before the Zone 1 element picks up (as in carrier-based schemes). [Figure 5.13](#) demonstrates a successful reclosing sequence for a Zone 1 fault where the trip is first initiated by the farther reaching Zone 2 element (not in the MRC mask). The element issues a reclose initiate signal because the Zone 1 element asserts while the trip signal is asserted.




Figure 5.13 Successful Reclose Sequence, Zone 1 Phase-to-Phase Trip Initiated by Zone 2

Example 5: Recloser Interval Time References

The oscillograph in [Figure 5.14](#) demonstrates a two-shot reclosing sequence for a Zone 1 phase-to-phase fault. Five and 15-cycle reclosing intervals are shown (79OI1 = 5 cycles, 79OI2 = 15 cycles). The Zone 1 element issues an RI signal for each shot while the trip element is asserted, but timing does not begin until the TRIP contact opens.




Figure 5.14 Two-Shot Reclosing Sequence Timing Diagram

Table 5.4 Trace Assignments for Examples 5 and 6 (Except Figures 5.18 and 5.19)

Trace Assignment	Description of Trace
A	Trip
B	Close
C	INVERTED 52A Status Input
D	52BT

Example 6: Coordination of 52BT and 790I Timers

It is important to distinguish between the four separate trip masks of the SEL-221G Relay. The masks are:

- MTU ≡ Mask for Trip Unconditional (no logic qualifiers)
- MPT ≡ Mask for trip with the Permissive Trip input asserted
- MTB ≡ Mask for Trip with the Block trip input not asserted
- MTO ≡ Mask for Trip while the 52BT element is asserted

- MTU: Mask for Trip Unconditional. Elements selected in this mask do not require an external or conditional input to close the trip output contact.
- MPT: Mask for Permissive Trip. Elements selected for this mask require that a permissive signal be present (or asserted) at the Permissive Trip input on the SEL-221G Relay rear panel.
- MTB: Mask for Trip Block. Elements selected for this mask, combined with the absence of a block signal at the rear-panel Block Trip input, allow the SEL-221G Relay to perform Directional Comparison Blocking (DCB) protective functions.
- MTO: Mask for Trip while the 52BT element is asserted. Elements selected in this mask regulate breaker tripping using very sensitive elements. Tripping occurs during line testing or when a line is energized for the first time. The 52BT time setting determines the time during which the relay enables switch-onto-fault logic. The 52BT element is an inverted time-delayed follower of the 52A input. When the 52A input to the relay goes from a high state (breaker closed) to a low state (breaker trips), the 52BT element remains low for the 52BT time selected in the setting procedure. When the breaker is closed (from an open state), the 52BT element remains high for 52BT time. Thus, for 52BT time after the breaker is closed, the elements selected in the MTO logic mask can sense fault conditions, providing switch-onto-fault protection.

The graph in [Figure 5.15](#) shows the timing relationship between the 52BT and 790I timers.




Figure 5.15 52BT and 790I Timing Diagram

During the time period shown for Regions 1 and 2, MTO logic is enabled because the 52BT element is asserted. Region 1 shows the time during which MTO logic is enabled to protect the open line breaker. Thus, for line breaker tank faults, the SEL-221G Relay can issue a trip signal required for breaker backup schemes.

Region 2 shows the time during which the MTO logic is performing true switch-onto-fault (SOTF) protection for the line. This feature allows the instantaneous elements to trip the line breaker immediately upon detecting a fault for a set amount of time. Normally, these elements are only used for tripping in conjunction with either a qualifying permissive signal from the remote end of the line (POTT schemes), or the absence of a block signal (DCB schemes).

Figure 5.16 shows a circuit with a phase-to-phase fault close to Breaker 2. Suppose that Breaker 1 is the preferred source for testing the line, while Breaker 2 is to remain open until Breaker 1 energizes the line. If standard time-stepped distance protection is used without SOTF protection, the fault would have to be cleared in Zone 2 time. However, using the MTO logic of the SEL-221G Relay, the non-time delayed Zone 2 phase elements can detect the fault and issue a trip signal very rapidly. This reduces the amount of time that the transmission line is faulted. The possibility of overreaching the remote terminal with the instantaneous Zone 2 element is nonexistent because Breaker 2 is open while the Breaker 1 MTO logic is enabled (see *Figure 5.17*). If the fault is not present when Breaker 1 tests the line, the Breaker 1 MTO logic resets and Breaker 2 is allowed to synchronize and close. Note that you must limit the time during which elements of the MTO mask can trip the breaker. The 52BT setting must be long enough for the sensitive elements masked into the MTO logic mask to assert, but shorter than the time allowed for Breaker 2 to parallel.




Figure 5.16 Faulted Line With All Sources In




Figure 5.17 Faulted Line With Breaker 2 Open

Figure 5.18 and *Figure 5.19* show the timing relationship for a B-C fault detected before and after the first open interval expires. The 79OI1 period is set for 20 cycles. *Table 5.5* shows the trace assignments for these figures.

Table 5.5 Oscilloscope Trace Assignments for Figures 5.18 and 5.19

Trace ID	Description of Trace
A	B _Φ Fault Current
B	Trip Output
C	INVERTED 52A Status Input
D	Close signal

The oscillograph in [Figure 5.18](#) shows a successful two-shot reclose sequence. The sequence was successful because the second fault occurred after the 79OI1 timing interval expired. The oscillograph in [Figure 5.19](#) shows an unsuccessful reclose sequence because the fault was detected prior to the 79OI1 interval expiration.




Figure 5.18 Successful Two-Shot Reclosing Sequence




Figure 5.19 Unsuccessful Two-Shot Reclosing Sequence

Oscillographs in [Figure 5.20](#) and [Figure 5.21](#) show a two-shot reclosing sequence for the same Zone 1 phase-to-phase fault used in Example 5. Reclosing intervals shown in [Figure 5.20](#) and [Figure 5.21](#) are 5 and 15 cycles respectively (79OI1 = 5 cycles, 79OI2 = 15 cycles). However, the 52BT element setting was not the same in both figures. In [Figure 5.20](#), the 52BT timer was set for five cycles (the same as the first reclose interval). In [Figure 5.21](#), the 52BT timer was set for 10 cycles (longer than the first reclose interval but shorter than the second reclose interval). Note that in [Figure 5.20](#), the 52BT element was asserted for each shot. In [Figure 5.21](#), the 52BT element was only asserted for the second shot. The 52BT element was asserted for both shots in [Figure 5.20](#) because the 52BT timer setting was equal to the first reclose interval.

Remember that the 52BT timer start is keyed by the 52A input state change, while the 79OI timer is keyed by trip output signal deassertion (remember: the 52A input must be present prior to TRIP signal assertion before reclosing is permitted). Because the open interval timer may start after the 52BT timer, a coincidence state may occur. This happens when the 52BT timer tries to start upon 52A contact breaker closure when the open interval timer expires. This chain of events resets the 52BT timer and eliminates use of switch-onto-fault logic. The 52BT element must be asserted high as a conditional for the elements programmed into the MTO logic mask.

A rule of thumb for setting the 52BT timer: when you want switch-onto-fault protection for all shots, set the 52BT element equal to or shorter than the first reclose interval. If you only want switch-onto-fault logic for second or third shots, set the 52BT timer longer than the reclose interval timer for the shot where you do not want switch-onto-fault logic.




Figure 5.20 52BT and 52A Contact Timing Diagram #1




Figure 5.21 52BT and 52A Contact Timing Diagram #2

Example 7: 79RS Timer Eliminates Standing Close

The 79RS element serves three purposes:

- Purpose 1: Resets CLOSE contact after 79RS expires to prevent a standing close condition if the circuit breaker never closes.
- Purpose 2: Resets recloser after 79RS time period.
- Purpose 3: Prevents reclosing sequence if an operator manually closes the circuit breaker into a fault.

The oscillograph in [Figure 5.22](#) demonstrates Purpose 1: the 79RS element resets the CLOSE contact after 60 cycles. In this example, an open in the close coil path prevented circuit breaker closure. The first reclose interval was set for ten cycles. Sixty cycles after CLOSE contact assertion, the 79RS element reset the CLOSE contact. Note that the 52A contact never asserted after opening.




Figure 5.22 79RS Element Reset of the CLOSE Contact

NOTE: The 79RS element begins timing at CLOSE contact closure.

Purpose 3 prevents the SEL-221G Relay recloser from initiating an automatic reclosing sequence after an operator (or SCADA) closes a circuit breaker into a fault. Circuit breaker close control always remains with the local operator. For a period equal to the 79RS timer after manual breaker closure, the recloser is prohibited from operating. If an operator notices a circuit breaker trip, the event report can assist in a decision to manually reclose again.

Table 5.6 Oscillograph Trace Assignments for Figure 5.22

Trace Assignments	Description of Trace
A	Trip
B	Close
C	RI
D	INVERTED 52A Status Input

SEL-221G, -3, -4 Settings Sheets

Substation _____ Circuit _____

Breaker _____ Device # _____

Function _____

Make _____ CT Setting _____

Model/Style # _____ PT Setting _____

Part # _____ Software Version _____

Serial # _____ Power Supply _____ Volts ac/dc _____ Logic Input _____ Vdc

Secondary Inputs: V/φ = 67L-N, nominal amps = 5, Hz = 60

Hexadecimal
Representation

Mask: MTU (Unconditional Trip)

Setting

Row #1: Relay Word Binary Representation	1ABC	2ABC	3ABC	4ABC	LOP	50H	50M	50L	
Row #2: Relay Word Binary Representation	51NT	67N1	67N2	67N3	51NP	Z1P	Z2P	Z3P	
Row #3: Relay Word Binary Representation	Z2PT	Z3PT	OSB	3P50	50MF	RC	RI	DF	
Row #4: Relay Word Binary Representation	ALRM	TRIP	TC	DT	52BT	52AT	Z3GT	Z3GT	

Hexadecimal
Representation

Mask: MPT (Permissive Trip)

Setting

Row #1: Relay Word Binary Representation	1ABC	2ABC	3ABC	4ABC	LOP	50H	50M	50L	
Row #2: Relay Word Binary Representation	51NT	67N1	67N2	67N3	51NP	Z1P	Z2P	Z3P	
Row #3: Relay Word Binary Representation	Z2PT	Z3PT	OSB	3P50	50MF	RC	RI	DF	
Row #4: Relay Word Binary Representation	ALRM	TRIP	TC	DT	52BT	52AT	Z3GT	Z3GT	

Hexadecimal
Representation

Mask: MTB (Block Trip)

Setting

Row #1: Relay Word Binary Representation	1ABC	2ABC	3ABC	4ABC	LOP	50H	50M	50L	
Row #2: Relay Word Binary Representation	51NT	67N1	67N2	67N3	51NP	Z1P	Z2P	Z3P	
Row #3: Relay Word Binary Representation	Z2PT	Z3PT	OSB	3P50	50MF	RC	RI	DF	
Row #4: Relay Word Binary Representation	ALRM	TRIP	TC	DT	52BT	52AT	Z3GT	Z3GT	

									Hexadecimal Representation
Mask: MTO (Switch Onto Fault)									Setting
Row #1: Relay Word Binary Representation	1ABC	2ABC	3ABC	4ABC	LOP	50H	50M	50L	
Row #2: Relay Word Binary Representation	51NT	67N1	67N2	67N3	51NP	Z1P	Z2P	Z3P	
Row #3: Relay Word Binary Representation	Z2PT	Z3PT	OSB	3P50	50MF	RC	RI	DF	
Row #4: Relay Word Binary Representation	ALRM	TRIP	TC	DT	52BT	52AT	Z3GT	Z3GT	

									Hexadecimal Representation
Mask: MA1 (A1 Contact)									Setting
Row #1: Relay Word Binary Representation	1ABC	2ABC	3ABC	4ABC	LOP	50H	50M	50L	
Row #2: Relay Word Binary Representation	51NT	67N1	67N2	67N3	51NP	Z1P	Z2P	Z3P	
Row #3: Relay Word Binary Representation	Z2PT	Z3PT	OSB	3P50	50MF	RC	RI	DF	
Row #4: Relay Word Binary Representation	ALRM	TRIP	TC	DT	52BT	52AT	Z3GT	Z3GT	

									Hexadecimal Representation
Mask: MA2 (A2 Contact)									Setting
Row #1: Relay Word Binary Representation	1ABC	2ABC	3ABC	4ABC	LOP	50H	50M	50L	
Row #2: Relay Word Binary Representation	51NT	67N1	67N2	67N3	51NP	Z1P	Z2P	Z3P	
Row #3: Relay Word Binary Representation	Z2PT	Z3PT	OSB	3P50	50MF	RC	RI	DF	
Row #4: Relay Word Binary Representation	ALRM	TRIP	TC	DT	52BT	52AT	Z3GT	Z3GT	

									Hexadecimal Representation
Mask: MA3 (A3 Contact)									Setting
Row #1: Relay Word Binary Representation	1ABC	2ABC	3ABC	4ABC	LOP	50H	50M	50L	
Row #2: Relay Word Binary Representation	51NT	67N1	67N2	67N3	51NP	Z1P	Z2P	Z3P	
Row #3: Relay Word Binary Representation	Z2PT	Z3PT	OSB	3P50	50MF	RC	RI	DF	
Row #4: Relay Word Binary Representation	ALRM	TRIP	TC	DT	52BT	52AT	Z3GT	Z3GT	

									Hexadecimal Representation
Mask: MA4 (A4 Contact)									Setting
Row #1: Relay Word Binary Representation	1ABC	2ABC	3ABC	4ABC	LOP	50H	50M	50L	
Row #2: Relay Word Binary Representation	51NT	67N1	67N2	67N3	51NP	Z1P	Z2P	Z3P	
Row #3: Relay Word Binary Representation	Z2PT	Z3PT	OSB	3P50	50MF	RC	RI	DF	
Row #4: Relay Word Binary Representation	ALRM	TRIP	TC	DT	52BT	52AT	Z3GT	Z3GT	

									Hexadecimal Representation
Mask: MRI (Reclose Initiative)									Setting
Row #1: Relay Word Binary Representation	1ABC	2ABC	3ABC	4ABC	LOP	50H	50M	50L	
Row #2: Relay Word Binary Representation	51NT	67N1	67N2	67N3	51NP	Z1P	Z2P	Z3P	
Row #3: Relay Word Binary Representation	Z2PT	Z3PT	OSB	3P50	50MF	RC	RI	DF	
Row #4: Relay Word Binary Representation	ALRM	TRIP	TC	DT	52BT	52AT	Z3GT	Z3GT	

									Hexadecimal Representation
Mask: MRC (Reclose Cancel)									Setting
Row #1: Relay Word Binary Representation	1ABC	2ABC	3ABC	4ABC	LOP	50H	50M	50L	
Row #2: Relay Word Binary Representation	51NT	67N1	67N2	67N3	51NP	Z1P	Z2P	Z3P	
Row #3: Relay Word Binary Representation	Z2PT	Z3PT	OSB	3P50	50MF	RC	RI	DF	
Row #4: Relay Word Binary Representation	ALRM	TRIP	TC	DT	52BT	52AT	Z3GT	Z3GT	

Binary	Hexadecimal	ACCESS command passwords: (6 characters excluding space, comma, semicolon, and slash)							
		0000	0	Level 0: =	ACCESS <Enter>		Password: _____		
0001	1	0010	2		Level 1: =>		2ACCESS <Enter>		
0011	3	0100	4		Password: _____		Password: _____		
0101	5	0110	6		Level 2: ==>				
0111	7	1000	8		Enter settings per matrix table.				
1001	9	1010	A						
1011	B	1100	C		NOTE: For new relays, begin with the Level 1 password (OTTER) and Level 2 password (TAIL). When in Level 2, modify passwords via password 1 and 2 commands.				
1101	D	1101	E						
1110	F	1111							

Description	POS-SEQ. IMPEDANCE		ZERO-SEQ. IMPEDANCE		LINE LENGTH*
Range	0–9999 (pri. ohms)		0–9999 (pri. ohms)		0.1–999 mi.
Abbreviated Setting	R1	X1	R0	X0	LL
Description	CT Ratio	PT Ratio	Max. Torque Angle	Enable Fault Locator	
Range	1–5000:1	1–10000:1	47°–90°	(Y or N)	
Abbreviated Setting	CTR	PTR	MTA	LOCAT	
Description	Recl. Open Interval 1	Recl. Open Interval 2	Recl. Open Interval 3	Recl. Reset Time	
Range	0–10000 cycles (1/4 cycle steps)	0–10000 cycles (1/4 cycle steps)	0–10000 cycles (1/4 cycle steps)	60–8000 cycles (1/4 cycle steps)	
Abbreviated Setting	790I1	790I2	790I3	79RS	
Description	Zone 1 Reach	Zone 2 Reach**	Zone 3 Rech.**		
Range	(0.125–64 Ω sec.) 0–2000% of R1 +jX1	(0.125–64 Ω sec.) 0–3200% of R1 +jX1	(0.125–64 Ω sec.) 0–3200% of R1 +jX1		
Abbreviated Setting	Z1%	Z2%	Z3%		
Description	Zone 1 ϕϕ & 3ϕ Timer	Zone 2 ϕϕ & 3ϕ Time-Step Backup Timer	Zone 3 ϕϕ & 3ϕ Time-Step Backup Timer		
Range	0–60 cycles (1/4 cycle steps)	0–2000 cycles (1/4 cycle steps)	0–2000 cycles (1/4 cycle steps)		
Abbreviated Setting	Z1DP	Z2DP	Z3DP		
Description	ϕ O/C Low Set Pickup	ϕ O/C Medium Set Pickup	ϕ O/C LOP Delay (Loss-of-Potential)	ϕ O/C High Set Pickup	
Range	(0.5–40 A sec.) 0.25–50000 A pri.	(0.5–40 A sec.) 0.25–50000 A pri.	0–60 cycles (1/4 cycle steps)	(0.5–80 A sec.) 0.25–50000 A pri.	
Abbreviated Setting	50L	50M	50MFD	50H	
Description	GND Time O/C	GND Time O/C Time Dial	GND Time O/C Curve Shape	GND Time O/C Torque Control	
Range	(0.25–6.3 A sec.) 0.25–50000 A pri.	0.5–15 (0.01 steps)	1, 2, 3, or 4	(Y or N)	
Abbreviated Setting	51NP	51NTD	51NC	51NTC	

Description	Zone 1 GND Inst. O/C ***	Zone 2 GND Inst. O/C ***	Zone 3 GND Inst. O/C ***		
Range	(0–25 A–48x51NP) 0.25–50000 A pri.	(0–25 A–48x51NP) 0.25–50000 A pri.	(0–25 A–48x51NP) 0.25–50000 A pri.		
Abbreviated Setting	50N1P	50N2P	50N3P		
Description	Zone 1 GND Time-Step Backup Timer	Zone 2 GND Time-Step Backup Timer	Zone 3 GND Time-Step Backup Timer	Minimum Trip Duration Timer	
Range	0–60 cycles (1/4 cycle steps)	0–2000 cycles (1/4 cycle steps)	0–2000 cycles (1/4 cycle steps)	0–2000 cycles (1/4 cycle steps)	
Abbreviated Setting	Z1DG	Z2DG	Z3DG	TDUR	
Description	52BT Time Delay	Zone 3 Direction	GND O/C Neg.-Seq. Polar.	GND O/C Zero-Seq. Voltage Polar.	GND O/C Zero-Seq. Current Polar.
Range	0.5–10000 cycles	(F or R)	(Y or N)	(Y or N)	(Y or N)
Abbreviated Setting	52BT	ZONE 3	32QE	32VE	32IE
Description	Out-of-Step Block for Zone 1	Out-of-Step Block for Zone 2	Out-of-Step Block for Zone 3	Out-of-Step Block Timer	Loss-of-Potential Enable
Range	(Y or N)	(Y or N)	(Y or N)	0.5–60 (1/4 cycle steps)	(Y or N)
Abbreviated Setting	OSB1	OSB2	OSB3	OSBT	LOPE
Description	SEL-221G Port #1 Timeout	SEL-221G Port #2 Timeout	Automatic Message Transmit Autoport Selection	# Rings After Which Modem Answers	
Range	0–30 minutes	0–30 minutes	Port 1, 2, or 3 (both)	1–30	
Abbreviated Setting	TIME1	TIME2	AUTO	RINGS	

* Line Length = Station #1 (relay location) to Station #2; the full distance in miles between stations.

NOTE: Length can also be represented in metric units, primary or secondary ohms, etc., but conversion to miles would be required.

** Zones 2 and 3 are limited as follows: ohmic range is 0.125 to 64 Ω secondary.

(a) For Zone 3 Forward: Zone 1 < Zone 2 < Zone 3

(b) For Zone 3 Reverse: Zone 1 < Zone 2 and Zone 1 < Zone 3

*** Lower setting limit for 50N1P, 50N2P, and 50N3P:

0.25 A for $51NP < 3.15$ A secondary

0.5 for $51NP \geq 3.15$ A secondary

Comments: _____

Settings recommended by _____

Settings approved by _____

Settings approved by _____

Settings performed by _____

Test printout req'd Yes No Substation _____

Section 6

Installation

For installation information regarding the SEL-121G, -3, -4 Relay, please see [Installing the SEL-121G, -3, -4 Relay](#). For installation information regarding the SEL-221G, -3, -4 Relay, please see [Installing the SEL-221G, -3, -4 Relay](#).

Installing the SEL-121G, -3, -4 Relay

Mounting

The relay is designed for mounting by its front vertical flanges in a 19" vertical relay rack. It can also be mounted semi-flush in a switchboard panel. Use four #10 screws for mounting. Front- and rear-panel drawings are included in [Figure 6.2](#).

Frame Ground Connection

Terminal 35 or 36 on the rear panel must be connected to frame ground for safety and performance. These terminals connect directly to the chassis ground of the instrument.

Power Connections

Terminals marked 37 and 38 on the rear panel must be connected to a source of control voltage. Control power passes through these terminals to the fuse(s) and a toggle switch, if installed. The power continues through a surge filter and connects to the switching power supply. The control power circuitry is isolated from the frame ground.

Secondary Circuits

The relay presents a very low burden to the secondary potential and current circuits. It requires four-wire wye potentials and three currents from the power system current transformer secondaries.

Control Circuits

The control inputs are dry. For example, to assert the 52A input, you must apply control voltage to the 52A input terminals. Each input is individually isolated, and a terminal pair is brought out for each input. There are no internal connections between control inputs.

Control outputs are dry relay contacts rated for tripping duty. A metal-oxide varistor protects each contact.

Communications Circuits

Connections to the two EIA-232 serial communications ports are made via the two nine-pin connectors labelled PORT 1 and PORT 2 on the rear panel. Pins 1 and 9 connect directly to frame (chassis) ground.

WARNING

Do not rely upon pins 1 and 9 for safety grounding, since their current-carrying capacity is less than control-power short circuit current and protection levels.

The communications circuits are protected by low-energy, low-voltage MOVs and passive RC filters. You can minimize communications-circuit difficulties by keeping the length of the EIA-232 cables as short as possible. Lengths of 12 feet or less are recommended, and the cable length should never exceed 100 feet. Use shielded communications cable for lengths greater than ten feet. Modems are necessary for communications over long distances.

Route the communications cables well away from the secondary and control circuits. Do not bundle the communications wiring with secondary or control circuit wiring. If these wires are bundled, switching spikes and surges can cause noise in the communications wiring. This noise can exceed the communications logic thresholds and introduce errors. The IRIG-B clock cable should also be routed away from the control wiring and secondary circuits.

Jumper Selection

EIA-232 Jumpers

CAUTION

Do not select two baud rates for the same port. This can damage the baud rate generator.

JMP105 provides EIA-232 baud rate selection. Available baud rates are 300, 600, 1200, 2400, 4800, and 9600. To select a baud rate for a particular port, place the jumper so it connects a pin labeled with the port you want to a pin labeled with the baud rate you want.

Password Protection Jumper

Put JMP103 in place to disable password protection. This feature is useful if passwords are not required or when passwords are forgotten.

OPEN/CLOSE Command Enable Jumper

With jumper JMP104 in place, the **OPEN** and **CLOSE** commands are enabled. If you remove jumper JMP104, executing **OPEN** and **CLOSE** commands results in the message: “Aborted.”

Output Contact Soldered Wire Jumpers


All the output contacts except TRIP can be configured as “a” or “b” contacts with soldered wire jumpers K501 through K506 (each jumper has positions A and B). The output contact/soldered wire jumper correspondence is as follows:

Output Contact	Jumper SEL-121G-3,-4
TRIP (terminals 1, 2)	No Jumper
TRIP (terminals 3, 4)	No Jumper
CLOSE	K506
A1	K505
A2	K504
A3	K503
A4	K502
ALARM	K501

EIA-232 and IRIG-B Installation

The following information contains specific details regarding communications port pinouts.

A pin definition of the nine-pin port connectors and cabling information for the EIA-232 ports appears in [Figure 6.1](#). The following cable listings show several types of EIA-232 cables. These and other cables are available from SEL. Cable configuration sheets are also available at no charge for a large number of devices. Contact the factory for more information.



Female chassis connector, as viewed from outside rear panel.

Figure 6.1 Nine Pin Connector Pin Number Convention

EIA-232 Cables

EIA RS-232-C cables

SEL Relay	25-Pin *DTE DEVICE	(SEL CABLE 123)
GND	1	7 GND
TXD	2	3 RXD
RTS	3	5 CTS
RXD	4	2 TXD
CTS	5	4 RTS
+5	6	
+12	7	
-12	8	
GND	9	1 GND
		6 DSR
		8 DCD
		20 DTR

SEL Relay 25-Pin **DCE DEVICE

SEL Relay	25-Pin **DCE DEVICE	(SEL CABLE 422)
GND	1	7 GND
TXD	2	2 RXD
RTS	3	20 DTR
RXD	4	3 TXD
CTS	5	8 CD
GND	9	1 GND

SEL Relay 9-Pin *DTE DEVICE

SEL Relay	9-Pin *DTE DEVICE	(SEL CABLE 134)
GND	1	5 GND
TXD	2	2 RXD
RTS	3	8 CTS
RXD	4	3 TXD
CTS	5	7 RTS
		1 DCD
		4 DIR
		6 DSR
		9 RI

SEL Relay PRTU

SEL Relay	PRTU	(SEL CABLE 331A - 338A)
GND	1	1 GND
TXD	2	4 RXD
RXD	4	2 TXD
CTS	5	7 +12
+12	7	5 CTS
GND	9	9 GND

* DTE = Data Terminal Equipment (Computer, Terminal, Printer, etc.)

* DCE = Data Communications Equipment (Modem, etc.)

IRIG-B Input Description

The port labelled J201 / AUX INPUT receives demodulated IRIG-B input. Pin definitions appear in [Table 6.1](#).

Table 6.1 AUX INPUT Pin Definitions

Pin	Name	Description
2	IRIGIN HI	Positive IRIGB input
3	IRIGIN LOW	Negative IRIGB input
6	+5*	
7	+12*	
8	-12*	
1, 5, 9	GND	Ground

*Consult the factory before using these power supply outputs

The actual IRIG-B input circuit is a $56\ \Omega$ resistor in series with an optocoupler input diode. The input diode has a forward drop of about 1.5 V. Driver circuits should put approximately 10 mA through the diode when “on.”

The IRIG-B serial data format consists of a one-second frame containing 100 pulses and divided into fields. The relay decodes the second, minute, hour, and day fields and sets the internal relay clock accordingly.

When IRIG-B data acquisition is activated either manually (with the **IRIG** command) or automatically, two consecutive frames are taken. The older frame is updated by one second, and the two frames are compared. If they do not agree, the relay considers the data erroneous and discards the information.

The relay reads the time code automatically about once every five minutes. The relay stops IRIG-B data acquisition ten minutes before midnight on New Year’s Eve, so the relay clock can implement the year change without interference from the IRIG-B clock. Ten minutes after midnight, the relay restarts IRIG-B data acquisition.

Installation Checkout

You can perform the following suggestions or combine them with your standard procedures. Never implement recommendations prohibited by the rules of your normal practice.

The following equipment is necessary for initial checkout:

- portable terminal or computer
- control power to the relay power connections
- source of three-phase voltages and at least one current source
- ohmmeter or contact opening/closing sensing device

1. Apply control power and make sure the terminal displays the startup message. If not, set AUTO = 2 with the **SET** command in Access Level 2. Check the settings with the **ACCESS** and **SHOWSET** commands. Use the **TIME** command to set the clock. Note that the A2 relay is closed because of the loss-of-potential condition.
2. Apply three-phase voltages in positive-sequence rotation. Execute the **METER** command and make sure the readings are

accurate. If they are not, be sure the correct PT ratio was entered. Remember that displayed values are in primary line-to-neutral and line-to-line kV.

3. Use the **TRIGGER** command to generate an event record. Type **EVENT 1 <ENTER>** and examine the event record. Refer to the top row of data as the “Y” components and the next row as the “X” components. Plot the three voltage phasors to ensure that they are 120 degrees apart, of reasonable magnitudes, and rotating in the positive-sequence direction. The zero-sequence voltage Y and X components (times a factor of three) are the totals of the three Y components and the three X components. These sums should be near zero if balanced three-phase potentials are present. See the SEL Direction and Polarity Check Form at the end of this section for this purpose.
4. Use the **TARGET** command to check the state of all contact inputs and outputs.
5. Proceed to Access Level 2 with the **2ACCESS** command and second password. Be sure the ALARM relay contacts close and open when the relay executes **2ACCESS**. The ALARM pulse will not be detectable if the ALARM contacts are closed because of an alarm condition.
6. Test the tripping function in three ways. First, be sure the circuit breaker can be tripped by **OPEN** command execution. Verify that the TC bit is set in the MTU mask. Second, the circuit breaker can be tripped by DIRECT TRIP input assertion if the DT bit is selected in the MTU mask. Third, the circuit breaker can be tripped by applying voltages and currents representing a fault condition for which the relay should respond. Here, the TRIP relay closes regardless of the 52A contact state. It opens when there are no currents above the 50L condition, zero-sequence current is below the 50NL threshold, and fault conditions no longer exist. The TRIP output always remains closed for at least the TDUR setting.
7. There are three ways the circuit breaker is closed: by **CLOSE** command execution, a reclose attempt by the reclosing relay, or DIRECT CLOSE input assertion. The CLOSE output relay closes for all of these conditions if the 52A input is not asserted (indicating the circuit breaker is open) and no trip condition is present. The CLOSE relay opens when the 52A input is asserted or the 79RS timer expires, whichever occurs first.
8. If the Permissive Trip and Block Trip inputs are used, check them for proper operation (see the LOGIC MPT and LOGIC MTB settings in [Section 3: Communications](#)). An event record should be generated after PT input assertion.
9. Assert the External Trigger input. This should trigger an event record, without affecting the protective relaying functions in any way.
10. Use the **STATUS** command to inspect the self-test status. You may want to save the reading as part of an “as-left” record.

When local checkout is complete, check communications with the instrument via a remote interface (if used). Make sure the automatic port is properly assigned and that you have selected the timeout intervals you want for each port. Also be certain to record password settings.

**6.6 | Installation
Installation Checkout**





Figure 6.2 Horizontal Front- and Rear-Panel Drawings



DWG. 1016-103

Figure 6.3 Vertical Front- and Rear-Panel Drawings

6.8 | Installation
Installation Checkout




Figure 6.4 Relay Dimensions, Panel Cutout, and Drill Plan




Figure 6.5 Communications and Clock Connections - One Unit at One Location




Figure 6.6 Communications and Clock Connections - Multiple Units at One Location




Figure 6.7 SEL Relay Communications Diagram for Connection to the SEL-DTA




Figure 6.8 External AC Current and Voltage Connections




Figure 6.9 External DC Connection Diagram (Typical)

Installing the SEL-221G, -3, -4 Relay

Mounting

The relay is designed for mounting by its front vertical flanges in a 19" vertical relay rack. It can also be mounted semi-flush in a switchboard panel. Use four #10 screws for mounting. Front- and rear-panel drawings are included in this manual.

Frame Ground Connection

The terminal marked GND on the rear panel must be connected to frame ground for safety and performance. This terminal connects directly to the chassis ground of the instrument.

Power Connections

Terminals marked + and – on the rear panel must be connected to a source of control voltage. Control power passes through these terminals to the fuse(s) and a toggle switch, if installed. The power continues through a surge filter and connects to the switching power supply. The control power circuitry is isolated from the frame ground.

Secondary Circuits

The relay presents a very low burden to the secondary potential and current circuits. It requires four-wire wye potentials and three currents from the power system current transformer secondaries.

Control Circuits

The control inputs are dry. For example, to assert the 52A input, you must apply control voltage to the 52A input terminals. Each input is individually isolated, and a terminal pair is brought out for each input. There are no internal connections between control inputs.

Control outputs are dry relay contacts rated for tripping duty. A metal-oxide varistor protects each contact.

Communications Circuits

WARNING

Do not rely upon pins 5 and 9 for safety grounding, since their current-carrying capacity is less than control power short circuit current and protection levels.

Connections to the two EIA-232 serial communications ports are made via the two nine-pin connectors labelled PORT 1 and PORT 2 on the rear panel and PORT 2F on the front panel. Pins 5 and 9 connect directly to frame (chassis) ground.

The communications circuits are protected by low-energy, low-voltage MOVs and passive RC filters. You can minimize communications-circuit difficulties by keeping the length of the EIA-232 cables as short as possible. Lengths of 12 feet or less are recommended, and the cable length should never exceed 100 feet. Use shielded communications cable for lengths greater than ten feet. Modems are necessary for communications over long distances.

Route the communications cables well away from the secondary and control circuits. Do not bundle the communications wiring with secondary or control circuit wiring. If these wires are bundled, switching spikes and surges can cause noise in the communications wiring. This noise can exceed the communications logic thresholds and introduce errors. The IRIG-B clock cable should also be routed away from the control wiring and secondary circuits.

Jumper Selection

All jumpers are on the front edge of the main board. They are easily accessed by removing the top cover or front panel.

EIA-232 Jumpers

CAUTION

Do not select two baud rates for the same port. This can damage the baud rate generator.

JMP105 provides EIA-232 baud rate selection. Available baud rates are 300, 600, 1200, 2400, 4800, and 9600. To select a baud rate for a particular port, place the jumper so it connects a pin labeled with the desired port to a pin labeled with the desired baud rate.

Password Protection Jumper

Put JMP103 in place to disable password protection. This feature is useful if passwords are not required or when passwords are forgotten.

OPEN/CLOSE Command Enable Jumper

With jumper JMP104 in place, the **OPEN** and **CLOSE** commands are enabled. If you remove jumper JMP104, executing **OPEN** and **CLOSE** commands results in the message: "Aborted."

A4 Output Contact Jumper (SEL-221G-3, -4 only)

With jumper JMP3 in the A4 position, the A4 output contact operates per logic mask MA4. With jumper JMP3 in the ALARM position, the A4 output contact operates with the ALARM output contact.

Output Contact Soldered Wire Jumpers

All the output contacts can be configured as "a" or "b" contacts with soldered wire jumpers JMP4 through JMP11 (each jumper has positions A and B). The output contact/soldered wire jumper correspondence is as follows:

Output Contact	Jumper SEL-221G-3,-4	Jumper SEL-121G-3,-4
TRIP (terminals 1, 2)	JMP11	No Jumper
TRIP (terminals 3, 4)	JMP10	No Jumper
CLOSE	JMP9	K506
A1	JMP8	K505
A2	JMP7	K504
A3	JMP6	K503
A4	JMP5	K502
ALARM	JMP4	K501

Communication Port External Power Jumpers (SEL-221G-3, -4 only)

DC power is available from Port 1 and Port 2R to power external devices. Jumpers must be selected to route dc power to the rear-panel connectors. The internal jumpers are near Port 1 and are labeled as follows: JMP12 = +5 V; JMP13 = +12 V; JMP14 = -12 V. Use caution to ensure the dc current requirement of the external equipment does not exceed the relay power supply specifications. Only route dc power to the rear ports if required for your application.

Jumper Installation Instructions

The power available from these ports is limited and should be used only for SEL-RDs, SEL-DTAs, dc-powered modems, or other low-wattage devices approved by SEL.

The power is available on either Port 1 or Port 2R. Port 2F, located on the front of the relay, does NOT have power available.

To install jumpers for supplying power through the rear EIA-232 ports, perform the following steps:

1. Remove the relay top cover or withdraw the main circuit board.
2. Locate jumpers JMP12 (+5 Vdc), JMP13 (+ 12 Vdc) and JMP14 (-12 Vdc) near the AUX INPUT connector.
3. Remove and install the needed jumpers in the “on” position.
4. Replace the top cover or reinsert the main circuit board.
(Ensure that the board is correctly seated and the cables to the power supply and input transformers are reconnected.)

EIA-232 and IRIG-B Installation

The following information contains specific details regarding communications port pinouts.

A pin definition of the nine-pin port connectors and cabling information for the EIA-232 ports appears in [Figure 6.10](#). The following cable listings show several types of EIA-232 cables. These and other cables are available from SEL. Cable configuration sheets are also available at no charge for a large number of devices. Contact the factory for more information.




Figure 6.10 Nine Pin Connector Pin Number Convention

EIA-232 Cables

SEL-221G = 9-PIN DTE DEVICE (connected to host)

GND	5	5	GND
TXD	3	2	RXD
RXD	2	3	TXD
RTS	7		(SEL CABLE 234A)
CTS	8		

Jumper

1	DCD
4	DTR
6	DSR
8	CTS
9	RI

Jumper

SEL-221G = 9-PIN DCE DEVICE (connected to host)

GND	5	7	GND
TXD	3	2	RXD
RTS	7	20	DTR
RXD	2	3	TXD
CTS	8	8	CD
GND	9	1	GND

(SEL CABLE 222)

PRTU	SEL-221G
GND	1
TXD	2
RXD	4
CTS	5
+12	7
GND	9
	5 GND
	2 RXD
	3 TXD
	7 RTS
	8 CTS
	9 GND

(SEL CABLE 231)

* DTE = Data Terminal Equipment (Computer, Terminal, Printer, etc.)

* DCE = Data Communications Equipment (Modem, etc.)

The port labelled J201 / AUX INPUT receives demodulated IRIG-B input.
Pin definitions appear in [Table 6.2](#).

Table 6.2 Pin Definitions

Pin	Name	Description
1	+5	*
2	IRIGIN HI	Positive IRIGB input
3	IRIGIN LOW	Negative IRIGB input
4	+12	*
6	-12	*
5,9	GND	Ground for ground wires and shields

*Consult the factory before using these power supply outputs

The actual IRIG-B input circuit is a $56\ \Omega$ resistor in series with a optocoupler input diode. The input diode has a forward drop of about 1.5 V. Driver circuits should put approximately 10 mA through the diode when “on.”

The IRIG-B serial data format consists of a one-second frame containing 100 pulses and divided into fields. The relay decodes the second, minute, hour, and day fields and sets the internal relay clock accordingly.

When IRIG-B data acquisition is activated either manually (with the **IRIG** command) or automatically, two consecutive frames are taken. The older frame is updated by one second, and the two frames are compared. If they do not agree, the relay considers the data erroneous and discards the information.

The relay reads the time code automatically about once every five minutes. The relay stops IRIG-B data acquisition ten minutes before midnight on New Year’s Eve, so the relay clock can implement the year change without interference from the IRIG-B clock. Ten minutes after midnight, the relay restarts IRIG-B data acquisition.

Installation Checkout

You can perform the following suggestions or combine them with your standard procedures. Never implement recommendations prohibited by the rules of your normal practice.

The following equipment is necessary for initial checkout:

- portable terminal or computer
- control power to the relay power connections
- source of three-phase voltages and at least one current source
- ohmmeter or contact opening/closing sensing device

1. Apply control power and make sure the terminal displays the startup message. If not, set AUTO = 2 with the **SET** command in Access Level 2. Check the settings with the **ACCESS** and **SHOWSET** commands. Use the **TIME** command to set the clock. Note that the A2 relay is closed because of the loss-of-potential condition.
2. Apply three-phase voltages in positive-sequence rotation. Execute the **METER** command and make sure the readings are accurate. If they are not, be sure the correct PT ratio was

entered. Remember that displayed values are in primary line-to-neutral and line-to-line kV.

3. Use the **TRIGGER** command to generate an event record. Type **EVENT 1 <ENTER>** and examine the event record. Refer to the top row of data as the “Y” components and the next row as the “X” components. Plot the three voltage phasors to ensure that they are 120 degrees apart, of reasonable magnitudes, and rotating in the positive-sequence direction. The zero-sequence voltage Y and X components (times a factor of three) are the totals of the three Y components and the three X components. These sums should be near zero if balanced three-phase potentials are present. See the SEL Direction and Polarity Check Form at the end of this section for this purpose.
4. Use the **TARGET** command to check the state of all contact inputs and outputs.
5. Proceed to Access Level 2 with the **2ACCESS** command and second password. Be sure the ALARM relay contacts close and open when the relay executes **2ACCESS**. The ALARM pulse will not be detectable if the ALARM contacts are closed because of an alarm condition.
6. Test the tripping function in three ways. First, be sure the circuit breaker can be tripped by **OPEN** command execution. Verify that the TC bit is set in the MTU mask. Second, the circuit breaker can be tripped by DIRECT TRIP input assertion if the DT bit is selected in the MTU mask. Third, the circuit breaker can be tripped by applying voltages and currents representing a fault condition for which the relay should respond. Here, the TRIP relay closes regardless of the 52A contact state. It opens when there are no currents above the 50L condition, zero-sequence current is below the 50NL threshold, and fault conditions no longer exist. The TRIP output always remains closed for at least the TDUR setting.
7. There are three ways the circuit breaker is closed: by **CLOSE** command execution, a reclose attempt by the reclosing relay, or DIRECT CLOSE input assertion. The CLOSE output relay closes for all of these conditions if the 52A input is not asserted (indicating the circuit breaker is open) and no trip condition is present. The CLOSE relay opens when the 52A input is asserted or the 79RS timer expires, whichever occurs first.
8. If the Permissive Trip and Block Trip inputs are used, check them for proper operation (see the LOGIC MPT and LOGIC MTB settings in [Section 3: Communications](#)). An event record should be generated after PT input assertion.
9. Assert the External Trigger input. This should trigger an event record, without affecting the protective relaying functions in any way.
10. Use the **STATUS** command to inspect the self-test status. You may want to save the reading as part of an “as-left” record.

When local checkout is complete, check communications with the instrument via a remote interface (if used). Make sure the automatic port is properly assigned and that you have selected the timeout intervals you want for each port. Also be certain to record password settings.





Figure 6.11 Horizontal Front- and Rear-Panel Drawings



NOTE:

1. ALL TOLERANCES ARE $\pm 0.020"$ (0.51mm)
2. TO DETERMINE THE CUTOUT DIMENSIONS CONSIDER BOTH SEL'S SPECIFIED TOLERANCE AND THE CUSTOMER'S ALLOWED TOLERANCE.
3. DRAWING NOT TO SCALE
4. SLP DIMENSIONS APPLY TO THE FOLLOWING SEL DEVICES:
 - a) ALL SEL-200 SERIES RELAYS EXCEPT FOR LP RELAYS WHICH INCLUDE:
279, 279H (1 Amp or 5 Amp), 251, 251C and 267-4 (1 Amp only)
 - b) ALL SEL-300 SERIES RELAYS EXCEPT 321 RELAYS
 - c) SEL-2020 and 2030

DWG. 11367
DATE: 12 AUG 98

Figure 6.12 Relay Dimensions and Drill Plan




Figure 6.13 Communications and Clock Connections – One Unit at One Location




Figure 6.14 Communications and Clock Connections – Multiple Units at One Location




Figure 6.15 SEL Relay Communications Diagram for Connection to the SEL-DTA




Figure 6.16 External AC Current and Voltage Connections




Figure 6.17 External DC Connection Diagram (Typical)

This page intentionally left blank

SEL DIRECTION AND POLARITY CHECK FORM



Station: _____ Date: _____ Tested By: _____
 Switch No.: _____ Equipment: _____
 Installation: _____ Routine: _____ Other: _____

Load Conditions

Station Readings: MW (OUT)(IN) _____ MVAR (OUT)(IN) _____ Volts _____ Amps _____
 SEL Readings: MW (+)(-) _____ MVAR(+)(-) _____

As Seen on Screen	Ia	Ib	Ic	Va	Vb	Vc	
Company Notation	I()	I()	I()	I()	I()	I()	
1st Line Chosen (Y Component)							
2nd Line Chosen (X Component)							
Calculated Magnitude $\sqrt{X^2 + Y^2}$							Row 1
Angle in Degrees Arctan Y/X							
Value of Va Degrees to Subtract to Obtain Va Degrees = 0							
@ Va Degrees = 0, Angle Used to Draw Phasor Diagram							Row 2

Use the values in Rows 1 and 2 above to draw phasor diagrams below.



This page intentionally left blank

SEL DIRECTION AND POLARITY CHECK FORM



Station: _____ Date: _____ Tested By: _____
 Switch No.: _____ Equipment: _____
 Installation: _____ Routine: _____ Other: _____

Load Conditions

Station Readings: MW (OUT)(IN) _____ MVAR (OUT)(IN) _____ Volts _____ Amps _____
 SEL Readings: MW (+)(-) _____ MVAR(+)(-) _____

As Seen on Screen	I_a	I_b	I_c	V_a	V_b	V_c	
Company Notation	I()	I()	I()	I()	I()	I()	
1st Line Chosen (Y Component)							
2nd Line Chosen (X Component)							
Calculated Magnitude $\sqrt{X^2 + Y^2}$							Row 1
Angle in Degrees Arctan Y/X							
Value of V _a Degrees to Subtract to Obtain V _a Degrees = 0							
@ V _a Degrees = 0, Angle Used to Draw Phasor Diagram							Row 2

Use the values in Rows 1 and 2 above to draw phasor diagrams below.



This page intentionally left blank

Section 7

Maintenance & Testing

Test Procedures

Test Aids Provided by the Relay

The following features assist you during relay testing and calibration.

METER Command	The METER command shows the voltages and currents presented to the relay in primary values. The relay calculates Megawatts (MW) and Megavars (MVAR) from these voltages and currents. These quantities are useful for comparing relay calibration against other meters of known accuracy. When testing the relay, first verify relay calibration. Consider all tests invalid if you determine that the relay is out of calibration. Each relay is calibrated at the factory prior to shipment and should not require further adjustments. If calibration is necessary, refer to <i>Calibration</i> .
TARGET Command	The relay allows you to reassign front-panel targets to indicate elements and intermediate logic results in the Relay Word as well as input and output contact status. Use the TARGET command to reassign the front-panel LEDs. Once target LEDs are reassigned from the default targets, the front-panel targets are no longer latching. This means the targets follow the pickup and dropout condition in much the same manner as an output contact. See <i>TARGET n k on page 3.13</i> for more information about the TARGET command. By using the target LEDs for testing, you need not change the relay settings during testing.
Event Reporting	The relay generates an 11-cycle event report in response to faults or disturbances. Each event report contains voltage and current information, relay element states, and input/output contact information in quarter-cycle resolution. If you question the relay response or your test method, use the event report for more information. Each event report is date and time tagged relative to the 16th quarter cycle. Each report is triggered upon assertion of designated relay elements and/or contact inputs and outputs. If the timeout of a protective element results in TRIP output contact closure, the trip generates a second event report. Thus, the relay generates two event reports: the first when the instantaneous element asserts, the second when the TRIP output contact closes. Where time-delayed pickup (TDPU) timers are concerned, the time tag in the event reports can be used to determine the validity of a TDPU timer setting. Simply subtract the latest event report time tag from the previous event report time tag. <i>Event Reporting on page U.2.5</i> has further details concerning event report generation.
Programmable Logic	Programmable logic allows you to isolate individual relay elements. See <i>LOGIC n on page 3.15</i> for further details.

Test Methods

There are two means of determining the pickup and dropout of relay elements: target lamp illumination and output contact closure.

Testing Via Target LED Illumination

During testing, you can use target lamp illumination to determine relay element status. Using the **TARGET** command, set the front-panel targets to display the element under test. For example, the Zone 1 three-phase distance element appears in Relay Word Row 1. When you type the command **TARGET 1 <ENTER>**, the LEDs display the status of the elements in Relay Word Row 1. Thus, with Target 1 displayed, if the Zone 1 three-phase distance element (1ABC) asserts, the left-most LED illuminates. Using LED illumination as an indicator, you can measure the element operating characteristics.

When the **TARGET** command sets the target LED output to a level other than 0 (Relay Targets), the front-panel target markings are no longer relative to illuminated LEDs and the LEDs do not latch.

If you place the relay in service with the target level other than Level 0, it automatically reverts to target Level 0 when an automatic message transmits to a timed-out port. While this feature prevents confusion among station operators and readers, it can be inconvenient if the relay tester does not want targets to revert to Level 0. Targets remain in the specified level if you set the communications port AUTO setting timeout equal to 0. This prevents automatic message transmission to a port that may be timed out.

Testing Via Output Contact Assertion

To test using this method, set one programmable output contact to assert when the element under test picks up. With the **LOGIC [N]** command, set a 1 in the mask for the element under test. Set all other elements in that mask to 0.

For an “a” contact, when the condition asserts, the output contact closes. When the condition deasserts, the output contact opens. For a “b” contact, when the condition asserts, the output contact opens. When the condition deasserts, the output contact closes. Programmable contacts can be specified at the factory as either an “a” or “b.” Using contact operation as an indicator, you can measure element operating characteristics, stop timers, etc.

Tests in this chapter use the output contact method and assume an “a” output contact.

Using a Breaker Simulator

Because the switch-onto-fault and recloser logic depend on whether the breaker is open (52A deenergized) or closed (52A energized), it is important to use a breaker simulator for these tests. We recommend testing the relay with a latching relay to simulate line breaker auxiliary contact action. This ensures proper assertion and deassertion of the 52A input contact on the back panel. If you do not have a means of simulating breaker action and status, zero out the MTO logic mask and omit the recloser tests.

Initial Checkout

The initial checkout procedure should familiarize you with the relay and ensure that all functions are operational. For a complete understanding of the relay capabilities, study [Functional Specifications on page U.2.2](#) and [Functional Description on page U.2.23](#), [Command Descriptions on page 3.6](#), and [Section 4: Event Reporting](#).

Minimum Equipment Required

The following equipment is necessary for initial checkout.

1. Terminal with EIA-232 serial interface
2. Interconnecting cable between terminal and relay
3. Source of control power
4. Source of three-phase voltages and at least two currents
5. Ohmmeter or contact opening/closing sensing device

Checkout Procedure

In the procedure below, you will use several relay commands. [Section 3: Communications](#) provides a full explanation of all commands. The following information should allow you to complete the checkout without referring to the detailed descriptions in [Section 3](#).

In this manual, commands to type appear in bold/uppercase: **OTTER**. Keys to press appear in bold/uppercase/brackets: <**ENTER**>.

Relay output appears in the following format:

Example 2230 kV Line Date: 1/1/90 Time: 01:01:01

Step 1

Purpose: Be sure you received the relay in satisfactory condition.

Method: Inspect the instrument for physical damage such as dents or rattles.

Step 2

Purpose: Verify the requirements for the relay logic inputs, control power voltage level, and voltage and current inputs.

Method: Refer to the information sticker on the rear panel of the relay. [Figure 7.1](#) provides an example. It is important that you read the information on this sticker before applying power to the relay or starting tests. Be sure your dc supply is correctly adjusted for the control and logic input requirements.




Figure 7.1 Relay Part Number and Hardware Identification Sticker

Step 3

Purpose: Verify the communications interface setup.

Method: Connect a computer terminal to PORT 2 on the relay front or rear panel. The terminal should be configured to 2400 baud, eight data bits, and no parity. The terminal should be set to two stop bits for standard (-E2) versions, or one stop bit for special-ordered (-E1) relays. The relay is shipped from the factory with PORT 2 set to 2400 baud and PORT 1 set to 300 baud.

Section 3: Communications provides additional information about port configurations. Baud rate selection is described under [Jumper Selection on page 6.12](#). *Figure 7.2* shows the typical communication interface setup for testing purposes.




Figure 7.2 Communication Interface Setup

Step 4

Purpose: Establish control power connections.
Method: Connect a frame ground to the terminal marked GND on the rear panel and connect rated control power to the + and - terminals. Polarity is unimportant. Relays supplied with 125 or 250 V power supplies can be powered from a 115 Vac wall receptacle for testing. In the final installation, we recommend that the relay receive control power from the station dc battery to avoid losing events stored in volatile memory when station service is lost.

Step 5

Purpose: Apply control voltage to the relay and start Access Level 0 communications.
Method: Turn on the relay power. The enable target (EN) should illuminate. If not, be sure that power is present and check the fuse or fuses. The following message should appear on the terminal:

```
Example 230 kV Line          Date: 1/1/90    Time: 01:01:01
SEL-121G
=
```

The ALARM relay should pull in, holding its "b" contacts open. Because the LOP bit of the MA4 mask is set, output relay A4 (set to follow LOP) should remain closed until the loss-of-potential problem is rectified. If the relay pulls in but no message is received, check the terminal configuration. If neither occurs, turn off the power and refer to [Troubleshooting](#).

The = prompt indicates that communications with the relay are at Access Level 0, the first of three levels. The only command accepted at this level is **ACCESS**, which opens communications on Access Level 1.

NOTE: If you are using a battery simulator, be sure the simulator voltage level is stabilized before turning the relay on. This ensures that the relay power supply self-test procedure is not confused by the current-limiting action of the battery simulator.

Step 6

Purpose: Establish Access Level 1 communications.
Method: Type **ACCESS** and press **<ENTER>**. At the prompt, enter the Access Level 1 password **OTTER** and press **<ENTER>**. The => prompt should appear, indicating that you have established communications at Access Level 1.

Step 7

Purpose: Verify self-test status of the relay.
 Method: Type **STATUS** and press <ENTER>. The following display should appear on the terminal:

```
Example 230 kV Line          Date: 1/1/90      Time: 01:04:56
SELF TESTS
W=Warn   F=Fail
OS     IP     IR     IA     IB     IC     VA     VB     VC
OS     0      0      0      0      0      0      0      0
PS     5.08   14.92  -14.99
RAM   ROM    A/D    MOF    SET
OK    OK     OK     OK     OK
=>
```

Step 8

Purpose: View the demonstration settings entered before shipment.
 Method: The relay is shipped with demonstration settings; type **SHOWSET <ENTER>** to view the settings. The terminal should display the following:

```
Settings for: Example 230 kV Line
R1 =8.56   X1 =77.77   R0 =35.12   X0 =236.96   LL =100.00
CTR =200.00 PTR =2000.00 MTA =83.72   LOCAT=Y
790I1=40.00 790I2=60.00 790I3=80.00 79RS =240.00
Z1% =80.00 Z2% =120.00 Z3% =120.00
Z1DP =0.00 Z2DP =20.00 Z3DP =60.00
50L =275.00 50M =500.00 50MFD=20.00 50H =3420.00
51NP =230.00 51NTD=4.00 51NC =3   51NTC=Y
50N1P=835.00 50N2P=276.00 50N3P=282.00
Z1DG =0.00 Z2DG =30.00 Z3DG =60.00 TDUR =9.00
52BT =20.00 ZONE3=R 32QE =Y 32VE =N 32IE =N
OSB1 =Y OSB2 =Y OSB3 =Y OSBT =30.00 LOPE =Y
TIME =5 TIME2=0 AUTO =2 RINGS=7
=>
```

SET n on page 3.18 and *LOGIC n on page 3.15* provide complete explanation of the settings.

Each column in the logic settings display shows masks for the four rows of the Relay Word as follows:

Relay Word Row 1	1ABC	2ABC	3ABC	4ABC	LOP	50H	50M	50L
Relay Word Row 2	51NT	67N1	67N2	67N3	51NP	Z1P	Z2P	Z3P
Relay Word Row 3	Z2PT	Z3PT	OSB	3P50	50MF	RC	RI	DF
Relay Word Row 4	ALRM	TRIP	TC	DT	52BT	52AT	Z2GT	Z3GT

Logic settings appear in hexadecimal format. A table and example of hexadecimal-to-binary conversion appears with the **SHOWSET** command description in *SHOWSET on page 3.10*.

Step 9

- Purpose: Connect voltage and current sources to the relay.
- Method: Turn power off and connect a source of three-phase voltages to the relay at terminals VA, VB, VC, and VN (See [Figure 7.9](#)). Apply 67 V per phase (line-to-neutral) in positive-sequence rotation. Wye-connect the two current sources as shown in [Figure 7.9](#) to generate balanced positive-sequence currents:
1. Connect the A ϕ and B ϕ current sources to the dotted A and B current input terminals.
 2. Connect both undotted A and B current input terminals to the undotted C current input terminal.
 3. Connect the dotted C current input terminal to both the A and B current source returns.
 4. Set the A-phase current source to 2 A, at the same angle as the A-phase voltage. Set the B-phase current source to 2 A, at the same angle as the B-phase voltage.

Step 10

- Purpose: Verify that a loss-of-potential condition is not present with balanced three-phase voltages applied to the relay.
- Method: Turn the relay power on and enter Access Level 1. With balanced positive-sequence potentials applied to the relay, the A4 relay should open.

Step 11

- Purpose: Verify correct voltage and current connections and levels.
- Method: Use the **METER** command to measure the voltages and currents applied in Step 9. With applied voltages of 67 V per phase and a potential transformer ratio of 2000:1, the displayed line-to-neutral voltages should be 134 kV. With applied currents of 2.0 A per phase and a current transformer ratio of 200:1, the displayed line-to-neutral currents should be 400 A. All line-to-line quantities should be balanced, differing from the line-to-neutral measurements by a factor of 1.73. Real power P should be approximately 160.1 MW; reactive power Q should be approximately 0 MVAR.

```
=>METER <ENTER>
Example 230kV Line          Date: 01/01/90      Time: 00:01:00
          A            B            C            AB           BC           CA
I (A)    401          398          399          695          690          691
V (kV)   134.4       134.4       134.4       233.1       232.8       232.9
          P (MW)        161.01
          Q (MVAR)       1.02
=>
```

If you inadvertently switched a pair of voltages or currents, the MW reading should be near zero.

Step 12

NOTE: To simplify this step, apply rated logic voltage across the 52A input prior to applying each fault. These inputs should remain energized for the duration of this step to block the switch-onto-fault (mho) and block trip (MTB) logic from operating. If a circuit breaker simulator is unavailable, set all elements in the MTO logic mask to zero.

Purpose: Test the fault locator.
Method: Test the fault locator, using the voltages and currents in [Table 7.1](#). These voltages and currents were obtained for various locations and fault types, assuming a radial line with a source impedance of 0.42 times the total 100-mile line impedance. A listing of this BASIC program is included at the end of this section.

Table 7.1 Fault Locator Test Values

Location	Type	VA	VB	VC	IA	IB	IC	Units
75 miles (forward direction fault)	AG	42.95	72.14	72.66	4.34	0.00	0.00	V or A Degrees
		0.00	-126.9	126.6	-82.4	0.00	0.00	
	BC	67.00	50.06	50.06	0.00	6.34	6.34	V or A Degrees
		0.00	-132.0	132.0	0.00	-173.7	6.3	
85 miles (forward direction fault)	AG	44.84	71.70	72.18	4.00	0.00	0.00	V or A Degrees
		0.00	-126.4	126.1	-82.4	0.00	0.00	
	BC	67.00	51.29	51.29	0.00	5.84	5.85	V or A Degrees
		0.00	-130.8	130.8	0.00	-173.7	6.3	
-85 miles (reverse direction fault)	AG	44.84	71.70	72.18	4.00	0.00	0.00	V or A Degrees
		0.00	-126.4	126.1	97.6	0.00	0.00	
	BC	67.00	51.29	51.29	0.00	5.84	5.84	V or A Degrees
		0.00	-130.8	130.8	0.00	6.3	-173.7	

Faults at 75 miles are within Zone 1, because the Zone 1 reach setting is 80 percent of the 100-mile positive-sequence line impedance (see Z1% in the settings). Faults at 85 miles are beyond Zone 1, but they are within the 120 percent setting of Zone 2 (see Z2% in the settings). Faults at -85 miles are behind the relay terminal and within Zone 3. These are set to 120 percent (see Z3% in the settings).

[Table 7.1](#) lists faults that cause certain combinations of output relays to close and front-panel LEDs to illuminate. [Table 7.2](#) shows the results. Please remember to press the target reset button between faults. Also note that these tests assume you are using a breaker simulator. If you are not using a breaker simulator, remember to zero out the MTO logic mask.

Table 7.2 Output Contact and Target LED Results

Location	Type	Output Relays	Target LED
75 mi	AG	TRIP, A2	G1, G2
75 mi	BC	TRIP, A2	$\phi 1, \phi 2$
85 mi	AG	TRIP, A2	G1, G2
85 mi	BC	TRIP, A2	$\phi 2$
-85 mi	AG	TRIP, A1	G3
-85 mi	BC	TRIP, A1	$\phi 3$

Output Contact Explanation.

The TRIP output closes in response to any of the following:

1. Any Zone 1 3 ϕ , ϕ - ϕ , or line-to-ground fault
2. Any Zone 2 3 ϕ or ϕ - ϕ fault that persists for 20 cycles
3. Any Zone 2 line-to-ground fault that persists for 30 cycles
4. Any Zone 3 3 ϕ or ϕ - ϕ fault that persists for 60 cycles
5. Any Zone 3 line-to-ground fault that persists for 60 cycles
6. Any forward line-to-ground fault that results in expiration of the residual time-overcurrent element (51NT)
7. Any overcurrent condition where the current exceeds the 50M threshold for 50MFD time following a loss-of-potential condition
8. DT input assertion
9. **OPEN** command execution

The A1 output relay is set to close for any Zone 3 fault. As [Table 7.2](#) shows, output relay A1 should close for all reverse faults.

The A2 output relay is set to close for any forward unbalanced faults the negative-sequence directional element detects. From the table, the A2 output relay should close for all forward unbalanced faults.

The programming of output relays A1–A4 and four trip logic masks is explained in detail in [LOGIC n on page 3.15](#).

Target LED Explanation.

NOTE: The [Table 7.2](#) Target LEDs indicated in bold relate to the SEL-221G-3 and SEL-221G-4 relays.

- G1: The AG ground fault at 75 miles should illuminate the Zone 1 and Zone 2 ground fault targets (G1 and G2).
- G2: The AG ground fault at 85 miles should illuminate the G1 and G2 targets. This is due to the residual current exceeding the 67N1 pickup threshold.
- G3: The AG ground fault at -85 miles should illuminate only the G3 target.
- ϕ 1: The Zone 1 BC fault at 75 miles should illuminate the f1 and ϕ 2 Targets.
- ϕ 2: The Zone 2 BC fault at 85 miles should illuminate only the ϕ 2 Target.
- ϕ 3: The Zone 3 BC fault at -85 miles should illuminate only the ϕ 3 Target.

NOTE: The target level must be at Level 0 to display the fault targets. See [TARGET n k on page 3.13](#) for more information.

Each fault generates a short event report. To see the full event report for the last fault, type **EVENT 1** and press **<ENTER>**. Each event report provides an 11-cycle record of the currents, voltages, relay element states, and all contact input and output states. The meter saves the 12 newest reports in volatile memory.

Step 13

Purpose: Test the loss-of-potential logic.

Method: The relay includes a check for loss-of-potential, which might occur when a secondary fuse in the potential circuit blows. To demonstrate the instrument response, be sure the currents are balanced. Turn off one of the three-phase potentials. The relay should respond by lighting the LOP bit in Relay Word Row 1 (**TAR 1** command).

This checkout procedure demonstrates only a few relay features. For a complete understanding of relay capabilities, study *Functional Description on page U.2.23*, *Command Descriptions on page 3.6*, and *Section 4: Event Reporting*. For more test procedures, see *Full Functional Test*.

Full Functional Test

This procedure allows you to test the protective and control functions of the relay more fully than you can with the initial checkout procedure.

Equipment Required

The following equipment is necessary to complete a full functional test:

1. Communications terminal with EIA-232 serial interface
2. Data cable to connect terminal and relay
3. Source of relay control power
4. Source of synchronized three-phase voltages and at least two currents
5. Ohmmeter or contact opening/closing sensing device
6. Timer with contact inputs for start and stop

What Should Be Tested

A full functional test includes the initial checkout procedure and the additional steps the following text describes. In general, these tests do not check relay performance; they ensure that relay settings match your application. For commissioning purposes, your company policy may require you to perform the full functional test. For maintenance purposes, a quick test of selected fault types and zones (Zone 1 AG fault, Zone 2 BC fault, and a Zone 3 ABC fault, for example) should suffice.

Setting Test

Purpose: Ensure that the relay accepts settings.

- Method:
1. Gain Level 2 Access (see [Access Level 0 Command on page 3.6](#) and [Access Level 1 Commands on page 3.6](#)).
 2. Change one setting. For example, change the Zone 1 reach from 80 to 82 percent.

Type **SET Z1%** and press **<ENTER>**.

Following the Z1% prompt, type **82** and press **<ENTER>**.

3. To complete the setting procedure, type **END** and press **<ENTER>**. Type **Y <ENTER>** at the prompt: “OK (Y or N) ?” The relay computes internal settings and compares them against fixed limits. If all settings are within acceptable ranges, the ALARM contact closes momentarily as the new settings are enabled unless an alarm condition already exists (e.g. self-test failure).
4. Use the **SHOWSET** command to inspect settings. Make sure your change was accepted.

Type **SHOWSET** and press **<ENTER>**.

5. Use **SET** and **SHOWSET** again to restore the initial values and check the settings.
6. Type **LOG MTU** and press **<ENTER>**.
7. Change one bit in the MTU logic mask. For example, remove the TC bit from the fourth row of the Relay Word, as in the following.

```
=>>LOG MTU <ENTER>
1 selects, 0 deselects.

1ABC 2ABC 3ABC 4ABC LOP 50H 50M 50L
1   0   0   0   0   0   0   0
? <ENTER>
51NT 67N1 67N2 67N3 51NP Z1P Z2P Z3P
1   1   0   0   0   1   0   0
? <ENTER>
Z2PT Z3PT Z3RB OSB 50MF RC RI DF
1   1   0   0   1   0   1   0
? <ENTER>
ALRM TRIP TC DT 52BT 52AT Z2GT Z3GT
0   0   1   1   0   0   1   1
? 00010011 <ENTER>
0   0   0   1   0   0   1   1
? <ENTER>

New MTU:

1ABC 2ABC 3ABC 4ABC LOP 50H 50M 50L
1   0   0   0   0   0   0   0
51NT 67N1 67N2 67N3 51NP Z1P Z2P Z3P
1   1   0   0   0   1   0   0
Z2PT Z3PT Z3RB OSB 50MF RC RI DF
1   1   0   0   1   0   1   0
ALRM TRIP TC DT 52BT 52AT Z2GT Z3GT
0   0   0   1   0   0   1   1

OK (Y/N) ? Y <ENTER>
=>>
```

8. Type **LOG MTU** and press **<ENTER>**. Make sure the bit change is present.
9. Use LOG MTU and SHOWSET to restore the initial values and check settings.

Meter Test

Purpose: Verify the magnitude accuracy and phase balance. This test only requires a single voltage and current test source.

Method:

1. Parallel all voltage inputs by connecting terminals VA, VB, and VC with a jumper. See *Figure 7.3* for the test connections.
2. Series all current inputs as shown in *Figure 7.3*.




Figure 7.3 METER Test Connections

3. Apply a voltage of 50 Vac between the paralleled voltage inputs to the neutral point and a current of 5 A through the three inputs. The phase angle of the voltage and current source should be set to zero degrees.
4. Use the **METER** command to inspect measured voltages, currents, and power. Voltages VA, VB, and VC should equal the applied voltage times the potential transformer ratio setting. With the Example 230 kV Line settings, you should obtain:

$$\begin{aligned} VA &= VB = VC = (50 \text{ V})(2000) \\ &= 100 \text{ kV} (\pm 0.5\%) \end{aligned}$$

Voltages VAB, VBC, and VCA should read less than 1.5 kV.

Similarly, currents IA, IB, and IC should equal the applied current times the current transformer ratio. With the Example 230 kV Line settings, you should obtain:

$$\begin{aligned} IA &= IB = IC = (5 \text{ A})(200) \\ &= 1000 \text{ A} (\pm 1\%) \end{aligned}$$

Difference currents IAB, IBC, and ICA should be less than 20 A. The power reading, P (MW), should read:

$$(VA)(IA) + (VB)(IB) + (VC)(IC) = 300 \text{ MW}$$

The reactive power reading Q (MVAR) should be less than 5 MVAR.

MHO Element Testing

Before you begin testing the mho distance elements, determine the test quantities. Refer to the end of this section for a simple program (ONEBUS) to calculate voltages and currents necessary to simulate a power system fault at the line angle.

NOTE: There is no requirement that you use ONEBUS to test the relay; it is included in the manual as a test aid.

During mho element tests, we recommend disabling the loss-of-potential (LOP) logic by setting LOPE = N in the setting procedure. This prevents an LOP condition from blocking mho distance elements. You must enable the LOP feature during LOP testing.

A. Determining Fault Simulation Values - Phase-Phase and Phase-Ground Faults

You must enter all line impedance entries for the ONEBUS program in secondary values. Convert the primary impedance settings from your relay setting sheet or SHOWSET printout to secondary values with the following formula:

$$R_1 \text{ secondary} = R_1 \left(\frac{\text{Current Transformer Ratio}}{\text{Potential Transformer Ratio}} \right)$$

$$X_1 \text{ secondary} = X_1 \left(\frac{\text{Current Transformer Ratio}}{\text{Potential Transformer Ratio}} \right)$$

$$R_0 \text{ secondary} = R_0 \left(\frac{\text{Current Transformer Ratio}}{\text{Potential Transformer Ratio}} \right)$$

$$X_0 \text{ secondary} = X_0 \left(\frac{\text{Current Transformer Ratio}}{\text{Potential Transformer Ratio}} \right)$$

Next, use the example settings provided with the relay to calculate required voltages and currents for a single-line-to-ground and phase-phase fault at the boundary of the Zone 1 reach. Enter the data shown in bold face from [Figure 7.4](#) into the ONEBUS program:

```
ENTER Z1: R,X? 0.856,7.777 <ENTER>
ENTER Z0: R,X? 3.512,23.696 <ENTER>
ENTER RF FOR GND FLTS? 0 <ENTER>
DIST SOURCE TO BUS (PU OF LINE)? 0.2 <ENTER>
DIST BUS TO FAULT (PU OF LINE)? 0.8 <ENTER>
```

Figure 7.4 Example ONEBUS Input Data for Phase-Phase and Ground Faults

ONEBUS should produce the following output:

VA	VB	VC	IA	IB	IC	
53.60	69.74	70.04	5.08	0.00	0.00	A-G
0.0	-124.0	123.8	-82.4	0.0	0.0	
VA	VB	VC	IA	IB	IC	
67.00	57.24	57.24	0.00	7.42	7.42	B-C
0.0	-125.8	125.8	0.0	-173.7	6.3	

IMP BUS FAULT OR QUIT (I,B,F,Q)?

Figure 7.5 Example ONEBUS Result Screen for Phase-Phase and Ground Faults

B. Onebus Input Description

Line 1: On the first line, enter the real and reactive values of the secondary positive-sequence impedance for the entire transmission line. Separate each value with a comma.

Line 2: On the second line, enter the real and reactive values of the secondary zero-sequence impedance for the entire transmission line.

Line 3: The “RF FOR GROUND FAULTS” input allows you to introduce ground fault resistance into the line-ground fault cases. In most instances, RF will be zero.

Line 4: The “DIST SOURCE TO BUS” input models the source strength behind the relay location as a source-to-line impedance ratio. This setting is entered as a per-unit value. For example, for a radial system with a source impedance equal to 20 percent of the line impedance, enter 0.2 for the per-unit distance from the source to the bus. Variations of the source impedance ratio (SIR) affect the magnitude and phase angle of the calculated voltages and currents.

You can use the source impedance ratio to adjust the current magnitude in cases where calculated currents exceed the output range of your current source. For example, on a short transmission line with a low source impedance, high current magnitudes result. Raising the source impedance ratio in ONEBUS results in a lower calculated current combined with a lower voltage.

If the source impedance ratio is unknown, enter a source impedance ratio of one to determine whether calculated currents are within the range of the current source. It is best to keep the source impedance ratio as realistic as possible.

Line 5: The final input is the “DIST BUS TO FAULT.” This is the distance from the relay terminal to the fault location. To obtain the voltages and currents for a fault at 80 percent of the line, enter 0.8 for the per-unit distance from the bus to the fault.

C. Determining Fault Simulation Values - Three-Phase Faults

You can calculate three-phase fault voltages and currents with the ONEBUS program. Enter the positive-sequence line impedance values at the prompt for zero-sequence values, and set the source impedance ratio to zero. The following example uses the example relay settings:

```
ENTER Z1: R,X? 0.856,7.777
ENTER Z0: R,X? 0.856,7.777
ENTER RF FOR GND FLTS? 0
DIST SOURCE TO BUS (PU OF LINE)? 0.0
DIST BUS TO FAULT (PU OF LINE)? 0.8
```

Figure 7.6 Example ONEBUS Input Data for Three-Phase Faults

The following output should result:

VA	VB	VC	IA	IB	IC	
67.00	67.00	67.00	10.70	0.00	0.00	A-G
0.0	-120.0	120.0	-83.7	0.0	0.0	

VA	VB	VC	IA	IB	IC	
67.00	67.00	67.00	0.00	9.27	9.27	B-C
0.0	-120.0	120.0	0.0	-173.7	6.3	

IMP BUS FAULT OR QUIT (I,B,F,Q)?

Figure 7.7 Example ONEBUS Result Screen for Three-Phase Faults

Use the calculated single-phase fault (AG) values to simulate a three-phase fault. Apply voltages as the program indicates. Apply the calculated A ϕ current magnitude to all three relay current inputs, with each current lagging the corresponding voltage phase angle by the transmission line angle.

Table 7.3 shows these values.

Table 7.3 Three-Phase Fault Voltages and Currents at MTA

VA	VB	VC	IA	IB	IC	Volts/Amps
67.00	67.00	67.00	10.70	10.70	10.70	Degrees
0.00°	-120.00°	120.00°	-83.70°	156.30°	36.30°	

The test procedure previously described two methods of observing element status: target LEDs and programmable output contacts. For the purposes of driving an external sense contact, the remainder of the test procedure will use the programmable output contact method.

D. Three-Phase Mho Relay Test

Purpose: Determine the pickup of each three-phase distance element at three points on the mho characteristic: MTA, MTA +45°, and MTA -45°.

Method: 1. Use the **LOGIC** command to program the programmable output contact (A1 – A4) you want to follow the appropriate instantaneous three-phase distance element. Select one of the three-phase elements from the first row of the Relay Word, as the following indicates:

1ABC = Zone 1 Instantaneous Three-Phase Mho Element

2ABC = Zone 2 Instantaneous Three-Phase Mho Element

3ABC = Zone 3 Instantaneous Three-Phase Mho Element

4ABC = Zone 4 Instantaneous Three-Phase Mho Element

Please note that the 1ABC element includes any delay the Z1DP timer setting established.

The Zone 4 offset mho circle diameter is 1.5 times the Zone 3 mho circle diameter. Therefore, the forward reach of Zone 4 is 1.25 times that of Zone 3, while the reverse reach is 0.25 times the Zone 3 setting. You can reverse Zone 3, but Zone 4 always remains forward.

The following example outlines the procedure for testing the Zone 1 three-phase distance element.

2. Connect the sources of voltage and current to the rear-panel terminals of the relay, per *Figure 7.8* or *Figure 7.9*. *Figure 7.8* uses three current sources, while *Figure 7.9* uses only two.




Figure 7.8 Three-Phase Voltage and Current Source Test Connections for Three-Phase Mho Test

The two-current source method yields the same results as does the three-current source method. For balanced three-phase faults, the residual or $3I_0$ is zero. From this, you can see why two current sources are adequate for three-phase element testing:

$$3I_0 = IA + IB + IC = 0$$

Therefore,

$$-IC = (IA + IB)$$

This has the same effect as performing the following steps:

- Connect the dotted output of A and B current sources to the dotted IA and IB inputs of the relay.
- Jumper together the undotted IA and IB current inputs of the relay. This forms the $(IA + IB)$ quantity.
- Connect a jumper between the undotted IA and IB current inputs to the undotted IC current input of the relay.
- Connect the dotted IC current input of the relay to the common current source return of current Source A and B.




Figure 7.9 Three-Phase Voltage and Two-Phase Current Source Test Connections for Three-Phase Mho Test

- Determine the voltages and currents necessary to simulate a fault at the boundary of the relay reach you want (through the use of ONEBUS or a similar method). *Table 7.4* shows currents and voltages necessary for testing the example Zone 1 reach at MTA. We calculated these quantities through the use of ONEBUS.

Table 7.4 Zone 1 Three-Phase Element Test Quantities at MTA

VA	VB	VC	IA	IB	IC	Volts/Amps
67.00	67.00	67.00	10.7	10.7	10.7	
0.00°	-120.00°	120.00°	-83.7°	156.3°	36.3°	Degrees

- Adjust the voltages and currents of the test set to the values in *Table 7.4*. Do not turn on the currents at this point.
- Turn on the voltage sources VA, VB, and VC.
- Apply current to the relay, and ramp the current source magnitudes together until the monitored output contact toggles to indicate pickup. Record the pickup current threshold, and compare this to the calculated threshold.

To calculate the three-phase element reach, you need only consider a single phase. For example, if the A_φ voltage magnitude is 67 V_{l-n} and the current magnitude for the boundary characteristic is 10.7 A, calculate the three-phase distance element reach as follows:

Zone 1 reach secondary,

$$Z_{1\ sec} = \frac{67V\angle 0^\circ}{10.7A\angle -83.7^\circ} = 6.26\Omega\angle 83.7^\circ \text{ secondary along the MTA}$$

In primary ohms,

Zone 1 reach primary along the MTA,

$$Z_{1\text{pri}} = (6.26\Omega \angle 83.7^\circ) \left(\frac{\text{PTR}}{\text{CTR}} \right) = 62.6\Omega \angle 83.7^\circ \text{ primary}$$

Where PTR = 2000 and CTR = 200.

7. Obtain two other convenient test points. Consider a square inscribed in a mho circle, with one diagonal of the square being the diameter along the MTA. We can obtain the two corners of that square on the other diagonal by increasing the current by a factor of 1.414 at angles of ± 45 degrees away from the angle we obtained through the use of the BASIC program.

For the three-phase example, the required voltages remained unchanged. The current magnitudes are 10.7 A (1.414) = 15.1 A at the angles in the following table:

Table 7.5 Zone 1 Three-Phase Test Quantities at MTA $\pm 45^\circ$

	Angle IA	Angle IB	Angle IC
MTA $+45^\circ$	-38.7°	-158.7°	81.3°
MTA -45°	-128.7°	111.3°	-8.7°

8. Test the relay at the two additional current phase angle settings (MTA $+45^\circ$ and MTA -45°). Record the results.

E. Phase-Phase Mho Element Tests

Purpose: Determine the pickup of the phase-phase distance element at three points on the mho characteristic: MTA, MTA +45° and MTA -45°.

Method: 1. Use the **LOGIC** command to program a single output relay (A1–A4) to follow the appropriate instantaneous phase-phase distance element. Select a phase-phase element from the Relay Word according to the following:

Z1P = Zone 1 Instantaneous Phase-Phase Element

Z2P = Zone 2 Instantaneous Phase-Phase Element

Z3P = Zone 3 Instantaneous Phase-Phase Element

Please note the Z1P element includes any delay the Z1DP timer establishes.

The following example outlines the test procedure for the Zone 1 phase-phase distance element.

2. Connect the sources of voltage and current to the relay rear-panel terminals (see [Figure 7.10](#) or [Figure 7.11](#)). Note that [Figure 7.10](#) employs two current sources, while [Figure 7.11](#) uses only one current source.

The single current source method yields the same results as the two current source method. The single current source method also ensures that the phase angle of the two involved currents is always 180° apart.

These steps connect a single current source to the relay for a BC phase-phase fault test.

- a. Connect the B current source dotted output to the dotted relay IB input.
 - b. Jumper undotted relay IB and IC current inputs together.
 - c. Connect the dotted relay IC current input to the common current source return of current Source B.
3. Determine the voltages and currents necessary to simulate a phase-phase fault at the boundary of the relay reach you want (using ONEBUS or a similar method). Currents and voltages necessary to test the Zone 1 phase-phase element reach of the example settings appear in [Table 7.6](#).




Figure 7.10 Three-Phase Voltage and Two-Phase Current Source Test Connections for Phase-Phase Mho Test




Figure 7.11 Three-Phase Voltage and One-Phase Current Source Test Connections for Phase-Phase Mho Test

Table 7.6 Zone 1 Phase-Phase Test Voltages and Currents, BC Fault

VA	VB	VC	IA	IB	IC	
67.00	57.24	57.24	0.00	7.42	7.42	Volts/Amps
0.0°	-125.8°	125.8°	0.0°	-173.7°	6.3°	Degrees

4. Adjust the test set voltages and currents to the values in [Table 7.6](#). Do not turn on the currents at this point.
5. Turn on the voltage sources VA, VB, and VC.
6. Apply current to the relay, and ramp the current source magnitudes together until the monitored output contact toggles to indicate pickup. Record the pickup current threshold, and compare it to the calculated threshold.

To calculate the phase-phase element reach, first calculate the resultant test voltage (VBC) and current (IBC).

BC Fault

$$VB = 57.24 \text{ V } \angle -125.8^\circ$$

$$VC = 57.24 \text{ V } \angle 125.8^\circ$$

$$VBC = VB - VC = 92.85 \text{ V } \angle -90^\circ$$

$$IB = 7.42 \text{ A } \angle -173.7^\circ$$

$$IC = 7.42 \text{ A } \angle 6.3^\circ$$

$$IBC = IB - IC = 14.84 \text{ A } \angle -173.7^\circ$$

Zone 1 reach secondary along the MTA,

$$Z_{1\ sec} = \frac{VBC}{IBC} = \frac{92.85 \text{ V } \angle -90^\circ}{14.85 \text{ A } \angle -173.7^\circ} = 6.26 \Omega \angle 83.7^\circ \text{ secondary}$$

In primary ohms,

Zone 1 reach primary along the MTA,

$$Z_{1\ pri} = (6.26 \Omega \angle 83.7^\circ) \left(\frac{\text{PTR}}{\text{CTR}} \right) = 62.6 \Omega \angle 83.7^\circ \text{ primary}$$

Where PTR = 2000 and CTR = 200.

7. Find two other convenient test points. Consider a square inscribed in a mho circle, with one diagonal being the diameter along the MTA. We can obtain the two corners of that square on the other diagonal by increasing the current by a factor of 1.414 at angles of ± 45 degrees away from the angle we obtained through use of the ONEBUS program.

For our Zone 1 BC phase-phase example, the required voltages remain unchanged. The current magnitudes are $(7.42)(1.414) = 10.49 \text{ A}$ at the angles in [Table 7.7](#).

8. Test the relay at the two additional current phase angle settings (MTA $+45^\circ$, MTA -45°). Record the results.

Table 7.7 Zone 1 Phase-Phase Test Quantities at MTA $\pm 45^\circ$

	Angle IB	Angle IC
MTA $+45^\circ$	-128.7°	51.3°
MTA -45°	141.3°	-38.7°

Directional Element Tests

Purpose: Verify the operate and restrain boundaries of the directional element for each residual overcurrent polarizing method enabled in the relay settings: 32Q, 32V, or 32I. In the example settings, the negative-sequence polarizing method is enabled (32QE = Y). Test procedures are also included for testing the 32D (32V and/or 32I) element.

Method: Program the programmable output (A1 – A4) you want to follow the DF bit in Relay Word Row 3. Use the **SET** command to disable the LOP scheme. This prevents test-condition voltages from setting the loss-of-potential condition and defeating the directional sensing ability of the relay. This step is unnecessary when testing the current polarized method alone (32IE=Y, 32QE=N, and 32VE=N).

32Q and 32V Tests

1. You can check the negative-sequence element and voltage-polarized part of the zero-sequence element in the same manner. With 32QE=Y, 32VE=N, and 32IE=N, check the negative-sequence element first.

Apply the following voltages to the relay:

Table 7.8 32Q and 32V Test Voltages

VA	VB	VC	
30.00	0.00	0.00	Volts
0.0°	0.0°	0.0°	Degrees

For the voltages shown in [Table 7.8](#), the resulting negative- and zero-sequence voltages are 10 V. The following equations illustrate the equations you should use to calculate magnitudes and angles for V2 and V0.

$$\begin{aligned} V0 &= \frac{1}{3}[VA + VB + VC] \\ &= \frac{1}{3}[30V\angle 0^\circ + 0V\angle 0^\circ + 0V\angle 0^\circ] \\ &= 10V\angle 0^\circ \end{aligned}$$

$$V2 = \frac{1}{3}[VA + a^2(VB) + a(VC)]$$

Where: $a \equiv 1 \angle 120^\circ$ and $a^2 \equiv 1 \angle 240^\circ$

$$\begin{aligned} V2 &= \frac{1}{3}[30V\angle 0^\circ + 0V\angle(0^\circ + 240^\circ) + 0V\angle(0 + 120^\circ)] \\ &= \frac{1}{3}[30V\angle 0^\circ + 0V\angle -120^\circ + 0V\angle 120^\circ] \\ &= 10V\angle 0^\circ \end{aligned}$$

To calculate I2 and I0, substitute currents for voltages in the previous equations.

Please note that the angular relationship of V2 and I2 (or V0 and I0) when you use a single voltage and current differs by 180° from use of three voltages and a single current. [Figure 7.12](#) illustrates the difference

between use of a single voltage and current and use of three voltages and a single current. For the sake of simplicity, this test uses the single voltage and current method. The relay declares ground faults in the forward direction when I₂ (I₀) leads $\pm 90^\circ$ from the MTA.




Figure 7.12 Three Voltage vs. One Voltage for Directional Tests (current vector shown in the operate region for MTA = 90°)

- 2 Apply IA = 3 A, corresponding to negative- and zero-sequence currents of one ampere. IB and IC are zero for this test.
- 3 Move the phase angle of the current with respect to the voltage, and observe the boundary of the directional element at MTA ± 90 degrees.
- 4 Repeat the previous steps with only 32VE enabled to check the zero-sequence voltage polarization directional element.
- 5 Verify the current polarization directional element boundaries by turning off the voltage and applying a second current source to the polarizing current input (IP).

Enable only the 32IE element in the relay-setting procedure. Apply the currents shown in [Table 7.9](#) to the IA and IP current inputs with the test connection in [Figure 7.13](#).

Table 7.9 32I Test Currents

IA	Ipol	
3.00	3.00	Amperes
0.0°	0.0°	Degrees

The DF bit should set and close the output contact when you apply both currents.

32I Tests




Figure 7.13 Current Polarized Directional Element Test Connection

- 6 Move the phase angle of IA with respect to the angle of IP to determine the zero torque axis. The maximum torque angle of the current polarized directional element is zero degrees (e.g. the A-phase current angle in phase with the IPOL current). The boundary of the characteristic should be at ± 90 degrees.

Residual Overcurrent Element Tests

Purpose: Verify the pickup thresholds of the 67N1, 67N2, 67N3, and 51NP residual overcurrent elements.

Method: 1. Using the **LOGIC** command, set the programmable output (A1–A4) you want to follow the appropriate overcurrent element. Select one of the overcurrent elements from the Relay Word according to the following:

67N1 = Zone 1 Instantaneous Residual Element
(pickup set by 50N1P setting)

67N2 = Zone 2 Instantaneous Residual Element
(pickup set by 50N2P setting)

67N3 = Zone 3 Instantaneous Residual Element
(pickup set by 50N3P setting)

51NP = Residual Time-Overcurrent Pickup Element

Please note that the 67N1 element includes any delay set by the Z1DG timer.

2. Disable all directional and LOP functions for this test. Set 51NTC, 32QE, 32VE, 32IE, ZONE3 = F, and LOP = N.
3. Apply current to one phase, and observe the pickup and dropout of each element. Record the results.

Residual Time-Overcurrent Element Timing Tests

Purpose: Verify the 51NT residual time-overcurrent element operating time.

- Method:
1. Disable all directional functions for this test. Set 51NTC, 32QE, 32VE, and 32IE = N.
 2. Set a programmable output (A1–A4) to follow the 51NP time-overcurrent pickup element. Use the assertion of this output (open to close) to start an external timer.
 3. Set another programmable output to follow the timeout of the time-overcurrent element timeout via the 51NT bit in the Relay Word. Use the assertion of this output to stop the external timer.
 4. Use the appropriate equation for the curve number to calculate the expected operating time of the 51NT element. The relay 51NC setting dictates this time. TD is the relay 51ND time dial setting. M is the multiple of pickup current you will need to apply to the relay. If you use example relay settings and a current multiple of pickup equal to three, the equation for the very inverse curve (3) is:

$$t_M = TD \left(0.0963 + \frac{3.88}{M^2 - 1} \right)$$

where:

M = Multiples of Pickup = 3

TD = Time Dial = 4

$t_M = 2.33$ seconds

For example, if the relay measures 3.45 A of residual current, the 51NT bit in the Relay Word asserts 2.33 seconds after the 51NP bit in the Relay Word asserts. *Table 7.10* shows the current quantities of the previous example.

Table 7.10 Current Quantities for 51N Timing Test Example

IA	IB	IC	
3.45	0.00	0.00	Amperes
0.0x	0.0x	0.0x	Degrees

5. Apply a multiple of pickup current to one phase. Record the operating time of the 51NT element, and compare this time to the calculated time.
6. Repeat the test for various multiples of pickup current (e.g. M = 3, 5, and 7) and various time dial settings (e.g. TD = 1, 5, and 10) for each of the four curve indexes.

Phase Overcurrent Element Tests

Purpose: Verify the pickup thresholds of the 50L, 50M, and 50H phase overcurrent elements.

Method: 1. Using the **LOGIC** command, set the programmable output (A1–A4) you want to follow the appropriate non-directional instantaneous phase overcurrent element. Select one of the phase overcurrent elements from the Relay Word according to the following:

50L = Low-set instantaneous phase overcurrent element

50M = Medium-set instantaneous phase overcurrent element

50H = High-set instantaneous phase overcurrent element

2. Apply current to one phase, and observe the pickup and dropout of each element. Record the results. Pickup of the 50H element generates an event report.

Memory Voltage Polarization Test

Purpose: Test the memory polarization duration for zero voltage close-in three-phase faults in front of the relay.

Method: 1. Using the factory relay settings, apply a zero voltage three-phase fault at the bus in front of the relay. Prefault and fault voltages and currents appear in [Table 7.11](#). Prefault voltages are necessary to charge the memory polarization filters.

Table 7.11 Three-Phase Close-In Fault

Prefault Quantities						
VA	VB	VC	IA	IB	IC	
67.00	67.00	67.00	0.00	0.00	0.00	Volts/Amps
0.0°	-120.0°	120.0°	0.0°	0.0°	0.0°	Degrees
Fault Quantities						
VA	VB	VC	IA	IB	IC	
0.00	0.00	0.00	11.00	11.00	11.00	Volts/Amps
0.0°	0.0°	0.0°	-83.7°	156.3°	36.3°	Degrees

2. In the generated event report, count the number of quarter cycles between when the time voltages collapse to zero and when the Zone 1 three-phase mho element drops out. The Zone 1 three-phase element should be asserted for a minimum of 16 quarter cycles. The 4ABC element should still be asserted, because it does not require memory polarization.

Loss-of-Potential Test

Purpose: Verify the SET LOP and CLEAR LOP conditions. The following equations show the SET LOP and CLEAR LOP logic equations.

$$\begin{aligned} \text{SET LOP} = & 47\text{NL} * \text{NOT}(50\text{NL}) + \text{NOT}(47\text{P}) \\ & * \text{NOT}(50\text{M}) \end{aligned}$$

$$\text{CLEAR LOP} = \text{NOT}(47\text{NL}) * 47\text{P}$$

Where: $47\text{NL} = 14 \text{ V of V0}$

$50\text{NL} = 0.083 \text{ A of I0 for } 51\text{NP} < 3.15 \text{ A}$
and $(0.083 \text{ A}) * (51\text{NP}/3.15)$, $51\text{NP} \geq 3.15 \text{ A}$

$47\text{P} = 14 \text{ V of V1}$

$50\text{M} = \text{Current in any phase over the 50M setting}$

Method: [Table 7.12](#) provides the voltage and current sets necessary to create SET LOP and CLEAR LOP conditions.

Table 7.12 Conditions for the SET LOP and CLEAR LOP Logic Equations

SET LOP						
VA	VB	VC	IA	IB	IC	
0.00	67.00	67.00	0.00	0.00	0.00	Volts/Amps
0.0°	-120.0°	120.0°	0.0°	0.0°	0.0°	Degrees
CLEAR LOP						
VA	VB	VC	IA	IB	IC	
67.00	67.00	67.00	0.00	0.00	0.00	Volts/Amps
0.0°	-120.0°	120.0°	0.0°	0.0°	0.0°	Degrees

50MF, 50MFD Test

Purpose: Verify that the 50MF bit in the Relay Word asserts 50MFD cycles after the current in any phase rises above the 50M setting following an LOP condition.

Method:

1. Program the programmable output (A1–A4) you want to follow the 50MF bit in the Relay Word.
2. Program another programmable output to follow the 50M bit in the Relay Word.
3. Start a timer when the 50M programmable output asserts (open to close).
4. Stop the timer when the 50MF bit asserts the output relay (open to close), and verify the accuracy of the 50MFD timer.

Z2DG and Z3DG Timer Tests

Purpose: Verify the Z2DG and Z3DG timer accuracy.

- Method:
1. Program the 67N2 bit in the Relay Word into one of the available outputs (A1–A4) to start an external timer.
 2. Program the Z2GT bit into a different output to stop the timer.
 3. Apply a Zone 2 AG fault as in [Table 7.13](#) for a duration that exceeds the Z2DG setting.

Table 7.13 Standard Zone 2 AG Fault Using Factory Relay Settings

2AG Fault						
VA	VB	VC	IA	IB	IC	
54.24	69.60	69.89	4.83	0.00	0.00	Volts/Amps
0.0°	-123.8°	123.6°	-82.4°	0.0°	0.0°	Degrees

4. Repeat steps 1 to 3, substituting 67N3 for 67N2 and Z3GT for Z2GT, using the appropriate programmable output. [Table 7.14](#) shows a standard Zone 3 AG fault. Apply this 3AG fault for a duration that exceeds the Z3DG setting.

Table 7.14 Standard Reverse Zone 3 AG Fault Using Factory Relay Settings

3AG Fault						
VA	VB	VC	IA	IB	IC	
54.24	69.60	69.89	4.83	0.00	0.00	Volts/Amps
0.0°	-123.8°	123.6°	97.6°	0.0°	0.0°	Degrees

NOTE: If an external timer is unavailable, use event report time tags to calculate Z2DG and Z3DG time delays with the following steps.

1. Mask only the Z2GT bit of the Relay Word into the MTU mask. Zero out the MTO mask so no other condition can assert the TRIP output.
2. Apply the Zone 2 AG fault, as given in [Table 7.13](#).
3. For Z2DG settings greater than approximately 6 cycles, the relay generates two event reports: one for the 67N2 element pickup, the other for TRIP output assertion (and the Z2GT bit of the Relay Word).
4. Calculate the Z2DG time delay, using the difference between the 67N2 element pickup in the first event report and the TRIP (and Z2GT bit) assertion in the second event report.
5. You can test the Z3DG timer with the same method, using the Zone 3 AG fault in [Table 7.14](#).

Z2DP and Z3DP Timer Tests

Purpose: Verify the Z2DP and Z3DP timer accuracy.

- Method:
1. Program the Z2P bit in the Relay Word into one of the available outputs (A1–A4) to start an external timer.
 2. Program the Z2PT bit into a different output to stop the timer.
 3. Apply the Zone 2 BC fault shown in [Table 7.15](#) for a duration that exceeds the Z2PT setting.

Table 7.15 Standard Zone 2 BC Fault Using Factory Relay Settings

2BC Fault						
VA	VB	VC	IA	IB	IC	
67.00	57.69	57.69	0.00	7.06	7.06	Volts/Amps
0.0°	-125.5°	125.5°	0.0°	-173.7°	6.3°	Degrees

4. Repeat steps 1 to 3, substituting 67N3 for 67N2 and Z3GT for Z2GT, using the fault in [Table 7.16](#).

Table 7.16 Standard Reverse Zone 3 BC Using Factory Relay Settings

3BC Fault						
VA	VB	VC	IA	IB	IC	
67.00	57.69	57.69	0.00	7.06	7.06	Volts/Amps
0.0°	-125.5°	125.5°	0.0°	6.3°	-173.7°	Degrees

NOTE: If an external timer is unavailable, use event report time tags to calculate the Z2DP and Z3DP time delays with the following steps.

1. Mask only the Z2PT bit of the Relay Word into the MTU mask. Zero out the MTO mask so no other condition can assert the TRIP output.
2. Apply the Zone 2 BC fault as given in [Table 7.15](#).
3. For Z2DP settings exceeding approximately 6 cycles, the relay generates two event reports: one for the 21P2 element pickup, the other for TRIP output assertion (and the Z2PT bit of the Relay Word).
4. Calculate the Z2DP time delay, using the difference from the 21P2 element pickup in the first event report to TRIP (and Z2PT bit) assertion in the second event report.
5. You can test the Z3DP timer with the same method, using the Zone 3 BC fault in [Table 7.16](#).

Switch-On-to-Fault Tests

Purpose: 1. Verify 52BT timer accuracy and MTO (Switch-On-to-Fault) Logic Mask.

2. Verify that elements enabled to trip via the MTO logic mask are only enabled when the breaker is open for a duration exceeding the 52BT setting (52BT bit in Relay Word is asserted).

Method: 1. Program one of the available output contacts (A1–A4) to follow the 52BT bit in the Relay Word.

2. Use the 52A contact input deassertion (control voltage on to off) to start an external timer.
3. Use the 52BT programmed contact output assertion (open to close) to stop the timer.
4. Compare the timer value to the 52BT setting.
5. To make sure the elements in the MTO logic mask are only enabled when 52BT = 1, apply a fault to pick up an element masked into the MTO logic mask but not the MTU mask.
6. *Table 7.17* contains prefault and fault voltage and current quantities for a Zone 2 AG fault.

Table 7.17 Zone 2 AG Fault Quantities

Prefault						
VA	VB	VC	IA	IB	IC	
67.00	67.00	67.00	0.00	0.00	0.00	Volts/Amps
0.0°	-120.0°	120.0°	0.0°	0.0°	0.0°	Degrees
2AG Fault						
VA	VB	VC	IA	IB	IC	
54.24	69.60	69.89	4.83	0.00	0.00	Volts/Amps
0.0°	-123.8°	123.6°	-82.4°	0.0°	0.0°	Degrees

7. Apply the Zone 2 AG fault with the breaker closed (52A = 1 and 52BT = 0). The relay should not trip instantaneously.
8. Open the breaker to deassert the 52A input, which asserts the 52BT bit in the Relay Word. Use the **TARGET 4** command to verify that 52BT is set.
9. Apply the same Zone 2 AG fault, and verify that the relay trips instantaneously.

Out-of-Step Blocking Test

Purpose: 1. Verify the out-of-step blocking timer (OSBT) accuracy.

2. Verify that three-phase mho elements for Zones 1, 2, or 3 are blocked from operating when out-of-step blocking is selected for that particular zone.

Method: 1. Program one of the available output contacts (A1–A4) to follow the 4ABC bit in the Relay Word.

2. Program another output contact to follow the OSB bit in the Relay Word.
3. When the Zone 4 three-phase mho element (4ABC) picks up, start an external timer with the chosen output contact.
4. Stop the timer when the OSB contact asserts.
5. Compare the OSB setting to the timer value.
6. Apply the Zone 4 three-phase fault as shown in [Table 7.18](#). To verify that the three-phase mho elements are blocked from operation, set OSB1, OSB2, and OSB3 to Y.
7. Apply a Zone 1 three-phase fault as shown in [Table 7.18](#). Verify that the Z1ABC mho element asserts (a “1” in the 213 column of the event report) when OSB is not asserted, and that Z1ABC does not assert when OSB is asserted. Remember that if OSB is masked into a programmable output, it will appear as an asterisk (*) in the event report. Because the out-of-step blocking condition only persists for two seconds, the fault must be stepped into the Zone 1 characteristic within two seconds after the OSB bit is set.
8. Repeat for a Zone 2 three-phase fault, as shown in [Table 7.18](#).

Table 7.18 Standard Three-Phase Faults

IABC Fault						
VA	VB	VC	IA	IB	IC	
67.00	67.00	67.00	10.70	10.70	10.70	Volts/Amps
0.0°	-120.0°	120.0°	-83.7°	156.3°	36.3°	Degrees
2ABC Fault						
VA	VB	VC	IA	IB	IC	
67.00	67.00	67.00	7.14	7.14	7.14	Volts/Amps
0.0°	-120.0°	120.0°	-83.7°	156.3°	36.3°	Degrees
4ABC Fault						
VA	VB	VC	IA	IB	IC	
67.00	67.00	67.00	5.82	5.82	5.82	Volts/Amps
0.0°	-120.0°	120.0°	-83.7°	156.3°	36.3°	Degrees

Recloser Test

NOTE: This test should be performed using a breaker simulator to simulate the action of the breaker 52A auxiliary contacts. A simple latching relay works well as a breaker simulator.

Purpose: Verify that the reclosing relay functions properly.

- Method:
1. Program the MRI (Mask for Reclose Initiate) with the 67N1 bit in the Relay Word. Make certain this same bit is not masked into the MRC (Mask for Reclose Cancel).
 2. Program the MTU (Mask for Unconditional Trip) with the 67N1 bit also.
 3. Apply a Zone 1 AG fault as shown in [Table 7.19](#). Make certain the 52A input is energized for 79RS cycles prior to applying the fault. The TRIP output contact closure should result in the circuit breaker simulator de-energizing the 52A input and removal of current inputs to the relay.

Table 7.19 IAG Fault

Prefault						
VA	VB	VC	IA	IB	IC	
52.89	70.12	70.06	0.00	0.00	0.00	Volts/Amps
0.0°	-124.0°	124.0°	0.0°	0.0°	0.0°	Degrees
IAG Fault						
VA	VB	VC	IA	IB	IC	
52.89	70.12	70.06	5.11	0.00	0.00	Volts/Amps
0.0°	-124.0°	124.0°	-80.0°	0.0°	0.0°	Degrees

4. Immediately following TRIP output closure, remove the A-Phase fault current. This allows the first open interval timer (790I1) to expire. Record the duration between TRIP output contact opening or 52A input deassertion (whichever occurs later) and CLOSE output contact closure.
5. Record this time, and compare it to the 790I1 setting.

Input Circuits Test

Purpose: Verify that logic inputs assert when you apply control voltage across the respective terminal pair.

- Method:
1. Set target LEDs to display the contact inputs by typing **TAR 5 <ENTER>**. The front-panel LEDs should now follow the contact inputs.
 2. Apply control voltage to each input and make sure the corresponding target LED turns on. Energizing the PT, BT, DT, and ET inputs should trigger an event report. [Table 7.20](#) lists the contact inputs.

Table 7.20 Contact Inputs

Direct Trip	(DT)
Permissive Trip	(PT)
Block Trip	(BT)
Direct Close	(DC)
52A	
External Trigger	(ET)

Serial Ports Test

Purpose: Verify operation of serial PORT 1.

Method: The initial checkout procedure assumes you connected a terminal to PORT 2. Set the baud rate of PORT 1 to match that of PORT 2, and switch your terminal from PORT 2 to PORT 1. Be sure you can communicate through this port. If you are testing an SEL-221G Relay, ensure that you can communicate through both the front- and rear-panel PORT 2 connectors.

IRIG-B Time Code Input Test

Purpose: Verify operation of the IRIG-B clock input port.

Method: 1. Connect a source of demodulated IRIG-B time code to the relay Auxiliary Port in series with a resistor to monitor the current. Adjust the source to obtain an “ON” current of about 10 mA.
 2. Execute the **IRIG** command. Make sure the relay clock displays the correct date and time.

NOTE: A recording of the IRIG-B signal passed through a simple demodulator provides a convenient, inexpensive test of the IRIG-B port. Please contact the factory for further details.

Power Supply Voltages Test

Purpose: Verify that correct output voltages are presented to PORT 1, PORT 2, and the auxiliary port. These voltages are required by external devices including a dc-powered modem or the SEL-DTA unit.

Method: 1. Execute the **STATUS** command and inspect the voltage readings for the +5 and ±15 volt supplies.
 2. At the Auxiliary Port, use a voltmeter to read the +5 and ±12 volt outputs. The 12 volt outputs are derived from the 15 volt supplies using three-terminal regulators. The following pins are the read points:

SEL-121G		SEL-221G	
Pin 6:	+5 Vdc	Pin 1:	+5 Vdc
Pin 7:	+12 Vdc	Pin 4:	+12 Vdc
Pin 8:	-12 Vdc	Pin 6:	-12 Vdc




Figure 7.14 SEL-121G Relay Nine Pin Connector Pin Number Convention




Figure 7.15 SEL-121G Relay Nine Pin Connector Pin Number Convention

3. Compare the +5 volt readings from the status report and voltmeter. The voltage difference should be less than 50 MV, and both readings should be within 0.15 V of 5 V.

The 12 volt supplies should be within 0.5 V of their nominal values.

Calibration

Each SEL relay is factory calibrated. If you suspect that the relay is out of calibration, please contact the factory.

Troubleshooting

Inspection Procedure

Complete the following procedure before disturbing the system. After you finish the inspection, proceed to the Troubleshooting Table.

1. Measure and record control power voltage at the power input terminals.
2. Check to see that the power is on, but do not turn system off if it is on.
3. Measure and record the voltage at all control inputs.
4. Measure and record the state of all output relays.
5. Inspect the cabling to the serial communications ports, and be sure a communications device is connected to at least one communications port.

Troubleshooting Table

All front-panel LEDs Dark

1. Power is off
2. Blown fuse
3. Input power not present
4. Self-test failure
5. Target command improperly set

NOTE: For 1, 2, 3, and 4, the ALARM relay contacts should be closed.

System Does Not Respond to Commands

1. Communications device not connected to system.
2. Relay or communications device at incorrect baud rate or other communication parameter incompatibility, including cabling error.
3. System is processing event record. Wait several seconds.
4. System is attempting to transmit information, but cannot because of handshake line conflict. Check communications cabling.
5. System is in the XOFF state, halting communications. Type **<CTRL>Q** to put system in XON state.

Tripping Output Relay Remains Closed Following Fault

1. Output relay contacts burned closed.
2. Main board failure.

No Prompting Message Issued to Terminal upon Power-Up

1. Terminal not connected to system.
2. Wrong baud rate.
3. Terminal improperly connected to system.
4. Other port designated AUTO in the relay settings.
5. Port timeout interval set to a value other than zero.
6. Main board failure.

System Does Not Respond to Faults

1. Relay improperly set. Review your settings with the **SHOWSET** command.
2. Improper test settings.
3. PT or CT input cable wiring error.
4. Analog input cable between transformer-termination and main board loose or defective.
5. Check self-test status with **STATUS** command.
6. Check input voltages and currents with **METER** command and **TRIGGER** and **EVENT** sequence.

Terminal Displays Meaningless Characters

Baud rate set incorrectly. Check terminal configuration. See [Section 3: Communications](#).

Self-Test Failure: +5 Volts

1. Power supply +5 volt output out of tolerance. See **STATUS** command.
2. A/D converter failure.

Self-Test Failure: +15 Volts

1. Power supply +15 volt output out of tolerance. See **STATUS** command.
2. A/D converter failure.

Self-Test Failure: -15 Volts

1. Power supply -15 volt output out of tolerance. See **STATUS** command.
2. A/D converter failure.

Self-Test Failure: Offset

1. Offset drift. Adjust offsets.
2. A/D converter drift.

Self-Test Failure: ROM Checksum

EPROM failure. Replace EPROM(s).

Self-Test Failure: RAM

Static RAM IC failure. Replace RAM(s).

Self-Test Failure: A/D Converter

1. A/D converter failure.
2. RAM error not detected by RAM test.

Alarm Contact Closed

1. Power is off.
2. Blown fuse.
3. Power supply failure.
4. Improper EPROMs or EPROM failure.
5. Main board failure.

Firmware Upgrade Instructions, SEL-121G Relay

SEL may occasionally offer firmware upgrades to improve the performance of your relay. These instructions explain how to install new firmware.

WARNING

This procedure requires that you handle electrostatic discharge sensitive components. If your facility is not equipped to work with these components, we recommend that you return the relay to SEL for firmware installation.

The modifications require that you power down the relay, remove its front panel, pull out the drawout unit, exchange several integrated circuit chips, and reassemble the relay. If you do not want to perform the modifications yourself, we can assist you. Simply return the relay and integrated circuit chips to us. We will install the new chips and return the unit to you within a few days.

Upgrade Instructions

1. If the relay is in service, disable its control functions. Turn off control power to the relay. Short the relaying CT secondary inputs to the relay by using appropriate shorting switches.
2. Remove the relay front panel by unscrewing the five front-panel screws. With the front panel removed, you can see the aluminum drawout chassis. The main board is attached to the top of the drawout chassis. The power supply and transformer assembly are attached to the bottom of the relay chassis.
3. Disconnect the power supply and transformer secondary cables from the underside of the drawout assembly.
4. Remove the drawout assembly by pulling the spacers on the bottom of the drawout chassis. You should be able to remove the assembly with your fingers. Because steps 5 and 6 involve handling electrostatic discharge (ESD) sensitive devices and assemblies, perform these steps at an ESD safe work station. This will help prevent possible damage by electrostatic discharge.
5. Note the orientation of the ICs to be replaced. Use a small screwdriver to pry the indicated ICs free from their sockets. Be careful not to bend the IC pins or damage adjacent components.
6. Carefully place the new ICs in the appropriate sockets. Check the orientation of the ICs. Be sure that each IC is in its corresponding socket. Look for IC pins that bent under or did not enter a socket hole.
7. Slide the drawout assembly into the relay chassis. Using your fingers, push the assembly in until the front of the assembly is flush with the front of the relay chassis. Reconnect the power supply and transformer secondary cables to the receivers on the underside of the drawout assembly. Replace the relay front panel.
8. With breaker control disabled, turn relay power on and enter your settings. Execute the **STATUS**, **METER**, and **TRIGGER** commands to ensure that all functions are operational. Set and record your Access Level 1 and 2 passwords and the date and time. The relay is now ready to resume protective functions.

Firmware Upgrade Instructions, SEL-221G Relay

WARNING

This procedure requires that you handle electrostatic discharge sensitive components. If your facility is not equipped to work with these components, we recommend that you return the relay to SEL for firmware installation.

SEL may occasionally offer firmware upgrades to improve the performance of your relay. These instructions explain how to remove the relay drawout assembly to install new firmware.

The modifications require that you power down the relay, remove the relay front panel, pull out the drawout unit, exchange several integrated circuit chips, and reassemble the relay. If you do not want to perform the modifications yourself, we can assist you. Simply return the relay and integrated circuit chips to us. We will install the new chips and return the unit to you within a few days.

Upgrade Instructions

1. If the relay is in service, disable its control functions. Turn off control power to the relay. Short the relaying CT secondary inputs to the relay by using appropriate shorting switches.
2. Remove the relay front panel by unscrewing the five front-panel screws. With the front panel removed, you can see the aluminum drawout chassis. The main board is attached to the top of the drawout chassis. The power supply and transformer assembly are attached to the bottom of the relay chassis.
3. Disconnect the power supply and transformer secondary cables from the underside of the drawout assembly.
4. Remove the drawout assembly by pulling the spacers on the bottom of the drawout chassis. You should be able to remove the assembly with your fingers. Because steps 5 and 6 involve handling electrostatic discharge (ESD) sensitive devices and assemblies, perform these steps at an ESD safe work station. This will help prevent possible damage by electrostatic discharge.
5. Note the orientation of the ICs to be replaced. Use a small screwdriver to pry the indicated ICs free from their sockets. Be careful not to bend the IC pins or damage adjacent components.
6. Carefully place the new ICs in the appropriate sockets. Check the orientation of the ICs. Be sure that each IC is in its corresponding socket. Look for IC pins that bent under or did not enter a socket hole.
7. Slide the drawout assembly into the relay chassis. Using your fingers, push the assembly in until the front of the assembly is flush with the front of the relay chassis. Reconnect the power supply and transformer secondary cables to the receivers on the underside of the drawout assembly. Replace the relay front panel.
8. With breaker control disabled, turn relay power on and enter your settings. Execute the **STATUS**, **METER**, and **TRIGGER** commands to ensure that all functions are operational. Set and record your Access Level 1 and 2 passwords and the date and time. The relay is now ready to resume protective functions.

Factory Assistance

If you have any questions regarding the performance, application, or repair of this or any other SEL product, do not hesitate to contact the factory. Our staff is always happy to assist you.

Schweitzer Engineering Laboratories, Inc.
2350 NE Hopkins Court
Pullman, WA 99163-5603 USA
Telephone: +1.509.332.1890
Fax: +1.509.332.7990
Internet: www.selinc.com
Email: info@selinc.com

Appendix A

Firmware and Manual Versions

Firmware

This manual covers SEL relays that contain firmware bearing the following part numbers and revision numbers.

Firmware Part/Revision No.	Description of Firmware
Firmware Revision 1, 121 G Main Board Configurations	
SEL-121G-R124	Base Product
SEL-121G-R168	Kilometers Version
SEL-121G3-R119	Recent Trip Targets
SEL-121G3-R219	Kilometers Version, Recent Trip Targets
SEL-121G3-R314	ACB Rotation, Recent Trip Targets
SEL-121G4-R120	Zone 4 = Zone 3* 2
Firmware Revision 4, 221G/121 G Main Board Configurations	
SEL-121G-R413	Base Product
SEL-121G-R463	50 Hz, Kilometers Version
SEL-121G3-R413	Recent Trip Targets
SEL-121G3-R459	50 Hz, Kilometers Version, Recent Trip Targets
SEL-121G3-R513	Kilometers Version, Recent Trip Targets
SEL-121G3-R613	ACB Rotation, Recent Trip Targets
SEL-121G3-R413	Base Product, Negative-Sequence Rotation

Earlier versions of firmware may not precisely match this manual. To find the firmware version number in your relay, obtain an event report (which identifies the firmware) by using the **EVENT** command. This is an FID number with the Part/Revision number in bold:

FID = **SEL-121G3-R413-V656mptr11sy5fs2-D941021-E2**

For a detailed explanation of the Firmware Identification Number (FID), refer to [Section 4: Event Reporting](#).

Manual Change Information

The date code at the bottom of each page of this manual reflects the creation or revision date. Date codes are changed only on pages that have been revised and any following pages affected by the revisions (i.e., pagination). If significant revisions are made to a section, the date code on all pages of the section will be changed to reflect the revision date.

Each time revisions are made, the table of contents is regenerated and the date code is changed to reflect the revision date.

Changes in this manual to date are summarized below (most recent revisions at top).

Manual Creation Date: 990602

Revision Date	Summary of Revisions
The Manual Change Information section has been created to begin a record of revisions to this manual. All changes will be recorded in this Summary of Revisions table.	
990602	<p>Incorporated addendum information regarding “<i>ACB Phase Rotation Option,</i> 50 Hz Options,” and “<i>Kilometer Option,</i>” into <i>Section 1: Introduction.</i></p> <p>Incorporated addendum information regarding “<i>New SEL-200 Series Optical Isolator Logic Input Rating</i>” into Relay Standards and Input Parameters in <i>Section 2: Specifications.</i> Title now reads “<i>Optoisolated Input Ratings.</i>”</p> <p>Incorporated addendum information regarding “<i>Jumper Installation Instructions</i>” into <i>Section 6: Installation.</i></p> <p>Updated <i>Figure 6.3: Relay Dimensions, Panel Cutout, and Drill Plan</i> and changed figure caption to read <i>Relay Dimension and Drill Plan.</i></p> <p>Updated <i>Figure B.1</i> in <i>Appendix B: SEL-221G, -3, -4 Main Board Jumper Connector and Socket Locations.</i></p>

Appendix B

SEL-221G, -3, -4 Main Board Jumper Connector and Socket Locations




Figure B.1 SEL-200 Series Main Board Troubleshooting Test Points and Jumper Locations

This page intentionally left blank

Appendix C

ONEBUS: Program to Compute Test Set Settings for Testing Distance Relays

The BASIC program in this note determines voltages and currents that would appear on distance relay terminals for ground and phase faults on a radial system with source impedance at the same angle as line impedance. It is useful in determining test voltage and current settings for SEL distance relays and fault locating equipment.

The program was initially designed to run on a TRS-80 Model 100 briefcase computer but may be installed on virtually any personal computer or laptop.

The program first prompts you for the positive- and zero-sequence impedances of the transmission line. Enter the data in secondary ohms for the entire length of the protected line.

Next, you can enter fault resistance, which is used in the ground-fault computations.

Enter source impedance as a per-unit value with a base of the previously entered transmission line data. For example, if the radial system has a source impedance of about ten percent of the entered line impedance, enter 0.1 for the per-unit distance from the source to the bus.

Specify the distance from the bus to the fault as a fraction of the total line length. To obtain the voltages and currents for a fault half the way down the line from the bus, enter 0.5 for the distance from the bus to the fault.

After you enter these data, the program begins computations. The display then shows voltages and currents for both an AG and BC fault. These data can be entered into any active test source.

The bottom line of the display offers you a choice of entering new impedance data (I), changing the distance from the source to the bus (B), specifying a new fault location (F), or quitting (Q).

This page intentionally left blank

SEL-221G/121G Relay Command Summary

This page intentionally left blank

SEL-221G/121G Relay Command Summary

This page intentionally left blank