







# ATP – Driver Setup Procedure

Document version: 1.0

Release date: 4 October 2017

#### **Document releases**

Release date	Version	Changes
4 October 2017	1.0	

### When to use this document

This document is used to setup the new payment driver in the ATP Platform.

#### **Destination**


This document is intended for internal usage.

## **Terminal Connection Setup**

Before connecting the terminal make sure you have the following information from Ingenico: Terminal ID, Communication Server 1 and Communication Server 2.

To use the terminal you need to connect it to the kiosk.


Check in device manager if the device is recognized by windows or appears in Other devices




If it appears under Other devices you need to install the driver located at C:\Acrelec\Core\Peripherals\Payments\[PaymentName]\[PaymentVersion]\WindowsDriver



When installing the driver, make sure that you select the correct Ingenico terminal



After install, a new COM port should be available in Device Manager:






#### **ATP SETUP**

Open the Admin and login.

Go to the "Peripherals" Tab > select one "Payment" Tab and select "UK\_IPP350".

Fill the required fields:



COM Port is the com port where the device is connected

Terminal ID should be provided by Ingenico

**Currency** is the used currency

Communication Server 1 should be provided by Ingenico

Communication Server 2 should be provided by Ingenico

Welcome message line 1/2 message that is displayed on the terminal screen

<u>Active applications</u> are the applications that will be active after the initialization of the terminal

#### **TEST ENVIRONMENT SETTINGS**

When configuring the device in LAB the following settings must be used:

 Terminal ID:
 20150001

 Communication Server 1:
 91.208.214.106 9744

 Communication Server 2:
 91.208.214.106 9744

These settings are NOT supposed to be used in real environments!