

TAP CISCO MPP Broadworks Provisioning

Test Plan Name: TAP_CiscoMPP_Broadworks_TestSuite

Introduction

➤ This test plan pertains to Cisco Broadworks Provisioning testing of Broadworks calling, with test calls conducted between Cisco MPP phones utilizing the Tekvizion Automation Platform. To use this test plan effectively, the following steps must be followed:

Prerequisites:

- > The Test Plan Required a minimum of 4 MPP phones and Broadworks Server.
- The minimum software version on the MPP phones for use with the 360 Automation Platform is **11.3.1** and higher.
- "Dial Plan" should be configured in MPP phone as below.

 - ⇒ Login to MPP phone-> Admin-> Advanced-> Voice-> Ext1 -> Dial Plan.
- "Auto Answer" should be disabled for all the respective MPP phones.
- ➤ WebSocket connection should be established between tap and MPP phone. (This applies for all available phones. Refer "360 Automation Platform Prerequisites Document -> Section No. 2.Prerequisites on MPP -> Pg No.2")
 - i. Access the phone Web UI: /admin/advanced.
 - ii. Navigate to Voice-> Phone-> WebSocket API fields a. Configure the Control Server URL to: ws://:80/onPOINTLink/sockserver b. Allowed APIs: .*
 - iii. Upon completing the aforementioned configuration, the respective MPP phones should be displayed in "Phone Manager" under "Unmanaged."
- The Call Servers screen provides a count of all the instances of the call servers configured and list the following details *against each: (Admin Panel -> Call Servers, Refer* **360 Automation Platform User Guide Section No. 10.1 Call Servers**)
 - i. Server Name
 - ii. Vendor
 - iii. Model
 - iv. IP Address

Copyright © 2023 by TekVizion PVS, Inc. All Rights Reserved.

TekVizion reserves the right to modify Cisco MPP Audio Call Regression Testing as a Service and the descriptions herein may vary from actual service delivery. Consult Service Terms and Conditions for up-to-date information.

- v. Relay Name
- vi. Server Port
- vii. Protocol
- viii. Status
- ix. Option to perform a Sync and Status of the last Sync action and when it was last updated.
- Adding the Call Servers to the TAP.
 - i. Click the 'New' link.
 - ii. Add a 'Server Name'.
 - iii. Select the 'Vendor' from the dropdown (currently BroadWorks).
 - iv. Choose the 'Model', type of Call server depending on the vendor selected (currently only the
 - v. APP Server is supported).
- > Feature Access Codes should work for all the MPP phones to test the features below.
 - i. Call Park (*68) and Retrieve (*88).
 - ii. Call Forward Always (Activate -*72, Deactivate-*73)
 - iii. Call Forward Busy (Activate -*90, Deactivate-*91)
 - iv. Call Forward NoAnswer (Activate -*92, Deactivate-*93)
 - v. Redial (*66).
 - vi. Return (*69).
 - vii. Cancel Call Waiting (*70).
 - viii. Do not disturb (Activate -*78, Deactivate-*79).
 - ix. Call Pickup (*98).
- Call Pickup should be configured as below.
 - i. In BWKS Navigate to Enterprise/Service provider user group
 - ii. Services >> call pickup >> Add >> Group Name>> Search User >> Add >> ok.
 - iii. Assign the Call pickup service to variable phone A and B as per the test Plan.

Broadworks_Services:

➤ In accordance with the **Test Plan**, the following BroadWorks services must be enabled for the corresponding Cisco MPP phone variables in order to conduct comprehensive testing.

Phone Variables	BWK Services
	Calling Name Delivery
	2. Calling Number Delivery
	3. Three-Way Call
	4. Call Waiting
	5. Call Transfer
	6. Call Forwarding Busy
	7. Call Forwarding Not Reachable
	8. Do Not Disturb
	9. Anonymous Call Rejection.
DUT	10. Intercept user.

Copyright © 2023 by TekVizion PVS, Inc. All Rights Reserved.

TekVizion reserves the right to modify Cisco MPP Audio Call Regression Testing as a Service and the descriptions herein may vary from actual service delivery. Consult Service Terms and Conditions for up-to-date information.

11. Speed Dial 100.	
12. Speed Dial 8.	
13. Push to talk.	
14. Simultaneous ring.	
15. Customer Ringback User.	
16. Authentication.	
17. Priority Alert.	
18. Alternate Numbers.	
Calling Name Delivery	
2. Calling Number Delivery	
3. Three-Way Call	
4. Call Waiting	
5. Call Transfer	
6. Call Return	
7. Call Pickup.	
8. Speed Dial 100.	
9. Speed Dial 8.	
10.	
Calling Name Delivery	
2. Calling Number Delivery	
3. Three-Way Call	
4. Call Waiting	
5. Call Pickup	
Calling Name Delivery	
2. Calling Number Delivery	
3. Call Waiting.	
	12. Speed Dial 8. 13. Push to talk. 14. Simultaneous ring. 15. Customer Ringback User. 16. Authentication. 17. Priority Alert. 18. Alternate Numbers. 1. Calling Name Delivery 2. Calling Number Delivery 3. Three-Way Call 4. Call Waiting 5. Call Transfer 6. Call Return 7. Call Pickup. 8. Speed Dial 100. 9. Speed Dial 8. 10. 1. Calling Name Delivery 2. Calling Number Delivery 3. Three-Way Call 4. Call Waiting 5. Call Pickup 1. Calling Name Delivery 2. Calling Number Delivery 3. Three-Way Call 4. Call Waiting 5. Call Pickup 1. Calling Name Delivery 2. Calling Number Delivery

Broadworks Group Level Services:

- In accordance with the Test Plan,
 - 1. **Identity/Device Profiles**: It should be configured for the Dut in Broadworks portal (This is for Codec supported test cases).
 - 2. **Broadworks Anywhere:** A call director number should be configured.
 - 3. **Group Intercept**: It should be added to the Group Services.

Recommendations for Test Cases:

In accordance with the Test Plan, the following details must be hard-coded for the corresponding test cases to ensure comprehensive testing.

Test Case ID	Hard Code Value Details
	Auto attendant number should provide in line number 4 to initiating the
tekV-Bwk-Ft-MPP-001	call from Dut.

Copyright © 2023 by TekVizion PVS, Inc. All Rights Reserved.

TekVizion reserves the right to modify Cisco MPP Audio Call Regression Testing as a Service and the descriptions herein may vary from actual service delivery. Consult Service Terms and Conditions for up-to-date information.

tekV-Bwk-Ft-MPP-003	Auto attendant number should provide in line number 8 to initiating the call from B.
tekV-Bwk-Ft-MPP-009	To Add the Speed Dial code to Dut, provide the value for test case in line number 4 in Broadworks Provisioning under Parameter. In line number 6, Dut should dial to the speed code value as per configuration of line number 4 .
tekV-Bwk-Ft-MPP-010	To Add the Speed Dial code to Dut, provide the value for test case in line number 6 in Broadworks Provisioning under Parameter. In line number 8, Dut should dial to the speed code value as per configuration of line number 4 .
tekV-Bwk-Ft-MPP-011	In line number 10, provide the Call Director number from the device associated with Number configured at Employee level Call Director settings of DUT user.
tekV-Bwk-Authentication-MPP- 013	Provide Username and New Password for Broadworks provisioning in line number 8. Configure Username in line number 10 for Setconfig. Configure password in line number 12 for Setconfig.
tekV-Bwk-Authentication-MPP- 014	Provide Username and New Password for Broadworks provisioning in line number 8. Configure Username in line number 10 for Setconfig. Configure password in line number 12 for Setconfig.
tekV-Bwk-Authentication-MPP- 015	Provide Username and New Password for Broadworks provisioning in line number 8. Configure Username in line number 10 for Setconfig. Configure password in line number 12 for Setconfig.