

Stepper Motors and Arduino – The Ultimate Guide



In this tutorial we will learn everything we need to know about controlling stepper motors with Arduino. We will cover how to control a NEMA17 stepper motor in combination with a A4988, a DRV8825 and a TMC2208 stepper driver.

This combination of stepper motors and drivers is used in countless applications where position control is needed, such as 3D Printers, CNC Machines, Robotics, Automation machines and so on.

I have already used it myself in many of my Arduino projects, like the following:

- DIY Camera Slider
- 3D Wire Bending Machine
- DIY Foam Cutting Machine
- DIY Laser Engraver
- Pen Plotter with Automatic Pen Changer
- SCARA Robot Arm

I will explain in details how they work, how to connect stepper motors with Arduino, how to set the current limit of the drivers and how to program them with or without an Arduino library. Also, I will show you how we can easily control multiple stepper motors using an Arduino CNC shield for any type of Arduino project.

So, we got quite a lot to cover in this tutorial. You can watch the following video or read the written tutorial below which also includes all example codes and wiring diagrams.




What is a Stepper Motor and How It Works?

I will start with briefly explaining what is stepper motor and how it works, as it will help us better understand everything else in this tutorial.

A stepper motor is a unique type of brushless DC motor which position can be precisely controlled even without any feedback.
The working principle of a stepper motor is based on magnetic fields. It has two main components, a stator and a rotor. The rotor is usually a permanent magnet and it's surrounded by some coils on the stator.
When we energize or let current flow through the coils, particular magnetic fields are generated in the stator that either attract or repel the rotor. By activating the coils, step by step, one after another in a particular order, we can achieve continues motion of rotor, but also, we can make it stop at any position.

So, that's why these motors are called stepper motors, they move in discrete steps.
By increasing the number of magnetic poles on the rotor, we can increase the number of possible stopping positions, thus increase the resolution or the precision of the motor. Please note that this is just a basic explanation and you can find more details in my How Stepper Motors Work tutorial. A typical stepper motor, a NEMA17 for example, has 50 stopping points or steps on the rotor. On the other hand, the stator can have several coils organized in two phases which provide four different magnetic field orientations or positions.

So, the 50 steps of the rotor multiplied by the 4 different magnetic field orientations, make total of 200
steps for completing a full rotation. Or if we divide 360 degrees by 200 steps, that's a resolution of 1.8 degrees per step.
I mentioned that the stator coils are organized in two phases, and we can also notice that if we take a look at number of wires of a stepper motor. It has 4 four wires, two for each phase. The four different magnetic field orientations are possible as we can let current flow through the phases in both directions.



Nevertheless, with this brief explanation, now we understand that for driving a stepper motor, we cannot just connect power to it as nothing will happen. Instead, we have to energize the two motor phases in both directions, and activate or send pulses to them in particular order, in a timely sequence. So, that's why we need drivers for controlling stepper motors.

There are many types and sizes of drivers, corresponding to the many types and sizes of stepper motors. However, the basic working principle of all of them is that they have two H-Bridges that allow energizing the motor phases in both directions.

Of course, they have many other functions like micro stepping, current limiting, and so on that enable us to easily control the stepper motors, which is the whole purpose of them.

How To Control NEMA17 Stepper Motor with Arduino and A4988 Stepper Driver

All right, now we can take a look at the first example for this tutorial, how to control a NEMA 17 stepper motor with an A4988 stepper driver.
All right, now we can take a look at the first example for this tutorial, how to control a NEMA 17 stepper motor with an A4988 stepper drive.
The NEMA17 is the most popular stepper motor among makers, as it offers great performances and it's affordable at the same time. It can be also found in almost any desktop 3D printer and laser engraver.
Generally, the NEMA17 stepper motor has 200 steps, or 1.8 degrees per step resolution, but there are
also models with 400 steps and 0.9 degrees per step resolution. We should note here that the designation NEMA17 actually describes just the size of the motor in terms of the front faceplate size.

The number stands for the size of faceplate in inches when divided by 10, or in this case that would be 17 divided by 10 equals 1.7 inches faceplate, or 2.3 inches faceplate in case of NEMA23.
So, the faceplate size is fixed, but the length of the NEMA17 steppers can vary from 20mm to 60mm, and with that the power requirement of the motor also varies. The power requirement is usually defined by how much current the motor is allowed to draw, and the range for these NEMA17 steppers motors is from 0.3A up to 2.5A.
Now, according to the current rating of the stepper motor, we need to choose a suitable driver which can handle that amount of current. The most popular driver controlling for NEMA17 stepper motors is the A4988 stepper motor driver.
So, the faceplate size is fixed, but the length of the NEMA17 steppers can vary from 20mm to 60mm, and with that the power requirement of the motor also varies. The power requirement is usually defined by how much current the motor is allowed to draw, and the range for these NEMA17 steppers motors is from 0.3A up to 2.5A. Now, according to the current rating of the stepper motor, we need to choose a suitable driver which can handle that amount of current. The most popular driver controlling for NEMA17 stepper motors is

The A4988 has a maximum current rating of 2A per coil, but that's actually a peak rating. It is recommended to keep the current to around 1A, but of course, it is also possible to go up to 2A of good cooling is provided to the IC.

A great feature the A4988 stepper driver has, actually all other drives have, is the current limiting. With this we can easily set how much current the motor will draw no matter the motor rating. For example, we can connect even a 2.5A rated stepper motor, but we will limit the current of the driver to 1.5A. So, although the motor won't work at its maximum capacity, we would still be able to use it.

On the other hand, if the motor is rated lower than the set current limit on the driver, the motor would overheat. Of course, it's always recommended to try to match the current rating of the motor with the current rating of the driver.

A4988 and Arduino Connection

All right, so now let's see how to connect the A4988 driver with the stepper motor and the Arduino controller.

You can get the components needed for this Arduino tutorial from the links below:

•	Stepper Motor NEMA	17	Amazon /	Banggood	/ AliExpress
---	--------------------	----	----------	----------	--------------

- A4988 Stepper Driver...... Amazon / Banggood / AliExpress
- DRV8825 Stepper Driver...... Amazon / Banggood / AliExpress
- TMC2208 Stepper Driver Amazon / Banggood / AliExpress
- Arduino CNC Shield Amazon / Banggood / AliExpress
- Arduino Uno....... Amazon / Banggood / AliExpress

Disclosure: These are affiliate links. As an Amazon Associate I earn from qualifying purchases.

At top right corner of the driver we have the VMOT and GND pins and here we connect the power supply for the motor which can range 8 to 36V. Here it is also recommended to use a decoupling capacitor across these two pins in order to protect the board from voltage spikes. We should use large electrolytic capacitor with at least 47uF capacity.

Next, are the four pins where we connect the stepper motor. One phase of the motor goes on 1A and 1B pins, and the other phase on 2A and 2B pins.

Sometimes, it can be a bit difficult to recognize which two wires of the motor make a phase, but are several ways to identify them. The simplest way is to rotate the shaft of the stepper motor by hand, and then connect two wires to each other. If you connect two wires that make a phase, the rotation of the shaft would be a bit more difficult.	
Another way is to use a multimeter and check for continuity between the two wires. If you connect two wires that make a phase, you will have a short circuit and the multimeter will start beeping.	

Once we find a phase, we can connect it to any position of the two positions on the driver, the order doesn't matter.

Next, we have the IC or the logic power supply pins, VDD and GND, which can be from 3V to 5V. On the other side we have the Step and the Direction pins, which can be connected to any pin of the Arduino board. With the Direction pin we select the rotation direction of the motor, and with the Step pin we control to steps of the motor. With each pulse we send to the Step pin, the motor will advance one step in the selected direction.

Right above these pins, we have the Sleep and the Reset pins which are used for, as their names suggest, putting the driver to sleep mode or resetting it. We should note that both of these pins are active low. The Sleep pin by default is HIGH state, but the RST pin is floating. That means in order to have the driver enabled, the easiest way is to just connect these two pins to each other, assuming we won't use these pins functions.

The Enable pin is also active low, so unless we pull it HIGH, the driver will be enabled.

The next three pins, MS1, MS2 and MS3, are for selecting the step resolution of the motor. We already said that the step resolution depends on the construction of the motor which is usually 200 steps per revolution for a NEMA 17 stepper motor. However, all stepper drivers have this feature called microstepping which allows driving the motor at higher resolutions. This is achieved by energizing the coils at an intermediate current level, which produce intermediate step locations.

For example, if we select quarter-step resolution, the 200 steps of the motor will become, 200 multiplied by 4 equals 800 microsteps per revolution. The driver will use four different current levels on the coils to achieve this.

The A4988 driver has a maximum resolution of 16 microsteps, which would make a 200 steps NEMA17 motor has 3200 steps per revolution, or that's 0.1125 degrees per step. That's really impressive precision and that's why these types of stepper motors and drivers are used in so many applications. Actually, there are stepper drivers that have up 256 microsteps, or that's a whopping 51200 steps per revolution, or 0.007 degrees per step.

Nevertheless, these three pins have pull-down resistors, so if we leave them disconnected, the driver will work in full-step mode. For selecting a different mircrostepping resolution we need to connect 5V to the appropriate pins according to this table.

A4988 Current Limiting

All right, so now that we know how to connect the stepper motor and the driver to the Arduino board, we can move on with explaining how to program or code the Arduino for controlling the stepper. However, before we do that, or before we power the motor, there is one more very important thing that we need to do, and that's to adjust the current limit of the driver.

As we already explained, we need to adjust the current limit of the driver to be lower than the current rating of the motor, or otherwise the motor would overheat.
There's a small trimmer potentiometer on the A4988 driver though which we can adjust the current limit. By rotating the potentiometer clockwise, the current limit raises, and vice versa. There are two methods which can be used for determining the actual value of the current limit.
The first method involves measuring the reference voltage across the potentiometer itself and GND. We can measure the reference voltage using a multimeter, and use that value in the following formula to calculate the current limit of the driver:

The Rcs is the current sense resistance or the values of the current sensing resistors located right next to the chip. Depending on the manufacturer, these values are usually 0.05, 0.1 or 0.2 ohms. So, we need to take a closer look at the value of these resistors in order to accurately calculate the current limit with

this method. In my case, these resistors were labeled R100, which meant 0.10hms.

Current Limit = Vref / (8 x Rcs)

As an example, if we measure a reference voltage of 0.7V, and we have 0.1 ohms resistors, the current limit would be a 0.875A. Or if we want to limit the current to, let's say 1A, we should adjust the reference voltage to 0.8V.

The second method for setting the current limit is by directly measure the current through the coils. For that purpose, we need to connect the stepper motor and the driver as explained previously. We can skip the controller connection, but instead connect 5V to the Direction and the Step pins so that the motor stays active and holds one position. The MS pins should be left disconnected so the driver would work in full-step mode. Then we can disconnect one line or coil from the motor, and connect it in series with an ammeter. In this way, once we power the driver with both the logic voltage, the 5V, and the power for the motor 12V in my case, we can read how much current is running through the coil.

Though, we should note here that when the driver works in full-step mode, the current in the coils can reach only 70% of the actually current limit. So, when using the driver in the other microstepping modes, the reading from the ammeter should be multiplied by 1.3 in order to get the actual value of the current limit of the driver.

I tried both methods for setting up the current limit of the driver and they gave me approximately the same results.

Stepper Motors and Arduino – Example Codes



Let's start with a very basic example code of how to control a stepper motor without using a library.


Example code 1

```
* Basic example code for controlling a stepper without library
 * by Dejan, https://howtomechatronics.com
// defines pins
#define stepPin 2
#define dirPin 5
void setup() {
 // Sets the two pins as Outputs
 pinMode(stepPin,OUTPUT);
 pinMode(dirPin,OUTPUT);
void loop() {
 digitalWrite(dirPin,HIGH); // Enables the motor to move in a particular direction
 // Makes 200 pulses for making one full cycle rotation
 for(int x = 0; x < 800; x++) {
  digitalWrite(stepPin,HIGH);
  delayMicroseconds(700); // by changing this time delay between the steps we can change the rotation speed
  digitalWrite(stepPin,LOW);
  delayMicroseconds(700);
 delay(1000); // One second delay
 digitalWrite(dirPin,LOW); //Changes the rotations direction
 // Makes 400 pulses for making two full cycle rotation
 for(int x = 0; x < 1600; x++) {
  digitalWrite(stepPin,HIGH);
  delayMicroseconds(500);
  digitalWrite(stepPin,LOW);
  delayMicroseconds(500);
 delay(1000);
```

Code description:

Here all we have to do is define to which pin number the STEP and DIR pins are connected and define them as outputs. In the loop, first we set the rotation direction of the motor by making the Direction pin status HIGH. Then using a "for" loop we send 200 pulses to the STEP pin which will make the motor rotate a full cycle, considering that it works in full-step mode. The pulses are generated simply by toggling the state of the STEP pin HIGH to LOW with some time delay between them. This time delay actually defines the speed of rotation. If we lower it, the speed of rotation will increase as the steps will occur faster, and vice versa.

Then we change the rotation direction, and using another "for" loop we send 400 pulses which would make to motor rotate two full cycles. However, if we change the microstepping mode of the driver, let's



int customDelay, customDelayMapped;

```
void setup() {
    // Sets the two pins as Outputs
pinMode(stepPin, OUTPUT);
pinMode(dirPin, OUTPUT);
}

void loop() {
    speedControl();
    // Makes pules with custom delay, depending on the Potentiometer, from which the speed of the motor depends
    digitalWrite(stepPin, HIGH);
    delayMicroseconds(customDelayMapped);
    digitalWrite(stepPin, LOW);
    delayMicroseconds(customDelayMapped);
}

// Custom function for reading the potentiometer and mapping its value from 300 to 3000, suitable for the custom delay value in microsecol
    void speedControl() {
        customDelay = analogRead(A0); // Read the potentiometer value
        customDelayMapped = map(customDelay, 0, 1023, 300, 3000); // Convert the analog input from 0 to 1024, to 300 to 3000
}
```

Code description:

We can then map or convert the potentiometer values which are from 0 to 1023, to values suitable for being a delay time in microseconds for the Step pulses. I found the minimum value for the delay between steps to be around 300 microseconds. By going lower that that the stepper motor started skipping steps.

Overall, controlling stepper motors with this method is easy and it works, but only if the required control is simple as shown in the examples. In case we need more complex control, the best way is to use an Arduino library.

Controlling Stepper Motors with Arduino and the AccelStepper Library – Examples

The most popular library for controlling stepper motors with Arduino is the AccelStepper library by Mike McCauley. It's an extremely versatile library featuring speed, acceleration and deceleration control, setting target positions, controlling multiple stepper motors simultaneously and so on.

The library has a great documentation explaining how each function work. I have already used this library for several of my Arduino projects, for controlling the motion of my DIY Camera Slider, the 3D wire bending machine, the SCARA robot arm and few others. In case you are interested, there are details and code explanations for each project on the website.

Now let's take a look at few examples code using this library.

Example code – Stepper motor speed control using a potentiometer

The first example will be controlling the speed of the motor using the potentiometer.

```
/*

* Basic example code for controlling a stepper with the AccelStepper library

* by Dejan, https://howtomechatronics.com

*/

#include <AccelStepper.h>

// Define the stepper motor and the pins that is connected to

AccelStepper stepper1(1, 2, 5); // (Type of driver: with 2 pins, STEP, DIR)

void setup() {
    // Set maximum speed value for the stepper
    stepper1.setMaxSpeed(1000);
}

void loop() {
    stepper1.setSpeed((analogRead(A0));
    // Step the motor with a constant speed previously set by setSpeed();
    stepper1.runSpeed();
}
```

Code description:

So, here first we need to include the AccelStepper library. Of course, before we do that, we need to install the library and we can do that from the Arduino IDE library manager. We just have to search "AccelStepper" and the library will show up and we can install it.

Then, we need to create an instance of the AccelStepper class for our motor. The first parameter here is the type of driver, in this case for a driver with two control pins this value is 1, and the other two parameters are the pin numbers to which our driver is connect to the Arduino. If we have multiple stepper motors, we need to define each of them like this, and we can name them however we want, in this case I named my motor stepper1.

In the setup section we just have to set the maximum speed of the motor which is defined as steps per second. This value can go up to 4000, but in the documentation of the library it is stated that speed values of more than 1000 steps per seconds might be unreliable.

In the loop section, using the setSpeed() function we set the current speed of the motor, and in this case that's the analog input from the potentiometer which is from 0 to 1023.

In order the motor to move and implement that constant speed, we need to call the runSpeed() function each interval. A negative value here, or simply including a minus sign before the value, would make the stepper motor rotate in the opposite direction.

Example code – Controlling two stepper motors with acceleration and deceleration

Here's another example of controlling two stepper motors with implementing acceleration and deceleration using the AccelStepper library.

```
by Dejan, https://howtomechatronics.com
#include <AccelStepper.h>
// Define the stepper motor and the pins that is connected to
AccelStepper stepper1(1, 2, 5); // (Typeof driver: with 2 pins, STEP, DIR)
AccelStepper stepper2(1, 3, 6);
void setup() {
 stepper1.setMaxSpeed(1000); // Set maximum speed value for the stepper
 stepper1.setAcceleration(500); // Set acceleration value for the stepper
 stepper1.setCurrentPosition(0); // Set the current position to 0 steps
 stepper2.setMaxSpeed(1000);
 stepper2.setAcceleration(500);
 stepper2.setCurrentPosition(0);
void loop() {
 stepper1.moveTo(800); // Set desired move: 800 steps (in quater-step resolution that's one rotation)
 stepper1.runToPosition(); // Moves the motor to target position w/ acceleration/ deceleration and it blocks until is in position
 stepper2.moveTo(1600);
 stepper2.runToPosition();
 // Move back to position 0, using run() which is non-blocking - both motors will move at the same time
 stepper1.moveTo(0);
 stepper2.moveTo(0);
 while (stepper1.currentPosition() != 0 || stepper2.currentPosition() != 0) {
  stepper1.run(); // Move or step the motor implementing accelerations and decelerations to achieve the target position. Non-blocking func
  stepper2.run();
  //
  //
 }
```

Code description:

So, we need to define the two stepper motors, and in the setup, using the setAcceleration() function set the acceleration value for the motors. Using the setCurrentPosition() function we set the position of the motors to be at 0 steps.

In the loop section, we start with the moveTo() function through which we tell the motor to what position to go or how many steps it should move. In case of quarter-step resolution, 800 steps would mean one full rotation. Then, the runToPosition() function moves the motor to that position while implementing acceleration and deceleration. However, this is a blocking function, so the code execution will stay there until the stepper motor reaches that position.

With the same method we move the second motor 1600 steps or two full rotations with quarter-step resolution.

If we don't want our code to be blocked until the motor reach the target position, instead of using the runToPosition() function, we should use the run() function. The run() also implements acceleration and deceleration to achieve the target position, but it just makes one step per call. Therefore, we need to call it as frequently as possible. For that reason, here we put the run() functions for both motors in this while loop, which is executed until both steppers reach position 0. We previously set the two motors to go to position 0 with the moveTo() functions.

We could also add more code in that "while" loop and do other stuff too along running the motor. Actually, there are many methods of running the motors and doing other stuff too. I recommend going through the nicely described documentation of the library so you can understand how each function works and implement them according to your needs.

Example code – Controlling multiple stepper motors with AccelStepper library

I would like to show you one more example using the AccelStepper library and that's controlling multiple stepper motors in a coordinated fashion. This means, we can set target positions for each stepper and they can reach their positions all at the same time, no matter the different distance they need to travel.

This can be easily done using the MultiStepper class that comes with the AccelStepper library.

```
Controlling multiple steppers with the AccelStepper and MultiStepper library
   by Dejan, https://howtomechatronics.com
#include <AccelStepper.h>
#include < MultiStepper.h>
// Define the stepper motor and the pins that is connected to
AccelStepper stepper1(1, 2, 5); // (Typeof driver: with 2 pins, STEP, DIR)
AccelStepper stepper2(1, 3, 6);
AccelStepper stepper3(1, 4, 7);
MultiStepper steppersControl; // Create instance of MultiStepper
long gotoposition[3]; // An array to store the target positions for each stepper motor
void setup() {
 stepper1.setMaxSpeed(1000); // Set maximum speed value for the stepper
 stepper2.setMaxSpeed(1000);
 stepper3.setMaxSpeed(1000);
 // Adding the 3 steppers to the steppersControl instance for multi stepper control
 steppersControl.addStepper(stepper1);
 steppersControl.addStepper(stepper2);
 steppersControl.addStepper(stepper3);
void loop() {
 // Store the target positions in the "gotopostion" array
 gotoposition[0] = 800; // 800 steps - full rotation with quater-step resolution
 gotoposition[1] = 1600;
 gotoposition[2] = 3200;
 steppersControl.moveTo(gotoposition); // Calculates the required speed for all motors
 steppersControl.runSpeedToPosition(); // Blocks until all steppers are in position
 delay(1000);
 gotoposition[0] = 0;
 gotoposition[1] = 0;
 gotoposition[2] = 0;
 steppers Control. move To (got oposition);\\
 steppersControl.runSpeedToPosition();
 delay(1000);
```

Code description:

Here we also need to include the MultiStepper class, and create an instance of it. Then we need to define an array, type "long", which will be used for storing the target positions for our motors. In the

setup section, we need to define the maximum speed values of the steppers and add the steppers to the previously created MultiStepper instance, which in my case I named it "steppersControl".

In the loop section, we start by storing the target position values in the array that we previously created. I set the first stepper to move one rotation, the second, two rotations and the third one, three rotations. Then we can assign this array to the moveTo() function which will calculate the required speeds for all motors to arrive at those positions at the same time. Then we just have to call the runSpeedToPosition() function which will move the motors to their position. Though we should note that this function blocks the code until the steppers reach their target position. We could use the run() function instead, if we don't want to block the code. We should also note that the MultiStepper class doesn't support acceleration and deceleration.

Nevertheless, if you want to learn more, from more advanced examples, you can check my Arduino projects that I already mentioned, all the details and the codes for them are on the website.

CNC shield for controlling multiple stepper motors for any Arduino project

Still taking about controlling multiple stepper motors, it's worth mentioning and taking a look at the Arduino CNC shield.

The main purpose of the Arduino CNC shield is for controlling 2 or 3-axis CNC machines, but it is actually a great option for controlling any type of project where we need to control multiple stepper motors as it is compact and provides easy connections for the drivers and the motors.

This shield goes on top of an Arduino UNO board, and can control up to 4 individual stepper motors, and have all the remaining Arduino pins available for use. I used this combination of an Arduino UNO board and the CNC shield for controlling my 4-axis SCARA robot arm.

I will update this section of the article, how to use the CNC shield with Arduino with more details soon.


DRV8825 vs A4988


All right, so now let's move on and see how we can control stepper motors using the other driver that I mentioned at the beginning, the DRV8825.


Actually, everything we explained so far about controlling stepper motors with the A4988 stepper driver, applies for the DRV8825 as well. The working principle, the connections and the coding are almost the same for both of these drivers. The difference between them is in their technical characteristics and now we will take a look at them and compare them.


The DRV8825 is a stepper driver by Texas Instruments which can be used as direct replacement for the Allegro A4988 driver as their connections are the same. The three key differences between them are that the DR8825 can deliver more current than the A4988 without additional cooling (1.5A vs 1A), it has

higher maximum supply voltage (45V vs 35V), and it offers higher microstepping resolution (32 vs 16 microsteps).
Of course, they also have some other minor differences. For example, the current limit potentiometer has a different location and the relationship between the current limit setting and the reference pin voltage is different. The DRV8825 doesn't need logic power supply, and the that pin location is used as FAULT output.
However, it is safe to connect the FAULT pin directly to 5V, so the DRV8825 can be used as a direct replacement in systems designed for the A4988 driver.
It's worth noting though, that when replacing an A4988 driver with an DRV8825 it is very important to make sure the orientation of the driver is correct. I already mentioned, their potentiometers are at different locations, on the A4988 it's below the chip, and on the DRV8825 is above the chip, and that can sometimes cause confusion and the driver can be easily placed on the wrong side.
For setting the current limit, we can measure the reference voltage with one probe on GND and the other on the potentiometer itself.









If you are interested in learning how to control bigger stepper motors like NEMA23 or NEMA34, I will have a dedicated tutorial for that too.

I hope you enjoyed this tutorial and learned something new. Don't forget to subscribe and feel free to ask any question in the comments section below.

■ Arduino Tutorials

nRF24L01 – How It Works, Arduino Interface, Circuits, Codes

CNC Machined vs 3D Printed Cycloidal Drive – Designing & Testing

4 thoughts on "Stepper Motors and Arduino – The Ultimate Guide"

Joe

November 1, 2022 at 6:36 pm

Great! However, is the quoted text below really true?

"On the other hand, if the motor is rated lower than the set current limit on the driver, the motor would overheat. Of course, it's always recommended to try to match the current rating of the motor with the current rating of the driver."

If the motor can only draw 2 amps, then having a larger supply (say 3 amps) should not hurt anything, since only 2 amps would ever get used. If we are talking about too much wattage, one would think that reducing the voltage or current limit could prevent overheating. Having a smaller amp draw on the motor (smaller motor) is likely an easier thing to deal with than having a smaller supply current (smaller driver). I would not think it's a good idea to 'match' the amperage of the driver and motor, but rather be sure you have a driver equal to or larger than the motor.

Nikki Wilson

October 16, 2022 at 3:35 am

Much thanks for an understandable and useful tutorial on this topic.

I also vote for a detailed description and examples of the TMC2208/2209 in UART / config / operation mode. And if you could throw in the utilization of the CNC shield that would tick all my boxes.

Keep up the outstanding work!

Reply

Chas

August 23, 2022 at 11:15 am

This is without a doubt the most comprehensive and useful article on stepper motor control by Arduino. Excellent stuff!

For me the one thing missing – if only you went on to show how to properly configure the advanced features of the Trinamic TMC2208 or TMC2209, in an Arduino sketch, without necessarily having to get to grips with the library (which defeats me) I for one, and I am sure many others) would be delighted.

Keep up the good work.

Reply

Dejan


August 31, 2022 at 11:13 am

Thank you, glad you found it useful!

Well, I will try to explain those TMC2208 configuration features in some future tutorials

Reply

Leave a Comment



Post Comment



Hey I'm Dejan, a maker, a techie and a mechatronics engineer. I love making electronics and robotics projects for you to learn and make something cool on your own.

Don't forget to check my 600K+ subs YouTube Channel.







Table of Contents

- 1. What is a Stepper Motor and How It Works?
- 2. How To Control NEMA17 Stepper Motor with Arduino and A4988 Stepper Driver

- 2.1. A4988 and Arduino Connection
- 2.2. A4988 Current Limiting
- 3. Stepper Motors and Arduino Example Codes
- 4. Controlling Stepper Motors with Arduino and the AccelStepper Library Examples
 - 4.1. Example code Stepper motor speed control using a potentiometer
 - 4.2. Example code Controlling two stepper motors with acceleration and deceleration
 - 4.3. Example code Controlling multiple stepper motors with AccelStepper library
- 5. CNC shield for controlling multiple stepper motors for any Arduino project
- 6. DRV8825 vs A4988
- 7. TMC2208 Stepper Driver
- 8. Conclusion

report this ad

FEATURED PROJECTS

report this ad

report this ad

How To Mechatronics

HowToMechatronics is an education website in the area of Mechanical, Electrical and Computer Engineering. Tutorials, Tips, Tricks, How It Works, Projects, Examples, Source Codes, Download files and much more can be found here.

Disclosure

HowToMechatronics is a participant in the Amazon Services LLC Associates Program, an affiliate advertising program designed to provide a means for sites to earn advertising fees by advertising and linking to Amazon.com

Copyright © 2023 HowToMechatronics.com. All rights reserved. Terms and Conditions | Privacy Policy