General Single Dish Data Format

The following format is a very general description of header and data values associated with spectral line and continuum single dish data*. This format has been produced with the combined efforts of NRAO, IRAM, Cambridge University and the University of Arizona. Its purpose is to standardize what header parameters may be included in single dish data as well as their names and units. Header parameters are grouped by class where the first n words of each class are defined. A prolog to the format declares the number of header classes and the starting location of each class. Each class may expand or contract as necessary as long as the order of the first n words in the class remains unchanged. A class may be omitted altogether or a subset of words in a class may appear in the format, but parameters may only be deleted from the bottom of a class. Implementation of the format as the internal representation of data in the analysis programs will facilitate easy merging of data from different observatories around the world.

All values in the header are eight-byte entities, either double precision real values (R*8) or character strings that are multiples of eight bytes (C*8). In the following table the first field names the data parameter, the second is a FITS keyword with a maximum of eight characters, the next field defines the data pointer name for each variable, the fourth field indicates the word location of the data parameter as a multiple of eight bytes, followed by the type of data (double precision real numbers or ASCII characters), the units of the parameters and lastly any comments.

Class 9 is an open area to be defined by each telescope for parameters unique to itself. Class 10 is an area to be defined by the observer when reducing the data.

Following the format table is a glossary of terms to describe each of the parameters in detail.

^{*} A single entity of data may represent more than one receiver polarization or more than one frequency range, but it may not represent more than one position on the sky.

General Single Dish Data Format

Number of Header Classes	I HEADCLS	I COHCL I	0 1	R+8
Starting Location of Class One	ONEPTR	C01P	i l	R+8
Starting Location of Class Two	TWOPTR	C02P	ž l	R+8
Starting Location of Class Three	THRPTR	CØ3P	<u> 3</u>	R+8
Starting Location of Class Four	FOURPTR	C04P	4	R+8
Starting Location of Class Five	FIVEPTR	C05P	5	R+8
Starting Location of Class Six	SIXPTR	CO6P	6	R+8
Starting Location of Class Seven	SEVPTR	C07P	7	R+8
Starting Location of Class Eight	EIGPTR	C08P	8	R+8
Starting Location of Class Nine	NINEPTR	C09P	9	R+8
Starting Location of Class Ten	TENPTR	C010P	10	R+8
Starting Location of Class Eleven	ELVPTR	C011P	11	R+8
Starting Location of Class Twelve	TWLPTR	C012P	12	R+8

Class 1 : Basic Information	All word locations are offsets from Class 1 Starting Location			
Length of Header Length of Data Scan Number Observer Initials Observer Name Telescope Descriptor Project Identification Source Name Type of Data and Observing Mode Frontend Descriptor Backend Descriptor Data Precision of Spectrum	HEADLEN			
Class 2 : Pointing Parameters	All word locations are offsets from the Class 2 Starting Location			
Total Az/RA Pointing Correction Total El/Dec Pointing Correction User Az/RA Pointing Correction User El/Dec Pointing Correction Pointing Constants(4) Receiver Box or Secondary Orientation Radial Focus North-South Focus East-West Focus	XPOINT			

Class 3 : Observing Parameters	All word locations are offsets from the Class 3 Starting Location
Universal Time Date Universal Time LST Number of Receiver Channels Number of Switching Variables Number of Phases per Cycle Length of Cycle Length of Sample	UTDATE C3DAT 0 R*8 Hours YY.MMDD UT C3UT 1 R*8 Hours LST C3LST 2 R*8 Hours NORCHAN C3NRC 3 R*8 NOSWVAR C3NSV 4 R*8 NOPHASE C3PPC 5 R*8 CYCLLEN C3CL 6 R*8 Sec SAMPRAT C3SRT 7 R*8 Sec
Class 4 : Positions	All word locations are offsets from Class 4 Starting Location
Epoch Commanded Source X Commanded Source Y Commanded Reference X Commanded Epoch Right Ascension Commanded Epoch Declination Commanded Galactic Longitiude Commanded Galactic Latitude Commanded Azimuth Commanded Elevation Indicated X Position Indicated Y Position Descriptive Origin(3) Coordinate System Code	EPOCH
Class 5 : Environment	All word locations are offsets from the Class 5 Starting Location
Ambient Temperature Pressure Relative Humidity Index of Refraction Dew Point VM H2O	TAMB

the state of the s

Class 6: Map Parameters	All word locations are offsets from the Class 6 Starting Location
Map Scanning Angle X Position at Map Reference Position Zero Y Position at Map Reference Position Zero Delta X or X Rate Delta Y or Y Rate Number of Grid Points Number of X Grid Points Number of Y Grid Points Starting X Grid Cell Number Starting Y Grid Cell Number XY Reference Frame Code	SCANANG
Class 7 : Data Parameters	All word locations are offsets from the Class 7 Starting Location
Beam Fullwidth at Half Maximum Off Scan Number Bad Channel Value Velocity Correction Velocity with respect to Reference Velocity Definition and Reference Type of Calibration	BFWHM
Class 8 : Engineering Parameters	All word locations are offsets from the Class 8 Starting Location
Antenna Aperture Efficiency Antenna Beam Efficiency [ETA(MB)] Antenna Gain ETAL Rear Spillover & Scattering Efficiency ETAFSS Forward Spillover & Scattering Eff	APPEFF C8AAE 0 R+8
Class 9 : Telescope Dependent Parameters	All word locations are offsets from the Class 9 Starting Location
Parameters Unique to Given Telescope	UNITEL C9UTL 0-9 R+8 See Extended Telescope Fo

the control of the co

Open Parameter Values(10)	OPENPAR	C10PV	0-9	C+8	ŀ
			·		
lass 11 : Phase Block Repeated for the Number of Switc All word locations are offsets i	ching Variablirom the Clas	es (NOSWVAR) s 11 Starting	Locatio	n	
/ariable Value /ariable Descriptor Phase Table	VARVAL VARDES PHASTB	C11VV C11VD C11TP	0 1 2	R+8 C+8 C+8	
Repeated for Number of Receiver All word locations are offsets for Number of Receiver All word locations are offsets for Receiver Frequency or Total Power Calibration Receiver Resolution or SP Calibration Receiver Temperature Calibration Temperature Receiver Temperature Reference System Temperature Reference System Temperature Reference Receiver Temperature Reference Receiver Re	OBSFREQ RESTFREQ FREQRES BW TRX TCAL STSYS RTSYS TSOURCE TRMS REFPT X0	C12CF C12RF C12RF C12FR C12FR C12FR C12CT C12CT C12CT C12CT C12CT C12CT C12CT C12CT C12CT C12CT C12CT C12CT C12CT	0 1 2 3 4 5 6 7 8 9 10	R*8 MHz R*8 MHz R*8 MHz R*8 MHz R*8 Deg K R*8 Deg K R*8 Deg K R*8 Deg K R*8 R*8 R*8 R*8	
(Value at the Reference Point Delta X Total Integration Time Number of Integrations Starting Point Number 120 Opacity 120 Temperature	DELTAX INTTIME NOINT SPN TAUH2O TH2O	C12DX C12IT C12NI C12SPN C12WO C12WT		R+8 Sec R+8 R+8 R+8 R+8 Deg K	

added to each class at the end and more classes may be added after class twelve. Spectral values will follow starting at byte location LENGTH OF HEADER + 1.

Spectral Values {Ph1(ch1), Ph2(ch1), ... | SPECT | | PRECIS |

L1 L1F1 L1F2 L2 L2F1 L2F1 L4 LB	L1 L1F1 L1F2 L2 L2F1 L2F2 LA	C9L1 C9L1F1 C9L1F2 C9L2 C9L2F1 C9L2F2 C9LA C9LB	0 1 2 3 4 5 6	R*8 R*8 R*8 R*8 R*8 R*8	MHz MHz MHz MHz MHz MHz MHz MHz
LC LD Level Correction	LC LD LEVCORR	C9LVC C9LD	8 9 10	R+8 R+8 R+8	MHz MHz
Pointing Fudge(2) RHO THETA Center Frequency Formula (4)	PTFUDGE RHO THETA CFFORM	C9PF C9RHO C9THE C9CFF	11 12 13 14–21	R+8 R+8 R+8 C+8	Deg Deg

Class 9 : Telescope Dependent Parameters — 12M

Synthesizer Frequency LO Factor Harmonic LO IF First IF Reference Azimuth Offset Reference Elevation Offset Beam Throw Beam Orientation Baseline Offset	SYNFREQ LOFACT HARMONIC LOIF FIRSTIF RAZOFF RELOFF BMTHROW BMORENT BASEOFF	C9SYN C9LOF C9HM C9LOI C9FIF C9RAO C9REO C9BT C9BOR C9BO	0 1 2 3 4 5 6 7 8 9	R**8 R**8 R**8 R**8 R**8 R**8 R**8	MHz MHz MHz MHz MHz Arcsec Arcsec Deg Deg K
Baseline Offset Observing Tolerance Sideband	BASEOFF OBSTOL SIDEBAND	C9BO C9OT C9SB	9 10 11	R+8 R+8 R+8	Deg K Arcsec

General Single Dish Data Format Glossary

The general single dish data format is divided into thirteen classes where the thirteenth is the spectral values. Each parameter is discussed in its class below.

Class 1: Basic Information

These parameters are used to identify the block of data with a particular Observer/Project/Telescope.

- Length of header -Number of bytes to describe this header. The spectral values start at byte address length of header + 1.
- Length of data -2. Number of bytes to describe the spectral values.
- 3. Scan Number -A number assigned at the telescope to be associated with this scan.
- 4. Observer Initials -A data ID used to segregate each observer's data.
- 5. Observer Name -Name of the primary Observer.
- Telescope Descriptor -A field of eight characters to describe where the data are taken. NRAO 12M NRAO 42M NRAO 93M MPI 100M

IRAM 30M NRO 45M PMO 14M OSO 20M MASS 14M UTX 5M UK-D 15M IRAM 15M

- Project Identification -The program ID associated with the proposal as it appears on the telescope schedule.
- Source Name -8. As provided by the observer.
- 9. Type of Data and Observing Mode -Field of 8 characters where four describe the type of data and four describe the observing mode. Type of Data Observing Mode LĬÑE PSSW PLSW CONT FQSW SHSW **FSAM** BMSW LDSW PULS

TLPW

10. Frontend Descriptor -

A field of 8 characters to describe the receiver used.

Typical NRAO frontends are:

2C3MMSIS 140CASS 2.7-1.2M 2C3MMSHM 21CM 4CH 1.2-0.6M 2MM 11CM3CH 100-30CM .8MM 6/25 6CM 25-20 CM BOLOMETR 23-17CM 6/2525CM 15-0.6CM

11. Backend Descriptor -

A field of 8 characters to describe the backend used.

Typical NRAO backends are:

DIĞITAL STD A/D FABRITEK 384ACIII 1024ACIV 1536HYSP .O3MHZFB .1MHZ FB .25MHZFB .5MHZ FB 1.MHZ FB 2.MHZ FB

12. Data Precision of the Spectrum -

The specification of the nuber of bits and data type used to represent the data. It may be one of the following:
L*1 I*2 I*4 R*4 R*8 R*16 C*8 C*16

Class 2: Pointing Parameters

This group of parameters refers to the telescope pointing, both those offsets and terms provided by the observer and those computed by the online program.

- Total Az/RA Pointing Correction –
 The total pointing correction applied in the X (horizontal) direction.
- 2. Total El/Dec Pointing Correction The total pointing correction applied in the Y (vertical)
 direction.
- 3. User Az/RA Pointing Correction Additional X pointing correction supplied by the observer.
- 4. User El/Dec Pointing Correction Additional Y pointing correction supplied by the observer.

At the 42M these constants refer to the PVAL's.

5. Pointing Constants(4) Up to four constants to describe a secondary pointing correction.
At the 12M these are AO, C, BO and ELO in the expressions below:
Delta Az = AO * COS(EL) + C
Delta El = BO * COS(EL) + ELO

- 6. Receiver or Secondary Orientation Rotation or polarization angle orientation of the receiver
 or reflector at the prime focus.
- 7. Radial Focus Radial focus position.
- 8. North-South Focus Vertical focus offset.
- 9. East-West Focus Horizontal focus offset.

Class 3 : Observing Parameters

A group of parameters that characterize the when and how of the observations.

- 1.-3. UT Date; UT Time: LST Date and time at the start of the observation.
 - 4. Number of Receiver Channels The number of independent polarizations or channels of this
 frontend. When receiver channels refer to different positions
 in the sky, they are expressed as separate scans.

The following parameters are defined as a very general description of observations made with one ore more of the observing variables being switched. For example, in beam-switched observations one variable, sky position, is switched (via subreflector motion or a comparision of two feed horns). One could also imagine beam switching at the same time that polarization was switched — in this case 2 variables are switched. If "phase" of a switched variable is used to describe one state of the switch, then a 2-position subreflector nutation, for example, would be a switch with "2 phases" per cycle. Similarly, if one switches between a center frequency and 2 offset frequencies, then this switch has "3 phases" per cycle and so forth.

- 5. Number of Switching Variables A simple integer count of the number of variables being switched.
- 6. Number of Phases per Cycle An integer count of the number of different states of the switched variables.
- 7. Length of Sample The time required to complete a single sample. A sample may be composed of multiple cycles. Also known as the SAMPLE RATE.

Class 4: Positions

For each scan the telescope is given, or computes following the observer's instructions, a position at a particular epoch. The right ascension of that position is "Epoch Right Ascension" and the declination is "Epoch Declination". At the time of the observation, however, the telescope is directed to a position corresponding to horizontal coordinate "xcoord", which may be either RA(date) or AZ(date), and corresponding to vertical coordinated "ycoord", which may be DEC(date) or EL(date). The actual position that the telescope points to differs from "xcoord" and "ycoord" by whatever are the current pointing offsets. This position, i.e., the position at which the telescope actually points, is the "indicated" position described by horizontal coordinate "indicated x telescope position" and vertical telescope coordinate "indicated y telescope position". Finally, using RA(epoch) one calculates the Galactic coordinates "longitude and latitude". For all observations the above parameters have meaning and are computed. If the observer wishes to define his own coordinate system relative to one of the standard coordinate systems defined above, he does so with the descriptive coordinate array.

- As specified by the observer.
 - 2. Epoch Right Ascension RA at "Epoch" of the source or position specfied.
 - 3. Epoch Declination Dec at "Epoch" of the source or position specified.
 - 4. Galactic Longitude Longitude of the source or position specified.
 - 5. Galactic Latitude Latitude of source or position specified.
 - 6. Azimuth Azimuth of the source or position specified.
 - 7. Elevation Elevation of the source or position specified.
 - 8. Source Xcoord Horizontal coordinate of source or position in the coordinate
 system specified by the observer.
 - 9. Source Ycoord Vertical coordinate of source or position in the coordinate
 system specified by the observer.
- 10. Reference Xcoord Horizontal coordinate of the reference position in the coordinate system specified by the observer.

- 11. Reference Ycoord Vertical coordinate of the reference position in the
 coordinate system specified by the observer.
- 12. Indicated Xcoord Horizontal telescope coordinate of the position actually observed, i.e. position measured by horizontal encoder.
- 13. Indicated Ycoord Vertical telescope coordinate of the position actually observed, i.e., position measured by vertical encoder.
- 14. Descriptive Origin(3) An orthogonal 2-dimensional coordinate system defined by
 the observer by means of
 - a. horizontal positionb. vertical position
 - c. position angle describing the orientation on the sky, of the "horizontal axis".
- 15. Coordinate System Code An eight character field which specifies in which coordinate system the observations are commanded:

GALACTIC = Galactic (LII, BII)

1950RADC = 1950 RA, Dec EPOCRADC = Epoch RA, Dec

MEANRADC = Mean RA, Dec at start of scan

APPRADC = Apparent RA, Dec APPHADC = Apparent HA, Dec 1950ECL = 1950 Ecliptic EPOCECL = Epoch Ecliptic

MEANECL = Mean Ecliptic at start of scan

APPECL - Apparent Ecliptic AZEL - Azimuth, Elevation

USERDEF - User defined coordinate system

2000RADC = 2000 RA, Dec

INDRADC - Indicated RA. Dec

Class 5 : Environment

The environment parameters define the external physical conditions affecting the telescope.

- 1. Ambient Temperature
- 2. Pressure
- 3. Relative Humidity
- 4. Index of Refraction
- 5. Dew Point
- 6. MM H20

Class 6: Map Parameters

The purpose here is to store an entire map as a single entity. The map is understood to be rectangular with dimensions "xpoints" by "ypoints" where these parameters simply count the number of map cells along the two orthogonal axes of the rectangular map. The orientation on the sky of the rectangle is defined by "map scanning angle", with this angle referring to the orientation of the horizontal, x, axis. A reference point for the map on the sky is specified by means of the horizontal and vertical telescope coordinates "xposition at zero" and "yposition at zero", respectively. The reference point need not be the center of the rectangle and, in fact, need not even be within the region mapped. The rectangle to be mapped is fully described by the parameters "starting xcell" and "starting ycell", together with the total number of points to be sampled in each coordinate "xpoint" and "ypoint", respectively.

For example, suppose we wish to construct a square map with 41 points on a side centered on the reference position. In this case.

starting xcell = -20 starting ycell = -20 xpoints = 41 ypoints = 41

On the other hand, suppose we wish to make the same map near, but not including, that same reference position. Then, perhaps

starting xcell = 20 starting ycell = -61 xpoints = 41 ypoints = 41

and the region from (x,y) = (20,-61) to (x,y) = (61,-20) will be mapped.

- 1. Map Scanning Angle Orientation on the sky in the reference frame specified by
 "XY Reference Frame Code" of the rectangle to be mapped.
 It is not the angle through the rectangle that the telescope
 is driven. This provides an alternate capability to that
 of using descriptive coordinates.
- 2. Xposition at Zero -Horizontal telescope coordinate at the map reference position. Together with "Yposition at Zero", this defines the cell (X,Y) = (0,0) at the map reference position.
- 3. Yposition at Zero Vertical telescope coordinate at the map reference position.
- 4. Delta X or X Rate The cell size or distance (in minutes of arc/minutes of time)
 between cells on the x axis.
- 5. Delta Y or Y Rate The cell size or distance between cells on the y axis.

- 6. Number of Xpoints Map sample points along the "x-edge" of the rectangle.
- 7. Number of Ypoints Map sample points along the "y-edge" of the rectangle.
- 8. Number of Points Total number of cells in the map. This should be (x*y).
- 9. Starting Xcell Cell number. May be positive, negative or zero. It is
 used to define the position of the rectangle to be mapped
 with respect to the reference position which, by definition
 is (x,y) = (0,0).
- 10. Starting Ycell Cell number as above.
- 11. XY Reference Frame Code —
 An eight character code which states whether the grid is polar (POLR) or cartesian (CART) and whether items 3 and 4 refer to STEP sizes or SCANning rates.

Class 7: Observing Parameters

- Beam Full Width at Half Maximum -Telescope main beamwidth at the observing frequency.
- 2. Off Scan Number Scan number of the last designated total power off scan.
- 3. Bad Channel Value The antenna temperature to be assigned to those filterbank channels that are noted as defective.
- 4. Velocity with respect to the Reference The source velocity specified by the observer relative to
 the velocity reference frame.
- 5. Doppler correction for the earth's motion in the source direction with respect to the velocity reference frame chosen.
- 6. Velocity Definition and Reference —
 An eight character field to describe the velocity system.
 The velocity definition may be:
 RADI OPTL RELV
 The velocity reference may be:
 LSR HELO EART BARI OBS

Class 8: Engineering Parameters

This is an area for describing the physical aspects of the telescope.

- 1. Antenna Aperture Efficiency The ratio of total power observed to the total power incident on the telescope.
- 2. Antenna Beam Efficiency The fraction of the beam lying in a diffraction limited
 main beam.
- 3. Antenna Gain
- 4. ETAL Rear Spillover and Scattering Efficiency
- 5. ETAFSS Forward Spillover and Scattering Efficiency

Class 9: Telescope Dependent Parameters

This is an area of 24 R*8 words reserved for those parameters that are unique to a given telescope.

For the Green Bank telescopes they are: the LO values - L1, L1F1, L1F2, L2, L2F1, L2F2, LA, LB, LC, LD, the level correction, the pointing fudge(2), and the center frequency formula(4). See addendum to format table.

For the 12M telescope they are: synthesizer frequency, LO Factor, Harmonic LOIF, first IF, reference azimuth offset, reference elevation offset, beam throw, beam orientation, baseline offset, sideband and observing tolerance.

Class 10 : Open Parameters

An area of 10 R*8 words are reserved for the observer to describe his data reduction of the current scan.

Class 11 : Phase Block

This block describes what variables are switched in the scan. For instance, a scan may be position switched, beam switched, frequency switched, load switched, focus switched, polarization switched, or any combination of the above or simply a measure of total power. The variable value is value of one switch state. For example, to switch high and low about a center frequency requires three variable values. A total power observation requires one value.

Associated with each variable value is a variable descriptor of eight characters and a 32 bit phase table which reflects when that particular state is on with a one and when it is off with a 0. These three parameters are repeated for as many times as there are switching states. Also note that the phases appear in the description of the spectrum in the same order as they appear here.

- 1. Variable Value The value of a single switch state.
- 2. Variable Descriptor An 8 character descriptor of the switching variable.
- 3. Phase Table A bit-map description of when each switch state is on and off. An integration can have a maximum of 32 states.

An example of a phase block is shown below: An observation is made by switching the telescope position and the focus. There are five switching states. The table would look like Variable Values - 0, +30, -30, +54, -54 Variable Descriptors - POSN ON, POSN HI, POSN LO, FOCUS HI, FOCUS LO Phase Table - 0 0 1 1 1 1 0 0

Class 12: Descriptor Block for each Receiver Channel

Certain parameters vary with an individual receiver channel. When multiple polarizations are used, this block must be repeated for each channel.

- 1. Observed Frequency The center frequency of the observation.
- 2. Rest Frequency/Total Power Calibration In the spectral line observation the rest frequency of the observation or in the continuum observation the total power calibration.
- 3. Frequency Resolution/Switched Power Calibration
 In the spectral line observation the frequency spacing of the spectral line backend or in the continuum observation the switched power calibration.
- 4. Bandwidth The total bandwidth in MHz of this receiver channel.
- 5. Receiver Temperature The receiver temperature measured for a given channel.

- 6. Calibration Temperature The value of the noise tube diode or other calibration temperature used to calibrate the data.
- 7. Source System Temperature The system temperature measured on source.
- 8. Reference System Temperature The system temperature measured on reference.
- 9. Source Temperature Source temperature computed for a series of on-off samples.

 10. RMS RMS value about the mean source temperature.
- 11. Reference Point Number The position in the spectral line device for which the observer enters a frequency and/or velocity. It is usually the first or center channel.
- 12. X value at the Reference Point Value of the x-axis at the reference point.
- 13. Delta X The step size along the x-axis.
- 14. Total Integration Time The total integration time for this receiver channel.
- 15. Number of Integrations The number of data points for this receiver channel.
- 16. Starting Point Number The starting point location of this receiver channel in the data area.
- 17. H2O Opacity The opacity of water as computed by a model.
- 18. H2O Temperature The temperature of water.
- 19. O2 Opacity The opacity of oxygen as computed by a model.
- 20. O2 Temperature The temperature of oxygen.
- 21. Polarization Description An eight character field to describe the type of polarization and the angle. The type may be RC, LC or LIN. The angle can be expressed to the nearest tenth of a degree.

Class 13 : Spectral Values

The spectral values (n phases for m channels) appear in an array where the data precision is defined in the first class.