



Horizontal Pressure Sand Filter with Manual Valves

Introduction

A pressure sand filter is one in which the water to be filtered is pumped through a layer of sand contained within a pressure vessel. High flow sand filters are designed for filtering rates of up to 20 gallons per minute per square foot of filtering area. This filter system will, with proper care and maintenance, give trouble-free and efficient operation.

The filtering principle is simple. Fine sand is used to filter out all the dirt suspended in the water. Pool water is forced by the pump through a distributor system at the top of the filtering tank. This distributor system is designed to maintain a uniform flow downward through the sand and out a second collector system at the bottom of the tank.

In sand filtration, at these high rates, penetration or depth filtration occurs within the sand; the dirt entrapped in the water passes down several inches into the sand rather than being collected on the surface of the sand or in a bed of alum as in the lower rate rapid sand pressure filters.

When dirt accumulates in the sand the influent pressure increases. When the desired flow rate can no longer be maintained, the filter is cleaned by simply reversing the flow. High-rate sand filtration is possible through the proper internal design of the filter. So long as the flow, either upward or downward, is uniform without jets or eddy currents, these high rates may be maintained without disrupting the filter bed.

This system is designed to run 24 hours a day. Filter cycles will vary. Bathing loads, suntan lotions and wind conditions, among other things, create variances in the filter cycle. Health departments in many areas maintain and exercise sanitary procedures; nevertheless, even though the flow rate is maintained, we recommend that the filters be put through the backwash cycle when the differential pressure between the influent and effluent reaches 10± psi or when the designed flow rate cannot be maintained (whichever occurs first). This will keep the filter in excellent, healthful, maintenance-free operation, year-in and year-out. Any backwash requirements of local or state regulatory agencies should also be met. The filters are usually cleaned in two to four minutes by reversing the flow of the water.



Operating Instructions

Valve Legend:

All normal functions of the filter(s) are controlled by wafer valves. It is good practice to stop the pump and motor before changing the position of the valves. For convenience in operation, all valves have been tagged and correspond with the filter valve legend on the filter drawings.

2. Return to Pool	4. Filter Influent
3. Backwash to Waste	5. Backwash Influent

Initial Start-Up:

The following steps are to be taken when you place your filter in operation for the first time:

1. Check pump strainer. Make sure it is clean and full of water.
2. Check pump rotation to ensure that the motor has been correctly wired.
 - a. **Note:** the impeller should rotate in a clockwise direction when viewed from the motor end. If rotation is opposite, the motor has been incorrectly wired.
3. Set the filter for backwash (see operating instructions). Backwash a minimum of (2 - 4) minutes to clean the filter media or Backwash until the sight glass runs clear.

In many areas when a new pool is filled, the water will appear green and/or cloudy. This green and/or cloudy appearance can be caused by plaster fines present in the water, traces of iron or organic matter, algae in the make-up water or by a combination of all. This type of contamination will always clog any type filter in a relatively short period of time.

If any appreciable amounts of iron or other metals are present, they may turn the pool water brown upon chlorination and stain the interior finish of the swimming pool. The pool water supply should be laboratory tested, and the water should be treated to remove the iron or other materials found in it before filling and/or super-chlorinating.

It is recommended that the pool be super-chlorinated immediately after filling and that the filter be backwashed promptly when the differential pressure between the influent and effluent reaches 10 $\pm$ psi or when the designed flow rate cannot be maintained. If this procedure is followed, the pool will be cleaned up in a minimum of time. After super-chlorination, do not enter the pool until chlorine level has returned to normal.

The backwash operation may be required daily or several times a day for the first few days until the water becomes sparkling blue. After the cloudiness and/or green appearance is gone, you need only backwash as covered elsewhere in this manual. Check the pump strainer, the converter strainer basket and any skimmer baskets daily and clean as required, establishing regular schedules.

To Backwash Filter:

Backwash Rate: SEE FILTER DRAWING

The filter should be backwashed when the differential pressure reaches 10 $\pm$ psi, or the flow rate can no longer be maintained.

All chemical systems, heaters and auxiliary pumping equipment should be turned off 15 minutes prior to backwashing. Heater isolation valves should be closed prior to backwashing.

Backwashing Steps:

1. Turn off pump
2. Move both linkage levers from filter to backwash and lock into place
3. Restart pump and backwash filter for 2-4 minutes or until water runs clear
4. Turn off pump
5. Move both linkage levers from backwash to filter and lock into place
6. Restart the pump



When initially starting the filter system, record the normal influent and effluent pressures with a clean filter operating at the prescribed filter flow rate.

Influent Pressure : _____ psi Effluent Pressure : _____ psi

Flow Rate: **SEE FILTER DRAWING**

To Filter Pool:

Place both linkages in filter mode and lock into place, then start pump.

In operation, flow is balanced from the perimeter overflow channel (PO) and the main drain. To balance flow, the MOL will need to be set. Instructions on how to do so can be found on the following page.

As activity increases in the pool, more water will flow from the PO channel causing the water level in the balance line/tank to rise. This increase in water level in the balance line (balance tank) will increase the head on the main drain line and less water will flow through from the main drain and the system will balance.

Checking the Flow Rate:

The recirculation pump is designed to deliver the designated flow rate at a specified total dynamic head. Total head on the pump is the combination of the vacuum and discharge pressure losses. The conversion factors for the vacuum and pressure reading to feet of head are:

1. One inch of vacuum equals 1.13 feet of head.
2. One psi equals 2.31 feet of head.

Procedure: (Assume a newly backwashed filter)

1. Set the system to filter position.
2. Read the vacuum gauge.
3. Convert vacuum reading to feet of head by multiplying by 1.13.
4. Subtract the results of no. 3 from the design head of your pump.
5. Divide the results of no. 4 by 2.31. This gives the pump discharge pressure to obtain the desired total dynamic head and, hence, the designed flow rate.
6. Should the vacuum reading drop appreciably, repeat steps 2 through 5.

Like a properly installed flow meter, a pump performance curve is guaranteed accurate within 5%. Flow meter installations vary, thus when pump pressures are set as described here, the flow meter reading should be noted as the proper recirculation rate, regardless of its actual reading.

To Set MOL:

This level should be set with a clean filter when there is no activity in the pool and all water is being drawn from the main drain. The system should be set to filter and the proper flow rate established with valve #2.

For a Balancing Line: Restrict the Main Drain valve just upstream of the connection with the balancing line until the minimum operating level (MOL) is established.

For closed balance tank: Restrict Main Drain valve until the red line on the water level gauge (Indicating MOL) has been reached.

For an open balance tank: Restrict the Main Drain valve at its entrance to the balancing tank until there is about 6" of water covering the pump suction line.

As water enters the gutter and fills the balancing line, the pressure in will increase and water will be taken from this line. When the perimeter overflow channel is running nearly full, most of the water required for the full re-circulating rate will be taken from the surface of the pool through the balancing line.

To Filter Pool and Vacuum - Portable Vacuum:

With valves in filter position, discharge portable pump into overflow channel. If a considerable amount of dirt is being vacuumed and the pressure builds in the filter tank, it should be backwashed.

To Clean the Strainer:

Slowly close isolation valve downstream of pump, then stop pump. Close isolation valve upstream of the strainer. Remove cover and clean basket. Be sure strainer is filled with water after cleaning. Replace cover tightly. Open upstream valve and start pump. Slowly open valve downstream of pump. Establish a regular schedule for checking the strainer.

To Empty Pool with Pump and Motor:

Exercise every possible care in this operation to prevent air from entering the main drain line or other piping, as this will cause the pump to lose its prime. Take care to maintain a positive pressure on the backwash discharge valve to avoid losing prime. It is advisable, when emptying the pool (unless the pump is located beneath the lowest point of the pool); to complete the operation without interruption, because turning off the pump and motor will normally result in loss of prime.

Set filter valves in their backwash positions and drain the pool through the filter system. If there is a filter bypass to waste valve, use it to bypass the filter and pump directly to waste.

For Further Information, please contact Paddock Pool Equipment Company - Customer Service.

