Steps to Fix CNANO Connectivity

Step	Description	Command/Action
1	Open Terminal or Command Prompt: Start by opening your terminal or command prompt	
2	Ensure pip is installed: Before installing the packages, ensure you have pip installed. If pip is not installed, follow these instructions to install it.	pipversion
3	Install Pydebugger: Pydebugger	pip install pydebugger
4	Verify Pydebugger Installation	pydebuggerversion
5	Install Pydebuggerconfig	pip install pydebuggerconfig
6	Verify Pydebuggerconfig Installation	pydebuggerconfigversion
7	Write Device Configuration	pydebuggerconfig write -d device- configs\AVR16EB32-device-blob.xml
8	Write Board Configuration	pydebuggerconfig write -b board- configs\AVR16EB32-CNANO.xml
9	Restart the Board:	Unplug and replug the board