


AC Paint Sprayer ORIGINAL INSTRUCTION




1




WARNING!
Please read all safety warnings careful and be sure that they are fully understood before handling the tool


■ PRODUCT DESCRIPTION






2



3



4



5

6

preventive safety measures reduce the risk of starting the power tool accidentally.
d. Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool. Power tools are dangerous in the hands of untrained users.
e. Maintain power tools and accessories. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tools operation. If damaged, have the power tool repaired before use. Many accidents are caused by poorly maintained power tools.
f. Keep cutting tools sharp and clean. Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.
g. Use the power tool, accessories and tool bits etc. in accordance with these instructions, taking into account the working conditions and the work to be performed. Use of the power tool for operations different from those intended could result in a hazardous situation.
h. Keep handles and grasping surfaces dry, clean and free from oil and grease. Slippery handles and grasping surfaces do not allow for safe handling and control of the tool in unexpected situations.

SERVICE

- a. Have your power tool serviced by a qualified repair person using only identical replacement parts. This will ensure that the safety of the power tool is maintained.
- b. Never service damaged battery packs. Service of battery packs should only be performed by the manufacturer or authorized service providers.

Safety Instructions for Spray Guns

- The device may not be used in workplaces covered by the explosion-protection regulations.
- There must be no sources of ignition such as, for example, open fires, smoke of lit cigarettes, cigars and tobacco pipes, sparks, glowing wires, hot surfaces, etc. in the vicinity during spraying.
- Do not spray any substances whose hazard potential is not known.

9

10

8. Turn off the machine and remove the plug.
9. Screw off the container and empty it. Pull out the suction tube with container seal. **CAUTION!** Never clean seals, diaphragm and nozzle or air holes of the spray gun with metal objects. The ventilation hose and diaphragm are only solvent-resistant to a limited extent. Do not immerse in solvent, only wipe.
11. The device can only be operated with an integer valve (figs. 10,1). If paint passes through the valve clearance (figs. 10,1), check and clean the valve (see Maintenance Section).
12. Rotate the mounting nut (fig. 12,1) to remove and remove it more easily.
13. Unscrew the mounting nut (12,1). Clean the air cap (2) and the nozzle (3) with a handbrush solvent or water.
14. Clean the outside of the spray gun and container with a cloth soaked in solvent or water.
15. Assemble the parts again (see Assembly).
16. Clean the outside of the spray gun and container with a cloth soaked in solvent or water. Unscrew the union nut (Fig. 19, 1) and remove the air cap (2) and nozzle (3). Clean the air cap, nozzle with a brush and solvent or water.

Accessories

- 1) Screw the union nut (Fig. 12, 1) onto the gun and tighten it.
- 2) Place the container seal from below on the suction tube and slide it over the collar, while turning the container seal slightly.

Spare Parts List

Pos.	Designation
1	Union nut
2	Air cap
3	2.0 nozzle
4	Spray gun front part
5	Material volume regulation with spring, complete
6	Spray gun rear part
7	Air filter
8	Air filter cover
9	Valve
10	Suction tube
11	Container seal

13

14

■ SAFETY INSTRUCTIONS

GENERAL SAFETY WARNINGS

WARNING! Read all safety warnings, instructions, illustrations and specifications provided with this power tool. Failure to follow all instructions listed below may result in electric shock, fire and/or serious injury.
Save all warnings and instructions for future reference. The term "power tool" in the warnings refers to your mains-operated (corded) power tool or battery operated (cordless) power tool."

WORK AREA SAFETY

- a. Keep work area clean and well lit. Cluttered or dark areas invite accidents.
- b. Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust. Power tools create sparks which may ignite the dust or fumes.
- c. Keep children and bystanders away while operating a power tool. Distractions can cause you to lose control.

ELECTRICAL SAFETY

- a. Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools. Unmodified plugs and matching outlets will reduce risk of electric shock.
- b. Avoid body contact with earthed or grounded surfaces, such as pipes, radiators, ranges and refrigerators. There is an increased risk of electric shock if your body is earthed or grounded.
- c. Do not expose power tools to rain or wet conditions. Water entering a power tool will increase the risk of electric shock.
- d. Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges or moving parts. Damaged or entangled cords increase the risk of electric shock.
- e. When operating a power tool outdoors, use an extension cord suitable for outdoor use. Use of a cord suitable for outdoor use reduces the risk of electric shock.
- f. If operating a power tool in a damp location is unavoidable, use a residual current device (RCD) protected supply. Use of an RCD reduces the risk of electric shock.

3

7

PERSONAL SAFETY

- a. Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication. A moment of inattention while operating power tools may result in serious personal injury.

- b. Use personal protective equipment. Always wear eye protection. Protective equipment such as a dust mask, nonskid safety shoes, hard hat, or hearing protection used for appropriate conditions will reduce personal injuries.

- c. Prevent unintentional starting. Ensure the switch is in the off-position before connecting to a power source and/or battery pack, picking up or carrying the tool. Carrying power tools with your finger on the switch or energising power tools that have the switch on invites accidents.

- d. Remove any adjusting key or wrench before turning the power tool on. A wrench or a key left attached to a rotating part of the power tool may result in personal injury.

- e. Do not overreach. Keep proper footing and balance at all times. This enables better control of the power tool in unexpected situations.

- f. Dress properly. Do not wear loose clothing or jewellery. Keep your hair and clothing away from moving parts. Loose clothes, jewellery or long hair can be caught in moving parts.

- g. If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used. Use of dust collection can reduce dust-related hazards.

- h. Do not let familiarity gained from frequent use of tools allow you to become complacent and ignore tool safety principles. A careless action can cause severe injury within a fraction of a second.

POWER TOOL USE AND CARE

- a. Do not force the power tool. Use the correct power tool for your application. The correct power tool will do the job better and safer at the rate for which it was designed.
- b. Do not use the power tool if the switch does not turn it on and off. Any power tool that cannot be controlled with the switch is dangerous and must be repaired.
- c. Disconnect the plug from the power source and/or remove the battery pack, if detachable, from the power tool before making any adjustments, changing accessories, or storing power tools. Such

8

■ Start-up

Before connecting to the mains supply, be sure that the supply voltage is identical with the value given on the rating plate.

- Unscrew the container from the spray gun.
- Aligning suction tube. (Fig. 2)
- If the suction tube is positioned correctly, the container contents can be sprayed without almost any residue.
- When working on lying objects: Turn the suction tube forwards. (Fig. 2 A)
- Spraying work when working on overhead objects: Turn the suction tube rearwards. (Fig. 2 B)

- Set the container on a sheet of paper, pour in the prepared coating material and screw the container tightly onto the spray gun.
- Connect the front part with the rear part of the gun (Fig. 3).
- Put the machine down only on a level, clean surface. Otherwise the machine could tip over!
- Pull the trigger guard. This has a two-stage trigger guard. In the first stage the turbine is started. If the trigger guard is pressed further, the material is transported.
- Adjust the spray setting on the spray gun.

■ Explanation of symbols used

	This symbol indicates a potential danger for you or for the device. Under this symbol you can find important information on how to avoid injuries and damage to the device.
	Danger of electrical shock
	Indicates tips for use and other particularly useful information.
	Devices and accessories marked with this symbol are suitable for processing low-viscosity materials such as paints, glazes and wall paints specifically designed for this purpose. If a material bears this logo, it is particularly well suited for use with the relevant device.

■ Description/ Scope of delivery

cope of delivery (Fig. 1)	
1) Nozzle	2) Air Cap
3) Union nut	4) Spray gun front part
5) Trigger	6) Spray gun rear part
7) Material volume adjustment	8) air filter cover
9) Mains lead	10) Container

■ Preparation of the Coating Material

The enclosed spray attachment can be used to spray paints, varnishes and glazes that are undiluted or slightly diluted. Detailed information is available in the technical data sheet of the manufacturer (→ Internet download).

1. Stir the material up and put the required amount into the paint container.

Thinning recommendation

Sprayed material	Thinning recommendation
Glazes	undiluted
Wood preservatives, mordants, oils, disinfection agents, plant protective agents	undiluted
Paints containing solvents and water-soluble paints, primers, vehicle coating paints, thick-jelly glazes	dilute by 5 - 10%
Wall paints with the red Perfect Spray logo	dilute in accordance with manufacturer's instructions

2. If the convey capacity is too low, add 5 - 10% dilution step-by-step until the convey capacity fulfils our requirements.

11

12	Container with cover
13	1.0 nozzle
14	1.5 nozzle
15	3.0 nozzle
16	Clean the connector
17	Dust blowing joint
18	Through needle
19	Cleaning brush
20	Viscosity cup

■ Accessories

The CLICK&PAINT SYSTEM with additional spray attachments and accessories offers the right tool for each work.

- We recommend against using the with the Wall Extra I-Spray spray attachment.

■ Correction of Malfunctions

Problem	Cause	Remedy
No coating material emerges from the nozzle	• Nozzle clogged • Feed tube clogged • Material volume setting turned too far to the left (-) • Feed tube loose • No pressure build-up in container	Clean Clean Turn to the right (+) Insert Tighten container
Coating material drips from the nozzle	• Nozzle loose • Nozzle worn • Nozzle seal is missing or worn • Coating material assembly at air cap, nozzle or needle	Tighten Change Insert an intact nozzle seal Clean
Atomisation too coarse	• Viscosity of coating material too high • Material volume too large • Material volume adjustment screw turned too far to the right (+) • Nozzle contaminated • Air filter heavily soiled • Too little pressure build-up in container	Thin Turn material volume adjusting screw to the left (-) Clean Change Tighten container

15</

■ RECYCLING AND DISPOSAL



Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice.



This product uses lithium-ion (Li-ion) batteries. Local, state or federal laws may prohibit disposal of batteries in ordinary trash. Consult your local waste authority for information regarding available recycling and/or disposal options.

■ STORAGE

- 1.Switch the product off.
- 2.Clean the product as described above.
- 3.Store the product and its accessories in a dark, dry, frost-free, well-ventilated place.
- 4.Always store the product in a place that is inaccessible to children.
- 5.We recommend using the original package for storage protect it against dust.

■ TRANSPORTATION

- 1.Switch the product off.
- 2.Attach transportation guards, if applicable.

3.Always carry the product by its handle.

4.Protect the product from any heavy impact or strong vibrations which may occur during transportation in vehicles.

5.Secure the product to prevent it from slipping or falling over.

■ WARRANTY

This product is guaranteed for 24 months in material and workmanship defects from the date of purchase.

This guarantee does not cover defects and damage caused by or resulting from:

- Normal wear and tear, including accessory wear
- Repairs attempted by anyone other than an authorised agent
- Cosmetic damage
- Damage caused by foreign objects, substances or accidents
- Accidental damage or modification
- Loss of use of the goods


18

xuzhoushihengyuandianqiyouxiangongsi

Tongshan Economic development

xuzhou jiangsu

sales@hoya.com.cn



Made in China

17