

# Computational Aircraft Prototype Syntheses: The CAPS API

Part of ESP Revision 1.18


### **Bob Haimes**

haimes@mit.edu

Aerospace Computational Design Lab Massachusetts Institute of Technology



### CAPS Infrastructure in ESP



2/47

### Problem Object

The Problem is the top-level *container* for a single mission. It maintains a single set of interrelated geometric models, analyses to be executed, connectivity and data associated with the run(s), which can be both multi-fidelity and multidisciplinary. There can be multiple Problems in a single execution of CAPS and each Problem is designed to be *thread safe* allowing for multi-threading of CAPS at the highest level.

### Value Object

A Value Object is the fundamental data container that is used within CAPS. It can represent *inputs* to the Analysis and Geometry subsystems and *outputs* from both. Also Value Objects can refer to *mission* parameters that are stored at the top-level of the CAPS database. The values contained in any *input* Value Object can be bypassed by the *linkage* connection to another Value (or *DataSet*) Object of the same *shape*. Attributes are also cast to temporary (*User*) Value Objects.

### Analysis Object

The Analysis Object refers to an instance of running an analysis code. It holds the *input* and *output* Value Objects for the instance and a directory path in which to execute the code (though no explicit execution is initiated). Multiple various analyses can be utilized and multiple instances of the same analysis can be handled under the same Problem.

### Bound Object

A Bound is a logical grouping of BRep Objects that all represent the same entity in an engineering sense (such as the "outer surface of the wing"). A Bound may include BRep entities from multiple Bodies; this enables the passing of information from one Body (for example, the aero OML) to another (the structures Body).

### Dimensionally:

- 1D Collection of Edges
- 2D Collection of Faces

### VertexSet Object

A VertexSet is a *connected* or *unconnected* group of locations at which discrete information is defined. Each *connected* VertexSet is associated with one Bound and a single *Analysis*. A VertexSet can contain more than one DataSet. A *connected* VertexSet can refer to 2 differing sets of locations. This occurs when the solver stores it's data at different locations than the vertices that define the discrete geometry (i.e. cell centered or non-isoparametric FEM discretizations). In these cases the solution data is provided in a different manner than the geometric.

### DataSet Object

A DataSet is a set of engineering data associated with a VertexSet. The rank of a DataSet is the (user/pre)-defined number of dependent values associated with each vertex; for example, scalar data (such as *pressure*) will have rank of one and vector data (such as *displacement*) will have a rank of three. Values in the DataSet can either be deposited there by an application or can be computed (via evaluations, data transfers or sensitivity calculations).



## **CAPS** Objects

Object	SubTypes	Parent Object
capsProblem	Parametric, Static	
capsValue	GeometryIn, GeometryOut,	capsProblem,
	Branch, Parameter, User	capsValue
capsAnalysis		capsProblem
capsValue	AnalysisIn, AnalysisOut	capsAnalysis,
		capsValue
capsBound		capsProblem
capsVertexSet	Connected, Unconnected	capsBound
capsDataSet	User, Analysis, Interpolate,	capsVertexSet
	Conserve, Builtin, Sensitivity	

Body Objects are EGADS Objects (egos)



## **CAPS** Body Filtering

Filtering the active CSM Bodies occurs at two different stages, once in the CAPS framework, and once in the AIMs. The filtering in the CAPS framework creates sub-groups of Bodies from the CSM stack that are passed to the specified AIM. Each AIM instance is then responsible for selecting the appropriate Bodies from the list it has received.

The filtering is performed by using two Body attributes: "capsAIM" and "capsIntent".

### Filtering within AIM Code

Each AIM can adopt it's own filtering scheme for down-selecting how to use each Body it receives. The "capsIntent" string is accessible to the AIM, but it is for information only.



## CAPS Body Filtering

## CSM AIM targeting: "capsAIM"

The CSM script generates Bodies which are designed to be used by specific AIMs. The AIMs that the Body is designed for is communicated to the CAPS framework via the "capsAIM" string attribute. This is a semicolon-separated string with the list of AIM names. Thus, the CSM author can give a clear indication to which AIMs should use the Body. For example, a body designed for a CFD calculation could have:

ATTRIBUTE capsAIM \$su2AIM;fun3dAIM;cart3dAIM

### CAPS AIM Instantiation: "capsIntent"

The "capsIntent" Body attribute is used to disambiguate which AIM instance should receive a given Body targeted for the AIM. An argument to <code>caps\_load</code> accepts a semicolon-separated list of keywords when an AIM is instantiated in CAPS/pyCAPS. Bodies from the "capsAIM" selection with a matching string attribute "capsIntent" are passed to the AIM instance. The attribute "capsIntent" is a semicolon-separated list of keywords. If the string to <code>caps\_load</code> is <code>NULL</code>, all Bodies with a "capsAIM" attribute that matches the AIM name are given to the AIM instance.



### Other Reserved CAPS Attribute names

### capsLength

This string Attribute must be applied to an EGADS Body to indicate the length units used in the geometric construction.

### capsBound


This string Attribute must be applied to EGADS BRep Objects to indicate which CAPS Bound(s) are associated with the geometry. A entity can be assigned to multiple Bounds by having the Bound names separated by a semicolon. Face examples could be "Wing", "Wing;Flap", "Fuselage", and etc.

Note: Bound names should not cross dimensional lines.

### capsGroup

This string Attribute can be applied to EGADS BRep Objects to assist in grouping geometry into logical sets. A geometric entity can be assigned to multiple groups in the same manner as the capsBound attribute.

Note: CAPS does not internally use this, but is suggested of classifying geometry.



Setup (or read) the Problem:

- Initialize Problem with csm (or static) file GeomIn and GeomOut parameters
- Specify mission parameters
- Make Analysis instances
   AnalysisIn and AnalysisOut params
- Create Bounds, VetrexSets & DataSets
- Establish linkages between parameters

### Run the Problem:

- Adjust the appropriate parameters
- Regenerate Geometry (if dirty)
- Call for Analysis Input file generation
- Framework/user runs each solver
- Inform CAPS that an Analysis has run fills AnalysisOut params & DataSets (lazy)
- Generate Objective Function

Save the Problem DB (checkpointing)

### Open CAPS Problem

```
icode = caps_open(char *name, char *pname, capsObj *problem)
          name the input file name – action based on file extension:
                           *.caps read the saved CAPS problem file
                            *.csm initialize the project using the specified OpenCSM file
                          *.egads initialize the project based on the static geometry
         pname the input CAPS problem process name
        problem the returned CAPS problem Object
```

### Set Verbosity Level

```
icode = caps_outLevel(capsObj problem, int outLevel)
       problem the CAPS problem object
       outLevel 0 - minimal, 1 - standard (default), 2 - debug
          icode the integer return code / old outLevel
```

### Close CAPS Problem

```
icode = caps_close(capsObj problem)
       problem the input CAPS problem to close and perform a memory cleanup
```

### CAPS API – Utilities

### Save Problem file

```
icode = caps_save(capsObj problem, char *name)
        problem the input CAPS problem Object to write
          name the save file name – no extension (added by this function)
          icode the integer return code
```

## Information about an Object

```
icode = caps_info(capsObj object, char **name, enum *type, enum *stype,
                       capsObj *link, capsObj *parent, capsOwn *last)
         object the input CAPS Object
          name the returned Object name pointer (if any)
           type the returned data type: Problem, Value, Analysis, Bound, VertexSet, DataSet
          stype the returned subtype (depending on type)
            link the returned linkage Value Object (NULL – no link)
         parent the returned parent Object (NULL for a Problem or an Attribute generated User Value)
            last the returned last owner to touch the Object
          icode integer return code
```

### caps

### Children Sizing info from a Parent Object

```
icode = caps_size(capsObj object, enum type, enum stype, int *size)
          object the input CAPS Object
           type the data type to size: Bodies, Attributes, Value, Analysis, Bound, VertexSet, DataSet
          stype the subtype to size (depending on type)
            size the returned size
          icode integer return code
```

### Get Child by Index

```
icode = caps_childByIndex(capsObj object, enum type, enum stype,
                                 int index, capsObj *child)
         object the input parent Object
           type the Object type to return: Value, Analysis, Bound, VertexSet, DataSet
          stype the subtype to find (depending on type)
          index the index [1-size]
          child the returned CAPS Object
          icode integer return code
```

13/47

### CAPS API – Utilities

### Get Child by Name

### Delete an Object

```
icode = caps_delete(capsObj object)
    object the Object to be deleted
        Note: only Value Objects of subtype User and Bound Objects may be deleted!
    icode integer return code
```

### Get Body by index

```
icode = caps_bodyByIndex(capsObj obj, int ind, ego *body, char **unit)
            obj the input CAPS Problem or Analysis Object
            ind the index [1-size]
          body the returned EGADS Body Object
          units pointer to the string declaring the length units – NULL for unitless values
          icode integer return code
```

### Set Owner Data

```
icode = caps_setOwner(capsObj prob, char *pname, capsOwn *owner)
           prob the input CAPS Problem Object
         pname a pointer to the process name character string
         owner a pointer to the CAPS Owner structure to fill
          icode integer return code
```

- Notes: (1) This increases the Problem's sequence number
  - (2) This does not return the owner pointer, but uses the address to fill
  - (3) The internal strings can be freed up with caps\_freeOwner

15/47

### caps

### Free Owner Information

```
caps_freeOwner(capsOwn *owner)
```

owner a pointer to the CAPS Owner structure to free up the members pname, pID and user

### Get Owner Information

### CAPS API – Utilities

### **Get Error Information**

### Free Error Structure

```
icode = caps_freeError(capsErrs *errors)
    errors the CAPS Error structure to be freed
    icode integer return code
```

### Free memory in Value Structure

```
caps_freeValue (capsValue *value)
value a pointer to the Value structure to be cleaned up
```

## Create A Value Object

```
icode = caps_makeValue(capsObj problem, char *vname, enum subtype,
                             enum vtype, int nrow, int ncol, void *data,
                             char *units, capsObj *val)
       problem the input CAPS Problem Object where the Value to to reside
         vname the Value Object name to be created
        subtype the Object subtype: Parameter or User
          vtype the value data type:
                      Boolean 2 Double
                                                           String Tuple
                      Integer 3 Character String
          nrow number of rows (not needed for Character Strings)
           ncol number of columns (not needed for strings) - vlen = nrow * ncol
           data pointer to the appropriate block of memory
                must be a pointer to a capsTuple structure(s) when vtype is a Tuple
           units pointer to the string declaring the units – NULL for unitless values
            val the returned CAPS Value Object
          icode integer return code
```



### Retrieve Values

```
icode = caps_getValue(capsObj val, enum *vtype, int *vlen, void **data,
                           char **units, int *nErr, capsErrs **errs)
            val the input Value Object
          vtype the returned data type:
                      Boolean 2 Double
                                                       4 String Tuple
                      Integer 3 Character String 5 Value Object
           vlen the returned value length
           data a filled pointer to the appropriate block of memory (NULL – don't fill)
                Can use childByIndex to get Value Objects
           units the returned pointer to the string declaring the units
           nErr the returned number of errors generated – 0 means no errors
           errs the returned CAPS error structure - NULL with no errors
          icode integer return code
```

Use the structure *capsTuple* when casting data if a Tuple (4)

## Reset A Value Object

```
icode = caps_setValue(capsObj val, int nrow, int ncol, void *data)
   val the input CAPS Value Object (not for GeometryOut or AnalysisOut)
   nrow number of rows (not needed for Character Strings)
   ncol number of columns (not needed for strings) - vlen = nrow * ncol
   data pointer to the appropriate block of memory used to reset the values
```

## Get Valid Value Range

```
icode = caps_getLimits(capsObj val, void **limits)
    val the input Value Object
limits an returned pointer to a block of memory containing the valid range [2*sizeof(vtype)
    in length] - or - NULL if not yet filled
```

### Set Valid Value Range

```
icode = caps_setLimits (capsObj val, void *limits)
    val the input Value Object (only for the User & Parameter subtypes)
    limits a pointer to the appropriate block of memory which contains the minimum and maximum range allowed (2 in length)
    icode integer return code
```

## Get Value Shape/Dimension

```
icode = caps_getValueShape(capsObj val, int *dim, enum *lfixed,
                                  enum *sfixed, enum *ntype,
                                  int *nrow, int *ncol)
            val the input Value Object
           dim the returned dimensionality:
                      scalar only
                      vector or scalar
                      scalar, vector or 2D array
          lfixed 0 – the length(s) can change, 1 – the length is fixed
          sfixed 0 - the Shape can change, 1 - Shape is fixed
          ntype 0 – NULL invalid, 1 – not NULL, 2 – is NULL
          nrow number of rows - parent index for Value vtypes
           ncol number of columns
                Note: vlen = nrow * ncol
          icode integer return code
```

## Set Value Shape/Dimension

out the returned converted value in the Value Object's units

### Units conversion

```
icode = caps_convert(capsObj val, char *units, double in, double *out)
    val the reference Value Object
    units the pointer to the string declaring the source units
    in the source value to be converted
```

### Transfer Values

```
icode = caps_transferValues(capsObj src, enum tmethod, capsObj dst,
                                    int *nErr, capsErrs **errs)
             src the source input Value Object (not for Value or Tuple vtypes) - or -
                 DataSet Object
        tmethod 0 - copy, 1 - integrate, 2 - weighted average - (1 & 2 only for DataSet src)
             dst the destination Value Object to receive the data
                 Notes:
                    Must not be GeometryOut or AnalysisOut
                       Shapes must be compatible
                       Overwrites any Linkage
           nErr the returned number of errors generated – 0 means no errors
            errs the returned CAPS error structure – NULL with no errors
          icode integer return code
```

### Establish Linkage

```
icode = caps_makeLinkage(capsObj link, enum tmethod, capsObj trgt)
```

link linking Value Object (not for Value or Tuple vtypes or Value subtype User) – or – DataSet Object

tmethod 0 - copy, 1 - integrate, 2 - weighted average - (1 & 2 only for DataSet link)

trgt the target Value Object which will get its data from link Notes:

- Must not be GeometryOut or AnalysisOut
- Shapes must be compatible
- link = NULL removes any Linkage

icode integer return code

Note: circular linkages are not allowed!

### caps

### Get Attribute by name

```
icode = caps_attrByName(capsObj object, char *name, capsObj *attr)
   object any CAPS Object
   name a string referring to the Attribute name
   attr the returned User Value Object (must be deleted when no longer needed)
   icode integer return code
```

### Get Attribute by index

```
icode = caps_attrByIndex(caps0bj object, int in, caps0bj *attr)
    object any CAPS Object
    in the index (bias 1) to the list of Attributes
    attr the returned User Value Object (must be deleted when no longer needed)
        Attribute name is the Value Object name
    icode integer return code
```

Note: The *shape* of the original Value Object is not maintained, but the length is correct.

Set an Attribute

```
icode = caps_setAttr(capsObj object, char *name, capsObj attr)
          object any CAPS Object
          name a string referring to the Attribute name – NULL: use name in attr
                 Note: an existing Attribute of this name is overwritten with the new value
            attr the Value Object containing the attribute
                 The attribute will not maintain the Value Object's shape
          icode integer return code
```

### Delete an Attribute

```
icode = caps_deleteAttr(capsObj object, char *name)
          object any CAPS Object
          name a string referring to the Attribute to delete
                 NULL deletes all attributes attached to the Object
          icode integer return code
```



## Query Analysis – Does not 'load' or create an object

```
icode = caps_queryAnalysis(capsObj problem, char *aname,
                                  int *nIn, int *nOut, int *execution)
        problem a CAPS Problem Object
         aname the Analysis (and AIM plugin) name
                 Note: this causes the the DLL/Shared-Object to be loaded (if not already resident)
            nIn the returned number of Inputs
          nOut the returned number of Outputs
      execution the returned execution flag: 0 – no execution, 1 – AIM performs analysis
          icode integer return code
```

### Get Bodies

```
icode = caps_qetBodies(capsObj analysis, int *nBody, ego **bodies)
        analysis the Analysis Object
         nBody the returned number of EGADS Body Objects that match the Analysis' intent
         bodies the returned pointer to a list of EGADS Body/Node Objects,
                Tessellation Objects (set by aim_setTess) follow (length - 2*nBody)
          icode integer return code
```

## Query Analysis Input Information

### **Query Analysis Output Information**

Haimes CAPS API 11 March 2020 28/47

## Load Analysis into a Problem

```
icode = caps_load(capsObj problem, char *aname, char *apath,
                       char *unitSys, char *intent, int naobj,
                       capsObj *aobjs, capsObj *analysis)
        problem a CAPS Problem Object
          aname the Analysis (and AIM plugin) name
                 Note: this causes the the DLL/Shared-Object to be loaded (if not already resident)
          apath the absolute filesystem path to both read and write files
                 this is required even if the AIM does not use the filesystem, so that the combination
                 of aname and apath is unique
         unitSys pointer to string describing the unit system to be used by the AIM (can be NULL)
                 see specific AIM documentation for a list of strings for which the AIM will respond
          intent the intent character string used to pass Bodies to the AIM, NULL - no filtering
          naobj the number of parent Analysis Object(s)
           aobjs a list of the parent Analysis Object(s) – may be NULL if naobj == 0
        analysis the resultant Analysis Object
          icode integer return code
```

## Initialize Analysis from another Analysis Object

## Get Dirty Analysis Object(s)

```
icode = caps_dirtyAnalysis(capsObj object, int *nAobj, capsObj **aobjs)

problem a CAPS Problem, Bound or Analysis Object

nAobjs the returned number of dirty Analysis Objects

aobjs a returned pointer to the list of dirty Analysis Objects (freeable)

icode integer return code
```



## Get Info about an Analysis Object

```
icode = caps_analysisInfo(capsObj analysis, char **apath,
                                   char **unitSys, char **intent, int *naobj,
                                   capsObj *aobjs, int *nfields, char ***fnames,
                                   int **ranks, int *exec, int *status)
        analysis the input Analysis Object
           apath a returned pointer to the string specifying the filesystem path for file I/O
         unitSys returned pointer to string describing the unit system used by the AIM (can be NULL)
          intent the returned pointer to the intent character string used to pass Bodies to the AIM
           naobj the returned number of parent Analysis Object(s)
           aobjs a returned pointer to a list of the parent Analysis Object(s)
          nfields the returned number of fields for DataSet filling
         fnames a returned pointer to a list of character strings with the field/DataSet names
           ranks a returned pointer to a list of ranks associated with each field
            exec the returned execution flag: 0 – no execution, 1 – AIM performs analysis
          status 0 – up to date, 1 – dirty Analysis inputs, 2 – dirty Geometry inputs
                  3 – both Geometry & Analysis inputs are dirty, 4 – new geometry,
                  5 – post Analysis required, 6 – Execution & post Analysis required
```

## Generate Analysis Inputs

## Mark Analysis as Run

```
icode = caps_postAnalysis (capsObj analysis, capsOwn current, int *nErr, capsErrs **errors)

analysis the Analysis Object
Note: this clears all Analysis Output Objects to force reloads/recomputes

current the CAPS owner structure information for the run

nErr the returned number of errors generated - 0 means no errors

errors the returned CAPS error structure - NULL with no errors

icode integer return code
```

## Create a Bound – Open until completeBound

### Complete a Bound

```
icode = caps_completeBound(capsObj bound)

bound the CAPS Bound Object to close after creating all of the VertexSets & DataSets

make calls to make VertexSet and make DataSet in between these 2 functions.
```

icode integer return code

### Get Information about a Bound

```
icode = caps_boundInfo(capsObj bound, enum *state, int *dim,
                              double *plims)
          bound the CAPS Bound Object
           state the returned Bound state:
                        Open
                       Empty & Closed
                        single BRep entity
                        multiple BRep entities
                        multiple BRep entities – Error in reparameterization!
            dim the returned dimensionality of the Bound (1-3)
          plims the filled parameterization limits (2 values when dim is 1, 4 when dim is 2)
          icode integer return code
```

Haimes CAPS API 11 March 2020 34 / 47

### Make a VertexSet

### Get Info about a VertexSet

## Fill VertexSets for cyclic/incremental transfers

```
icode = caps_fillVertexSets(capsObj bound, int *nErr, capsErrs **errs)
bound an input closed CAPS Bound Object
    nErr the returned number of errors generated - 0 means no errors
    errs the returned CAPS error structure - NULL with no errors
```

icode integer return code

Note: Causes the filling of the VertexSets owned by the Bound by forcing the invocation of the appropriate aimDiscr functions in the AIM. Under normal circumstances this is deferred to the last postAnalysis call of the collected VertexSets.

### Fill an Unconnected VertexSet

```
icode = caps_fillUnVertexSet(capsObj vset, int npts, double *xyzs)
     vset the input Unconnected VertexSet Object
     npts the number of points in the VertexSet
     xyzs the point positions (3*npts in length)
     icode integer return code
```



## Output a VertexSet for Plotting/Debugging

The CAPS application **vVS** can be used to interactively view the file generated by this function.

## DataSet Naming Conventions

- Multiple DataSets in a Bound can have the same Name
- Allows for automatic data transfers
- One *source* (from either *Analysis* or *User* Methods)
- Reserved Names:

DSet Name	rank	Meaning	Comments	
xyz	3	Geometry Positions		
xyzd	3	Data Positions	Not for vertex-based discretizations	
param*	1/2	t or [u,v] data for <i>Geometry</i> Positions		
paramd*	1/2	t or [u,v] for <i>Data</i> Positions	Not for vertex-based discretizations	
GeomIn*	3	Sensitivity for the Geometry Input <i>GeomIn</i>	can have [irow, icol] in name	
* Note: not valid for 3D Rounds				

### Create a DataSet

### Initialize DataSet for cyclic/incremental startup

Note: invocations of caps\_getData and aim\_getDataSet will return this data (and a length of 1) until properly filled.

### Get Data from a DataSet

### Get History of a DataSet

### Put *User* Data into a DataSet

## Get DataSet Objects by Name

### Get Triangulations for a 2D VertexSet

icode = caps\_triangulate(capsObj vset, int \*nGtris, int \*\*Gtris,



## CAPS API – Analysis (AIM) Debug

## Backdoor AIM Specific Communication

Note: Look at the specific AIM documentation to determine if it will respond and to what JSONin commands.



### caps CAPS Return Codes

CAPS_SUCCESS	0	CAPS_UNITERR	-320
CAPS_BADRANK	-301	CAPS_NULLBLIND	-321
CAPS_BADDSETNAME	-302	CAPS_SHAPEERR	-322
CAPS_NOTFOUND	-303	CAPS_LINKERR	-323
CAPS_BADINDEX	-304	CAPS_MISMATCH	-324
CAPS_NOTCHANGED	-305	CAPS_NOTPROBLEM	-325
CAPS_BADTYPE	-306	CAPS_RANGEERR	-326
CAPS_NULLVALUE	-307	CAPS_DIRTY	-327
CAPS_NULLNAME	-308	CAPS_HIERARCHERR	-328
CAPS_NULLOBJ	-309	CAPS_STATEERR	-329
CAPS_BADOBJECT	-310	CAPS_SOURCEERR	-330
CAPS_BADVALUE	-311	CAPS_EXISTS	-331
CAPS_PARAMBNDERR	-312	CAPS_IOERR	-332
CAPS_NOTCONNECT	-313	CAPS_DIRERR	-333
CAPS_NOTPARMTRIC	-314	CAPS_NOTIMPLEMENT	-334
CAPS_READONLYERR	-315	CAPS_EXECERR	-335
CAPS_FIXEDLEN	-316	CAPS_CLEAN	-336
CAPS_BADNAME	-317	CAPS_BADINTENT	-337
CAPS_BADMETHOD	-318	CAPS_NOTNEEDED	-339
CAPS_CIRCULARLINK	-319	CAPS_NOSENSITVTY	-340

Haimes CAPS API 44/47 11 March 2020



### Bounds and the use of Intermediate Results

## The Population of the VertexSets

Bounds needed to be fully populated (i.e., the VertexSets need to be filled for all analyses) before they can be used. This is due to the requirement to have all points available to ensure that there is a single UV space (either by construction or by re-parameterization).

By default this is done in the "post" phase of the last analysis in the Bound to be updated, which makes it basically impossible to have an intermediate result for the first iteration (such as in Fluid/Structure Interaction). This issue is mitigated by using the function <code>caps\_fillVertexSets</code> before the first analysis is invoked. What this does is call the AIM to fill the aimDiscr structure (basically the VertexSet) before the "pre" phase but requires the mesh (or performs the meshing) at that time.

NOTE: An analysis AIM that supports aimDiscr and also generates meshes "on the fly" must be able to generate meshes and call aim\_setTess from both aimDiscr and aimPreAnalysis (whenever and wherever the mesh gets generated).

Haimes CAPS API 11 March 2020 45/47



### Bounds and the use of Intermediate Results

### Fluid/Structure Interaction Pseudocode

```
caps load TetGen aim -> mobi
caps load fluids aim -> fobj
caps_load structures -> sobj
caps makeBound "srf" -> bobj
caps makeVertexSet(bobj, fobj) -> vfobj
caps makeVertexSet(bobi, sobi) -> vsobi
caps_makeDataSet(vfobj, "Pressure", Analysis, 1) -> dpfobj
caps makeDataSet(vsobj, "Pressure", Conserve, 1) -> dpsobj
caps makeDataSet(vsobi, "Displace", Analysis, 3) -> ddsobi
caps_makeDataSet(vfobj, "Displace", Conserve, 3) -> ddfobj
caps completeBound(bobj)
caps_preAnalysis(mobj)
caps postAnalysis (mobj)
                                             /* generate fluids mesh */
caps fillVertexSets(bobj)
                                             /* Note #1 */
caps_initDataSet(ddfobj, 3, zeros)
                                             /* Note #2 */
for (iter = 0; iter < nIter; iter++) {
        caps_getData(ddfobj, ...)
                                             /* Note #3 */
        caps_preAnalysis(fobj)
        /* execute fluids analysis */
        caps postAnalysis(fobi)
                                       /* Note #3 */
        caps getData(dpsobj, ...)
        caps preAnalysis(sobj)
        /* execute structures analysis */
        caps postAnalysis(sobj)
```



### Bounds and the use of Intermediate Results

### Pseudocode Notes

The fluids AIM requires the "Displace" values during its "pre" phase, just as the structural analysis AIM requires "Pressure" (i.e., loads) during its "pre" phase to fill in all the inputs.

- caps\_fillVertexSets calls aimDiscr in the fluids AIM, so that AIM must transfer the data from the TetGen AIM to populate the aimDiscr structure. The structures AIM can still do the tessellation in its aimDiscr function, but it will be invoked before any "pre" phase. Care must be taken so that any tessellation input data can be taken from the AIM inputs.
- eaps\_initDataSet gets called to set the first displacement data to zeros, in that no structural analysis will have been run at start, but is needed by the fluids.
- Saps\_getData is currently required to actually do the interpolation/conservative data transfer (i.e., it cannot be done in the AIM by the invocation of aim\_getDataSet). This will be changed in the future, so these calls will not be required, but current scripts and code will still function.
- The lines in red cause aimUsesDataSet to be invoked to determine if the DataSet is required by the Analysis (and will make it *dirty*).