Explanation of ArUco Tag detection is well explained here:

■ ArUco Library Documentation

Code used for TARS is based on this GitHub (following these steps can recreate the code):

https://github.com/immersive-command-system/Pose-Estimation-Aruco-Marker-Ros

# 1) Obtain image from USB Cam

Usb\_cam (<a href="http://wiki.ros.org/usb\_cam">http://wiki.ros.org/usb\_cam</a>) package was used to obtain the /image raw topic from the USB Cam on TARS.

Added camera image flip based on:

https://github.com/ros-drivers/usb\_cam/pull/116/commits/89dd4ca50aa1 89df7212b5bb48792f6aaa5d10ed (this is because TARS usb cam module natively flips the image, so need to flip it back) remove this part of the code if needed.

## Note: param highlighted in yellow

In the launch file of usb\_cam pkg, change the param value of /dev/videox based on your camera's port (eg. video0,video1,video2 etc.) Also, change the pixel format based on your camera's supported format (eg. yuyv, uyvy, mjpeg, grey, rgb24, yuvmono10).

2) Camera calibration to remove distortion Follow the calibration steps mentioned in ArUco Detetction TARS Auto Docking

Note: To run calibration script, execute the following:
\$ rosrun camera\_calibration cameracalibrator.py --size 8x6 --square

0.108 image:=/usb cam/image raw camera:=/usb cam

Change –size 8x6 to –size <your grid size>, –square 0.108 to –size <size of 1 grid square in metres>. Ensure the topic names for image and camera match your settings.

3) Aruco\_ros Pose Estimation

Install aruco\_ros pkg from ArUco Detetction TARS Auto Docking, this pkg publishes the /aruco\_single/pose topic (pos x,y,z and quaternion x,y,z,w)

Note: In aruco\_ros/src/simple\_single.cpp

The line highlighted in yellow is the "manual offset" used to correct the pose z value based on real-world experiment testing. Change this value to offset your error.

4) My\_aruco\_tracker pkg
This package combines the usb\_cam pkg and aruco\_ros pkg to be used together, the write data python script can be ignored

### 5) Docking movement pkg

This package includes the docking movement for TARS, the launch file launches usb\_cam and aruco\_ros pkgs with the command: Roslaunch docking\_movement dock.launch (gazebo.launch is used align with gazebo only, difference in tag size)

#### Run:

- 1. Usb\_cam\_stream\_publisher.launch (to run usb cam only)
- 2. Aruco\_marker\_finder.launch (to detect aruco tag only, must launch usb\_cam\_stream\_publisher first)
- 3. Aruco\_gazebo.launch (for gazebo use)
- 4. Dock.launch (to run usb cam, detect aruco, docking movement in 1 file)

#### **NOTE IMPORTANT:**

Make sure when migrating packages to a new system (ie.PC), migrate the camera\_info folder in /home/.ros as well