Imperx Camera Python SDK 1.5.0.56

Generated by Doxygen 1.8.11

Contents

1	Impe	erx Camera Python SDK	1
	1.1	General Information	1
	1.2	IpxCamPy namespace	1
	1.3	IpxGenParamPy namespace	2
	1.4	IpxGuiPy namespace	2
2	Nam	nespace Index	3
	2.1	Packages	3
3	Hier	rarchical Index	5
	3.1	Class Hierarchy	5
4	Clas	ss Index	7
	4.1	Class List	7
5	Nam	nespace Documentation	9
	5.1	IpxCamPy Namespace Reference	9
		5.1.1 Detailed Description	9
	5.2	IpxGenParamPy Namespace Reference	10
		5.2.1 Detailed Description	10
	5.3	IpxGuiPy Namespace Reference	11
		5.3.1 Detailed Description	11

iv CONTENTS

6	Clas	ass Documentation					
	6.1	lpxCar	nPy::PyBu	ffer Class Reference	13		
		6.1.1	Detailed	Description	14		
		6.1.2	Member	Function Documentation	14		
			6.1.2.1	GetWidth()	14		
			6.1.2.2	GetHeight()	14		
			6.1.2.3	GetBufferPtr()	14		
			6.1.2.4	GetImage()	15		
			6.1.2.5	IsIncomplete()	15		
			6.1.2.6	GetPixelFormat()	15		
			6.1.2.7	GetFrameID()	15		
			6.1.2.8	GetXOffset()	15		
			6.1.2.9	GetYOffset()	16		
			6.1.2.10	GetXPadding()	16		
			6.1.2.11	GetYPadding()	16		
			6.1.2.12	GetTimestamp()	16		
	6.2	IpxCar	nPy::PyDa	taStream Class Reference	17		
		6.2.1	Detailed	Description	17		
		6.2.2	Member	Function Documentation	18		
			6.2.2.1	GetBufferSize()	18		
			6.2.2.2	GetBufferAlignment()	18		
			6.2.2.3	GetMinNumBuffers()	18		
			6.2.2.4	StartAcquisition()	18		
			6.2.2.5	StopAcquisition(const Py::Tuple &args)	18		
			6.2.2.6	CreateBuffer(const Py::Tuple &args)	19		
			6.2.2.7	GetBufferQueueSize()	19		
			6.2.2.8	GetBuffer(const Py::Tuple &args)	19		
			6.2.2.9	QueueBuffer(const Py::Tuple &args)	20		

CONTENTS

		6.2.2.10	FlushBuffers(const Py::Tuple &args)	0
		6.2.2.11	RevokeBuffer(const Py::Tuple &args)	1
		6.2.2.12	AllocBufferQueue(const Py::Tuple &args)	1
		6.2.2.13	ReleaseBufferQueue()	1
		6.2.2.14	Release()	2
		6.2.2.15	CancelBuffer()	2
6.3	lpxCar	mPy::PyDe	vice Class Reference	2
	6.3.1	Detailed	Description	3
	6.3.2	Member	Function Documentation	3
		6.3.2.1	GetInfo()	3
		6.3.2.2	GetDisplayName()	3
		6.3.2.3	GetNumStreams()	4
		6.3.2.4	Release()	4
		6.3.2.5	ReadMem(const Py::Tuple &args)	4
		6.3.2.6	WriteMem(const Py::Tuple &args)	4
		6.3.2.7	GetStreamByIndex(const Py::Tuple &args)	5
		6.3.2.8	GetStreamById(const Py::Tuple &args)	5
		6.3.2.9	SaveConfiguration(const Py::Tuple &args)	5
		6.3.2.10	LoadConfiguration(const Py::Tuple &args)	6
		6.3.2.11	GetCameraParameters()	6
		6.3.2.12	GetTransportParameters()	6
		6.3.2.13	RegisterEvent(const Py::Tuple &args)	6
		6.3.2.14	UnRegisterEvent(const Py::Tuple &args)	7
6.4	lpxCar	nPy::PyDe	viceInfo Class Reference	7
	6.4.1	Detailed	Description	8
	6.4.2	Member	Function Documentation	8
		6.4.2.1	GetInterface()	8
		6.4.2.2	GetModel()	9

vi CONTENTS

		6.4.2.3	GetVendor()	29
		6.4.2.4	GetVersion()	29
		6.4.2.5	GetSerialNumber()	29
		6.4.2.6	GetDisplayName()	29
		6.4.2.7	GetUserDefinedName()	30
		6.4.2.8	GetAccessStatus()	30
		6.4.2.9	GetIPAddress()	30
		6.4.2.10	GetIPMask()	30
		6.4.2.11	GetIPGateway()	31
		6.4.2.12	ForcelP(const Py::Tuple &args)	31
6.5	lpxCar	nPy::PyDe	eviceInterface Class Reference	31
	6.5.1	Detailed	Description	32
	6.5.2	Member	Function Documentation	32
		6.5.2.1	GetDescription()	32
		6.5.2.2	GetFirstDeviceInfo()	32
		6.5.2.3	ReEnumerateDevices()	33
		6.5.2.4	GetDeviceInfoList()	33
		6.5.2.5	GetType()	33
6.6	lpxGer	nParamPy:	::PyGenParam Class Reference	34
	6.6.1	Detailed	Description	34
	6.6.2	Member	Function Documentation	35
		6.6.2.1	GetType()	35
		6.6.2.2	GetName()	35
		6.6.2.3	GetToolTip()	35
		6.6.2.4	GetDescription()	35
		6.6.2.5	GetDisplayName()	35
		6.6.2.6	GetVisibility()	36
		6.6.2.7	IsVisible(const Py::Tuple &args)	36

CONTENTS vii

		6.6.2.8	IsValueCached()	36
		6.6.2.9	IsAvailable()	36
		6.6.2.10	IsWritable()	36
		6.6.2.11	IsReadable()	37
		6.6.2.12	IsStreamable()	37
6.7	lpxGer	ParamPy:	:PyGenParamBoolean Class Reference	37
	6.7.1	Detailed	Description	38
	6.7.2	Member	Function Documentation	38
		6.7.2.1	GetType()	38
		6.7.2.2	GetValue()	38
		6.7.2.3	SetValue(const Py::Tuple &args)	38
		6.7.2.4	IsWritable()	39
		6.7.2.5	IsReadable()	39
6.8	lpxGer	ParamPy:	:PyGenParamCategory Class Reference	39
	6.8.1	Detailed	Description	40
	6.8.2	Member	Function Documentation	40
		6.8.2.1	GetType()	40
		6.8.2.2	GetCount()	40
		6.8.2.3	GetParamByIndex(const Py::Tuple &args)	40
		6.8.2.4	GetNode()	41
6.9	lpxGer	ParamPy:	:PyGenParamCommand Class Reference	41
	6.9.1	Detailed	Description	41
	6.9.2	Member	Function Documentation	42
		6.9.2.1	Execute()	42
		6.9.2.2	IsDone()	42
6.10	lpxGer	ParamPy:	:PyGenParamEnum Class Reference	42
	6.10.1	Detailed	Description	43
	6.10.2	Member	Function Documentation	43

viii CONTENTS

		6.10.2.1	GetCount()	43
		6.10.2.2	GetValue()	43
		6.10.2.3	GetValueStr()	43
		6.10.2.4	SetValue(const Py::Tuple &args)	43
		6.10.2.5	SetValueStr(const Py::Tuple &args)	44
		6.10.2.6	GetType()	44
		6.10.2.7	GetEnumEntryByIndex(const Py::Tuple &args)	44
6.11	IpxGen	ParamPy:	:PyGenParamEnumEntry Class Reference	45
	6.11.1	Detailed	Description	45
	6.11.2	Member	Function Documentation	45
		6.11.2.1	GetValue()	45
		6.11.2.2	GetValueStr()	46
		6.11.2.3	GetType()	46
		6.11.2.4	IsAvailable()	46
6.12	IpxGen	ParamPy:	:PyGenParamFloat Class Reference	46
	6.12.1	Detailed	Description	47
	6.12.2			17
		Member	Function Documentation	4/
			GetType()	
		6.12.2.1		47
		6.12.2.1 6.12.2.2	GetType()	47 47
		6.12.2.1 6.12.2.2 6.12.2.3	GetType()	47 47 48
		6.12.2.1 6.12.2.2 6.12.2.3 6.12.2.4	GetType() IsWritable() IsReadable()	47 47 48 48
		6.12.2.1 6.12.2.2 6.12.2.3 6.12.2.4 6.12.2.5	GetType() IsWritable() IsReadable() GetValue()	47 47 48 48
		6.12.2.1 6.12.2.2 6.12.2.3 6.12.2.4 6.12.2.5 6.12.2.6	GetType() IsWritable() IsReadable() GetValue() SetValue(const Py::Tuple &args)	47 47 48 48 48
		6.12.2.1 6.12.2.2 6.12.2.3 6.12.2.4 6.12.2.5 6.12.2.6 6.12.2.7	GetType() IsWritable() IsReadable() GetValue() SetValue(const Py::Tuple &args) GetMin()	47 47 48 48 48 49
6.13	IpxGen	6.12.2.1 6.12.2.2 6.12.2.3 6.12.2.4 6.12.2.5 6.12.2.6 6.12.2.7 6.12.2.8	GetType() IsWritable() IsReadable() GetValue() SetValue(const Py::Tuple &args) GetMin() GetMax()	47 48 48 48 49
6.13		6.12.2.1 6.12.2.2 6.12.2.3 6.12.2.4 6.12.2.5 6.12.2.6 6.12.2.7 6.12.2.8 ParamPy:	GetType() IsWritable() IsReadable() GetValue() SetValue(const Py::Tuple &args) GetMin() GetMax() GetUnit()	47 48 48 48 49 49

CONTENTS ix

		6.13.2.1	GetType()	50
		6.13.2.2	IsWritable()	50
		6.13.2.3	IsReadable()	50
		6.13.2.4	GetValue()	50
		6.13.2.5	SetValue(const Py::Tuple &args)	50
		6.13.2.6	GetMin()	51
		6.13.2.7	GetMax()	51
		6.13.2.8	GetIncrement()	51
6.14	lpxGen	ParamPy::	PyGenParamNode Class Reference	52
	6.14.1	Detailed [Description	52
6.15	lpxGen	ParamPy::	PyGenParamNodeMap Class Reference	52
	6.15.1	Detailed [Description	52
6.16	lpxGen	ParamPy::	PyGenParams Class Reference	52
	6.16.1	Detailed [Description	54
	6.16.2	Member F	Function Documentation	54
		6.16.2.1	SetIntegerValue(const Py::Tuple &args)	54
		6.16.2.2	GetIntegerValue(const Py::Tuple &args)	54
		6.16.2.3	SetFloatValue(const Py::Tuple &args)	55
		6.16.2.4	GetFloatValue(const Py::Tuple &args)	55
		6.16.2.5	ExecuteCommand(const Py::Tuple &args)	55
		6.16.2.6	GetStringValue(const Py::Tuple &args)	55
		6.16.2.7	SetStringValue(const Py::Tuple &args)	56
		6.16.2.8	GetEnumValueStr(const Py::Tuple &args)	56
		6.16.2.9	GetEnumValue(const Py::Tuple &args)	56
		6.16.2.10	SetEnumValueStr(const Py::Tuple &args)	57
		6.16.2.11	SetEnumValue(const Py::Tuple &args)	57
		6.16.2.12	GetEnum(const Py::Tuple &args)	57
		6.16.2.13	GetParamByIndex(const Py::Tuple &args)	58

x CONTENTS

	6.16.2.14 GetParam(const Py::Tuple &args)	58
	6.16.2.15 GetCount()	59
	6.16.2.16 GetRootCategory()	59
	6.16.2.17 GetBooleanValue(const Py::Tuple &args)	59
	6.16.2.18 SetBooleanValue(const Py::Tuple &args)	59
	6.16.2.19 GetBoolean(const Py::Tuple &args)	60
	6.16.2.20 GetInt(const Py::Tuple &args)	60
	6.16.2.21 GetString(const Py::Tuple &args)	60
	6.16.2.22 GetFloat(const Py::Tuple &args)	61
	6.16.2.23 GetCommand(const Py::Tuple &args)	61
	6.16.2.24 IsCommandDone(const Py::Tuple &args)	61
	6.16.2.25 GetNodeMap()	62
6.17	IpxGenParamPy::PyGenParamString Class Reference	62
	6.17.1 Detailed Description	63
	6.17.2 Member Function Documentation	63
	6.17.2.1 GetType()	63
	6.17.2.2 IsWritable()	63
	6.17.2.3 IsReadable()	63
	6.17.2.4 GetValue()	63
	6.17.2.5 SetValue(const Py::Tuple &args)	63
6.18	IpxGuiPy::PyGenParamView Class Reference	64
	6.18.1 Detailed Description	64
6.19	IpxCamPy::PyImage Class Reference	64
	6.19.1 Detailed Description	65
	6.19.2 Member Function Documentation	65
	6.19.2.1 getImage()	65
6.20	PylpxCameraApi Class Reference	65
	6.20.1 Detailed Description	66

CONTENTS xi

Index				73
		6.23.2.1	SelectCamera(const Py::Tuple &args)	71
	6.23.2	Member F	function Documentation	71
	6.23.1	Detailed D	Description	71
6.23	lpxGuil	Py::PylpxS	ystemGui Class Reference	71
		6.22.2.4	CreateDeviceFromConfig(const Py::Tuple &args)	70
		6.22.2.3	GetVersion()	70
		6.22.2.2	GetDisplayName()	70
		6.22.2.1	GetInterfaceList()	70
	6.22.2	Member F	Function Documentation	70
	6.22.1	Detailed D	Description	70
6.22	IpxCan	nPy::Pylpx8	System Class Reference	69
		6.21.2.4	PyDestroyGenParamTreeView(const Py::Tuple &args)	68
		6.21.2.3	PyCreateGenParamTreeViewForArray(const Py::Tuple &args)	68
		6.21.2.2	PyShowImageOnDisplay(const Py::Tuple &args)	68
			PyCreateDisplay(const Py::Tuple &args)	
			Function Documentation	
	6.21.1	Detailed D	Description	67
6.21	lpxGuiF	Py::PylpxC	ameraApiGui Class Reference	66
		6.20.2.1	PylpxCreateDevice(const Py::Tuple &args)	66
	6.20.2	Member F	Function Documentation	66

Chapter 1

Imperx Camera Python SDK

1.1 General Information

The Imperx Camera Python SDK is designed to provide software developers with API methods for ease of integrating Imperx cameras into their software application, created with Python programming language The Python API mainly repeats C++ API structure and functionality. It includes three namespaces: IpxCamPy, IpxGuiPy and IpxGenParamPy. The API implemented in two libraries: IpxCameraApiPy (implementing IpxCamPy and IpxGenParamPy) and IpxCameraGuiApiPy (implementing IpxGuiPy).

The IpxCamPy namespace provides the scope to the API of GenICam GenTL transport layer to acquire images with an Imperx Camera. The IpxGenParamPy namespace provides the scope to the API to control the GenICam camera parameters, like image Width, Height, Pixel Format, Gain, Exposure, Trigger settings, etc. The IpxGuiPy namespace provides the scope for the user interface functionality, like windows and panels.

1.2 **IpxCamPy namespace**

The lpxCam namespace consist of several main classes that represent the GenTL modules and GUI objects. The main classes are

- IpxCamPy.PyIpxSystem The System class is the entry point to the GenTL Producer software driver.
- IpxCamPy.PyDeviceInterface The Interface class provides method to represents an individual physical interface, like GigE or USB3
- IpxCamPy.PyDevice The Device class provides methods to enable the communication with the camera device
 and enumerate/instantiate the video data streams.
- IpxCamPy.PyDataStream The Stream class purpose is to access the image buffer data acquirement from the Acquisition engine.
- IpxCamPy.PyBuffer The Buffer class contains the methods to access the image data and parameters of the
 acquired image buffer.

1.3 IpxGenParamPy namespace

The IpxGenParamPy namespace consist of the following main classes to access the GenICam parameters features. The main classes are

- IpxGenParamPy.PyGenParam General class for accessing the GenlCam feature node of the Camera parameters.
- IpxGenParamPy.PyGenParamBoolean Class representing the Boolean GenICam camera parameter.
- IpxGenParamPy.PyGenParamCommand Class representing the Command GenICam camera parameter.
- IpxGenParamPy.PyGenParamEnum Class representing the Enumeration GenICam camera parameter.
- IpxGenParamPy.PyGenParamFloat Class representing the Float GenICam camera parameter.
- IpxGenParamPy.PyGenParamInt Class representing the Integer GenICam camera parameter.
- IpxGenParamPy.PyGenParamString Class representing the String GenICam camera parameter.

1.4 **IpxGuiPy namespace**

The lpxCam namespace consist of several main classes that represent the GenTL modules and GUI objects. The main classes are

- · IpxGuiPy.PyGenParamView The class representing node tree view of GenICam parameters panel
- IpxGuiPy.PyIpxSystemGui The class extending the IpxCamPy.PyIpxSystem to provide the GUI functionality
- IpxGuiPy.PyIpxCameraApiGui The class extending the IpxCamPy.PyIpxCameraApi to provide the GUI functionality

Chapter 2

Namespace Index

2.1 Packages

Here are the packages with brief descriptions (if available):

IpxCamPy	
Python Wrapper for IpxCameraApi.dll	ç
lpxGenParamPy	
A namespace provides the scope to the API to access the GenlCam parameters	IC
IpxGuiPy	11

4 Namespace Index

Chapter 3

Hierarchical Index

3.1 Class Hierarchy

This inheritance list is sorted roughly, but not completely, alphabetically:

IpxCamPy::PyBuffer
IpxCamPy::PyDataStream
IpxCamPy::PyDevice
IpxCamPy::PyDeviceInfo
IpxCamPy::PyDeviceInterface
IpxGenParamPy::PyGenParam 34
IpxGenParamPy::PyGenParamBoolean 37
IpxGenParamPy::PyGenParamCategory
IpxGenParamPy::PyGenParamCommand 41
IpxGenParamPy::PyGenParamEnum42
IpxGenParamPy::PyGenParamEnumEntry
IpxGenParamPy::PyGenParamFloat46
IpxGenParamPy::PyGenParamInt49
IpxGenParamPy::PyGenParamNode 52
IpxGenParamPy::PyGenParamNodeMap 52
IpxGenParamPy::PyGenParams
IpxGenParamPy::PyGenParamString 62
IpxGuiPy::PyGenParamView
IpxCamPy::PyImage
PylpxCameraApi
lpxGuiPy::PylpxCameraApiGui
IpxCamPy::PyIpxSystem
lpxGuiPy::PylpxSystemGui

6 Hierarchical Index

Chapter 4

Class Index

4.1 Class List

Here are the classes, structs, unions and interfaces with brief descriptions:

IpxCamPy::PyBuffer	
Buffer module in the GenTL module hierarchy	13
IpxCamPy::PyDataStream	
Data stream module in the GenTL module hierarchy	17
IpxCamPy::PyDevice	
The Device class represents the device module in the GenTL module hierarchy	22
IpxCamPy::PyDeviceInfo	
DeviceInfo class provides the information about the device	27
IpxCamPy::PyDeviceInterface	
Interface module in the GenTL module hierarchy	31
IpxGenParamPy::PyGenParam	
General class for GenlCam parameter	34
IpxGenParamPy::PyGenParamBoolean	
PyGenParamBoolean class represents the Boolean GenICam camera parameter	37
IpxGenParamPy::PyGenParamCategory	
A class containing methods that the user can access the categories GenlCam features. It will access	
the node object's of an ICategory interface. Each feature of a device will be placed in a Category.	
The Category feature is used to present the user with a group of features for the named category	39
IpxGenParamPy::PyGenParamCommand	
PyGenParamCommand class represents Command GenICam camera parameter	41
IpxGenParamPy::PyGenParamEnum	
PyGenParamEnum class represents Enumeration GenICam camera parameter	42
IpxGenParamPy::PyGenParamEnumEntry	
PyGenParamEnumEntry class represents the entry of GenICam Enum parameter	45
IpxGenParamPy::PyGenParamFloat	
PyGenParamFloat class represents Float GenICam camera parameter	46
IpxGenParamPy::PyGenParamInt	
PyGenParamInt class represents Integer GenICam camera parameter	49
IpxGenParamPy::PyGenParamNode	
PyGenParamNode class represents GenICam INode class	52
lpxGenParamPv::PvGenParamNodeMap	52

Class Index

8

lpxGenParamPy::PyGenParams	
An PyGenParams class contains methods to access all GenICam camera parameters	52
pxGenParamPy::PyGenParamString	
PyGenParamString class represents String GenICam camera parameter	62
pxGuiPy::PyGenParamView	64
pxCamPy::PyImage	64
PylpxCameraApi	
Python wrapper for General API	65
pxGuiPy::PylpxCameraApiGui	
Extension of IpxCamPy.PyIpxCameraApi class to provide the GUI functionality	66
pxCamPy::PyIpxSystem	
Abstraction of the System module of the GenTL module hierarchy	69
pxGuiPy::PyIpxSystemGui	
Extension of IpxCamPy.PyIpxSystem class to provide the GUI functionality	71

Chapter 5

Namespace Documentation

5.1 **IpxCamPy Namespace Reference**

Python Wrapper for IpxCameraApi.dll.

Classes

class PyBuffer

The PyBuffer class represents the buffer module in the GenTL module hierarchy.

class PyDataStream

The PyDataStream class represents the data stream module in the GenTL module hierarchy.

class PyDevice

The Device class represents the device module in the GenTL module hierarchy.

class PyDeviceInfo

DeviceInfo class provides the information about the device.

class PyDeviceInterface

The PyDeviceInterface class represents a interface module in the GenTL module hierarchy.

- class Pylmage
- class PylpxSystem

The PylpxSystem class represents an abstraction of the System module of the GenTL module hierarchy.

5.1.1 Detailed Description

Python Wrapper for IpxCameraApi.dll.

A namespace providing scope to the GenlCam GenTL transport layer interface to acquire images with an Imperx Camera

Python Wrapper for IpxCameraApi.dll. Python 3 API providing scope to the GenlCam GenTL transport layer interface to acquire images and control the Imperx camera.

IpxCam namespace includes classes that represent the base GenTL transport layer modules: System, Interface, Device, Stream, Buffer. These modules can be used to enumerate the interfaces in the system, enumerate the cameras, connected to each interface, connect to necessary camera, allocate the memory buffers for images, and run the video acquisition.

5.2 **IpxGenParamPy Namespace Reference**

A namespace provides the scope to the API to access the GenlCam parameters.

Classes

class PyGenParam

General class for GenlCam parameter.

class PyGenParamBoolean

PyGenParamBoolean class represents the Boolean GenICam camera parameter.

class PyGenParamCategory

A class containing methods that the user can access the categories GenlCam features. It will access the node object's of an ICategory interface. Each feature of a device will be placed in a **Category**. The Category feature is used to present the user with a group of features for the named category.

class PyGenParamCommand

PyGenParamCommand class represents Command GenICam camera parameter.

class PyGenParamEnum

PyGenParamEnum class represents Enumeration GenICam camera parameter.

class PyGenParamEnumEntry

PyGenParamEnumEntry class represents the entry of GenICam Enum parameter.

class PyGenParamFloat

PyGenParamFloat class represents Float GenICam camera parameter.

· class PyGenParamInt

PyGenParamInt class represents Integer GenICam camera parameter.

class PyGenParamNode

PyGenParamNode class represents GenICam INode class.

- class PyGenParamNodeMap
- class PyGenParams

An PyGenParams class contains methods to access all GenICam camera parameters.

· class PyGenParamString

PyGenParamString class represents String GenICam camera parameter.

5.2.1 Detailed Description

A namespace provides the scope to the API to access the GenlCam parameters.

The IpxGenParamPy namespace provides the scope to the API to control the GenlCam camera parameters of types: Boolean, Enumeration, String, Float, Integer, Commands and Categories. Such parameters may include image Width, Height, Pixel Format, Gain, Exposure, Trigger, I/O settings, etc. Parameters are described in camera GenlCam XML file, and documented in appropriate camera user's manual.

5.3 **IpxGuiPy Namespace Reference**

Classes

- class PyGenParamView
- class PylpxCameraApiGui

Extension of IpxCamPy.PyIpxCameraApi class to provide the GUI functionality.

• class PylpxSystemGui

Extension of IpxCamPy.PyIpxSystem class to provide the GUI functionality.

5.3.1 Detailed Description

The IpxGuiPy namespace is a declarative region that provides a scope to the Imperx Camera GUI API classes and functions.

Chapter 6

Class Documentation

6.1 IpxCamPy::PyBuffer Class Reference

The PyBuffer class represents the buffer module in the GenTL module hierarchy.

```
#include <IpxCameraApiPy.h>
```

Inherits PythonExtension < PyBuffer >.

Public Member Functions

• Py::Object GetWidth ()

Returns the image width.

• Py::Object GetHeight ()

Returns the image height.

• Py::Object GetBufferPtr ()

Returns the image data array.
• Py::Object GetImage ()

This method returns the Image object, associated with the Buffer object.

• Py::Object IsIncomplete ()

This method returns a flag indicating if the buffer data has been fully transferred or incompleted.

• Py::Object GetPixelFormat ()

This method returns the pixel format of the buffer object.

Py::Object GetFrameID ()

This method returns the identificator of the image stream block of the buffer object.

• Py::Object GetXOffset ()

Returns the horizontal offset of the image data in the buffer.

Py::Object GetYOffset ()

Returns the vertical offset of the image data in the buffer.

Py::Object GetXPadding ()

This method returns the number of extra bytes padded in the horizontal direction.

Py::Object GetYPadding ()

This method returns the number of extra bytes padded in the vertical direction.

Py::Object GetTimestamp ()

This method returns the timestamp of the acquired buffer.

14 Class Documentation

6.1.1 Detailed Description

The PyBuffer class represents the buffer module in the GenTL module hierarchy.

The Buffer class contains the methods that can be used to get the pointer to the acquired image data memory and / or retrieve the information about the received image data such as timestamp, image size, pixel format, etc

IpxCamPy.PyBuffer Python class is wrapper around C++ class IpxCam::Buffer

6.1.2 Member Function Documentation

```
6.1.2.1 Py::Object lpxCamPy::PyBuffer::GetWidth ( )
```

Returns the image width.

This method returns the image width of the buffer data in number of pixels. Usually the return value equals to **Width** GenlCam parameter value

Returns

Returns the image width. Value type: Integer

6.1.2.2 Py::Object lpxCamPy::PyBuffer::GetHeight ()

Returns the image height.

This method returns the image height of the buffer data in number of lines. Usually the return value equals to **Height** GenlCam parameter value

Returns

Returns the image height. Value type: Integer

6.1.2.3 Py::Object IpxCamPy::PyBuffer::GetBufferPtr ()

Returns the image data array.

This method returns the array of the image data of the Buffer object.

Returns

Returns the image data array. Value type: bytearray

```
6.1.2.4 Py::Object lpxCamPy::PyBuffer::GetImage ( )
```

This method returns the Image object, associated with the Buffer object.

Returns

Returns the Image object, associated with the Buffer object. Value type: IpxCamPy.PyImage

```
6.1.2.5 Py::Object lpxCamPy::PyBuffer::IsIncomplete ( )
```

This method returns a flag indicating if the buffer data has been fully transferred or incompleted.

Returns

Returns True, if buffer transfer was incompleted, False, if transfer was successful. Value type: Boolean

```
6.1.2.6 Py::Object lpxCamPy::PyBuffer::GetPixelFormat ( )
```

This method returns the pixel format of the buffer object.

Returns

Returns the pixel format of the image in the buffer object. Value type: Integer This value equals to **PixeFormat** GenlCam parameter

```
6.1.2.7 Py::Object lpxCamPy::PyBuffer::GetFrameID ( )
```

This method returns the identificator of the image stream block of the buffer object.

Returns

Returns the identificator of the image stream block of the buffer object. Value type: Integer

```
6.1.2.8 Py::Object lpxCamPy::PyBuffer::GetXOffset ( )
```

Returns the horizontal offset of the image data in the buffer.

This method returns the horizontal offset of the image data in the buffer in number of pixels from the image origin. Usually the return value equals to **OffsetX** GenlCam parameter value

Returns

Returns the horizontal offset in number of pixels. Value type: Integer

16 Class Documentation

```
6.1.2.9 Py::Object lpxCamPy::PyBuffer::GetYOffset ( )
```

Returns the vertical offset of the image data in the buffer.

This method returns the vertical offset of the image data in the buffer in number of lines from the image origin. Usually the return value equals to **OffsetY** GenlCam parameter value

Returns

Returns the vertical offset of the data in the buffer in number of lines from the image origin. Value type: Integer

```
6.1.2.10 Py::Object IpxCamPy::PyBuffer::GetXPadding ( )
```

This method returns the number of extra bytes padded in the horizontal direction.

Returns

Returns the XPadding of the data in the buffer in number of bytes. Value type: Integer

```
6.1.2.11 Py::Object IpxCamPy::PyBuffer::GetYPadding ( )
```

This method returns the number of extra bytes padded in the vertical direction.

Returns

Returns the YPadding of the data in the buffer in number of bytes. Value type: Integer

```
6.1.2.12 Py::Object lpxCamPy::PyBuffer::GetTimestamp ( )
```

This method returns the timestamp of the acquired buffer.

This method returns the timestamp of the acquired buffer. Imperx USB3 and GEV cameras have 10ns timestamp granularity. GEV cameras timestamp clock frequency can be obtained from **GevTimestampTickFrequency** GenICam parameter

Returns

Returns the timestamp of the acquired buffer. Value type: Integer

The documentation for this class was generated from the following file:

IpxCameraApiPy.h

6.2 IpxCamPy::PyDataStream Class Reference

The PyDataStream class represents the data stream module in the GenTL module hierarchy.

```
#include <IpxCameraApiPy.h>
```

Inherits PythonExtension < PyDataStream >.

Public Member Functions

• Py::Object GetBufferSize ()

This method returns the buffer size of the data stream object.

• Py::Object GetBufferAlignment ()

This method returns the alignment size of the stream object.

• Py::Object GetMinNumBuffers ()

This method returns the minimum number of buffers.

Py::Object StartAcquisition ()

Starts the Acquisition Engine.

Py::Object StopAcquisition (const Py::Tuple & args)

Stops the stream's acquisition engine.

Py::Object CreateBuffer (const Py::Tuple & args)

Creates the buffer in the data stream object.

• Py::Object GetBufferQueueSize ()

Retrieves the Buffer Queue size.

Py::Object GetBuffer (const Py::Tuple & args)

This method retrieves the buffer object.

• Py::Object QueueBuffer (const Py::Tuple &args)

This method queues the specified buffers.

• Py::Object FlushBuffers (const Py::Tuple &args)

This method flushes the buffers of the data stream object.

Py::Object RevokeBuffer (const Py::Tuple & args)

Revokes any announced buffer.

Py::Object AllocBufferQueue (const Py::Tuple & args)

Allocates the Buffer Queue.

Py::Object ReleaseBufferQueue ()

Releases the Buffer Queue.

- Py::Object Release ()
- Py::Object CancelBuffer ()

Cancels the buffer events waiting.

6.2.1 Detailed Description

The PyDataStream class represents the data stream module in the GenTL module hierarchy.

This data stream class provides buffer methods. This data stream class purpose is to access the buffer data acquirement from the Acquisition engine.

lpxCamPy::PyDataStream Python class is wrapper around C++ class lpxCam::Stream

18 Class Documentation

6.2.2 **Member Function Documentation** 6.2.2.1 Py::Object lpxCamPy::PyDataStream::GetBufferSize () This method returns the buffer size of the data stream object. Returns Returns the buffer size. Value type: Integer 6.2.2.2 Py::Object lpxCamPy::PyDataStream::GetBufferAlignment () This method returns the alignment size of the stream object. Returns Returns the alignment size in bytes of the buffer passed. Value type: Integer 6.2.2.3 Py::Object lpxCamPy::PyDataStream::GetMinNumBuffers () This method returns the minimum number of buffers. Returns Returns the minimum number of buffers to announce. Value type: Integer 6.2.2.4 Py::Object lpxCamPy::PyDataStream::StartAcquisition () Starts the Acquisition Engine. This method starts the acquisition engine of the stream to acquire the unlimited number of image data frames to the queued buffers Returns True, if acquisition successfully started, False otherwise. Value type: Boolean 6.2.2.5 Py::Object lpxCamPy::PyDataStream::StopAcquisition (const Py::Tuple & args) Stops the stream's acquisition engine.

This method stops the acquisition engine of the stream and terminates the image data frames acquisition

Parameters

in	args[0]	- Value type: Integer. Flags:
		 ACQ_STOP_FLAGS_DEFAULT=0, Stop the acquisition engine when the currently running tasks like filling a buffer are completed (default behavior).
		 ACQ_STOP_FLAGS_KILL=1, Stop the acquisition engine immediately and leave buffers currently being filled in the Input Buffer Pool.

Returns

True, if acquisition successfully stopped, False otherwise. Value type: Boolean

6.2.2.6 Py::Object lpxCamPy::PyDataStream::CreateBuffer (const Py::Tuple & args)

Creates the buffer in the data stream object.

This method allocates the memory for a buffer and announces this buffer to the data stream

Parameters

in	args[0]	Buffer size in bytes. Value type: Integer	1
	uigoloj	Banor bizo in bytob. Value type: integer	П

Returns

Returns IpxCamPy.PyBuffer object created

6.2.2.7 Py::Object lpxCamPy::PyDataStream::GetBufferQueueSize ()

Retrieves the Buffer Queue size.

This functions returns the buffer queue size of the data stream object.

Returns

Returns the Buffer Queue size. Value type: Integer

6.2.2.8 Py::Object lpxCamPy::PyDataStream::GetBuffer (const Py::Tuple & args)

This method retrieves the buffer object.

Retrieves the next acquired buffer entry from the acquisition engine's queue and returns the acquired Buffer object

20 Class Documentation

Parameters

in	args[0]	timeout in milliseconds
----	---------	-------------------------

Returns

Returns the IpxCamPy.PyBuffer object for acquired buffer

6.2.2.9 Py::Object lpxCamPy::PyDataStream::QueueBuffer (const Py::Tuple & args)

This method queues the specified buffers.

During the acquisition, this method is used to return the specified buffer to the acquisition engine's queue

Parameters

in	args[0]	IpxCamPy.PyBuffer object
----	---------	--------------------------

Returns

True, if buffer was successfully queued, False otherwise. Value type: Boolean

6.2.2.10 Py::Object lpxCamPy::PyDataStream::FlushBuffers (const Py::Tuple & args)

This method flushes the buffers of the data stream object.

Performs the specified Flush Operation on the acquisition engine's queue. Operations type is defined in FlushOperations enum.

Parameters

in	args[0]	operation FlushOperation. Value type: Integer. Possible values are:	
		 PyDataStream.Flush_OutputDiscard (1) Discards all buffers in the output queue and if necessary remove the entries from the event data queue. 	
		 PyDataStream.Flush_AllToInput (2) Puts all buffers in the input pool. Even those in the output queue and discard entries in the event data queue. 	
		 PyDataStream.Flush_UnqueuedToInput (3) Puts all buffers that are not in the input pool or the output queue in the input pool. 	
		PyDataStream.Flush_AllDiscard (4) Discards all buffers in the input pool and output queue.	

Returns

True, if operation completed OK, False otherwise. Value type: Boolean

6.2.2.11 Py::Object lpxCamPy::PyDataStream::RevokeBuffer (const Py::Tuple & args)

Revokes any announced buffer.

This method removes the specified announced Buffer from the acquisition engine's queue

Parameters

in	args[0]	IpxCamPy.PyBuffer object
----	---------	--------------------------

Returns

True, if operation completed OK, False otherwise. Value type: Boolean

6.2.2.12 Py::Object lpxCamPy::PyDataStream::AllocBufferQueue (const Py::Tuple & args)

Allocates the Buffer Queue.

This method allocates the buffers in the queue of the acquisition engine of the data stream object.

Parameters

in	args[0]	number of Buffers to allocate. Value type: Integer.

Returns

True, if operation completed OK, False otherwise. Value type: Boolean

6.2.2.13 Py::Object IpxCamPy::PyDataStream::ReleaseBufferQueue ()

Releases the Buffer Queue.

This method releases the buffer queue of the data stream object.

Returns

True, if operation completed OK, False otherwise. Value type: Boolean

22 Class Documentation

```
6.2.2.14 Py::Object lpxCamPy::PyDataStream::Release ( )
```

This method releases the instance of the lpxCamPy.PyDataStream object.

```
6.2.2.15 Py::Object lpxCamPy::PyDataStream::CancelBuffer ( )
```

Cancels the buffer events waiting.

This method cancels any previously registered buffer events that have been waiting to be performed.

Returns

True, if operation completed OK, False otherwise. Value type: Boolean

The documentation for this class was generated from the following file:

· IpxCameraApiPy.h

6.3 IpxCamPy::PyDevice Class Reference

The Device class represents the device module in the GenTL module hierarchy.

```
#include <IpxCameraApiPy.h>
```

Inherits PythonExtension < PyDevice >.

Public Member Functions

Py::Object GetInfo ()

This method returns IpxCamPy.PyDeviceInfo object, associated with the PyDevice object.

Py::Object GetDisplayName ()

This method returns the user readable display name of the Camera device object.

• Py::Object GetNumStreams ()

This method retrieves the number of the data streams, provided by the Device.

Py::Object Release ()

This method releases the IpxCamPy.PyDevice object.

Py::Object ReadMem (const Py::Tuple & args)

This method reads a number of bytes from a given address.

Py::Object WriteMem (const Py::Tuple & args)

This method writes a number of bytes at a given address.

Py::Object GetStreamByIndex (const Py::Tuple & args)

This method retrieves the PyDataStream object by stream index.

Py::Object GetStreamByld (const Py::Tuple & args)

This method retrieves the PyDataStream object by stream identifier.

- Py::Object SaveConfiguration (const Py::Tuple &args)
 - This method saves the camera device configuration to the file.
- Py::Object LoadConfiguration (const Py::Tuple & args)
 - This method loads the camera device configuration from the file.
- Py::Object GetCameraParameters ()
 - This method returns the camera parameters of the device object.
- Py::Object GetTransportParameters ()
 - This method returns the transport parameters of the device object.
- Py::Object RegisterEvent (const Py::Tuple & args)
 - This method registers the Device class method as a callback method to be called when event of the specified type occurs.
- Py::Object UnRegisterEvent (const Py::Tuple & args)

This method unregisters the Device class callback method for the event type.

6.3.1 Detailed Description

The Device class represents the device module in the GenTL module hierarchy.

This Device class provides methods to enable the communication and control of the Imperx device and enumerate/instantiate data stream objects. The methods can be used to enumerate and instantiate the Data Stream module objects. The device must must correspond to the interface transport layer technology. For example, the device could be an Imperx GEV Camera and the transport layer technology would be GEV. The Device class can be used to retrieve data information about the device by returning the pointer to the DeviceInfo class. It can be used to retrieve the pointer to the Stream object and save / load the camera configurations to / from file.

lpxCamPy.PyDevice class is wrapper around C++ class lpxCam::Device

6.3.2 Member Function Documentation

6.3.2.1 Py::Object lpxCamPy::PyDevice::GetInfo ()

This method returns IpxCamPy.PyDeviceInfo object, associated with the PyDevice object.

Returns

Returns IpxCamPy.PyDeviceInfo class object

6.3.2.2 Py::Object lpxCamPy::PyDevice::GetDisplayName ()

This method returns the user readable display name of the Camera device object.

Returns

Returns the user readable name of the Camera device. Value type: String

24 Class Documentation

```
6.3.2.3 Py::Object lpxCamPy::PyDevice::GetNumStreams ( )
```

This method retrieves the number of the data streams, provided by the Device.

Returns

returns the number of the data streams. Value type: Integer

```
6.3.2.4 Py::Object lpxCamPy::PyDevice::Release ( )
```

This method releases the IpxCamPy.PyDevice object.

Returns

none

6.3.2.5 Py::Object lpxCamPy::PyDevice::ReadMem (const Py::Tuple & args)

This method reads a number of bytes from a given address.

Parameters

ir	args[0]	Byte address to read from. Value type: Integer
ir	args[1]	Amount of bytes to read from the register map address. Value type: Integer

Returns

Returns Tuple of:

- [0] Boolean value: Success of operation
- [1] Py::Bytes array of readout data

6.3.2.6 Py::Object lpxCamPy::PyDevice::WriteMem (const Py::Tuple & args)

This method writes a number of bytes at a given address.

Parameters

in	args[0]	Byte address to write to
in	args[1]	Py::Bytes array

Returns

Returns Tuple of:

- · [0] Boolean value: Success of operation
- [1] Integer value: number of bytes written

6.3.2.7 Py::Object lpxCamPy::PyDevice::GetStreamByIndex (const Py::Tuple & args)

This method retrieves the PyDataStream object by stream index.

Parameters

in	args[0]	stream index.	Value type:	Integer
----	---------	---------------	-------------	---------

Returns

Returns the IpxCamPy.PyDataStream object or None

6.3.2.8 Py::Object lpxCamPy::PyDevice::GetStreamById (const Py::Tuple & args)

This method retrieves the PyDataStream object by stream identifier.

Parameters

in	args[0]	stream identifier. Value type: String

Returns

Returns the IpxCamPy.PyDataStream object or None

6.3.2.9 Py::Object lpxCamPy::PyDevice::SaveConfiguration (const Py::Tuple & args)

This method saves the camera device configuration to the file.

Parameters

in	args[0]	Configuration file name. Value type: String

Returns

Returns True, if operation completed OK, False otherwise. Value type: Boolean

6.3.2.10 Py::Object lpxCamPy::PyDevice::LoadConfiguration (const Py::Tuple & args)

This method loads the camera device configuration from the file.

Parameters

in	args[0]	Configuration file name.	Value type: String
----	---------	--------------------------	--------------------

Returns

Returns True, if operation completed OK, False otherwise. Value type: Boolean

6.3.2.11 Py::Object lpxCamPy::PyDevice::GetCameraParameters ()

This method returns the camera parameters of the device object.

Returns

Returns IpxGenParamPy.PyGenParams object

6.3.2.12 Py::Object IpxCamPy::PyDevice::GetTransportParameters ()

This method returns the transport parameters of the device object.

Returns

Returns IpxGenParamPy.PyGenParams object

6.3.2.13 Py::Object IpxCamPy::PyDevice::RegisterEvent (const Py::Tuple & args)

This method registers the Device class method as a callback method to be called when event of the specified type occurs.

Parameters

in	args[0]	Event Type. Value type: Integer. It can receive one of the following values:	
		 GenICamEvent [1002] - this event occurs, if GenICam event was triggered by the camera 	
		 CameraConnected [1003] - this event occurs, when camera was connected to the computer 	
		 CameraDisconnected [1004] - this event occurs, when camera was disconnected from the computer 	
in	args[1]	event handler callback function.	

Returns

Returns True, if operation completed OK, False otherwise. Value type: Boolean

6.3.2.14 Py::Object lpxCamPy::PyDevice::UnRegisterEvent (const Py::Tuple & args)

This method unregisters the Device class callback method for the event type.

Parameters

in	args[0]	Event Type. Value type: Integer. It can receive one of the following values:	
		GenICamEvent [1002] - this event occurs, if GenICam event was triggered by the camera	
		 CameraConnected [1003] - this event occurs, when camera was connected to the computer 	
		• CameraDisconnected [1004] - this event occurs, when camera was disconnected from the computer	
in	args[1]	event handler callback function.	

Returns

Returns True, if operation completed OK, False otherwise. Value type: Boolean

The documentation for this class was generated from the following file:

IpxCameraApiPy.h

6.4 IpxCamPy::PyDeviceInfo Class Reference

DeviceInfo class provides the information about the device.

```
#include <IpxCameraApiPy.h>
```

Inherits PythonExtension < PyDeviceInfo >.

Public Member Functions

• Py::Object GetInterface ()

This method returns the interface of the device object.

Py::Object GetModel ()

This method returns the Camera device model name of the device object.

Py::Object GetVendor ()

This method returns the device vendor name of the device object.

• Py::Object GetVersion ()

This method returns the version of the Camera device.

Py::Object GetSerialNumber ()

This method returns the serial number of the Camera device.

• Py::Object GetDisplayName ()

This method returns the user readable display name of the Camera device object.

Py::Object GetUserDefinedName ()

This method returns the user defined name.

• Py::Object GetAccessStatus ()

Returns the device access status.

• Py::Object GetIPAddress ()

Returns the IP address of the GEV camera.

Py::Object GetIPMask ()

Returns the IP subnet mask of the GEV camera.

Py::Object GetIPGateway ()

Returns the IP gateway of GEV camera.

Py::Object ForceIP (const Py::Tuple & args)

Set the IP address to GEV camera.

6.4.1 Detailed Description

DeviceInfo class provides the information about the device.

The device info class can be used to retrieve information about the device. DeviceInfo class provides the information about the camera device.

The DeviceInfo class can be used to retrieve the information about the device, and to create the IpxCamPy.PyDevice object by PyIpxCameraApi.PyIpxCreateDevice() method call IpxCamPy.PyDeviceInfo Python class is wrapper around C++ class IpxCam::DeviceInfo

6.4.2 Member Function Documentation

6.4.2.1 Py::Object lpxCamPy::PyDeviceInfo::GetInterface ()

This method returns the interface of the device object.

Returns the lpxCamPy.PyDeviceInterface object for the camera device, associated with the PyDeviceInfo object

Returns

Returns the IpxCamPy.PyDeviceInterface class object

```
6.4.2.2 Py::Object lpxCamPy::PyDeviceInfo::GetModel ( )
This method returns the Camera device model name of the device object.
Returns
     Returns the Camera device model name. Value type: String
6.4.2.3 Py::Object lpxCamPy::PyDeviceInfo::GetVendor ( )
This method returns the device vendor name of the device object.
Returns
     Returns the Imperx Camera device vendor name. Value type: String
6.4.2.4 Py::Object lpxCamPy::PyDeviceInfo::GetVersion ( )
This method returns the version of the Camera device.
Returns
     Returns the Camera Device version. Value type: String
6.4.2.5 Py::Object lpxCamPy::PyDeviceInfo::GetSerialNumber ( )
This method returns the serial number of the Camera device.
Returns
     Returns the serial number of the Camera device. Value type: String
6.4.2.6 Py::Object lpxCamPy::PyDeviceInfo::GetDisplayName ( )
This method returns the user readable display name of the Camera device object.
```

Returns the user readable name of the Camera device. Value type: String

Generated by Doxygen

Returns

6.4.2.7 Py::Object lpxCamPy::PyDeviceInfo::GetUserDefinedName ()

This method returns the user defined name.

Returns

Returns the user defined name of the device. Value type: String

6.4.2.8 Py::Object lpxCamPy::PyDeviceInfo::GetAccessStatus ()

Returns the device access status.

This method returns the information about the current access status of the Camera device

Returns

Status Access Code. Value type: Integer. It can receive one of the following values:

- 0 (AccessStatusUnknown) The current availability of the device is unknown.
- 1 (AccessStatusReadWrite) The device is available for Read/Write access
- 2 (AccessStatusReadOnly) The device is available for Read only access
- 3 (AccessStatusNoAccess) The device is not available either because it is already open or because it is not reachable.
- 1001 (IpSubnetMismatch) The device is available, but IP address does not match to the host subnet mask.

6.4.2.9 Py::Object lpxCamPy::PyDeviceInfo::GetIPAddress ()

Returns the IP address of the GEV camera.

This method returns the IP address of the GEV camera, retrieved from DISCOVERY_ACK packet, received from the camera device

Returns

Returns IP Address string or empty string for non-GEV camera. Value type: String

6.4.2.10 Py::Object lpxCamPy::PyDeviceInfo::GetIPMask ()

Returns the IP subnet mask of the GEV camera.

This method returns the IP subnet mask of the GEV camera, retrieved from DISCOVERY_ACK packet, received from the camera device

Returns

Returns IP subnet mask string or empty string for non-GEV camera. Value type: String

6.4.2.11 Py::Object lpxCamPy::PyDeviceInfo::GetIPGateway ()

Returns the IP gateway of GEV camera.

This method returns the IP gateway of the GEV camera, retrieved from DISCOVERY_ACK packet, received from the camera device

Returns

Returns IP gateway string or empty string for non-GEV camera. Value type: String

6.4.2.12 Py::Object lpxCamPy::PyDeviceInfo::ForceIP (const Py::Tuple & args)

Set the IP address to GEV camera.

This method sets the specified IP address to the GEV camera, using ForceIP GVCP command

Parameters

in	args[0]	IP Address string to set	
in	args[1]	IP Address subnet mask string	
in	args[2]	Gateway address string	

Returns

Returns True, if operation completed OK, False otherwise. Value type: Boolean

The documentation for this class was generated from the following file:

• IpxCameraApiPy.h

6.5 IpxCamPy::PyDeviceInterface Class Reference

The PyDeviceInterface class represents a interface module in the GenTL module hierarchy.

#include <IpxCameraApiPy.h>

Inherits PythonExtension < PyDeviceInterface >.

Public Member Functions

• Py::Object GetDescription ()

This method returns the description of the interface.

Py::Object GetFirstDeviceInfo ()

This method retrieves the DeviceInfo object for the first device available on this Interface.

Py::Object ReEnumerateDevices ()

This method re-enumerates the devices.

Py::Object GetDeviceInfoList ()

This method retrieves the list of PyDeviceInfo objects for the camera devices, available on this Interface.

Py::Object GetType ()

This method gets the type of interface.

6.5.1 Detailed Description

The PyDeviceInterface class represents a interface module in the GenTL module hierarchy.

This class represents an individual physical interface in the System. For example, a network interface card (NIC) for GigE Vision connection, CXP or Camera Link frame grabber board, or USB3 Vision driver in the GenTL system. The PyDeviceInterface class includes methods to enumerate the available devices on the physical interface in the system.

IpxCamPy.PyDeviceInterface Python class is wrapper around C++ class IpxCam::Interface

6.5.2 Member Function Documentation

6.5.2.1 Py::Object lpxCamPy::PyDeviceInterface::GetDescription ()

This method returns the description of the interface.

The GetDescription method gets the user readable string description of the interface.

Returns

Returns the Description of the interface. Value type: String

6.5.2.2 Py::Object lpxCamPy::PyDeviceInterface::GetFirstDeviceInfo()

This method retrieves the DeviceInfo object for the first device available on this Interface.

Returns

Returns the IpxCamPy.PyDeviceInfo object

```
6.5.2.3 Py::Object lpxCamPy::PyDeviceInterface::ReEnumerateDevices ( )
```

This method re-enumerates the devices.

The ReEnumerateDevices method allows the user to re-enumerate the devices connected to the Interface and update the list of PyDeviceInfo objects returned by subsequent GetDeviceInfoList() method calls.

Returns

returns Tuple of:

- [0] Boolean value: Success of operation
- [1] Boolean value: True if list of devices was changed, False no changes

```
6.5.2.4 Py::Object lpxCamPy::PyDeviceInterface::GetDeviceInfoList ( )
```

This method retrieves the list of PyDeviceInfo objects for the camera devices, available on this Interface.

Returns

Returns the list of IpxCamPy.PyDeviceInfo objects

```
6.5.2.5 Py::Object lpxCamPy::PyDeviceInterface::GetType ( )
```

This method gets the type of interface.

The GetType method returns the Interface Type (Transport Layer Technology) of this interface object

Returns

Returns Interface Type. Value type: Integer. Possible values:

- 1 USB3Vision
- 2 GigEVision
- 3 CameraLink
- · 4 CoaxPress
- 5 HdSdi

The documentation for this class was generated from the following file:

IpxCameraApiPy.h

6.6 IpxGenParamPy::PyGenParam Class Reference

General class for GenICam parameter.

```
#include <IpxGenParamApiPy.h>
```

Inherits PythonExtension < PyGenParam >.

Public Member Functions

Py::Object GetType ()

This method returns the Parameter Node Type.

Py::Object GetName ()

This method returns the parameter node name.

Py::Object GetToolTip ()

This method returns a short description of the parameter node.

Py::Object GetDescription ()

This method returns a long description of the parameter node.

• Py::Object GetDisplayName ()

This method returns the string to be used for the parameter displaying.

• Py::Object GetVisibility ()

This method returns the visibility of the node.

Py::Object IsVisible (const Py::Tuple & args)

This method checks if the Param is visible.

Py::Object IsValueCached ()

This method checks if the parameter node is cached.

• Py::Object IsAvailable ()

This method checks if parameter node is available.

• Py::Object IsWritable ()

This method checks if parameter node is writable.

• Py::Object IsReadable ()

This method checks if the parameter node is readable.

• Py::Object IsStreamable ()

This method checks if the parameter node is streamable.

6.6.1 Detailed Description

General class for GenlCam parameter.

PyGenParam Class for accessing the GenICam feature node of the Camera parameters

IpxGenParamPy.PyGenParam is wrapper around IpxGenParam::Param C++ class

6.6.2 Member Function Documentation

6.6.2.1 Py::Object lpxGenParamPy::PyGenParam::GetType ()

This method returns the Parameter Node Type.

Returns

Returns the parameter type or 0 if failed. Value type: Integer.

6.6.2.2 Py::Object lpxGenParamPy::PyGenParam::GetName ()

This method returns the parameter node name.

Returns

If the method succeeds, it will return the parameter node name. Otherwise, it will return None. Value type: String.

6.6.2.3 Py::Object lpxGenParamPy::PyGenParam::GetToolTip ()

This method returns a short description of the parameter node.

Returns

If the method succeeds, it will return a short description of the parameter node. Otherwise, it will return None. Value type: String.

6.6.2.4 Py::Object lpxGenParamPy::PyGenParam::GetDescription ()

This method returns a long description of the parameter node.

Returns

If the method succeeds, it will return a long description of the parameter node. Otherwise, it will return None. Value type: String.

6.6.2.5 Py::Object lpxGenParamPy::PyGenParam::GetDisplayName ()

This method returns the string to be used for the parameter displaying.

Returns

If the method succeeds, it will return the parameter display name. Otherwise, it will return None. Value type: String.

```
6.6.2.6 Py::Object lpxGenParamPy::PyGenParam::GetVisibility ( )
```

This method returns the visibility of the node.

Returns

It will return the visibility setting of the parameter node. Possible values are: Basic (0), Expert (1), Guru (2), Invisible (3) or Undefined (99). Value type: Integer

6.6.2.7 Py::Object lpxGenParamPy::PyGenParam::IsVisible (const Py::Tuple & args)

This method checks if the Param is visible.

Parameters

in	args[0]	Visibility of the parameter node
----	---------	----------------------------------

Returns

True if the parameter node is visible. Otherwise, it is not visible.

6.6.2.8 Py::Object lpxGenParamPy::PyGenParam::IsValueCached ()

This method checks if the parameter node is cached.

Returns

True if the value is cached. False if the value is not cached. Value type: Boolean

6.6.2.9 Py::Object lpxGenParamPy::PyGenParam::IsAvailable ()

This method checks if parameter node is available.

Returns

True if the parameter node is available. False if it is not available. Value type: Boolean

6.6.2.10 Py::Object IpxGenParamPy::PyGenParam::IsWritable ()

This method checks if parameter node is writable.

Returns

True if the parameter node is writable. False if is not writable. Value type: Boolean

```
6.6.2.11 Py::Object lpxGenParamPy::PyGenParam::lsReadable ( )
```

This method checks if the parameter node is readable.

Returns

True if the parameter node is readable. False if it is not readable. Value type: Boolean

```
6.6.2.12 Py::Object lpxGenParamPy::PyGenParam::IsStreamable ( )
```

This method checks if the parameter node is streamable.

Returns

True if the parameter node is streamable. False if it is not streamable. Value type: Boolean

The documentation for this class was generated from the following file:

· IpxGenParamApiPy.h

6.7 IpxGenParamPy::PyGenParamBoolean Class Reference

PyGenParamBoolean class represents the Boolean GenlCam camera parameter.

```
#include <IpxGenParamApiPy.h>
```

Inherits PythonExtension < PyGenParamBoolean >.

Public Member Functions

Py::Object GetType ()

This method returns the node object Boolean type.

• Py::Object GetValue ()

This method gets the Boolean node value.

• Py::Object SetValue (const Py::Tuple &args)

This method sets the Boolean node value.

• Py::Object IsWritable ()

This method checks if parameter node is writable.

• Py::Object IsReadable ()

This method checks if parameter node is readable.

6.7.1 Detailed Description

PyGenParamBoolean class represents the Boolean GenICam camera parameter.

PyGenParamBoolean class contains methods that map the integer element value of a GenICam IBoolean interface feature to true or false.

For example, the mapping below will illustrate the IBoolean interfaces of a LUTEnable feature.

IpxGenParamPy.PyGenParamBoolean class is a wrapper around IpxGenParam::Boolean C++ class

6.7.2 Member Function Documentation

6.7.2.1 Py::Object lpxGenParamPy::PyGenParamBoolean::GetType ()

This method returns the node object Boolean type.

Returns

Returns the node object Boolean type. Value type: Integer.

6.7.2.2 Py::Object lpxGenParamPy::PyGenParamBoolean::GetValue ()

This method gets the Boolean node value.

Returns

Returns tuple of Success of the operation ant the Boolean value. Value type: Boolean.

6.7.2.3 Py::Object lpxGenParamPy::PyGenParamBoolean::SetValue (const Py::Tuple & args)

This method sets the Boolean node value.

Parameters

in	args[0]	Boolean node value to set. Value type: Boolean.
----	---------	---

Returns

Returns Success of the operation. Value type: Boolean.

6.7.2.4 Py::Object lpxGenParamPy::PyGenParamBoolean::IsWritable ()

This method checks if parameter node is writable.

Returns

True if the parameter node is writable, False - otherwise. Value type: Boolean.

6.7.2.5 Py::Object lpxGenParamPy::PyGenParamBoolean::IsReadable ()

This method checks if parameter node is readable.

Returns

True if the parameter node is readable, False - otherwise. Value type: Boolean.

The documentation for this class was generated from the following file:

· IpxGenParamApiPy.h

6.8 IpxGenParamPy::PyGenParamCategory Class Reference

A class containing methods that the user can access the categories GenlCam features. It will access the node object's of an lCategory interface. Each feature of a device will be placed in a **Category**. The Category feature is used to present the user with a group of features for the named category.

```
#include <IpxGenParamApiPy.h>
```

Inherits PythonExtension < PyGenParamCategory >.

Public Member Functions

• Py::Object GetType ()

This method returns the node object Category type.

• Py::Object GetCount ()

This method returns the number of parameters in the category.

Py::Object GetParamByIndex (const Py::Tuple & args)

This method returns the Parameter by Index.

Py::Object GetNode ()

This method returns the PyGenParamNode object.

6.8.1 Detailed Description

A class containing methods that the user can access the categories GenlCam features. It will access the node object's of an ICategory interface. Each feature of a device will be placed in a **Category**. The Category feature is used to present the user with a group of features for the named category.

A class containing methods for GenlCam Category Properties. For example, the mapping below will illustrate the I← Category interfaces categories such as DeviceControl and EventControl.

PyGenParamCategory class represents the GenICam Category.

PyGenParamCategory class contains methods that the user can access the categories of GenlCam features. It will access the node object's of an ICategory interface. Each feature of a device will be placed in a **Category**. The Category feature is used to present the user with a group of features for the named category.

For example, the mapping below will illustrate the ICategory interfaces categories such as DeviceControl and Event ← Control.

IpxGenParamPy.PyGenParamCategory class is a wrapper around IpxGenParam::Category C++ class

6.8.2 Member Function Documentation

6.8.2.1 Py::Object lpxGenParamPy::PyGenParamCategory::GetType ()

This method returns the node object Category type.

Returns

Returns the node object Category type. Value type: Integer.

6.8.2.2 Py::Object lpxGenParamPy::PyGenParamCategory::GetCount ()

This method returns the number of parameters in the category.

Returns

Returns the number of parameters in the category. Value type: Integer.

6.8.2.3 Py::Object lpxGenParamPy::PyGenParamCategory::GetParamByIndex (const Py::Tuple & args)

This method returns the Parameter by Index.

Parameters

in	args[0]	parameter index

Returns

Returns the parameter object

6.8.2.4 Py::Object lpxGenParamPy::PyGenParamCategory::GetNode ()

This method returns the PyGenParamNode object.

Returns

If the method succeeds, it will return IpxGenParamPy.PyGenParamNode object for this Parameter. Otherwise, it will return a value of None.

The documentation for this class was generated from the following file:

IpxGenParamApiPy.h

6.9 IpxGenParamPy::PyGenParamCommand Class Reference

PyGenParamCommand class represents Command GenICam camera parameter.

```
#include <IpxGenParamApiPy.h>
```

Inherits PythonExtension < PyGenParamCommand >.

Public Member Functions

- Py::Object Execute ()
 - This method executes the command.
- Py::Object IsDone ()

This method queries whether the command is executed and completed.

6.9.1 Detailed Description

PyGenParamCommand class represents Command GenICam camera parameter.

A class for GenICam Command contains methods that allow the user submit a command for execution as well as poll the command status.

For example, the mapping below will illustrate the ICommand interface for AcquisitionStart. This feature starts the Acquisition of the device.

lpxGenParamPy.PyGenParamCommand class is a wrapper around lpxGenParam::Command C++ class

6.9.2 Member Function Documentation

6.9.2.1 Py::Object lpxGenParamPy::PyGenParamCommand::Execute ()

This method executes the command.

Returns

Success of the operation. Value type: Boolean.

6.9.2.2 Py::Object lpxGenParamPy::PyGenParamCommand::IsDone ()

This method queries whether the command is executed and completed.

Returns

Returns True, if the command has finished. Otherwise, it returns False. Value type: Boolean.

The documentation for this class was generated from the following file:

· IpxGenParamApiPy.h

6.10 IpxGenParamPy::PyGenParamEnum Class Reference

PyGenParamEnum class represents Enumeration GenICam camera parameter.

```
#include <IpxGenParamApiPy.h>
```

Inherits PythonExtension< PyGenParamEnum >.

Public Member Functions

• Py::Object GetCount ()

This method gets count of the entry items the Enum.

Py::Object GetValue ()

This method gets the Enum Entry node value.

• Py::Object GetValueStr ()

This method gets the Enum Entry node String value.

Py::Object SetValue (const Py::Tuple &args)

This method Sets the Enum Entry node numerical value.

Py::Object SetValueStr (const Py::Tuple & args)

This method Sets the Enum Entry node String value.

• Py::Object GetType ()

This method returns the node object Enum type.

Py::Object GetEnumEntryByIndex (const Py::Tuple & args)

This method gets the Enum Entry node by the Index number.

6.10.1 Detailed Description

PyGenParamEnum class represents Enumeration GenICam camera parameter.

A class containing methods to access the Enumeration GenlCam camera parameter, using Integer or String value.

For example, the picture below illustrates the enumeration "WhiteBalanceMode".

IpxGenParamPy.PyGenParamEnum class is a wrapper around IpxGenParam::Enum C++ class

6.10.2 Member Function Documentation

```
6.10.2.1 Py::Object IpxGenParamPy::PyGenParamEnum::GetCount ( )
```

This method gets count of the entry items the Enum .

Returns

Returns Tuple of values:

- [0] Boolean value: Success of the operation
- [1] Integer value: Number of entries in the Enum

6.10.2.2 Py::Object lpxGenParamPy::PyGenParamEnum::GetValue ()

This method gets the Enum Entry node value.

Returns

Returns Tuple of values:

- [0] Boolean value: Success of the operation
- [1] Integer value: Enum numerical value

6.10.2.3 Py::Object lpxGenParamPy::PyGenParamEnum::GetValueStr ()

This method gets the Enum Entry node String value.

Returns

Returns Tuple of values:

- [0] Boolean value: Success of the operation
- [1] String value: Enum string value

6.10.2.4 Py::Object lpxGenParamPy::PyGenParamEnum::SetValue (const Py::Tuple & args)

This method Sets the Enum Entry node numerical value.

Parameters

in	args[0]	Enum numerical value. Value type: Integer	Enum numerical value. Value type: Integer
----	---------	---	---

Returns

Returns True, if operation succeeded. False, if failed. Value type: Boolean

6.10.2.5 Py::Object lpxGenParamPy::PyGenParamEnum::SetValueStr (const Py::Tuple & args)

This method Sets the Enum Entry node String value.

Parameters

in	args[0]	Enum string value.	Value type: String
----	---------	--------------------	--------------------

Returns

Returns True, if operation succeeded. False, if failed. Value type: Boolean

6.10.2.6 Py::Object lpxGenParamPy::PyGenParamEnum::GetType ()

This method returns the node object Enum type.

Returns

Returns the parameter type. Value type: Integer

6.10.2.7 Py::Object lpxGenParamPy::PyGenParamEnum::GetEnumEntryByIndex (const Py::Tuple & args)

This method gets the Enum Entry node by the Index number.

Parameters

in	args[0]	Index of the Enum Entry. Value type: Integer
----	---------	--

Returns

If the method succeeds, it returns the IpxGenParamPy.PyGenParamEnumEntry object, otherwise returns None.

The documentation for this class was generated from the following file:

IpxGenParamApiPy.h

6.11 IpxGenParamPy::PyGenParamEnumEntry Class Reference

PyGenParamEnumEntry class represents the entry of GenICam Enum parameter.

```
#include <IpxGenParamApiPy.h>
```

Inherits PythonExtension < PyGenParamEnumEntry >.

Public Member Functions

Py::Object GetValue ()

This method gets the EnumEntry numerical value.

• Py::Object GetValueStr ()

This method gets the EnumEntry String value.

Py::Object GetType ()

This method returns the node object EnumEntry type.

• Py::Object IsAvailable ()

This method checks if EnumEntry is available.

6.11.1 Detailed Description

PyGenParamEnumEntry class represents the entry of GenICam Enum parameter.

A Class for GenICam Enum Entries has methods to access the Enumeration GenICam parameter entry.

For example, the mapping below illustrates entries of the IEnumeration interface for the AOI2_Select feature. This feature can select the mode of operation for Slave AOI #2. The enumeration entries could be "Off", "Include", and "Exclude".

IpxGenParamPy.PyGenParamEnumEntry class is a wrapper around IpxGenParam::EnumEntry C++ class

6.11.2 Member Function Documentation

6.11.2.1 Py::Object lpxGenParamPy::PyGenParamEnumEntry::GetValue ()

This method gets the EnumEntry numerical value.

Returns

Returns Tuple of values:

- [0] Boolean value: Success of the operation
- [1] Integer EnumEntry value

```
6.11.2.2 Py::Object lpxGenParamPy::PyGenParamEnumEntry::GetValueStr ( )
This method gets the EnumEntry String value.
Returns
     Returns Tuple of values:
        • [0] Boolean value: Success of the operation
        • [1] String EnumEntry value
6.11.2.3 Py::Object lpxGenParamPy::PyGenParamEnumEntry::GetType ( )
This method returns the node object EnumEntry type.
Returns
     Returns the node type. Value type: Integer
6.11.2.4 Py::Object lpxGenParamPy::PyGenParamEnumEntry::IsAvailable ( )
This method checks if EnumEntry is available.
Returns
     True, if EnumEntry is available. False, if it is not available. Value type: Boolean
The documentation for this class was generated from the following file:

    IpxGenParamApiPy.h

       IpxGenParamPy::PyGenParamFloat Class Reference
6.12
PyGenParamFloat class represents Float GenICam camera parameter.
```

#include <IpxGenParamApiPy.h>

Inherits PythonExtension < PyGenParamFloat >.

Public Member Functions

Py::Object GetType ()

This method returns the node object Float type.

• Py::Object IsWritable ()

This method checks if parameter node is writable.

Py::Object IsReadable ()

This method checks if parameter node is readable.

• Py::Object GetValue ()

This method gets the Float node value.

Py::Object SetValue (const Py::Tuple &args)

This method sets the Float node value.

Py::Object GetMin ()

This method gets the minimum value.

Py::Object GetMax ()

This method gets the maximum value.

• Py::Object GetUnit ()

This method gets the Unit string.

6.12.1 Detailed Description

PyGenParamFloat class represents Float GenlCam camera parameter.

A class containing methods to access the Float GenlCam camera parameter as floating point value.

For example, the picture below illustrates the float "ExposureTime".

IpxGenParamPy.PyGenParamFloat class is a wrapper around IpxGenParam::Float C++ class

6.12.2 Member Function Documentation

6.12.2.1 Py::Object lpxGenParamPy::PyGenParamFloat::GetType ()

This method returns the node object Float type.

Returns

Returns the parameter type. Value type: Integer.

6.12.2.2 Py::Object IpxGenParamPy::PyGenParamFloat::IsWritable ()

This method checks if parameter node is writable.

Returns

True if the parameter node is writable, False - otherwise. Value type: Boolean.

6.12.2.3 Py::Object IpxGenParamPy::PyGenParamFloat::IsReadable ()

This method checks if parameter node is readable.

Returns

True if the parameter node is readable, False - otherwise. Value type: Boolean.

6.12.2.4 Py::Object lpxGenParamPy::PyGenParamFloat::GetValue ()

This method gets the Float node value.

Returns

Returns Tuple of values:

- [0] Boolean: Success of the operation
- [1] Integer: Float parameter value

6.12.2.5 Py::Object lpxGenParamPy::PyGenParamFloat::SetValue (const Py::Tuple & args)

This method sets the Float node value.

Parameters

in	args[0]	Float node value to set.	Value type: Integer.
----	---------	--------------------------	----------------------

Returns

Returns Success of the operation. Value type: Boolean.

6.12.2.6 Py::Object lpxGenParamPy::PyGenParamFloat::GetMin ()

This method gets the minimum value.

Returns

Returns Tuple of values:

- [0] Boolean: Success of the operation
- [1] Integer: Float parameter minimum value

```
6.12.2.7 Py::Object lpxGenParamPy::PyGenParamFloat::GetMax ( )
```

This method gets the maximum value.

Returns

Returns Tuple of values:

- [0] Boolean: Success of the operation
- [1] Integer: Float parameter maximum value

6.12.2.8 Py::Object lpxGenParamPy::PyGenParamFloat::GetUnit ()

This method gets the Unit string.

Returns

Returns Tuple of values:

- [0] Boolean: Success of the operation
- [1] String: Float parameter measurement unit string

The documentation for this class was generated from the following file:

· IpxGenParamApiPy.h

6.13 IpxGenParamPy::PyGenParamInt Class Reference

PyGenParamInt class represents Integer GenICam camera parameter.

```
#include <IpxGenParamApiPy.h>
```

Inherits PythonExtension < PyGenParamInt >.

Public Member Functions

Py::Object GetType ()

This method returns the node object Int type.

• Py::Object IsWritable ()

This method checks if parameter node is writable.

• Py::Object IsReadable ()

This method checks if parameter node is readable.

• Py::Object GetValue ()

This method gets the Int node value.

Py::Object SetValue (const Py::Tuple & args)

This method sets the Int node value.

• Py::Object GetMin ()

This method gets the minimum value.

Py::Object GetMax ()

This method gets the maximum value.

• Py::Object GetIncrement ()

This method gets the Increment value.

6.13.1 Detailed Description

PyGenParamInt class represents Integer GenICam camera parameter.

A class containing methods to access the Integer GenlCam camera parameter as integer value.

For example, the mapping below illustrates "Width" Integer parameter.

IpxGenParamPy.PyGenParamInt class is a wrapper around IpxGenParam::Int C++ class

6.13.2 Member Function Documentation

```
6.13.2.1 Py::Object lpxGenParamPy::PyGenParamInt::GetType ( )
```

This method returns the node object Int type.

Returns

Returns the parameter type. Value type: Integer.

```
6.13.2.2 Py::Object lpxGenParamPy::PyGenParamInt::IsWritable ( )
```

This method checks if parameter node is writable.

Returns

True if the parameter node is writable, False - otherwise. Value type: Boolean.

```
6.13.2.3 Py::Object lpxGenParamPy::PyGenParamInt::IsReadable ( )
```

This method checks if parameter node is readable.

Returns

True if the parameter node is readable, False - otherwise. Value type: Boolean.

```
6.13.2.4 Py::Object IpxGenParamPy::PyGenParamInt::GetValue ( )
```

This method gets the Int node value.

Returns

Returns Tuple of values:

- [0] Boolean: Success of the operation
- [1] Integer: Int parameter value

6.13.2.5 Py::Object lpxGenParamPy::PyGenParamInt::SetValue (const Py::Tuple & args)

This method sets the Int node value.

Parameters

	in	args[0]	Int node value to set. Value	ue type: Integer.	
--	----	---------	------------------------------	-------------------	--

Returns

Returns Success of the operation. Value type: Boolean.

6.13.2.6 Py::Object lpxGenParamPy::PyGenParamInt::GetMin ()

This method gets the minimum value.

Returns

Returns Tuple of values:

- [0] Boolean: Success of the operation
- [1] Integer: Int parameter minimum value

6.13.2.7 Py::Object lpxGenParamPy::PyGenParamInt::GetMax ()

This method gets the maximum value.

Returns

Returns Tuple of values:

- [0] Boolean: Success of the operation
- [1] Integer: Int parameter maximum value

6.13.2.8 Py::Object lpxGenParamPy::PyGenParamInt::GetIncrement ()

This method gets the Increment value.

Returns

Returns Tuple of values:

- [0] Boolean: Success of the operation
- [1] Integer: Int parameter increment value

The documentation for this class was generated from the following file:

IpxGenParamApiPy.h

6.14 IpxGenParamPy::PyGenParamNode Class Reference

PyGenParamNode class represents GenICam INode class.

```
#include <IpxGenParamApiPy.h>
```

Inherits PythonExtension < PyGenParamNode >.

Public Member Functions

• Py::Object IsFeature ()

Returns True if the node can be reached via category nodes from a category node named "Root". Otherwise it returns False.

6.14.1 Detailed Description

PyGenParamNode class represents GenICam INode class.

The documentation for this class was generated from the following file:

· IpxGenParamApiPy.h

6.15 lpxGenParamPy::PyGenParamNodeMap Class Reference

```
#include <IpxGenParamApiPy.h>
```

Inherits PythonExtension < PyGenParamNodeMap >.

6.15.1 Detailed Description

Interface to access the node map

The documentation for this class was generated from the following file:

· IpxGenParamApiPy.h

6.16 IpxGenParamPy::PyGenParams Class Reference

An PyGenParams class contains methods to access all GenlCam camera parameters.

```
#include <IpxGenParamApiPy.h>
```

Inherits PythonExtension < PyGenParams >.

Public Member Functions

Py::Object SetIntegerValue (const Py::Tuple & args)

This method sets the Integer value of the Integer node.

Py::Object GetIntegerValue (const Py::Tuple & args)

This method gets the Integer value of the Integer node.

Py::Object SetFloatValue (const Py::Tuple & args)

This method sets the Float value of the Float node.

Py::Object GetFloatValue (const Py::Tuple & args)

This method gets the Float value of the Float node.

• Py::Object ExecuteCommand (const Py::Tuple &args)

This method executes/submits the command.

• Py::Object GetStringValue (const Py::Tuple & args)

This method gets the String value of the String node.

Py::Object SetStringValue (const Py::Tuple & args)

This method sets the String value of the String node.

Py::Object GetEnumValueStr (const Py::Tuple & args)

This method gets the String value of the Enum node.

Py::Object GetEnumValue (const Py::Tuple & args)

This method gets the Integer value of the Enum node.

Py::Object SetEnumValueStr (const Py::Tuple & args)

This method sets the String value of the Enum node.

Py::Object SetEnumValue (const Py::Tuple & args)

This method sets the Integer value of the Enum node.

Py::Object GetEnum (const Py::Tuple & args)

This method gets link to the Enum object for the specified node name of the camera descriptor XML file.

Py::Object GetParamByIndex (const Py::Tuple & args)

This method gets the parameter object by index.

Py::Object GetParam (const Py::Tuple & args)

This method gets the parameter object by name.

Py::Object GetCount ()

This method gets the number of nodes.

Py::Object GetRootCategory ()

This method gets the object of the root category node. The Root node is considered a special node. It has no parent node. In the topology graph, it is the top node which connects to at least one child node. The child node may connect to the device node that provides the connection to the transport layer.

Py::Object GetBooleanValue (const Py::Tuple & args)

This method gets the value of the Boolean node.

Py::Object SetBooleanValue (const Py::Tuple & args)

This method sets the value of the Boolean node.

• Py::Object GetBoolean (const Py::Tuple &args)

This method gets the PyGenParamBoolean class object for the specified node name of the camera descriptor XML file.

Py::Object GetInt (const Py::Tuple &args)

This method gets link to the Int object for the specified node name of the camera descriptor XML file.

Py::Object GetString (const Py::Tuple & args)

This method gets the PyGenParamString class object for the specified node name of the camera descriptor XML file.

• Py::Object GetFloat (const Py::Tuple &args)

This method gets the PyGenParamFloat class object for the specified node name of the camera descriptor XML file.

• Py::Object GetCommand (const Py::Tuple &args)

This method gets the PyGenParamCommand class object for the specified node name of the camera descriptor XML file.

Py::Object IsCommandDone (const Py::Tuple & args)

This method polls the corresponding executed command to see if the executed command is done or not.

Py::Object GetNodeMap ()

This method gets the pointer to the NodeMap interface. The NodeMap interface will provide methods to retrieves all nodes in the node map.

6.16.1 Detailed Description

An PyGenParams class contains methods to access all GenlCam camera parameters.

This class contains methods that can access each node from the GenlCam camera description XML file by parameters type and name.

6.16.2 Member Function Documentation

6.16.2.1 Py::Object lpxGenParamPy::PyGenParams::SetIntegerValue (const Py::Tuple & args)

This method sets the Integer value of the Integer node.

Parameters

in	args[0]	String value: Unique name of Integer parameter to set
in	args[1]	Integer value: value to set

Returns

Returns Success of the operation. Value type: Boolean

6.16.2.2 Py::Object IpxGenParamPy::PyGenParams::GetIntegerValue (const Py::Tuple & args)

This method gets the Integer value of the Integer node.

Parameters

١	in	arac[0]	Unique name of Integer parameter to get. Value type: String
	T11	arysįvį	Offique frame of integer parameter to get. Value type. String

Returns

Tuple of values:

- [0] Boolean value: Success of the operation
- [1] Integer value: Parameter value

6.16.2.3 Py::Object lpxGenParamPy::PyGenParams::SetFloatValue (const Py::Tuple & args)

This method sets the Float value of the Float node.

Parameters

in	args[0]	String value: Unique name of Float parameter to set
in	args[1]	Float value: value to set

Returns

Returns Success of the operation. Value type: Boolean

6.16.2.4 Py::Object lpxGenParamPy::PyGenParams::GetFloatValue (const Py::Tuple & args)

This method gets the Float value of the Float node.

Parameters

in	args[0]	Unique name of Float parameter to get. Value type: String
----	---------	---

Returns

Tuple of values:

- [0] Boolean value: Success of the operation
- [1] Float value: Parameter value

6.16.2.5 Py::Object lpxGenParamPy::PyGenParams::ExecuteCommand (const Py::Tuple & args)

This method executes/submits the command.

Parameters

in	args[0]	Unique name of Command type node in the camera descriptor XML file. Value type: Strir	ng
----	---------	---	----

Returns

Returns True, if operation succeeded. False, if failed. Value type: Boolean

6.16.2.6 Py::Object lpxGenParamPy::PyGenParams::GetStringValue (const Py::Tuple & args)

This method gets the String value of the String node.

Parameters

in	args[0]	Unique name of String parameter to get.	Value type: String	
----	---------	---	--------------------	--

Returns

Tuple of values:

- [0] Boolean value: Success of the operation
- [1] String value: Parameter value

6.16.2.7 Py::Object lpxGenParamPy::PyGenParams::SetStringValue (const Py::Tuple & args)

This method sets the String value of the String node.

Parameters

in	args[0]	String value: Unique name of String parameter to set
in	args[1]	String value: value to set

Returns

Returns Success of the operation. Value type: Boolean

6.16.2.8 Py::Object lpxGenParamPy::PyGenParams::GetEnumValueStr (const Py::Tuple & args)

This method gets the String value of the Enum node.

Parameters

_			
	in	args[0]	Unique name of Enum parameter to get. Value type: String

Returns

Tuple of values:

- [0] Boolean value: Success of the operation
- [1] String value: Enum parameter value

6.16.2.9 Py::Object lpxGenParamPy::PyGenParams::GetEnumValue (const Py::Tuple & args)

This method gets the Integer value of the Enum node.

Parameters

	in	args[0]	Unique name of Enum parameter to get. Value type: String	
--	----	---------	--	--

Returns

Tuple of values:

- [0] Boolean value: Success of the operation
- [1] Integer value: Enum parameter value

6.16.2.10 Py::Object lpxGenParamPy::PyGenParams::SetEnumValueStr (const Py::Tuple & args)

This method sets the String value of the Enum node.

Parameters

in	args[0]	String value: Unique name of Enum parameter to set
in	args[1]	String value: value to set

Returns

Returns Success of the operation. Value type: Boolean

6.16.2.11 Py::Object lpxGenParamPy::PyGenParams::SetEnumValue (const Py::Tuple & args)

This method sets the Integer value of the Enum node.

Parameters

in	args[0]	String value: Unique name of Enum parameter to set
in	args[1]	Integer value: value to set

Returns

Returns Success of the operation. Value type: Boolean

6.16.2.12 Py::Object lpxGenParamPy::PyGenParams::GetEnum (const Py::Tuple & args)

This method gets link to the Enum object for the specified node name of the camera descriptor XML file.

Parameters

in	name	Unique name of a node in node map.	1
----	------	------------------------------------	---

Returns

If the method succeeds, it returns link to the Enum object. Otherwise, it returns a None. This method gets the PyGenParamEnum class object for the specified node name of the camera descriptor XML file

Parameters

in	args[0]	A unique name of Enum type node in the camera descriptor XML file. Value type: String	
----	---------	---	--

Returns

If the method succeeds, it returns the IpxGenParamPy.PyGenParamEnum class object for the specific node name. Returns None if failed

6.16.2.13 Py::Object lpxGenParamPy::PyGenParams::GetParamByIndex (const Py::Tuple & args)

This method gets the parameter object by index.

Parameters

in	args[0]	Parameter index.	Value type: Integer
----	---------	------------------	---------------------

Returns

If the method succeeds, it returns <code>lpxGenParamPy.PyGenParam</code> or <code>lpxGenParamPy.PyGenParamCategory</code> object of the node, referenced by the index value. Returns None if failed.

6.16.2.14 Py::Object lpxGenParamPy::PyGenParams::GetParam (const Py::Tuple & args)

This method gets the parameter object by name.

Parameters

in	args[0]	Parameter name. Value type: String

Returns

If the method succeeds, it returns IpxGenParamPy.PyGenParam or IpxGenParamPy.PyGenParamCategory object of the node, referenced by the index value. Returns None if failed.

6.16.2.15 Py::Object lpxGenParamPy::PyGenParams::GetCount ()

This method gets the number of nodes.

Returns

Returns the number of nodes. This number should be greater than 0. Value type: Integer

6.16.2.16 Py::Object lpxGenParamPy::PyGenParams::GetRootCategory ()

This method gets the object of the root category node. The Root node is considered a special node. It has no parent node. In the topology graph, it is the top node which connects to at least one child node. The child node may connect to the device node that provides the connection to the transport layer.

Returns

If the method succeeds, it returns the IpxGenParamPy.PyGenParamCategory object of the root category node. Returns None if failed

6.16.2.17 Py::Object lpxGenParamPy::PyGenParams::GetBooleanValue (const Py::Tuple & args)

This method gets the value of the Boolean node.

Parameters

in	args[0]	Unique name of Boolean parameter to get. Value type: String	
----	---------	---	--

Returns

Tuple of values:

- [0] Boolean value: Success of the operation
- [1] Boolean value: Parameter value

6.16.2.18 Py::Object lpxGenParamPy::PyGenParams::SetBooleanValue (const Py::Tuple & args)

This method sets the value of the Boolean node.

Parameters

in	args[0]	String value: Unique name of Boolean parameter to set
in	args[1]	Boolean value: value to set

Returns

Returns Success of the operation. Value type: Boolean

6.16.2.19 Py::Object lpxGenParamPy::PyGenParams::GetBoolean (const Py::Tuple & args)

This method gets the PyGenParamBoolean class object for the specified node name of the camera descriptor XML file.

Parameters

in	args[0]	A unique name of Boolean type node in the camera descriptor XML file.	Value type: String
----	---------	---	--------------------

Returns

If the method succeeds, it returns the IpxGenParamPy.PyGenParamBoolean class object for the specific node name. Returns None if failed

6.16.2.20 Py::Object lpxGenParamPy::PyGenParams::GetInt (const Py::Tuple & args)

This method gets link to the Int object for the specified node name of the camera descriptor XML file.

Parameters

in	name	Unique name of a node in node map.
----	------	------------------------------------

Returns

If the method succeeds, it returns link to the Int object. Otherwise, it returns a None. This method gets the Py← GenParamInt class object for the specified node name of the camera descriptor XML file

Parameters

in	args[0]	A unique name of Int type node in the camera descriptor XML file. Value type: String
----	---------	--

Returns

If the method succeeds, it returns the lpxGenParamPy.PyGenParamInt class object for the specific node name. Returns None if failed

6.16.2.21 Py::Object lpxGenParamPy::PyGenParams::GetString (const Py::Tuple & args)

This method gets the PyGenParamString class object for the specified node name of the camera descriptor XML file.

Parameters

in	args[0]	A unique name of String type node in the camera descriptor XML file.	Value type: String
----	---------	--	--------------------

Returns

If the method succeeds, it returns the IpxGenParamPy.PyGenParamString class object for the specific node name. Returns None if failed

6.16.2.22 Py::Object lpxGenParamPy::PyGenParams::GetFloat (const Py::Tuple & args)

This method gets the PyGenParamFloat class object for the specified node name of the camera descriptor XML file.

Parameters

Returns

If the method succeeds, it returns the lpxGenParamPy.PyGenParamFloat class object for the specific node name. Returns None if failed

6.16.2.23 Py::Object lpxGenParamPy::PyGenParams::GetCommand (const Py::Tuple & args)

This method gets the PyGenParamCommand class object for the specified node name of the camera descriptor XML file.

Parameters

in	args[0]	A unique name of Command type node in the camera descriptor XML file. Value type: String

Returns

If the method succeeds, it returns the <code>lpxGenParamPy.PyGenParamCommand</code> class object for the specific node name. Returns None if failed

6.16.2.24 Py::Object lpxGenParamPy::PyGenParams::IsCommandDone (const Py::Tuple & args)

This method polls the corresponding executed command to see if the executed command is done or not.

Parameters

1	in	args[0]	A unique name of Command type node in the camera descriptor XML file.
---	----	---------	---

Returns

Tuple of values:

- [0] Boolean value: Success of the operation
- [1] Boolean value: True, if command done, False otherwise

```
6.16.2.25 Py::Object lpxGenParamPy::PyGenParams::GetNodeMap ( )
```

This method gets the pointer to the NodeMap interface. The NodeMap interface will provide methods to retrieves all nodes in the node map.

Returns

Tuple of values:

- [0] Boolean value: Success of the operation
- [1] PyGenParamNodeMap object

The documentation for this class was generated from the following file:

· IpxGenParamApiPy.h

6.17 IpxGenParamPy::PyGenParamString Class Reference

PyGenParamString class represents String GenlCam camera parameter.

```
#include <IpxGenParamApiPy.h>
```

Inherits PythonExtension< PyGenParamString >.

Public Member Functions

Py::Object GetType ()

This method returns the node object Param type.

Py::Object IsWritable ()

This method checks if parameter node is writable.

• Py::Object IsReadable ()

This method checks if parameter node is readable.

Py::Object GetValue ()

This method gets the value of the string node.

• Py::Object GetMaxLength ()

This method gets the Maximum Length of the string. Value type: Integer.

Py::Object SetValue (const Py::Tuple & args)

This method sets the value of the string node.

6.17.1 Detailed Description

PyGenParamString class represents String GenICam camera parameter.

A class containing methods to access the String GenlCam camera parameter as zero-terminated array of characters For example, the image below illustrates "DeviceModelName" parameter.

IpxGenParamPy.PyGenParamString class is a wrapper around IpxGenParam::String C++ class

6.17.2 Member Function Documentation

```
6.17.2.1 Py::Object lpxGenParamPy::PyGenParamString::GetType ( )
```

This method returns the node object Param type.

Returns

The parameter type

6.17.2.2 Py::Object lpxGenParamPy::PyGenParamString::IsWritable ()

This method checks if parameter node is writable.

Returns

True if the parameter node is writable. False, it is not writable. Value type: Boolean.

6.17.2.3 Py::Object lpxGenParamPy::PyGenParamString::IsReadable ()

This method checks if parameter node is readable.

Returns

True if the parameter node is readable. False, it is not readable. Value type: Boolean.

6.17.2.4 Py::Object lpxGenParamPy::PyGenParamString::GetValue ()

This method gets the value of the string node.

Returns

Returns Tuple of values:

- [0] Boolean value: Success of the operation
- [1] String parameter value

6.17.2.5 Py::Object lpxGenParamPy::PyGenParamString::SetValue (const Py::Tuple & args)

This method sets the value of the string node.

Parameters

in	args[0]	String value to set.	Value type: String.
----	---------	----------------------	---------------------

Returns

Returns True if operation succeeded, False - otherwise. Value type: Boolean.

The documentation for this class was generated from the following file:

IpxGenParamApiPy.h

6.18 IpxGuiPy::PyGenParamView Class Reference

```
#include <IpxCameraGuiApiPy.h>
```

Inherits PythonExtension < PyGenParamView >.

Public Member Functions

· void clearParams ()

This method clears the parameters node tree view of the panel.

• void release ()

This method destroys the IlpxGenParamTreeView class previously created.

6.18.1 Detailed Description

The PyGenParamView class represents node tree view of GenICam parameters panel

The documentation for this class was generated from the following file:

· IpxCameraGuiApiPy.h

6.19 IpxCamPy::PyImage Class Reference

```
#include <IpxCameraApiPy.h>
```

Inherits PythonExtension< Pylmage >.

Public Member Functions

IpxImage * getImage ()
 Returns IpxImage object.

6.19.1 Detailed Description

! The Image class represents the image, acquired from the camera /** Image object can be created from IpxCam Py::Buffer object, and can be used to display the image on the screen or convert it to Bitmap and save it to the hard drive.

lpxCamPy::Image Python class is wrapper around C++ structure lpxImage

6.19.2 Member Function Documentation

6.19.2.1 lpxlmage* lpxCamPy::Pylmage::getlmage()

Returns lpxImage object.

Returns

IpxImage object.

The documentation for this class was generated from the following file:


· IpxCameraApiPy.h

6.20 PylpxCameraApi Class Reference

Python wrapper for General API.

#include <IpxCameraApiPy.h>

Inheritance diagram for PylpxCameraApi:



Public Member Functions

Py::Object PylpxCreateDevice (const Py::Tuple & args)
 Creates IpxCamPy.PyDevice object.

6.20.1 Detailed Description

Python wrapper for General API.

6.20.2 Member Function Documentation

6.20.2.1 Py::Object PylpxCameraApi::PylpxCreateDevice (const Py::Tuple & args)

Creates IpxCamPy.PyDevice object.

This method creates IpxCamPy.PyDevice object, representing the Camera

Parameters

in	IpxCamPy.PyDeviceInfo	object
----	-----------------------	--------

Returns

Returns IpxCamPy::PyDevice object or None

The documentation for this class was generated from the following file:


· IpxCameraApiPy.h

6.21 IpxGuiPy::PyIpxCameraApiGui Class Reference

Extension of IpxCamPy.PyIpxCameraApi class to provide the GUI functionality.

#include <IpxCameraGuiApiPy.h>

Inheritance diagram for IpxGuiPy::PyIpxCameraApiGui:



Public Member Functions

- Py::Object PyCreateDisplay (const Py::Tuple &args)
 - Creates the display window.
- Py::Object PyShowImageOnDisplay (const Py::Tuple &args)
 - Displays the image.
- Py::Object PyCreateGenParamTreeViewForArray (const Py::Tuple &args)
 - Creates the GenICam parameters panel.
- Py::Object PyDestroyGenParamTreeView (const Py::Tuple & args)

Destroys the GenlCam parameters panel.

6.21.1 Detailed Description

Extension of IpxCamPy.PyIpxCameraApi class to provide the GUI functionality.

6.21.2 Member Function Documentation

6.21.2.1 Py::Object lpxGuiPy::PylpxCameraApiGui::PyCreateDisplay (const Py::Tuple & args) [virtual]

Creates the display window.

Creates the child window to display the images acquired from the camera

Parameters

in	args[0]	Handle of parent window

Returns

Returns True, if window created OK, False - otherwise. Value type: Boolean

Reimplemented from PylpxCameraApi.

6.21.2.2 Py::Object lpxGuiPy::PylpxCameraApiGui::PyShowImageOnDisplay (const Py::Tuple & args) [virtual]

Displays the image.

Shows the image on display window created by SystemGui::CreateDisplay method

Parameters

in	args[0]	lpxCamPy.PyImage object to display
----	---------	------------------------------------

Returns

None

Reimplemented from PylpxCameraApi.

6.21.2.3 Py::Object lpxGuiPy::PylpxCameraApiGui::PyCreateGenParamTreeViewForArray (const Py::Tuple & args)
[virtual]

Creates the GenlCam parameters panel.

Creates the panel of the camera GenICam parameters for specified lpxGenParamPy.PyGenParams object

Parameters

in	args[0]	IpxGenParamPy.PyGenParams object
in	args[1]	Handle of parent window

Returns

IpxGuiPy.PyGenParamView class object, representing the panel created

Reimplemented from PylpxCameraApi.

6.21.2.4 Py::Object lpxGuiPy::PylpxCameraApiGui::PyDestroyGenParamTreeView (const Py::Tuple & args) [virtual]

Destroys the GenlCam parameters panel.

Closes and destroys the GenlCam parameters panel, previously created with PyCreateGenParamTreeViewForArray method

Parameters

in	args[0]	IpxGenParamPy.PyGenParams object
----	---------	----------------------------------

Returns

Returns True, operation completed successfully, False - otherwise. Value type: Boolean

Reimplemented from PylpxCameraApi.

The documentation for this class was generated from the following file:


· IpxCameraGuiApiPy.h

6.22 IpxCamPy::PyIpxSystem Class Reference

The PylpxSystem class represents an abstraction of the System module of the GenTL module hierarchy.

#include <IpxCameraApiPy.h>

Inheritance diagram for IpxCamPy::PyIpxSystem:



Public Member Functions

• Py::Object GetInterfaceList ()

This method returns the list of all the interfaces of the system object.

• Py::Object GetDisplayName ()

Returns the name of the GenTL Producer.

• Py::Object GetVersion ()

Returns the GenTL Producer version.

• Py::Object CreateDeviceFromConfig (const Py::Tuple &args)

Creates the Device object from configuration file.

6.22.1 Detailed Description

The PylpxSystem class represents an abstraction of the System module of the GenTL module hierarchy.

This class provides member functions to enumerate and instantiate the available interfaces reachable. It also provides a method for the configuration of the device module. This system module is the root of the GenTL Module hierarchy. IpxCamPy.PyIpxSystem class has member functions to find all the interfaces, display the user readable name and producer version of the GenTL system. The IpxCamPy.PyIpxSystem class can be used to obtain the list of PyDevice Interface objects, then get the list of IpxCamPy.PyDeviceInfo objects for the devices connected to the Interface, and create IpxCamPy.PyDevice object, representing the camera device.

IpxCamPy.PyIpxSystem Python class is wrapper around C++ class IpxCam::System

6.22.2 Member Function Documentation

```
6.22.2.1 Py::Object lpxCamPy::PylpxSystem::GetInterfaceList ( )
```

This method returns the list of all the interfaces of the system object.

GetInterfaceList method lists all the available hardware interfaces with the transport layers technologies, supported by GenTL producer library

Returns

Returns the list of IpxCamPy.PyDeviceInterface objects

```
6.22.2.2 Py::Object lpxCamPy::PylpxSystem::GetDisplayName ( )
```

Returns the name of the GenTL Producer.

This method returns the User readable name of the GenTL Producer of the system object.

Returns

Returns the system display name. Value type: String

```
6.22.2.3 Py::Object IpxCamPy::PyIpxSystem::GetVersion ( )
```

Returns the GenTL Producer version.

This method returns the version of the GenTL Producer of the system object.

Returns

Returns the System version. Value type: String

6.22.2.4 Py::Object lpxCamPy::PylpxSystem::CreateDeviceFromConfig (const Py::Tuple & args)

Creates the Device object from configuration file.

This method creates, configures and sets up the device using the information retrieved from the specified configuration file

Parameters

in args[0] Cor	figuration file to open. Value type: String
----------------	---

Returns

Returns IpxCamPy.PyDevice object or None if device cannot be instantiated

The documentation for this class was generated from the following file:


· IpxCameraApiPy.h

6.23 IpxGuiPy::PylpxSystemGui Class Reference

Extension of IpxCamPy.PyIpxSystem class to provide the GUI functionality.

#include <IpxCameraGuiApiPy.h>

Inheritance diagram for IpxGuiPy::PyIpxSystemGui:



Public Member Functions

virtual Py::Object SelectCamera (const Py::Tuple & args)
 Creates the camera selection dialog.

6.23.1 Detailed Description

Extension of IpxCamPy.PyIpxSystem class to provide the GUI functionality.

6.23.2 Member Function Documentation

6.23.2.1 virtual Py::Object lpxGuiPy::PylpxSystemGui::SelectCamera (const Py::Tuple & args) [virtual]

Creates the camera selection dialog.

This method creates the modal device discovery dialog to select the camera and obtain the PyDeviceInfo object. Py← DeviceInfo object can be used to create PyDevice object, representing the camera device

Parameters

in	args[0]	- Handle of parent window
in	args[1]	- True if device discovery polling is ON by default, False - polling is OFF. Value type: Boolean.

Returns

Returns IpxCamPy.PyDeviceInfo object or None, if nothing selected

Reimplemented from lpxCamPy::PylpxSystem.

The documentation for this class was generated from the following file:

• IpxCameraGuiApiPy.h

Index

AllocBufferQueue	IpxGenParamPy::PyGenParam, 35
IpxCamPy::PyDataStream, 21	GetDeviceInfoList
	IpxCamPy::PyDeviceInterface, 33
CancelBuffer	GetDisplayName
IpxCamPy::PyDataStream, 22	IpxCamPy::PyDevice, 23
CreateBuffer	lpxCamPy::PyDeviceInfo, 29
IpxCamPy::PyDataStream, 19	lpxCamPy::PylpxSystem, 70
CreateDeviceFromConfig	lpxGenParamPy::PyGenParam, 35
IpxCamPy::PyIpxSystem, 70	GetEnum
	IpxGenParamPy::PyGenParams, 57
Execute	GetEnumEntryByIndex
IpxGenParamPy::PyGenParamCommand, 42	IpxGenParamPy::PyGenParamEnum, 4
ExecuteCommand	GetEnumValue
IpxGenParamPy::PyGenParams, 55	IpxGenParamPy::PyGenParams, 56
	GetEnumValueStr
FlushBuffers	IpxGenParamPy::PyGenParams, 56
IpxCamPy::PyDataStream, 20	GetFirstDeviceInfo
ForceIP	
IpxCamPy::PyDeviceInfo, 31	IpxCamPy::PyDeviceInterface, 32
	GetFloat
GetAccessStatus	IpxGenParamPy::PyGenParams, 61
IpxCamPy::PyDeviceInfo, 30	GetFloatValue
GetBoolean	IpxGenParamPy::PyGenParams, 55
IpxGenParamPy::PyGenParams, 60	GetFrameID
GetBooleanValue	IpxCamPy::PyBuffer, 15
IpxGenParamPy::PyGenParams, 59	GetHeight
GetBuffer	IpxCamPy::PyBuffer, 14
IpxCamPy::PyDataStream, 19	GetIPAddress
GetBufferAlignment	IpxCamPy::PyDeviceInfo, 30
IpxCamPy::PyDataStream, 18	GetIPGateway
GetBufferPtr	IpxCamPy::PyDeviceInfo, 30
IpxCamPy::PyBuffer, 14	GetIPMask
GetBufferQueueSize	IpxCamPy::PyDeviceInfo, 30
IpxCamPy::PyDataStream, 19	GetImage
GetBufferSize	IpxCamPy::PyBuffer, 14
IpxCamPy::PyDataStream, 18	getlmage
GetCameraParameters	IpxCamPy::PyImage, 65
IpxCamPy::PyDevice, 26	GetIncrement
GetCommand	IpxGenParamPy::PyGenParamInt, 51
IpxGenParamPy::PyGenParams, 61	GetInfo
GetCount	IpxCamPy::PyDevice, 23
IpxGenParamPy::PyGenParamCategory, 40	GetInt
lpxGenParamPy::PyGenParamEnum, 43	IpxGenParamPy::PyGenParams, 60
lpxGenParamPy::PyGenParams, 58	GetIntegerValue
GetDescription	IpxGenParamPy::PyGenParams, 54
InxCamPv::PvDeviceInterface 32	GetInterface

lpxCamPy::PyDeviceInfo, 28	IpxGenParamPy::PyGenParamInt, 50
GetInterfaceList	IpxGenParamPy::PyGenParamString, 63
IpxCamPy::PyIpxSystem, 70	GetUnit
GetMax	IpxGenParamPy::PyGenParamFloat, 49
IpxGenParamPy::PyGenParamFloat, 48	GetUserDefinedName
IpxGenParamPy::PyGenParamInt, 51	IpxCamPy::PyDeviceInfo, 29
GetMin	GetValue
IpxGenParamPy::PyGenParamFloat, 48	IpxGenParamPy::PyGenParamBoolean, 38
IpxGenParamPy::PyGenParamInt, 51	IpxGenParamPy::PyGenParamEnum, 43
GetMinNumBuffers	IpxGenParamPy::PyGenParamEnumEntry, 45
IpxCamPy::PyDataStream, 18	IpxGenParamPy::PyGenParamFloat, 48
GetModel	IpxGenParamPy::PyGenParamInt, 50
IpxCamPy::PyDeviceInfo, 28	IpxGenParamPy::PyGenParamString, 63
GetName	GetValueStr
IpxGenParamPy::PyGenParam, 35	IpxGenParamPy::PyGenParamEnum, 43
GetNode	IpxGenParamPy::PyGenParamEnumEntry, 45
IpxGenParamPy::PyGenParamCategory, 41	GetVendor
GetNodeMap	IpxCamPy::PyDeviceInfo, 29
IpxGenParamPy::PyGenParams, 62	GetVersion
GetNumStreams	IpxCamPy::PyDeviceInfo, 29
IpxCamPy::PyDevice, 23	IpxCamPy::PyIpxSystem, 70
GetParam	GetVisibility
IpxGenParamPy::PyGenParams, 58	IpxGenParamPy::PyGenParam, 35
GetParamByIndex	GetWidth
IpxGenParamPy::PyGenParamCategory, 40	IpxCamPy::PyBuffer, 14
IpxGenParamPy::PyGenParams, 58	GetXOffset
GetPixelFormat	IpxCamPy::PyBuffer, 15
IpxCamPy::PyBuffer, 15	GetXPadding
GetRootCategory	IpxCamPy::PyBuffer, 16
IpxGenParamPy::PyGenParams, 59	GetYOffset
GetSerialNumber	IpxCamPy::PyBuffer, 15
IpxCamPy::PyDeviceInfo, 29	GetYPadding
GetStreamByld	IpxCamPy::PyBuffer, 16
IpxCamPy::PyDevice, 25	
GetStreamByIndex	IpxCamPy, 9
IpxCamPy::PyDevice, 25	IpxCamPy::PyBuffer, 13
GetString	GetBufferPtr, 14
IpxGenParamPy::PyGenParams, 60	GetFrameID, 15
GetStringValue	GetHeight, 14
IpxGenParamPy::PyGenParams, 55	GetImage, 14
GetTimestamp	GetPixelFormat, 15
IpxCamPy::PyBuffer, 16	GetTimestamp, 16
GetToolTip	GetWidth, 14
IpxGenParamPy::PyGenParam, 35	GetXOffset, 15
GetTransportParameters	GetXPadding, 16
IpxCamPy::PyDevice, 26	GetYOffset, 15
GetType	GetYPadding, 16
IpxCamPy::PyDeviceInterface, 33	IsIncomplete, 15
IpxGenParamPy::PyGenParam, 35	IpxCamPy::PyDataStream, 17
IpxGenParamPy::PyGenParamBoolean, 38	AllocBufferQueue, 21
IpxGenParamPy::PyGenParamCategory, 40	CancelBuffer, 22
IpxGenParamPy::PyGenParamEnum, 44	CreateBuffer, 19
IpxGenParamPy::PyGenParamEnumEntry, 46	FlushBuffers, 20
IpxGenParamPy::PyGenParamFloat, 47	GetBuffer, 19

GetBufferAlignment, 18	GetDisplayName, 35
GetBufferQueueSize, 19	GetName, 35
GetBufferSize, 18	GetToolTip, 35
GetMinNumBuffers, 18	GetType, 35
QueueBuffer, 20	GetVisibility, 35
Release, 21	IsAvailable, 36
ReleaseBufferQueue, 21	IsReadable, 36
RevokeBuffer, 21	IsStreamable, 37
StartAcquisition, 18	IsValueCached, 36
StopAcquisition, 18	IsVisible, 36
IpxCamPy::PyDevice, 22	IsWritable, 36
GetCameraParameters, 26	IpxGenParamPy::PyGenParamBoolean, 37
GetDisplayName, 23	GetType, 38
GetInfo, 23	GetValue, 38
GetNumStreams, 23	IsReadable, 39
GetStreamByld, 25	IsWritable, 38
GetStreamByIndex, 25	SetValue, 38
GetTransportParameters, 26	IpxGenParamPy::PyGenParamCategory, 39
LoadConfiguration, 25	GetCount, 40
ReadMem, 24	GetNode, 41
RegisterEvent, 26	GetParamByIndex, 40
Release, 24	GetType, 40
SaveConfiguration, 25	IpxGenParamPy::PyGenParamCommand, 41
UnRegisterEvent, 27	Execute, 42
WriteMem, 24	IsDone, 42
IpxCamPy::PyDeviceInfo, 27	IpxGenParamPy::PyGenParamEnum, 42
ForceIP, 31	GetCount, 43
GetAccessStatus, 30	GetEnumEntryByIndex, 44
GetDisplayName, 29	GetType, 44
GetIPAddress, 30	GetValue, 43
GetIPGateway, 30	GetValueStr, 43
GetIPMask, 30	SetValue, 43
GetInterface, 28	SetValueStr, 44
GetModel, 28	IpxGenParamPy::PyGenParamEnumEntry, 45
GetSerialNumber, 29	GetType, 46
GetUserDefinedName, 29	GetValue, 45
GetVendor, 29	GetValueStr, 45
GetVersion, 29	IsAvailable, 46
IpxCamPy::PyDeviceInterface, 31	IpxGenParamPy::PyGenParamFloat, 46
GetDescription, 32	GetMax, 48
GetDeviceInfoList, 33	GetMin, 48
GetFirstDeviceInfo, 32	GetType, 47
GetType, 33	GetUnit, 49
ReEnumerateDevices, 32	GetValue, 48
IpxCamPy::PyImage, 64	IsReadable, 47
getImage, 65	IsWritable, 47
lpxCamPy::PylpxSystem, 69	SetValue, 48
CreateDeviceFromConfig, 70	IpxGenParamPy::PyGenParamInt, 49
GetDisplayName, 70	GetIncrement, 51
GetInterfaceList, 70	
GetVersion, 70	GetMax, 51 GetMin, 51
IpxGenParamPy, 10	GetType, 50
·	GetValue, 50
IpxGenParamPy::PyGenParam, 34	
GetDescription, 35	IsReadable, 50

IsWritable, 50	IsReadable
SetValue, 50	IpxGenParamPy::PyGenParam, 36
IpxGenParamPy::PyGenParamNode, 52	lpxGenParamPy::PyGenParamBoolean, 39
IpxGenParamPy::PyGenParamNodeMap, 52	IpxGenParamPy::PyGenParamFloat, 47
IpxGenParamPy::PyGenParamString, 62	lpxGenParamPy::PyGenParamInt, 50
GetType, 63	IpxGenParamPy::PyGenParamString, 63
GetValue, 63	IsStreamable
IsReadable, 63	lpxGenParamPy::PyGenParam, 37
IsWritable, 63	IsValueCached
SetValue, 63	lpxGenParamPy::PyGenParam, 36
IpxGenParamPy::PyGenParams, 52	IsVisible
	IpxGenParamPy::PyGenParam, 36
ExecuteCommand, 55	IsWritable
GetBoolean, 60	
GetBooleanValue, 59	IpxGenParamPy::PyGenParam, 36
GetCommand, 61	IpxGenParamPy::PyGenParamBoolean, 38
GetCount, 58	IpxGenParamPy::PyGenParamFloat, 47
GetEnum, 57	IpxGenParamPy::PyGenParamInt, 50
GetEnumValue, 56	IpxGenParamPy::PyGenParamString, 63
GetEnumValueStr, 56	1 10 1
GetFloat, 61	LoadConfiguration
GetFloatValue, 55	IpxCamPy::PyDevice, 25
GetInt, 60	De Ours ets Disculses
GetIntegerValue, 54	PyCreateDisplay
GetNodeMap, 62	IpxGuiPy::PyIpxCameraApiGui, 67
GetParam, 58	PyCreateGenParamTreeViewForArray
GetParamByIndex, 58	IpxGuiPy::PyIpxCameraApiGui, 68
GetRootCategory, 59	PyDestroyGenParamTreeView
GetString, 60	IpxGuiPy::PyIpxCameraApiGui, 68
GetStringValue, 55	PylpxCameraApi, 65
IsCommandDone, 61	PylpxCreateDevice, 66
SetBooleanValue, 59	PylpxCreateDevice
SetEnumValue, 57	PylpxCameraApi, 66
SetEnumValueStr, 57	PyShowImageOnDisplay
SetFloatValue, 54	IpxGuiPy::PyIpxCameraApiGui, 68
SetIntegerValue, 54	
•	QueueBuffer
SetStringValue, 56	IpxCamPy::PyDataStream, 20
IpxGuiPy, 11	
IpxGuiPy::PyGenParamView, 64	ReEnumerateDevices
IpxGuiPy::PyIpxCameraApiGui, 66	IpxCamPy::PyDeviceInterface, 32
PyCreateDisplay, 67	ReadMem
PyCreateGenParamTreeViewForArray, 68	IpxCamPy::PyDevice, 24
PyDestroyGenParamTreeView, 68	RegisterEvent
PyShowImageOnDisplay, 68	IpxCamPy::PyDevice, 26
IpxGuiPy::PyIpxSystemGui, 71	Release
SelectCamera, 71	IpxCamPy::PyDataStream, 21
IsAvailable	IpxCamPy::PyDevice, 24
IpxGenParamPy::PyGenParam, 36	ReleaseBufferQueue
IpxGenParamPy::PyGenParamEnumEntry, 46	IpxCamPy::PyDataStream, 21
IsCommandDone	RevokeBuffer
IpxGenParamPy::PyGenParams, 61	IpxCamPy::PyDataStream, 21
IsDone	production just just a second and a second a
IpxGenParamPy::PyGenParamCommand, 42	SaveConfiguration
IsIncomplete	IpxCamPy::PyDevice, 25
IpxCamPy::PyBuffer, 15	SelectCamera

```
IpxGuiPy::PyIpxSystemGui, 71
SetBooleanValue
    IpxGenParamPy::PyGenParams, 59
SetEnumValue
    IpxGenParamPy::PyGenParams, 57
SetEnumValueStr
    IpxGenParamPy::PyGenParams, 57
SetFloatValue
    IpxGenParamPy::PyGenParams, 54
SetIntegerValue
    IpxGenParamPy::PyGenParams, 54
SetStringValue
    IpxGenParamPy::PyGenParams, 56
SetValue
    IpxGenParamPy::PyGenParamBoolean, 38
    IpxGenParamPy::PyGenParamEnum, 43
    IpxGenParamPy::PyGenParamFloat, 48
    IpxGenParamPy::PyGenParamInt, 50
    IpxGenParamPy::PyGenParamString, 63
SetValueStr
    IpxGenParamPy::PyGenParamEnum, 44
StartAcquisition
    IpxCamPy::PyDataStream, 18
StopAcquisition
    IpxCamPy::PyDataStream, 18
UnRegisterEvent
    IpxCamPy::PyDevice, 27
WriteMem
    IpxCamPy::PyDevice, 24
```