

# Adding, removing, or changing ISL ports nondisruptively

**ONTAP MetroCluster** 

netapp-ivanad, netapp-martyh, ntap-bmegan May 14, 2021

### **Table of Contents**

Adding,	removing,	or changing	ISL ports	nondisruptively	′	

# Adding, removing, or changing ISL ports nondisruptively

You might need to add, remove, or change ISL ports. You can convert dedicated ISL ports to shared ISL ports, or change the speed of ISL ports on a switch. ISLs traveling greater distances might require lower speeds to improve quality. You also might need to increase the speed of ISL ports to take advantage of system upgrades and add ISLs to a Cisco IP switch if you are adding or upgrading hardware.

If you are converting dedicated ISL ports to shared ISL ports, ensure the new ports meet the requirements for shared ISL ports.

xref:./maintain/../install-ip/concept considerations layer 2.adoc

You must complete all the steps on both switches to ensure ISL connectivity.

The following procedure assumes you are replacing a 10-Gb ISL connected at switch port Eth1/24/1 with two 100-Gb ISLs that are connected to switch ports 17 and 18.

#### **Steps**

1. Disable the ISL ports of the ISLs on both switches in the fabric that you want to change.



You only need to disable the current ISL ports if you are moving them to a different port, or the speed of the ISL is changing. If you are adding an ISL port with the same speed as the existing ISLs, go to Step 3.

You must enter only one configuration command for each line and press Ctrl-Z after you have entered all the commands, as shown in the following example:

```
switch_A_1# conf t
switch_A_1(config)# int eth1/24/1
switch_A_1(config-if)# shut
switch_A_1(config-if)#
switch_A_1#

switch_B_1# conf t
switch_B_1(config)# int eth1/24/1
switch_B_1(config-if)# shut
switch_B_1(config-if)# shut
switch_B_1(config-if)#
switch_B_1#
```

- 2. Remove the existing cables and transceivers.
- 3. Change the ISL port as required.

Option	Step
To change the speed of an ISL port	Cable the new ISLs to the designated ports according to their speeds. You must ensure that these ISL ports for your switch are listed in the MetroCluster IP Installation and Configuration Guide.
To add an ISL	Insert QFSPs into the ports you are adding as ISL ports. Ensure they are listed in the <i>MetroCluster IP Installation and Configuration Guide</i> and cable them according to this guide.

4. Enable all ISL ports (if not enabled) on both switches in the fabric beginning with the following command:

#### switch A 1# conf t

You must enter only one configuration command per line and press Ctrl-Z after you have entered all the commands:

```
switch A 1# conf t
switch A 1(config) # int eth1/17
switch A 1(config-if) # no shut
switch A 1(config-if)# int eth1/18
switch A 1(config-if)# no shut
switch A 1(config-if)#
switch A 1#
switch A 1# copy running-config startup-config
switch B 1# conf t
switch B 1(config) # int eth1/17
switch B 1(config-if) # no shut
switch B 1(config-if)# int eth1/18
switch B 1(config-if) # no shut
switch B 1(config-if)#
switch B 1#
switch B 1# copy running-config startup-config
```

5. Verify that the ISLs are established between both switches:

```
switch_A_1# show int eth1/17,eth1/18 brief
```

You should see the ISL interfaces in the command output as shown in the following example:

Ethernet Port	VLAN	Type Mode	Status	Reason		Spee
Interface Ch #						
	10	eth	access	up	none	
100G(D) 10	1.0	- + 1-				
Eth1/18	10	eth	access	up	none	
	show int	eth1/17,eth	1/18 brie	:f		
switch_B_1# Ethernet Port Interface						Spee
switch_B_1# Ethernet Port Interface						Spee
switch_B_1# Ethernet Port Interface Ch #	VLAN	Type Mode	Status	Reason		Spee
Ethernet Port Interface Ch # Eth1/17	VLAN		Status	Reason	none	Spee
switch_B_1# Ethernet Port Interface Ch #	VLAN 	Type Mode	Status	Reason		Spee

### 6. Repeat the procedure for fabric 2.

#### **Copyright Information**

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

#### **Trademark Information**

NETAPP, the NETAPP logo, and the marks listed at <a href="http://www.netapp.com/TM">http://www.netapp.com/TM</a> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.