




# STM 32 F767ZI

GPIO, INTERRUPTS AND UART

ÁLVARO CASTRO LEITE NOV 2019





# Requirements

Micro-USB cable

STM32 development board

PC with all the tools installed

Serial Port terminal



# Agenda

Skill level: Beginner

Intruduction to HAL API

STMCubeMX walkthrough

**GPIO** 


Interrupt management

On-chip debug


**UART** 




#### Introduction HAL API


































Question: How many user LED's the board has? 3 right? Where's the green LED?

Tip: Open UM1974 and go to page 24.

Answer: PB0




































Home > STM32F	767ZITx - NUCLEO-F767ZI	Untitled - Project Manager		GENERATE CODE
Pinout 8	k Configuration	Clock Configuration	Project Manager	Tools
Project	STM32Cube MCU packages and  Copy all used libraries into th  Copy only the necessary library files as	e project folder		
Code Generator	Generated files  Generate peripheral initializat  Backup previously generated  Keep User Code when re-gen  Delete previously generated fi	erating		
Advanced Settings	_	optimize the power consumption)	Settings	







☑ Options for Target 'GPIOandUART'							
Device Target Output   Listing   User   C/C++	- Asm	Linker	Debug   l	Jtilities			
STMicroelectronics STM32F767ZITx	Code Generation						
Xtal (MHz): 216	ARM	Compiler:	Use defau	ılt compiler versio	on 5 <u>▼</u>		
Operating system: None	Use Cross-Module Optimization						
System Viewer File:	▼ Use MicroLIB ☐ Big Endian						
STM32F7x7_v1r2.svd	Floating Point Hardware: Double Precision			on 🔻			
Use Custom File							
Read/Only Memory Areas		-Read/	Write Mem	ory Areas			
default off-chip Start Size	Startup	default	off-chip	Start	Size	NoInit	
ROM1:	0		RAM1:				
ROM2:	0		RAM2:				
ROM3:	0		RAM3:				
on-chip			on-chip		,		
IROM1: 0x8000000 0x200000	•	✓	IRAM1:	0x20000000	0x80000		
☐ IROM2:			IRAM2:				
, ,				,			
OK Cancel Defaults Help							



Options for Target 'GPIOandUART'			>
Device Target Output Listing User	C/C++ Asm   Linker   Debug   Utilitie	es	
Preprocessor Symbols  Define: USE_HAL_DRIVER,STM32  Undefine:	PF767xx,USE_HAL_DRIVER,STM32F767xx	C .	
Language / Code Generation			
Execute-only Code	Strict ANSI C	Wamings: All Wamings	-
Optimization: Level 0 (-00) ▼	Enum Container always int	☐ Thumb Mode	
Optimize for Time	Plain Char is Signed	☐ No Auto Include	es
Split Load and Store Multiple	Read-Only Position Independent	▼ C99 Mode	
One ELF Section per Function	Read-Write Position Independent	☐ GNU extensions	8
Include Paths Misc Controls	32F7xx_HAL_Driver/Inc;/Drivers/STM32f	F7xx_HAL_Driver/Inc/Legacy	
Compiler control stringc99 -ccpu Cortex-M7.fp.c	lp -D_EVAL -D_MICROLIB -g -O0apcs= //32F7xx_HAL_Driver/Inc -I	. –	^ ~
0	K Cancel Defaults	He	elp



In UM1905 User Manual, on Chapter 26 (page 372), you can find the information about the GPIO HAL API.

It's important that you understand the structure associated with each I/O port and the API (set of functions to handle all GPIO).

HAL provides four manipulation routines to read, change and lock the state of an I/O.



HAL provides four manipulation routines to read, change and lock the state of an I/O and two for configuration.

To read the status of an I/O we can use the function:

• GPI0\_PinState HAL\_GPI0\_ReadPin(GPI0\_TypeDef\* GPI0x,
 uint16 t GPI0 Pin)

which accepts the GPIO descriptor and the pin number. It returns GPIO\_PIN\_RESET when the I/O is low or GPIO\_PIN\_SET when high.



Conversely, to change the I/O state, we have the function:

```
ovoid HAL_GPI0_WritePin(GPI0_TypeDef* GPI0x, uint16_t
GPI0 Pin, GPI0 PinState PinState)
```

which accepts the GPIO descriptor, the pin number and the desired state.



If we want to simply invert the I/O state, then we can use this convenient routine:

```
ovoid HAL_GPIO_TogglePin(GPIO_TypeDef* GPI0x,
uint16 t GPI0 Pin)
```



Example 1: Make a blinking led with the three LEDs reconfigured before.

After writing the following lines, compile and flash, and the leds should blink.



Example 2: Make the green LED to change the state when you push the user button.

```
97  while (1)
98  {
99    if (HAL_GPIO_ReadPin(GPIOC, GPIO_PIN_13))
100         HAL_GPIO_TogglePin(GPIOB, GPIO_PIN_0);
101         HAL_GPIO_TogglePin(GPIOB, GPIO_PIN_7);
102         HAL_GPIO_TogglePin(GPIOB, GPIO_PIN_14);
103         HAL_Delay(500);
104         /* USER CODE_END_WHILE_*/
```

The problem: the system isn't analyzing the button all the time, most of it is doing other stuff (in the case: the delay).

The solution could be, use interrupts.



ARM architecture defines events as something that can be originated both by the hardware and the software itself. ARM architecture events are distinguished between two types: interrupts originated by the hardware, exceptions by the software (e.g., invalid access to the memory location).



Cortex-M processors provide a unit dedicated to event management. This is called Nested Vectored Interrupt Controller (NVIC). NVIC is a dedicated hardware unit inside the Cortex-M based microcontrollers that is responsible for handling exceptions. You can find more information about NVIC in RM0410, chapter 10.

A dedicated programmable controller, named External Interrupt/Event Controller (EXTI), is responsible for the interconnection between the external I/O signals and the NVIC controller, as we will see next.




STM32 microcontrollers provide a variable number of external interrupt sources connected to the NVIC through the EXTI controller, which in turn is capable of managing several EXTI lines. The number of interrupt sources and lines depends on the specific STM32 family.


GPIO is connected to the EXTI lines, and it is possible to enable interrupts for every MCU GPIO, even if most of them share the same interrupt line. For example, for an STM32F7 MCU, up to 114 GPIOs are connected to 16 EXTI lines. However, there are only 11 independent interrupt in the EXTI.

You can find more information about EXTI in RM0410, chapter 11.





















**?** 7 UM1974 page 75











The STM32CubeMX already added implementation implementation code of the EXTI15\_10\_IRQHandler function, this code is on stm32f7xx\_it.c file.

```
203 void EXTI15 10 IRQHandler(void)
204 □ {
205
      /* USER CODE BEGIN EXTI15 10 IRQn 0 */
206
207
      /* USER CODE END EXTI15 10 IRQn 0 */
      HAL GPIO EXTI IRQHandler (GPIO PIN 13);
208
      /* USER CODE BEGIN EXTI15 10 IRQn 1 */
209
210
211
      /* USER CODE END EXTI15 10 IRQn 1 */
212
213
```



You must implement the HAL\_GPIO\_Callback function on GPIO file.


```
89  /* USER CODE BEGIN 2 */
90
91  void HAL_GPIO_EXTI_Callback(uint16_t GPIO_Pin) {
   if (GPIO_Pin == GPIO_PIN_13)
        HAL_GPIO_TogglePin(GPIOB, GPIO_PIN_0);
94  }
95  /* USER CODE END 2 */
```



In order to debug our code we need to prepare the peripherals for the communication.

To do this it's necessary to enable the Single Wire Debug in the SYS(tem) peripheral.






Generate the code again.




```
Peripherals Tools SVCS Window Help
                                🔽 🗟 🏴 🔯 r | 🌢 🌣 🔗 🚵 r | 🛅 🔻
      main.c gpio.c startup_stm32f767xx.s
          /* Infinite loop */
    95
          /* USER CODE BEGIN WHILE */
    96
    97
          while (1)
    98 🖨
    99
            HAL GPIO TogglePin(GPIOB, GPIO PIN 7);
   100
            HAL GPIO TogglePin(GPIOB, GPIO PIN 14);
   101
            HAL Delay(500);
            /* USER CODE END WHILE */
   102
   103
```











In order to use UART and USART peripherals, HAL API offers a set of functions.

To transmit a sequence of bytes over the USART in polling mode the HAL provides the function:

```
HAL_StatusTypeDef HAL_UART_Transmit(UART_HandleTypeDef
*huart, uint8_t *pData, uint16_t Size, uint32_t
Timeout);
```



To receive a sequence of bytes over the USART in polling mode the HAL provides the function:

```
HAL_StatusTypeDef HAL_UART_Receive(UART_HandleTypeDef
*huart, uint8_t *pData, uint16_t Size, uint32_t
Timeout);
```



To transmit a sequence of bytes in interrupt mode, the HAL defines the function:

```
HAL_StatusTypeDef
HAL_UART_Transmit_IT(UART_HandleTypeDef *huart,
uint8_t *pData, uint16_t Size);
```



To receive a sequence of bytes over the USART in interrupt mode the HAL provides the function:

```
HAL_StatusTypeDef
HAL_UART_Receive_IT(UART_HandleTypeDef *huart, uint8_t
*pData, uint16 t Size);
```



Example 3: Create a program that communicates with the computer through the RS232 protocol, echoing whatever the computer sent, using an UART (or USART) peripheral in the STM32 and a terminal program in the computer. The program may send a message on startup and should change the state of the red led every time a message is receved.




Question: The STM32F767ZI has 8 UART/USART peripherals, what we should use?

Tip: Open UM1974, go to chapter 6 (page 11), try to understand Figure 3, and after go to section 6.9 (page 26).

**Answer: UART3** 



Let's edit the project in STM32CubeMX.






Let's correct the GPIO Pins.


Tip: To discover alternatives pins you can press CTRL and click over

the pin.





#### Do not forget to enable the USART3 interrupt






Question: How to design the application?


Tip: Use some flowchart or algorithm








**USART Callback:** 





newMessage():





Let's implement...

Usart.c

```
/* USER CODE BEGIN 0 */
24
//UART3 RX data structures
uint8_t UART3Rx_Buffer[128];
uint8_t Rx_Buffer[128];
int receve_flag = 0;
volatile uint8_t UART3Rx_index = 0;
```



#### Usart.h

```
35 /* USER CODE BEGIN Private defines */
36 extern uint8 t Rx Buffer[128];
   extern int receve flag;
38 /* USER CODE END Private defines */
39
   void MX USART3 UART Init(void);
41
   /* USER CODE BEGIN Prototypes */
43
   void newMessage(void);
   void init UART3(void);
46
   /* USER CODE END Prototypes */
```



At usart.c file you must add some functions.

```
/* USER CODE BEGIN 1 */
116

117 void init_UART3() {
    // set the interrupt for UART3 Rx
119 HAL_UART_Receive_IT(&huart3, &UART3Rx_Buffer[UART3Rx_index], 1);
120 }
```



#### The Usart Callback

```
//implemantation of UART ISR

123 void HAL_UART_RxCpltCallback(UART_HandleTypeDef* huart) {
    if (huart->Instance == USART3) { //current UART?

        UART3Rx_index++;

        UART3Rx_index &= ~(1<<7); //keep index inside the limits

        // set the interrupt for UART3 Rx again

        HAL_UART_Receive_IT(&huart3, &UART3Rx_Buffer[UART3Rx_index], 1);

129 }

130 }</pre>
```



#### newMessage()

```
132 void newMessage() {
133
     static int local index = 0;
134
    int out index = 0;
135 ₺
     while(local index != UART3Rx index) {
        Rx Buffer[out index] = UART3Rx Buffer[local index];
136
137
        out index++;
138
        local index++;
139
        local index \&= \sim (1 << 7);
        receve flag = 1;
140
141
142
      Rx Buffer[out index] = ' \ 0';
143
```



To make the printf work you must change the output of the function by redefining the fputc function in usart.c file.

```
//redifine the stdout
fut fputc(int ch, FILE *f) {
   HAL_UART_Transmit(&huart3, (uint8_t*)&ch, 1, 100);
   return ch;
}

/* USER CODE END 1 */
```




#### At main.c implement the main function

```
/* Initialize all configured peripherals */
90
91
     MX GPIO Init();
     MX USART3 UART Init();
92
     /* USER CODE BEGIN 2 */
93
94
95
     init UART3();
     printf("Hello STM32!!\r\n");
96
97
     printf("Type a message and press enter\r\n");
98
99
     /* USER CODE END 2 */
```




```
/* Infinite loop */
101
102
      /* USER CODE BEGIN WHILE */
103
      while (1)
104 =
105
        HAL GPIO TogglePin(GPIOB, GPIO PIN 7);
106
        newMessage();
        if(receve flag){
107 ₺
108
          receve flag = 0;
          printf("The mesage was: [\"%s\"]\r\n", Rx Buffer);
109
          printf("Type another message and press enter\r\n");
110
111
          HAL GPIO TogglePin (GPIOB, GPIO PIN 14);
112
113
        HAL Delay(500);
        /* USER CODE END WHILE */
114
```
















### Conclusion

With this you've learned enough to continue your study of the GPIO, interrupt management and the USART peripherals.

The tools shouldn't be a problem now.

Keep in mind, there is much more to learn, this is just the beginning and the only way to improve is doing it yourselves.