Product Version IC23.1 June 2023 © 2013-2023 Cadence Design Systems, Inc.

Printed in the United States of America.

Cadence Design Systems, Inc. (Cadence), 2655 Seely Ave., San Jose, CA 95134, USA.

Open SystemC, Open SystemC Initiative, OSCI, SystemC, and SystemC Initiative are trademarks or registered trademarks of Open SystemC Initiative, Inc. in the United States and other countries and are used with permission.

Trademarks: Trademarks and service marks of Cadence Design Systems, Inc. contained in this document are attributed to Cadence with the appropriate symbol. For queries regarding Cadence's trademarks, contact the corporate legal department at the address shown above or call 800.862.4522. All other trademarks are the property of their respective holders.

Restricted Permission: This publication is protected by copyright law and international treaties and contains trade secrets and proprietary information owned by Cadence. Unauthorized reproduction or distribution of this publication, or any portion of it, may result in civil and criminal penalties. Except as specified in this permission statement, this publication may not be copied, reproduced, modified, published, uploaded, posted, transmitted, or distributed in any way, without prior written permission from Cadence. Unless otherwise agreed to by Cadence in writing, this statement grants Cadence customers permission to print one (1) hard copy of this publication subject to the following conditions:

- 1. The publication may be used only in accordance with a written agreement between Cadence and its customer.
- 2. The publication may not be modified in any way.
- 3. Any authorized copy of the publication or portion thereof must include all original copyright, trademark, and other proprietary notices and this permission statement.
- 4. The information contained in this document cannot be used in the development of like products or software, whether for internal or external use, and shall not be used for the benefit of any other party, whether or not for consideration.

Disclaimer: Information in this publication is subject to change without notice and does not represent a commitment on the part of Cadence. Except as may be explicitly set forth in such agreement, Cadence does not make, and expressly disclaims, any representations or warranties as to the completeness, accuracy or usefulness of the information contained in this document. Cadence does not warrant that use of such information will not infringe any third party rights, nor does Cadence assume any liability for damages or costs of any kind that may result from use of such information.

Cadence is committed to using respectful language in our code and communications. We are also active in the removal and replacement of inappropriate language from existing content. This product documentation may however contain material that is no longer considered appropriate but still reflects long-standing industry terminology. Such content will be addressed at a time when the related software can be updated without end-user impact.

Restricted Rights: Use, duplication, or disclosure by the Government is subject to restrictions as set forth in FAR52.227-14 and DFAR252.227-7013 et seq. or its successor.

Contents

Virtuoso FinFET Support 5
Technology File Requirements for FinFET-based Design
Layer Definition Requirements7
Snap Pattern Definition Requirements
Snap Pattern SKILL Functions9
FinFET Support in Layout L
Snapping Objects to Local Snap Pattern Shapes
Snapping Objects to the Global Snap Pattern Grid
Controlling the Display of the Snap Pattern in the Palette
Modes for Object Placement12
SKILL Function for Fin Grid Snapping13
Customizing the Create Guard Ring Form
FinFET Support in Layout XL14
Component Type Definition for FinFET Devices
Generating a Constraint-Driven PR Boundary14
Preserving Snap Patterns and Generating Devices
Folding FinFET Devices
FinFET Support in Modgens
Snapping Modgens16
FinFET Support in DRD Editing

Virtuoso FinFET Support

Virtuoso[®] Layout Suite incorporates full support for the use of optimized 16nm native SKILL[®] process design kits (PDKs). This enables innovative FinFET custom design flows by supporting FinFET-based devices and rules at every design stage, together with a robust set of productivity-enhancing Virtuoso capabilities for leading custom and analog design.

This document summarizes the new capabilities added to Virtuoso layout tools to enable the structured FinFET custom placement using module generators (modgens); complex autoalignment, device snapping, and abutment of FinFET-based devices; advanced rule support for layout automation; and sophisticated fluid guard ring generation.

Important

This document is not intended as a comprehensive FinFET user guide. It provides information on the enhancements made to various Virtuoso products to support FinFET-based design and includes links to more detailed information in the documentation of the specific products involved.

This user guide is aimed at developers and designers of integrated circuits and assumes that you are familiar with:

- The Virtuoso Studio design environment and application infrastructure mechanisms designed to support consistent operations between all Cadence[®] tools.
- The applications used to design and develop integrated circuits in the Virtuoso Studio design environment, notably, the Virtuoso Layout Suite.
- The Virtuoso Studio design environment technology file.

At advanced process nodes, CMOS technology is moving away from planar field-effect transistors (FETs) towards more advanced device structures that offer reduced leakage and better control over short channel effects. This has led to the development of multi-gate FETs also known as tri-gate FETs or FinFETs.

FinFETS use long, narrow fins fabricated on top of the substrate and surrounded by the gate on three sides. The fin pitch is typically the same for all devices and fins are surrounded by a fin boundary shape. The devices also come with new design rule checks that are required to ensure that device are correctly and legally placed.

Virtuoso FinFET Support

This document provides an overview of the enhancements made to Virtuoso layout editing tools in order to support FinFET-based design. These include:

- Updates to the **technology file definitions** to let you define snap patterns for each layer-purpose pair on which FinFET devices will be placed. These snap patterns help ensure that placement constraints are honored when FinFET devices are created or edited either manually or automatically in the layout canvas.
 - For more information, see <u>Technology File Requirements for FinFET-based Design</u>.
- Updates to **Virtuoso Layout Suite L** (Layout L) to let you display the fin grids in the layout canvas, as well as automatically snap shapes and design objects to these grids when they are created or moved around the canvas.
 - For more information on these features, see FinFET Support in Layout L.
- Updates to **Virtuoso Layout Suite XL** (Layout XL) to preserve any snap patterns during layout generation; to generate a place and route boundary that is correctly sized in relation to the fin grid; to automatically snap FinFET devices to the fin grid when generating devices in the layout canvas; and fold FinFET devices based on a specified number of fins rather than the transistor width used to fold conventional devices.
 - For more information, see FinFET Support in Layout XL.
- Updates to the **Virtuoso Module Generator** feature to snap modgens to the top-level snap pattern shape and to let you specify the number of fins required for dummy devices.
 - For more information, see <u>FinFET Support in Modgens</u>.
- Updates to the layout editor **design rule driven (DRD) editing** feature, which now supports the generation and placement of FinFET devices based on FinFET-specific spacing, width, and enclosure rules.

6

For more information, see FinFET Support in DRD Editing.

Virtuoso FinFET Support

Technology File Requirements for FinFET-based Design

This section summarizes the technology file definitions required to support snap patterns in your design, along with the public SKILL functions provided to create and locate snap pattern definitions in your technology files.

- Layer Definition Requirements
- Snap Pattern Definition Requirements
- Snap Pattern SKILL Functions

Layer Definition Requirements

You must update your layer definitions to define a purpose for each fin boundary type you require. The purpose you define

- Must have parent purpose "annotation"
- Must be a user-defined purpose; you cannot specify a Virtuoso system-reserved purpose

You do this in the techPurposes section of the technology file. For example:

When the purpose is defined, you can reference it in the snap pattern definition.

Snap Pattern Definition Requirements

You define snap patterns in the layerRules section of the technology file. A snap pattern definition lets you store and access the attributes for snap pattern shapes on a specific fin boundary LPP.

The snapPatternDef syntax is as follows:

Virtuoso FinFET Support

The attributes defined in a snap pattern definition are listed below. For more detailed syntax information and examples of snap pattern definitions, see snapPatternDefs in the *Virtuoso Technology Data ASCII Files Reference*.

- Name, which must be unique
- Layer-purpose pair, which provides the link between the snap pattern definition in the technology file and the snap pattern shapes drawn in the design
- Step, which specifies the spacing between snap pattern tracks
- Step direction, which specifies the direction in which to create the snap pattern tracks, either horizontal (grid step is applied left to right) or vertical (grid step is applied from bottom to top)
- **Type**, which can be local or global
 - When snapping a shape to a snap pattern grid, snap pattern shapes whose snap pattern definition is of type local have higher priority than those of type global
- Offset, which specifies the distance of the first snap pattern track from the lower (for vertical direction) or left (for horizontal direction) edge of the shape bounding box
- Snapping layers; shapes on these layers snap to the snap pattern tracks. Each snapping layer has the following attributes:
 - Purposes; shapes on the snapping layer with one of these snapping purposes snap to this snap pattern shape
 - ☐ Enclosures, which specify a list of enclosures of a snapping shape beyond a grid line in the snap pattern direction
- Track width, which specifies the width of the physical shape that each track represents

With the snap pattern definition loaded for the design, you can draw a fin boundary in the layout canvas, and when you move parameterized cells, vias, shapes, or instances over this fin boundary, the layout editor automatically snaps the objects to the defined fin grid. For more information, see <u>Snapping Objects to Local Snap Pattern Shapes</u>.

Virtuoso FinFET Support

Snap Pattern SKILL Functions

You can use the following public SKILL functions to create and find snap pattern definitions in your technology files:

- <u>techCreateSnapPatternDef</u> lets you create a snap pattern definition in the current technology file
- <u>techFindSnapPatternDefByLP</u> lets you find a snap pattern definition based on its layer purpose pair
- <u>techFindSnapPatternDefByName</u> lets you find a snap pattern definition by name

Virtuoso FinFET Support

FinFET Support in Layout L

This section summarizes the enhancements made to Layout L to support FinFET devices in your design. These include mechanisms to let you display the snap pattern grid in the layout canvas; to specify that design objects are to be automatically snapped to that grid; and to quickly place objects manually without zooming in to the canvas.

Layout L can now:

- Display fins, fin boundaries, and snap patterns in the layout canvas and specify that objects are automatically snapped to the snap pattern grid. See <u>Snapping Objects to Local Snap Pattern Shapes</u> for more information.
- Snap objects to a global snap pattern grid. See <u>Snapping Objects to the Global Snap Pattern Grid</u> for more information.
- Display snap patterns in the Palette assistant. See <u>Controlling the Display of the Snap Pattern in the Palette</u> for more information.
- Use Abstract Mode placement to improve performance when placing large blocks. See <u>Modes for Object Placement</u> for more information.

You customize the Create Guard Ring form to support advanced node design methodologies. For more information, see:

Customizing the Create Guard Ring Form

Snapping Objects to Local Snap Pattern Shapes

Layout L has been enhanced to let you display fin grids in the layout canvas and automatically snap design objects to these grids when the object is moved over the fin boundary LPP. For more information, see the following topics in the *Virtuoso Layout Suite L User Guide*.

- Controlling the Display of Snap Patterns
- Turning On Snap Pattern Snapping
- Object Snapping
- Group Snapping

Snapping Objects to the Global Snap Pattern Grid

The layout editor can now display a uniform fin grid called a global snap pattern grid that extend over the entire design window. You can use the global grid to

Virtuoso FinFET Support

- Snap local fin boundaries by adding the fin boundary LPP to the list of snappingLayers for the global snap pattern definition
- Snap Active shapes by adding the Active LPP to the list of snappingLayers for the global snap pattern definition

You create a global snap pattern grid by specifying the value global in the type constraint of the snap pattern definition, as shown below:


You activate the global grid either through a constraint (snapGridVertical or snapGridHorizontal) or by drawing a corresponding snap pattern shape in the canvas.

For more information, see:

- Controlling the Display of Global Grid in Palette Assistant
- Anchoring the Global Grid

Controlling the Display of the Snap Pattern in the Palette

You control the visibility of local and global snap pattern grids on the Grids panel of the Palette assistant.



The grid drawing style is controlled through the *Snap Pattern Display* field in the Display Options form.

For more information, see Controlling the Display of Snap Patterns.

Modes for Object Placement

For small FinFET devices, placement is performed by searching the instance master for fin grids. If no fin grids are found, the snapping shapes are searched. This functionality is referred to as *Detail Mode Placement*.

When placing large blocks it is not feasible to search through instance masters and snapping shapes. Instead, Cadence recommends that you use *Abstract Mode Placement*, which allows fast placement of large layout blocks. In Abstract Mode, an instance snaps to a global

Virtuoso FinFET Support

snap pattern grid using either its snap boundary or PR boundary, or – if neither is found – the instance origin axis. For more information, see <u>Abstract Mode Placement</u>.

There may also be situations where neither Detail Mode or Abstract Mode are appropriate; for example, when the design has a third-party IP block laid out using a different methodology. In these cases, you can use the *Manual Mode Placement Override* to manually specify the placement mode or offset on a per instance or per master basis. You do this by setting the <code>leSnapPatternSnapping</code> property on either the instance or the master concerned. For more information, see <u>Manual Mode Placement Override</u>.

SKILL Function for Fin Grid Snapping

A new <u>leGetSnapToSPTransform</u> SKILL function has been added to compute how far and in which direction an object must be moved to align it with the grid. It can be used in conjunction with existing SKILL commands used to move objects, such as <code>dbMoveFig</code>, and helps ensure that objects are placed legally after the move is complete.

Customizing the Create Guard Ring Form

When working at advanced node and advanced nodes methodologies, some system-defined GUI components available on the Create Guard Ring form might not be applicable. In such circumstances, you can customize the Create Guard Ring form to display user-defined widgets that let you use fluid guard rings for your specific design needs. Virtuoso provides some triggers and SKILL API functions specifically designed for this purpose. For more information, see <u>Customizing the Create Guard Ring Form</u> in the *Virtuoso Fluid Guard Ring User Guide*.

Virtuoso FinFET Support

FinFET Support in Layout XL

This section summarizes the enhancements made to Layout XL to support FinFET devices in your design. These include the provision of new NFIN and PFIN component type attributes in CPH and the LAM file and the enhancement of the folding engine to support folding of FinFET devices. There is also support for snapping during the generation and editing of FinFET devices in the layout canvas and for generating a constraint-driven PR boundary.

Component Type Definition for FinFET Devices

For FinFET devices to be recognized by layout generation commands such as *Generate All From Source* and for these devices to support operations such as chaining and folding, they must be assigned to an appropriate component type—PFIN or NFIN. You define these component types and assign devices to them using either:

- The Configure Physical Hierarchy command. See Component Types Mode for more information.
- The library and attributes mapping (LAM) file. See <u>LAM File Component Type Section</u> for more information.

Generating a Constraint-Driven PR Boundary

The Generate All From Source and Update Components And Nets commands now generate a PR boundary with dimensions based on a new allowedPRBoundaryDimensions constraint, which ensures that the PR boundary is legal for use in FinFET-based designs.

The constraint has the following syntax:

```
spacings(
    (allowedPRBoundaryDimensions
    ['vertical | 'horizontal]
    ['stepSize g_step] (g_ranges)
    )
);spacings
```

The allowedPRBoundaryDimensions constraint can be applied separately for the horizontal and vertical directions to cover all the dimensions of a PR boundary.

Virtuoso FinFET Support

Preserving Snap Patterns and Generating Devices

Generate All From Source now features an option to preserve any Snap Patterns already defined in the layout view. See <u>Preserving Snap Patterns during Layout Generation</u> for more information.

Layout XL now also correctly snaps FinFET devices to the fin grid defined for the design in the following scenarios:

- When placing FinFET devices in your layout using the *Generate Selected From Source* command in *Group As In Schematic* mode, the generated devices are automatically snapped to the fin grid.
- When moving a chain of abutted devices in the layout canvas, all the devices in the chain are snapped together (i.e., the snapping does not break any existing chains).

Folding FinFET Devices

Folding lets you divide an individual device or a chain of devices into two or more layout instances with terminals connected in parallel to the same nets. The aim is to change the aspect ratio of the devices in your design while retaining the original orientation and design intent of the device that was folded.

To enable folding for FinFET devices, the devices in question must have their component classes correctly defined as either NFIN or PFIN as described above. See <u>Component Types Mode</u> for more information.

Additionally, the *Number of fins* parameter or the *Width parameter* must be set in the folding form. For more information, see Folding a Transistor in the *Virtuoso Layout Suite XL User Guide*.

Virtuoso FinFET Support

FinFET Support in Modgens

The Module Generator feature has also been enhanced to support FinFET-based design.

Snapping Modgens

Because the layout editor has been enhanced to automatically snap the parameterized cells in modgens to the snap pattern, the entire modgen block is also snapped to the top-level snap pattern shape.

Additionally, the modgen <u>Dummy Options</u> form now includes an option to specify the number of fins for dummy devices.

Virtuoso FinFET Support

FinFET Support in DRD Editing

Design rule driven editing now supports the creation and placement of FinFET devices that adhere to FinFET-specific spacing, width, and enclosure rules:

- Use the allowedSpacingRanges constraint to define legal spacing rules in the form of ranges and discrete values. See <u>Defining Discrete Spacing Rules</u>.
- Use the minSpacing constraint with derived layers to define the minimum spacings between fin boundaries. See <u>Defining Minimum Spacing Rules</u>.
- Use the allowedWidthRanges constraint to define directional legal width rules in the form of ranges and discrete values. See <u>Defining Directional and Discrete Width Rules</u>.
- Use the allowedPRBoundaryDimensions and minPRBoundaryInteriorHalo constraints to define directional legal spacing and width rules for PR boundaries. See <u>Defining Directional and Discrete P&R Boundary Rules</u>.
- Use the minOppExtension constraint to define directional and discrete enclosure rules for overlapping shapes on two different layers. See <u>Defining Directional and Discrete Opposite Extension Rules</u>.

For more information on these features, see <u>DRD Support for FinFET Devices</u> in the *Virtuoso Design Rule Driven Editing User Guide*.